






1




2



3

ATLAS 202 LH BAGMAKER


4) Adjust the ZERO Sensor, to sense the right hand side of flag.



Front of the Bagmaker

ATLAS 202 RH BAGMAKER

4) Adjust the ZERO Sensor, to sense the left hand side of flag.



Front of the Bagmaker

Right hand bagmaker