




Replacement Parts

Replacement Parts

The recommended spare parts list is provided below. The part number of each spare part is listed and the corresponding assembly reference is displayed adjacent to each recommended spare part. All machine parts are catalogued in the *Mechanical Assembly Drawing Set*, while all the electrical parts are identified by their device number in the *Electrical Diagrams*; each of these are provided under separate cover.

Always provide the job number or serial number when ordering parts.

Note: part numbers may be displayed more than once. If a part number is marked as a spare it will show up for every assembly where it is used.

For your convenience the Radiotelephony Spelling Alphabet is reproduced below.

NOTICE

Please not that on multiple page drawings, the table will be located *ONLY* on the lead page, subsequent pages will have ballooned call outs, but you will have to reference the first page to find the part in the table.

NOTICE

Belts for BluePrint Automation machines are custom manufactured for each machine and application. For this reason BluePrint Automation is unable to keep any belts in stock. Standard lead time for all belts is 7 to 10 working days.

ICAO/ITU-R Radiotelephony Spelling Alphabet			
Alphabet		Number + Punctuation	
Character	Telephony	Character	Telephony
A	Alfa	1	Wun
B	Bravo	2	Too
C	Charlie	3	Tree
D	Delta	4	Fower
E	Echo	5	Fife
F	Foxtrot	6	Six
G	Golf	7	Seven
H	Hotel	8	Eight
I	India	9	Niner
J	Juliett	0	Zero
K	Kilo	hundred	Hundred
L	Lima	thousand	Thousand
M	Mike	. (decimal point)	Decimal
N	November	-	Dash
O	Oscar	. (period)	Full Stop
P	Papa	,	Comma
Q	Quebec	/	Fraction bar
R	Romeo		
S	Sierra		
T	Tango		
U	Uniform		
V	Victor		
W	Whiskey		
X	Xray		
Y	Yankee		
Z	Zulu		

Recommended Spare Parts List

Part Number	Part Description	Assembly Where Used	Assembly Description	UoM	Qty
100-455	BEARING, 3/4 BORE	2402-062-01 2143-991-02	INFEED CONV. 9'-3" EXIT CONVEYOR 7.0 FT	EA	2
100-528	BUSHING 1108 1 DIA BORE	2143-989 2148-089	COUNT BELT ASSEMBLY STD COLLATOR IMPERIAL W/ HMI K	EA	2
101-572	BELT TIMING 240H150	2148-089	STD COLLATOR IMPERIAL W/ HMI K	EA	1
102-130	BEARING, FLANGE, GRFT204-12	2148-089 2143-989	STD COLLATOR IMPERIAL W/ HMI K COUNT BELT ASSEMBLY	EA	2
1028-554-02	BELT MOL 2W10-0GY-TT 300MM X 4510MM	2143-991-02	EXIT CONVEYOR 7.0 FT	EA	1
1302-419-01	BELT 4648 mm x 300 mm CLEATED, FELW-2.5	2402-062-01	INFEED CONV. 9'-3"	EA	1
102-883	BUSHING 1108 3/4 DIA BORE	2148-089	STD COLLATOR IMPERIAL W/ HMI K	EA	2
104-489	BELT, TIMING 300H150 1.5" x 30"	2148-089	STD COLLATOR IMPERIAL W/ HMI K	EA	1
104-494	NORD MOTOR SK2SM63AZB-71L/4 72 RPM	2402-606	KIT - COLLATOR PARTS FOR 220/1	EA	1
104-495	NORD MOTOR SK 172.1-63 LA/4 CUS 96 RPM	2402-606	KIT - COLLATOR PARTS FOR 220/1	EA	1
104-498	NORD MOTOR SK 172.1-71 L/4 CUS 243 RPM	2402-606	KIT - COLLATOR PARTS FOR 220/1	EA	1
104-563	HINGE- 095009	2143-995	COLLATOR GUARDING	EA	2
106-390	BEARING, RADIAL 62032RS 40MM OD	2143-989	COUNT BELT ASSEMBLY	EA	2
107-270	SPRING, GAS 9416K19 20LB FORCE, 8.27" S	2143-995	COLLATOR GUARDING	EA	2
109-223	CONVEYOR BELT 60MM WIDE X 1110MM LONG, (-0/+1/8 on width) LACED WITH UNIBAR #36 SHORT POINT STAINLESS, (2)K-6 DEEP NOTCHED CLEAR HARD PU GUIDES FLUSH ON EACH EDGE ON BOTTOM OF BELT 2R5-0G	2143-989	COUNT BELT ASSEMBLY	EA	1

Replacement Parts



THIS PAGE INTENTIONALLY LEFT BLANK