



Parts List


Electrical



Electrical Layout




Motor Detail



ITEM	DESIGNATOR	PART NUMBER	DESCRIPTION	OLD PART NO.	Q'TY.
1	1Q8	5001264-BBT-V1 5001264-BBT-V0	ELECTRICAL BOX, 230 V ELECTRICAL BOX 110 V	P0323-0000600 P0323-0000700	1
1a	1F8	5005197	FUSE	P0305-030002600	1
2	1M8	5001714-TB 5001714-BB-V1	MOTOR 110V/60Hz T18:1 MOTOR 110V/50Hz T15:1 MOTOR 210V/60Hz T18:1 MOTOR 210V/50Hz T15:1	745111M1 745111M2 745122M1 745122M2	1

Machine Body and Tables




ITEM	PART NO.	DESCRIPTION	OLD PART NO.	Q'TY
1	5004137	MACHINE FRAME	KA11106710	1
2	5004132	PLATE A	CA33060A	4
3	5004138	CONNECTING BASE	KA11108000	1
4	5004139	SAFETY COVER	DA11107400	2
5	5002147	GUIDE RAIL (SQUEEZER) BAR (R)	KA030520R0	1
6	5002116	GUIDE RAIL (SQUEEZER) BAR (L)	KA030520L0	1
7	5004140	CAP PLUG	P1114-010001200	4
8	5002131	HANDLE KNOB M10 × 40I	KA0400610	1
9	5004141	GUIDE RAIL (SQUEEZER) ARM (R)	KA11107510	1
10	5004142	GUIDE RAIL (SQUEEZER) ARM (L)	KA11107610	1
11	5004143	GUIDE RAIL SIMULTANEOUS BAR	KA03051800	1
12	5002133	JOINT BEARING PHS08	81060051	1
13	5002132	SCREW	KA03052700 / 5001993	2
14	5004144	RING	KA30016100	4
15	5004145	GUIDE RAIL (SQUEEZER) ARM SHAFT	P02-016200A	2
16	5001922	CHAIN WHEEL	KA31005800	1
17	5001939	SHAFT	KA03066400	1
18	5001867	BEARING SEAT	CA131000	2
19	5001701	BEARING 6203ZZ (CWB)	30302030	2
20	5002102	BELT ROLLER	P0703-000670B	2
21	5004146	MOTOR SPROCKET WHEEL	KA11117000	1
22	5001714-TB 5001714-BB-V1	MOTOR 110V/60Hz T18:1 MOTOR 110V/50Hz T15:1 MOTOR 210V/60Hz T18:1 MOTOR 210V/50Hz T15:1	745111M1 745111M2 745122M1 745122M2	1
23	5001905	CHAIN WHEEL 12T	CA331300	1
24	5004147	CHAIN COVER	KA11118600	1
25	5004148	MOTOR COVER	KA11117200	1
26	5001040	BELT	KA30016800	2
27	5004149	BELT ROLLER SHAFT	KA03052300	2
28	5000969	BELT ROLLER	KA30016500	2
29	5002151	BELT WASHER	KA30019000	4
30	5004150	ROLLER SHAFT	KA03055600	4
31	4500171	BEARING 6900ZZ	30309000	8

34 Illustrated Parts List

ITEM	PART NO.	DESCRIPTION	OLD PART NO.	Q'TY
32	5004151	ROLLER	KA30016700	4
33	5004152	BELT ROLLER SUPPORT	KA11108400	2
34	5004153	CASTER FIXER	P01-022400A	1
35	5004154	FIXED PLATE	KA11107800	2
36	5004155	LEG	P01-020000C	2
37	5004156	FIXED PLATE	KA11107900	2
38	5002107	ADJUSTABLE LEG	KA11107700	4
39	5001902	CASTER, SWIVEL, LOCKING	KA04010800	4
40	5004157	CONTROL BOX FIX PLATE	KA11113600	1
41	5002117	PACKING PLATE	KA30016600	2
42	5004158	PACKING TABLE	KA11106810	2
43	5004159	GUIDE RAIL GUIDE	KA11108500	1
44	5004160	LEG	P01-020100C	2
45	5000968	BEARING 6201ZZ	30302010	4
46	5004161	RING	KA03076600	2
47	5001264-BBT	ELECTRICAL BOX 110V	KA02002810 / P0323-0000700	1
	5001264-BBT-V1	ELECTRICAL BOX 230V	KA02002800 / P0323-0000600	1

Mast and Upper Tape Head Seat



ITEM	PART NO.	DESCRIPTION	OLD PART NO.	Q'TY
1	5004162	UPPER TAPER SEAT	KA11106910	1
2	5004163	UPPER TAPER FRONT PLATE	KA11107010	1
3	5004164	PLATE HOLDING SHAFT	KA03051210	2
4	5001696B	UPPER BLOCK B	CA100300	2
5	5004165	UPPER TAPER SHIELD	KA11108110	1
6	5004166	PLATE HOLDING SHAFT	KA03051100	3
7	5004167	COLUMN	KA11107300	1
8	5004168	PLUG - HP25	7030HP25	5
9	5004169	FIXED PLATE	KA11129800	2
10	5004083	RING	CA200200-01	2
11	5004084	WASHER AS1528	3036AS05	2
	5004085	BEARING AXK1528	30301528	1
12	5004086	HEIGHT ADJUSTABLE SPINDLE	KA03072800	1
13	5004087	NUT, LEADSCREW	CA1-1061-01	1
14	5004088	WASHER	KA11129700	1
15	5004089	SPRING	KA04014500	1
16	5004090	SPINDLE SEAT	KA03072900	1
17	5004170	COVER PLATE	KA30016300	2
18	5000968	BEARING 6201ZZ	30302010	4
19	5004171	RING	KA03051300	8
20	5004172	BEARING 6301ZZ	30303010	4
21	5004176	FIXED RING	KA03009600	1
22	5001710	HANDLE CRANK ARM	CA201500	1
23	5004091	BEARING SEAT	KA03052400	4
24	5004174	SQUARE PLUG	91350007	1
25	5004175	COVER	KA11108300	1
26	5001697B	UPPER BLOCK A	CA100200	2
27	5001913	SCREW-WING THUMB M4 × 10		

Tape Head (2" or 3") — Refer to Tape Head User Guide.

Refer to the User Guide provided with the Tape Head for the Illustrated Parts List and part numbers for Tape Head parts.