

TABLE OF CONTENTS

INTRODUCTION

Chart I-1-1 Model Number Standards	I-2
Table I-1-2 Double Arm Mixer Capacities	I-3
Figure I-1-3 Peerless Horizontal Tilt Bowl Mixer	I-4

CHAPTER 1. SAFETY

1-1 Safety Precautions	1-4
1-2 Personal Protective Equipment	1-9
1-3 Zero Energy State Procedures	1-10
Chart 1-3-1 Mixer Energy Sources	1-10
Example 1-3-2 LockOut Procedure	1-11
1-4 Warning Label Details	1-12
Figure 1-4-1 Warning Label #0907310	1-13
Figure 1-4-2 Warning Label #0908795	1-13
Figure 1-4-3 Warning Label #0908788	1-14
Figure 1-4-4 Warning Label #0908789	1-14
Figure 1-4-5 Warning Label #0908790	1-15
Figure 1-4-6 Warning Label #0908791	1-15
Figure 1-4-7 Warning Label #0908792	1-16
Figure 1-4-8 Warning Label #0908793	1-16
Figure 1-4-9 Warning Label #0908794	1-17
Figure 1-4-10 Warning Label #0908796	1-17
Figure 1-4-11 Warning Label #0903927	1-18
1-5 Warning Label Locations	1-19
Figure 1-5-1 Warning Label Locations	1-20
1-6 General Safety Information	1-21
1-6-1 User Responsibility	1-21
1-6-2 Safety First	1-21
1-6-3 Operation Safety	1-22
1-6-4 Cleaning Safety	1-24
1-6-5 Service and Maintenance Safety	1-24

CHAPTER 2. OPTIONS

2-1 Options Checklist	2-3
Warranty	2-8

CHAPTER 3. INSTALLATION

3-1 Off Loading and Hoisting	3-4
Figure 3-1-1 Mixer Specifications	3-5
Figure 3-1-2 Optional Lifting Lugs	3-6
Figure 3-1-3 Mixer Shipping Skids Arrangement	3-8

TABLE OF CONTENTS

3-2 Unpacking	3-9
3-3 Site Preparation	3-10
<i>Figure 3-3-1</i> Recommended Mixer Foundation Pad	3-12
3-4 Mixer Installation	3-13
<i>Figure 3-4-1</i> Mixer Bolt-On Legs	3-14
3-5 Mixer Wiring	3-15
<i>Figure 3-5-1</i> Mixer Field Wiring Diagram	3-17
<i>Chart 3-5-2</i> Mixer Field Wiring Summary	3-18
<i>Figure 3-5-3</i> Terminal Strip Wiring Example	3-19
<i>Figure 3-5-4</i> Agitator Rotation Direction	3-23
3-6 Refrigeration Connection--Indirect Liquid	3-24
<i>Figure 3-6-1</i> Refrigeration Hose Locations	3-26
<i>Chart 3-6-2</i> Indirect Liquid Jacket Connection Data	3-27
3-7 Flour Gate Connection	3-28
<i>Figure 3-8-1</i> Flour Gate Connection	3-29
3-8 Air Supply Connection	3-30
3-9 Liquid Ingredient Connections	3-31
<i>Chart 3-9-1</i> Liquid Ingredient Fitting Vendor	3-31
3-10 Flour Dust Vent	3-32
<i>Figure 3-10-1</i> Flour Dust Vent Assembly	3-33

CHAPTER 4. OPERATION

4-1 Operator Controls	4-5
<i>Chart 4-1-1</i> Operation Controls Summary	4-6
<i>Figure 4-1-2</i> Standard Control Panel	4-8
<i>Figure 4-1-3</i> Optional Control Panel with Refrigeration	4-9
4-2 Mix Time, Timer Operation	4-11
4-2-1 Eagle Digital Timer Operation	4-12
<i>Figure 4-2-1</i> Eagle Digital Timer	4-13
4-2-2 Eagle Mechanical Timer Operation	4-14
<i>Figure 4-2-2</i> Eagle Mechanical Timer	4-14
4-3 Motor Load Meter	4-15
4-4 Dough Thermometer.	4-16
<i>Figure 4-4-1</i> Dough Thermometer	4-16
<i>Flow Chart 4-4-2</i> Software Lockout Procedure	4-20
4-5 Dough Temperature Controller	4-21
4-6 Operating Procedures	4-22
4-6-1 Simplified Operating Procedure	4-23
<i>Flow Chart 4-6-1</i> Typical Operating Procedure	4-24
4-6-2 Detailed Operating Procedure	4-26
4-7 Refrigeration Operation Procedure	4-31
4-8 Operator Trouble-Shooting Guide.	4-32

TABLE OF CONTENTS

Table 4-8-1 Operator Trouble-Shooting Guide	4-32
4-9 Optional Equipment Operation	4-33
4-10 Video Control Panels	4-35
4-10-1 Cutler-Hammer IDT PanelMate® Series 1000	4-36
Figure 4-10-1 Cutler-Hammer IDT PanelMate® 1000 VCP	4-36
Figure 4-10-2 Cutler-Hammer IDT PanelMate® 1000 VCP General Page Layout	4-37
4-10-2 Cutler-Hammer IDT PanelMate® Power Series 3000	4-41
Figure 4-10-3 Cutler-Hammer IDT PanelMate® 3000 VCP	4-41
Figure 4-10-4 Cutler-Hammer IDT PanelMate® 3000 VCP General Page Layout	4-42
4-10-3 Allen-Bradley PanelView® Series 550	4-45
Figure 4-10-5 Allen-Bradley PanelView® 550 VCP	4-45
Figure 4-10-6 Allen-Bradley PanelView® 550 VCP Mixer Control Screen	4-47
Figure 4-10-7 Allen-Bradley PanelView® 550 VCP Preset Timers Page	4-49
4-10-4 Multiple Product Mixer Control Feature (MPMCF)	4-50
Figure 4-10-8 Current Mix Cycle Editor Page	4-50
Figure 4-10-9 Master Product Code Editor Page	4-51
Figure 4-10-10 Master Product Code Mixer Preset Table Template. Table 4-10-11 Master Product Code Preset	4-51
Chart 4-10-12 VCP Controls Summary	4-52
4-10-5 VCP Diagnostics Screen	4-54
Figure 4-10-13 Diagnostics Screen General Page Layout	4-55
Chart 4-10-14 Diagnostics Screen Functions Summary	4-56
4-10-6 Maintenance Clock and Agitator Hours Timer	4-58
 CHAPTER 5. MAINTENANCE	
5-1 Start-Up Checklist	5-6
Table 5-1-1 Start-Up Checklist	5-7
5-2 Preventive Maintenance	5-8
5-2-1 Recommended Preventive Maintenance Schedule	5-9
Table 5-2-1 Recommended Preventive Maintenance Schedule	5-9
5-2-2 Weekly Maintenance Detail	5-11
5-2-3 Monthly Maintenance Detail	5-14
5-2-4 Six Month Maintenance Detail	5-16
Table 5-2-5 Recommended Lubricants Chart	5-17
5-3 Safety Interlocks	5-18
Chart 5-3-1 Operation Controls Summary	5-18
5-4 Maintenance Trouble-Shooting Guide	5-20
Table 5-4-1 Maintenance Trouble-Shooting Guide	5-20

TABLE OF CONTENTS

5-5 Repair Parts Ordering	5-23
5-6 Manual Central Lube System	5-24
<i>Figure 5-6-1</i> Manual Central Lube System	5-25
<i>Figure 5-6-2</i> Divider Valve System	5-27
5-7 Auto Central Lube System	5-30
<i>Figure 5-7-1</i> Auto Central Lube System	5-31
<i>Figure 5-7-2</i> Pneumatic Pump Operation	5-32
5-8 Agitator Assembly	5-35
5-8-1 Double Arm Agitator Assembly	5-36
<i>Figure 5-8-1</i> Double Arm Agitator Assembly	5-36
5-9 Left-Hand Agitator Shaft Bearing Assembly	5-37
<i>Figure 5-9-1</i> Left-Hand Agitator Shaft Bearing Assembly	5-38
<i>Figure 5-9-2</i> Heavy-Duty Left-Hand Agitator Shaft Bearing Assembly	5-40
5-10 Bowl Mounting Assemblies	5-43
<i>Figure 5-10-1</i> Bowl Mounting Assembly	5-44
5-11 Bowl Tilt System	5-45
<i>Figure 5-11-1</i> Hydraulic Tilt Cylinder System	5-46
<i>Figure 5-11-2</i> Hydraulic Rotary Actuator Tilt System	5-48
<i>Figure 5-11-3</i> Hydraulic Power Unit	5-50
<i>Figure 5-11-4</i> Hydraulic Stack	5-51
5-11-1 System Relief Valve	5-52
<i>Table 5-11-5</i> Hydraulic System Pressure Settings	5-53
5-11-2 Flow-Control Valves	5-54
5-11-3 Pressure Operated Check Valves (PO Checks)	5-54
5-11-4 B-port Pressure Reducing Valve (120-degree systems only)	5-54
5-11-5 Directional Valve	5-55
5-11-6 Return Filter	5-55
5-11-7 Oil Fill Fitting	5-56
5-11-8 Sight Gauge	5-57
5-11-9 Tank Drain Fitting	5-57
5-11-10 Hand Pump	5-57
5-11-11 Tilt Cylinders	5-58
5-11-12 Rotary Actuator	5-58
5-11-13 Tilt Limit Switches	5-58
5-11-14 Manual Tilt Procedure	5-60
5-11-15 Tilt System Trouble-Shooting Guide	5-60
<i>Table 5-11-6</i> Tilt System Trouble-Shooting Guide	5-61
5-12 Drive System	5-62
5-12-1 Chain Drive System	5-63
<i>Figure 5-12-1</i> Chain Drive System	5-64
<i>Figure 5-12-2</i> Automatic Electric Chain Oiler	5-65
<i>Figure 5-12-3</i> Roller Chain Tension	5-66
<i>Figure 5-12-4</i> Roller Chain Wear	5-67

TABLE OF CONTENTS

5-12-2	Belt Drive System (Optional)	5-67
Figure 5-12-5	Belt Drive System	5-68
Figure 5-12-6	Belt Idler Operation	5-70
Figure 5-12-7	Belt Drive Misalignments	5-71
Figure 5-12-8	Linear Belt Drive Alignment	5-72
Figure 5-12-9	Belt Alignment Gauge	5-73
5-12-3	Drive Motor	5-76
5-12-4	Motor Coupling	5-78
Figure 5-12-10	Drive Motor Coupling	5-78
5-12-5	Gear Reducer	5-79
Figure 5-12-11	Eurodrive Gear Reducer	5-79
Table 5-12-12	Oil Capacities for Eurodrive Gear Reducers	5-81
5-12-6	Right-Hand Gear Case Assembly	5-81
Figure 5-12-13	Right-Hand Gear Case Assembly	5-83
5-13	Electrical System	5-86
5-13-1	Programmable Logic Controller (PLC)	5-86
Figure 5-13-1	Allen-Bradley Model SLC 500 PLC	5-87
5-13-2	Electrical System Trouble-Shooting Guide	5-90
5-13-3	Motor Thermal Overload Module (MTOM)	5-91
5-13-4	Overloading	5-92
5-13-5	Starter Overload Relay	5-93
Figure 5-13-2	Starter Overload Relay	5-94
Figure 5-13-3	Starter Overload Relay with <i>RESET</i> Push Lever	5-94
5-13-6	Cutler-Hammer IDT PanelMate® 3000 VCP Repair	5-95
5-14	Pneumatic System	5-104
Figure 5-14-1	Air Preparation Assembly	5-104
5-15	Indirect Refrigeration System	5-107

CHAPTER 6. SANITATION

6-1	Sanitation Schedule	6-4
Table 6-1-1	Sanitation Schedule	6-5
6-1-1	Daily Cleaning Detail	6-6
6-1-2	Weekly Cleaning Detail	6-8
6-1-3	Monthly Cleaning Detail	6-9
6-2	Agitator Shaft Seal Cleaning	6-10
6-3	Flour Gate Cleaning	6-17
6-4	Flour Dust Vent Cage/Sock	6-20
6-5	Inside Bowl	6-21
6-6	Mixer End Columns	6-22

CHAPTER 7. REFRIGERATION

7-1	Refrigeration Systems	7-4
------------	------------------------------	------------

TABLE OF CONTENTS

7-1-1	Safety	7-5
7-1-2	Indirect Refrigeration Systems	7-6
7-1-3	Sizing Systems	7-7
	Checklist 7-1-1 Refrigeration Data	7-8
	Chart 7-1-2 Refrigeration Data Sample Output	7-9
	Chart 7-1-3 Mixer Motor--Tonnage vs Horsepower	7-10
	Table 7-1-4 Typical Refrigeration System Specifications	7-11
	Table 7-1-5 Glycol Solution Recommendations	7-11
	Table 7-1-6 Indirect Refrigeration Recommended Flow Rates	7-12
7-2	Installation of Refrigeration Systems	7-13
7-2-1	Indirect Refrigeration Systems	7-14
	Chart 7-2-1 Indirect Refrigeration System Schematic	7-16
7-3	General Specifications	7-21
	Table 7-3-1 Jacket Volume	7-17
	Figure 7-3-2 Standard Bowl Coolant Flow	7-18
	Figure 7-3-3 Bowl Coolant Flow with End Cooling	7-19
7-4	Refrigeration System Trouble-Shooting Guide	7-20
	Table 7-4-1 Optional Refrigeration Controls Trouble-Shooting Guide	7-21

CHAPTER 8. SPECIAL PAGES FOR ORDER

8-1	Special Pages for Order	8-2
-----	-----------------------------------	-----

CHAPTER 9. APPENDIX

9-1	Complete List of Revision Dates by Page Number	9-3
-----	--	-----

NOTE: The following items have been attached loose to this manual:

Front Pocket: Customer Assistance flyer, Recommended Spare Parts List

Front Window Pocket: Business cards for Service Manager, Parts Manager

Back Pocket: Certified Data Sheet, Wiring Diagrams.

ALPHABETICAL LIST OF FIGURES, CHARTS, TABLES, EXAMPLES

INTRODUCTION

	Figure #	Page
Double Arm Mixer Capacities Table	I-1-2	I-3
Model Number Standards Chart	I-1-1	I-2
Peerless Horizontal Tilt Bowl Mixer Figure	I-1-3	I-4

CHAPTER 1. SAFETY

LockOut Procedure Example	1-3-2	1-11
Mixer Energy Sources Chart	1-3-1	1-10
Warning Label #0907310 Figure	1-4-1	1-13
Warning Label #0913927 Figure	1-4-11	1-14
Warning Label #0908788 Figure	1-4-3	1-14
Warning Label #0908789 Figure	1-4-4	1-15
Warning Label #0908790 Figure	1-4-5	1-15
Warning Label #0908791 Figure	1-4-6	1-16
Warning Label #0908792 Figure	1-4-7	1-16
Warning Label #0908793 Figure	1-4-8	1-17
Warning Label #0908794 Figure	1-4-9	1-13
Warning Label #0908795 Figure	1-4-2	1-17
Warning Label #0908796 Figure	1-4-10	1-18
Warning Label Locations Figure	1-5-1	1-20

CHAPTER 2. OPTIONS CHECKLIST

CHAPTER 3. INSTALLATION

Flour Dust Vent Assembly Figure	3-10-1	3-33
Flour Gate Connection Figure	3-7-1	3-29
Indirect Liquid Jacket Connection Data Chart	3-6-2	3-27
Liquid Ingredient Fitting Vendor Chart	3-9-1	3-31
Mixer Field Wiring Diagram Figure	3-5-1	3-17
Mixer Field Wiring Summary Chart	3-5-2	3-18
Mixer Bolt-On Legs Figure	3-4-1	3-14
Mixer Specifications Figure	3-1-1	3-5
Mixer Shipping Skids Arrangement Figure	3-1-4	3-8
Optional Lifting Lugs Figure	3-1-3	3-6
Recommended Mixer Foundation Pad Figure	3-3-1	3-12
Refrigeration Hose Locations Figure	3-6-1	3-26
Rotation Direction of Agitators Figure	3-5-4	3-23
Terminal Strip Wiring Example Figure	3-5-3	3-19

ALPHABETICAL LIST OF FIGURES, CHARTS, TABLES, EXAMPLES

CHAPTER 4. OPERATION

Allen-Bradley PanelView® 550 VCP Figure	4-10-5	4-45
Allen-Bradley PanelView® 550 VCP Mixer Control Screen Figure	4-10-6	4-47
Allen-Bradley PanelView® 550 VCP Preset Timers Page Figure	4-10-7	4-49
Current Mix Cycle Editor Page Figure	4-10-8	4-50
Cutler-Hammer IDT PanelMate® 1000 VCP Figure	4-10-1	4-36
Cutler-Hammer IDT PanelMate® 1000 General Page Layout Figure	4-10-2	4-37
Cutler-Hammer IDT PanelMate® 3000 VCP Figure	4-10-3	4-41
Cutler-Hammer IDT PanelMate® 3000 VCP General Page Layout Figure	4-10-4	4-42
Diagnostics Screen Functions Summary Chart	4-10-14	4-56
Diagnostics Screen General Page Layout Figure	4-10-13	4-55
Dough Thermometer Figure	4-4-1	4-16
Eagle Digital Timer Figure	4-2-1	4-13
Eagle Mechanical Timer Figure	4-2-2	4-14
Master Product Code Editor Page Figure	4-10-9	4-51
Master Product Code Mixer Preset Table Template Figure	4-10-10	4-51
Master Product Code Preset Table	4-10-11	4-52
Operation Control Summary Chart	4-1-1	4-6
Operator Trouble-Shooting Guide Table	4-8-1	4-32
Software Lockout Procedure Flow Chart	4-4-2	4-20
Standard Control Panel Figure	4-1-2	4-8
Optional Control Panel with Refrigeration Figure	4-1-3	4-9
Typical Operating Procedure Flow Chart	4-6-1	4-24
VCP Controls Summary Chart	4-10-12	4-54

CHAPTER 5. MAINTENANCE

Air Preparation Assembly Figure	5-14-1	5-104
Allen-Bradley Model SLC 500 PLC Figure	5-13-1	5-87
Auto Central Lube System Figure	5-7-1	5-31
Automatic Electric Chain Oiler Figure	5-12-2	5-65
Belt Alignment Gauge Figure	5-12-9	5-73
Belt Drive Misalignments Figure	5-12-7	5-71
Belt Drive System Figure	5-12-5	5-68
Belt Idler Operation Figure	5-12-6	5-70
Bowl Mounting Assembly Figure	5-10-1	5-44
Chain Drive System Figure	5-12-1	5-64
Divider Valve System Figure	5-6-2	5-27

ALPHABETICAL LIST OF FIGURES, CHARTS, TABLES, EXAMPLES

CHAPTER 5. MAINTENANCE (con't.)

Drive Motor Coupling Figure	5-12-10	5-78
Double Arm Agitator Assembly Figure	5-8-1	5-36
Eurodrive Gear Reducer Figure	5-12-11	5-79
Heavy-Duty Left-Hand Agitator Shaft Bearing Assembly Figure	5-9-2	5-40
Hydraulic Stack Figure	5-11-4	5-51
Hydraulic Tilt Cylinder System Figure	5-11-1	5-46
Hydraulic Power Unit Figure	5-11-3	5-50
Hydraulic Rotary Actuator Tilt System Figure	5-11-2	5-48
Hydraulic System Pressure Settings Table	5-11-5	5-53
Left-Hand Agitator Shaft Bearing Assembly Figure	5-9-1	5-38
Linear Belt Drive Alignment Figure	5-12-8	5-72
Maintenance Trouble-Shooting Guide Table	5-4-1	5-20
Manual Central Lube System Figure	5-6-1	5-25
Oil Capacities for Eurodrive Gear Reducers Table	5-12-12	5-81
Operation Controls Summary Chart	5-3-1	5-18
Pneumatic Pump Operation Figure	5-7-2	5-32
Recommended Lubricants Table	5-2-5	5-17
Recommended Preventive Maintenance Schedule Table	5-2-1	5-9
Right-Hand Gear Case Assembly Figure	5-12-13	5-83
Roller Chain Tension Figure	5-12-3	5-66
Roller Chain Wear Figure	5-12-4	5-67
Starter Overload Relay Figure	5-13-2	5-94
Starter Overload Relay with RESET Push Lever Figure	5-13-3	5-94
Start-Up Checklist Table	5-1-1	5-7
Tilt System Trouble-Shooting Guide Table	5-11-6	5-61

CHAPTER 6. SANITATION

Sanitation Schedule Table	6-1-1	6-5
----------------------------------	-------	-----

CHAPTER 7. REFRIGERATION

Bowl Coolant Flow with End Cooling Figure	7-3-3	7-19
Glycol System Schematic Chart	7-2-2	7-20
Glycol Solution Recommendations Table	7-1-5	7-11
Indirect Refrigeration Recommended Flow Rates Table	7-1-6	7-12
Indirect Refrigeration System Schematic Figure	7-2-1	7-16
Jacket Volume Table	7-3-1	7-17
Mixer Motor--Tonnage vs Horsepower Chart	7-1-3	7-10
Optional Refrigeration Controls Trouble-Shooting Guide Table	7-4-1	7-21

ALPHABETICAL LIST OF FIGURES, CHARTS, TABLES, EXAMPLES

CHAPTER 7. REFRIGERATION (con't.)

Refrigeration Data Checklist		7-1-1	7-8
Refrigeration Data Sample Output Chart		7-1-2	7-9
Standard Bowl Coolant Flow Figure		7-3-2	7-18
Typical Refrigeration System Specifications Table		7-1-4	7-11

CHAPTER 8. SPECIAL PAGES FOR ORDER

CHAPTER 9. APPENDIX