




Diagram 5.1

1	101035	Guide Plate	13	911005W (white) 911005B (black)	Solid Ink Wheel
2	101023	Adjusting Block of Driven Wheel	14	101528	Ink Wheel Swing Arm Adjusting Bolt
3	101021	Driven Wheel	15	201002	Ink Wheel Heating Block
4	101502	Control Plate	16	105023	Guiding Wheel
5	930301T (top) 930301B (bottom)	Heating Block	17	910801	Conveyor Belt
6	901903	Sealing Belts (Top/Bottom)	18	101501	Conveyor Table
7	101503	Impressing Wheel	19	930111	Fastening Knob-Lifting Conveyor Table
8	930302T (top) 930302B (bottom)	Cooling Block	20	101512	Conveyor Horizontal Adjust Tightening Knob
9	105022	Driving Wheel	21	101504	Ledge
10	101018	Pattern Printing Wheel	22	105009	Silicone Wheel
11	101036	Rubber Wheel	23	940705	Sensor
12	201013	Printing Wheel			




Diagram 5.2

1	101506	Base	16	101006	Working Table
2	101501	Conveyor Table	17	105026	Adjusting Block of Conveyor Belt
3	101012	Driving Roller	18	930113	Adjusting Knob of Conveyor Belt
4	101505	Conveyor Belt	19	105005	Upper Splint
5	101504	Fixed Bracket	20	201002	Ink Wheel Heating Block
6	101507	Slip Bracket	21	101513	Guiding Wheel Shaft
7	101508	Safety Guard	22	101530	Guiding Wheel
8	201016	Ink Wheel Swing Arm Adjusting Knob	23	910801	Guiding Belt
9	101509	Pattern Printing Wheel Adjusting Knob	24	930301U (upper) 930301L (lower)	Heating Block
10	101510	Machine Body	25	105005	Lower Splint
11	101502	Control Plate	26	910903	Sealing Belt
12	101511	Machine Breaker	27	101520	Vertical Shaft
13	101035	Guide Plate	28	101514	Universal Joint Assembly
14	101512	Fastening Knob	29	101515	Umbrella Gear Wheel Assembly
15	93011	Tightening Nut			