


Parts List

Accumulation Table — TT36 & TT48



ITEM	PART NO.	DESCRIPTION	Quantity	
			TT36	TT48
1	5001207	Caster – Heavy Duty Locking, standard	1	1
2	ESC00562	Sprocket 40B18 1-Inch Bore	1	1
3	ESC00574	Bearing, 1-inch Bore, Flanged	2	2
4	ET820021	Bearing, 1-inch Bore, Flanged	1	1
5	TT000001	Top Mount Plate	1	1
6	TT000002	Drive Shaft	1	1

ITEM	PART NO.	DESCRIPTION	Quantity	
			TT36	TT48
7	TT000005	Side Plate	3	3
8	TT000006	Front Plate	1	1
9	TT000007	Control Box Mount Plate	1	1
10	TT000020	Sidewall Mount Support Angle	4	4
11	TT000050	Table Base Weldment	1	1
12	TT000550	DC Gear Motor 14 RPM	1	1
13	TT000551	Threaded Tube Insert	4	4
14	TT000552	Leveling Feet	4	4
15	TT000560	Wheel Assembly, Turntable Support (Inverted Caster)	4	4
16	TT000561	DC Control Box With Forward/Brake/Reverse Switch	1	1
17	TT360001	Table Top Plate, 36-inch Diameter	1	–
17	TT480001	Table Top Plate, 48-inch Diameter	–	1
18	TT360002	Sidewall, Circumferential, 36-inch Diameter	1	–
18	TT480002	Sidewall, Circumferential, 48-inch Diameter	–	1