



COLLATOR 200

Flexible Semi-Automatic
Product Package Vertical
Collator

User Manual

Hershey Salty Snacks Co
Bethlehem, PA

97250

Serial Numbers: 5595-5596



Warranty Information

Unless otherwise explicitly agreed in the written confirmation of order, for a period of twelve (12) months after delivery , the Seller warrants to the Purchaser:

1. That the materials and workmanship of the equipment are free from defects; and
2. That components or parts which are properly made, manufactured and/or assembled by manufacturers other than the Seller will not be rendered otherwise defective because of their inclusion in the Seller's items of equipment. In the event of the failure of an item of equipment, the Purchaser must notify the Seller in writing within thirty (30) days after discovery of the claimed defect. Within a reasonable time after such notification, the Seller will perform reasonable repairs to the items of equipment, limited to either repairing or replacing, at its discretion, the nonconforming parts or components. Any part or component replaced pursuant to this warranty shall become the property of the Seller.

The Seller does not warrant:

3. Any components or parts used in this equipment which are purchased from other manufacturers, in which case the original manufacturer's warranty shall apply;
4. Damage caused by use of the items of equipment for purposes other than those for which they were designed;
5. Damage to items of equipment caused by disasters such as fire, flood, wind and lightening;
6. Damage to items of equipment caused by alteration or modification without the Seller's advice and prior consent;
7. Damage to any item of equipment resulting from use not in compliance with recommended procedures, improper service or any other cause beyond the control of the Seller; or
8. Damage resulting from the neglect, abuse

or misuse of items of equipment, including vandalism.

9. **EXCEPT AS EXPRESSLY SET FORTH IN THIS WARRANTY SECTION, BluePrint Automation, Inc. MAKES NO WARRANTY, EXPRESSED OR IMPLIED, ORAL OR WRITTEN, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR USE OR OTHERWISE, WITH RESPECT TO ANY MACHINERY OR LABOUR FURNISHED DURING THE SALE, DELIVERY OR SERVICING OF ANY MACHINERY.**
10. In no case shall the Seller be liable for any special, incidental or consequential damages based upon breach of warranty, breach of contract, negligence, strict tort liability or any other legal theory. Such damages include, but are not limited to, loss of profits, loss of revenue, loss of use of the items of equipment, cost of capital, cost of any substitute items of equipment, facilities or services, downtime, claims of third parties including customers, and injury to property.
11. Any claim alleging breach of this Warranty is expressly made subject to the binding arbitration provisions; any such arbitration or other action relating to this Warranty must be commenced within twelve (12) months following delivery of the items of equipment.
12. Unless modified by provisions contained in the confirmation of order, this Warranty is understood to be the complete and exclusive agreement between the parties, superseding all prior agreements, oral or written, and all other communications between the parties relating to the subject matter of this Warranty. No employee, other than an officer of the Company, or representative of the Seller is authorized to make any warranty in addition to those made herein.
13. All OEM equipment not manufactured by BluePrint Automation will carry only the OEM equipment manufacturer's warranty.
14. No warranty provisions contained herein

© BluePrint Automation 2024

All right reserved. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage or retrieval system, without permission in writing from **BluePrint** Automation, except for use in the operation or servicing of this equipment.

Every possible care has been taken to ensure the information in this manual is correct and accurate. However, no liability can be accepted by **BluePrint** Automation Inc. for loss, damage, or injury caused by errors in, or omissions from, this document.

Information in this manual is subject to change without notice. Vendors supply some of this information to **BluePrint** Automation. **BluePrint** Automation, Inc. is not responsible for false or inaccurate information.

Formatted to PMMI specification, Set in Arial.

Reprinting This Manual

You may print as many copies of this manual as required for your company. Every effort has been taken to include the highest quality photos and illustrations (in these electronic manual files) to provide the best possible images when reprinting. These manual sections were designed and written to be printed in colour. Reproducing sections in black and white, while possible, is not desirable. Some image quality will suffer and some connexions between instruction and illustrations will be lost without colour. We strongly recommend reproductions be done in a colour format.

This document is originally written in English, a document in another language is a translation.

Manual Release & Revised Dates

Release/Revised Date	Version	Pages	Edition
December 2024	00001.1	112	First edition, second release.
MM/YYYY	##	###	
MM/YYYY	##	###	
MM/YYYY	##	###	
MM/YYYY	##	###	
MM/YYYY	##	###	
MM/YYYY	##	###	
MM/YYYY	##	###	
MM/YYYY	##	###	

Contents

Introduction

Introduction	7
Safety	13
Installation	27
Setup and Changeover	33
Operation	45
Maintenance	65
Troubleshooting	95
Replacement Parts	101
Index	107

Customer Service and Support

Technical Support

BluePrint Automation offers twenty four hours, seven days a week, 365 days a year technical support as outlined below.

Call: **001 804 520 5400**

Business hours: *Ask for technical support.*

After hours: *Prompt for Customer Service.*

A technical support ticket is created and escalated ASAP if technical support cannot correct the issue.

Note: The following email in-boxes are monitored during business hours only.

New project needs:

Sales@blueprintautomation.com

Dedicated in-box for technical support questions:

Help@blueprintautomation.com

Dedicated in-box for service orders including spare parts, technician visits, and upgrades:

Orders@blueprintautomation.com

Turnaround Time on Replacement Parts

Standard emergency fabrication part lead times are 24-48 hours.



Other Service Department Offerings

Secured Remote Support

- Secure software is used to remotely support our customers when needed.
- Virtual Private Network (VPN) devices available for install for faster remote connexions.

Asset Health and Reliability Program

- Dedicated reliability engineer.
- The asset health and reliability program (AHRP) is designed to support the customer through the entire life cycle of their equipment and extend the life cycle of the equipment.

Service Health Check

Regular Service Health Checks help you to minimize your maintenance expenses, while maximizing operational continuity. Our life-cycle logbook helps you to easily manage the condition of your machine.

Hands-on Classroom Learning


Utilize the full potential of your machine, by learning every detail of its operation and maintenance. By optimizing the human factor, your organization reaches the highest level of efficiency and output.

BluePrint Automation, Inc.

16037 Innovation Drive
South Chesterfield, Virginia 23834-5951 USA
Telephone: **001 804 520 5400**
www.blueprintautomation.com

BluePrint Automation, Inc.

4093 Specialty PI A
Longmont, CO 80504-5400
Telephone: **001 804 520 5400**
www.blueprintautomation.com



About This Manual

Purpose

The purpose of this manual is to help you get the best value from your equipment. It provides information and procedures for operating, maintaining and servicing; and it offers diagnostic and repair procedures to follow when trouble occurs.

Using the manual

This manual is broken up into the following chapters:

- Introduction
- Safety
- Installation
- Setup and Changeover
- Operation
- Maintenance
- Troubleshooting
- Replacement Parts
- Index

Because this is a User Manual it is not necessary for all personnel to read the entire manual cover to cover.

Operators

Operators should read the Introduction, Safety, Operation, and Changeover. Each of these sections will help familiarise them with safety procedures and Safety/Warning signs. Also, the operator will be introduced to the following:

- A brief description of system components.
- Theory of operation.
- How to change recipe code parameters.
- How to enter and change passwords.
- Description of each HMI screen.
- Operator shift cleaning instructions.


Maintenance Personnel

Maintenance personnel should read the entire manual to familiarise themselves with the safety precautions, safety devices, and safety signs used on this equipment. Maintenance will need to refer to each section at different times during maintenance. Items of particular interest to maintenance personnel include but are not limited to the following:

- Maintenance schedules, instructions, and supplies.
- Troubleshooting.
- Calibration instructions (if applicable), located in the Operation chapter.
- Recommended spare parts list.

Complete documentation package

The complete updated documentation package for this equipment will include at least the *User Manual*, *Mechanical Assembly Drawings*, *Electrical Schematics*, *OEM documentation* (if applicable), and the *Safety Data Sheets*, these can be accessed by scanning the QR code or clicking on the hyper-link below:





THIS PAGE INTENTIONALLY LEFT BLANK