Pre Charge (off board)

Main rail bulk caps

Main Current Sensor

Back current protection

Actuator rails

ESTOP

48V to 3.3V buck

48V to 24V buck + current sensor

48V to 6V Converter

