



Dante Config Editor

Quick start - offline StageFlow projects and Dante XML editing

Third-party tool, not an official Audinate product. Work on a copy and always validate the final XML by importing it into the appropriate official Dante tool before real use.

Recommended workflow

- 1** Open or create
Choose a .stageflow project, create one, or open legacy Dante XML. DCE remains standalone and offline.
- 2** Review alerts
Show affected devices and verify every reported item.
- 3** Edit
Use Devices, Matrix, Easy patch, Rx-to-Tx list, or global actions. Lock devices that must be excluded.
- 4** Review
Use Modified only and Before / after. Unknown technical changes are blocked.
- 5** Validate and save
The pre-export assistant separates errors, warnings, and information. Fix errors, acknowledge warnings, then choose a new name.
- 6** Test the import
Import the result into Dante Controller on a working copy before any field operation.

Useful features

Visual patch Every click or drag applies the patch immediately. Replacement warnings for already-patched Rx channels are enabled by default and can be cleared.	Native project, LIVE, and console DCE directly creates and saves .stageflow directories. A valid StageFlow LIVE session can synchronize only UUID-linked Rx channels. On Windows, the local console can open Patch, validation, or save the Dante domain, with no network command.
First launch A guided welcome offers to open StageFlow or XML, create a project, browse banks, or read the guide. Reopen it from Help > Discover DCE.	Import / Export JSON/CSV, DMT XLSX/ODS, A&H; CSV, and Yamaha ZIP labels are grouped. From a StageFlow project, a patch group can also name all or part of a Dante device's RX channels.
Synoptic Group devices by location, open a separate proportion-preserving preview, and export SVG or PDF without changing Dante XML.	Machine bank Review provenance and verification level, then prepare a sanitized contribution or add an independent instance.
License The trial lasts 30 days. DCE then remains fully accessible; a commercial or complimentary license removes the startup reminder.	

Labels: choose Native A&H; CSV - dLive/Avantis, Native Yamaha ZIP - CL/QL, or DMT XLSX/ODS. In a StageFlow project, also use Map the StageFlow patch to RX channels. Empty cells are ignored.

Exercise: Atomic Bomb has its own screen. Clear categories you want to spare, turn the key, click the cover to open it, then press ARM, LOCK, and FIRE. Then use Save as to create the trainee file. Technical identifiers remain protected.

Remember: no real-time control, no Audinate API, and no guarantee for every XML format. Import validation in official tools remains mandatory.

Free and optional StageFlow: <https://github.com/Mamat79/StageFlow>

Public repository: github.com/Mamat79/Dante-Config-Editor