# Dante Config Editor 2027.2.14

## Quick start | macOS

1. Download the Apple Silicon or Intel DMG matching your Mac, verify its origin, and copy DCE into Applications.

2. Create a configuration and Open a configuration are the two first-step choices at the same level. Create opens an empty draft: add devices from the bank. Open chooses the starting XML. Add configurations is optional: resolve duplicates, then add the batch. Local StageFlow project opens a .stageflow folder; StageFlow LIVE joins a coded session.

3. In Devices, check the selected device, enable editing, rename, and apply supported settings. Global actions target multiple devices. The bank creates and duplicates instances.

4. In Patch, use the main matrix or open Easy Patch… and expand devices. Drag diagonally or along a column with amber previews. Flip swaps the chosen device pair; Locate finds connections.

5. Double-click labels to rename inline and drag the fill handle to extend a series. Multicast selects audio Tx channels and creates, updates, or removes simple preset flows.

6. Under Import / Export, map StageFlow entries to Rx by UUID, exchange labels, and generate reports or PDF/SVG synoptics.

7. Validate before saving. Save writes the project; in StageFlow, only the Dante domain is updated. File > Export to Dante Controller produces a separate copy without changing the open project or its history. Check this deliverable in Dante Controller.

Free use: no code or online activation required. Choose Continue with DCE, even without Internet. No reminder for 30 days; then a 5-second countdown and full access. A purchased or complimentary permanent license is optional; a valid license removes reminder and wait. Price: EUR 29 including French VAT. Compatible V1 codes remain valid. V2 codes: Internet to activate or deactivate this Mac, a macOS Keychain key, then offline verification after restarting. If access is refused, unlock Keychain and retry the same code.

GitHub : installateurs et notices / installers and guides