Dante Config Editor 2027.3

Quick start | macOS, offline XML projects

1. Download the Apple Silicon or Intel DMG matching your Mac, verify its origin, and copy DCE into Applications.

2. Create a configuration and Open a configuration are the two first-step choices at the same level. Create opens an empty draft: add devices from the bank. Open chooses the starting XML. Add configurations is optional: resolve duplicates, then add the batch. Local StageFlow project opens a .stageflow folder; StageFlow LIVE joins a coded session.

3. In Devices, check the selected device, enable editing, rename, and apply supported settings. Global actions target multiple devices. The bank creates and duplicates instances.

4. In Patch, use the main matrix or open Easy Patch… and expand devices. Drag diagonally or along a column with amber previews. Flip swaps the chosen device pair; Locate finds connections.

5. Double-click labels to rename inline and drag the fill handle to extend a series. Multicast selects audio Tx channels and creates, updates, or removes simple preset flows.

6. Under Import / Export, map StageFlow entries to Rx by UUID, exchange labels, and generate reports or PDF/SVG synoptics.

7. Validate before saving. Save writes the project; in StageFlow, only the Dante domain is updated. File > Export to Dante Controller produces a separate copy without changing the open project or its history. Check this deliverable in Dante Controller.

Permanent license for EUR 49 including French VAT. If you have no valid license, the 30-day trial starts on the first launch of 2027.3 and works offline. A valid license is required afterwards. Existing permanent licenses remain valid. A V2 code requires internet access for the first activation on this Mac. DCE then checks the license offline.

GitHub : installateurs et notices / installers and guides