

Dante Config Editor V3.08 Beta

Full user guide - version 3.08-beta

Important: this is a third-party tool, not an official Audinate product. V3.08 is a Windows beta; V3.07 remains the recommended stable release. It edits XML files offline without connecting to a Dante network or using an Audinate API. Keep the original and validate the generated file in Dante Controller before production use.

1. Installation and startup

The Windows x64 installer includes the application and the required .NET 8 runtime. A separate .NET installation is normally not required.

- The default location is Program Files, with a Start menu shortcut.
- V3.08 Beta uses its own Program Files folder, shortcut, and Appld.
- It can coexist with stable V3.07 and only upgrades an earlier V3.08 installation.
- V3.08 Beta is not distributed on Mac; use stable V3.07 until the official V3.08 Release.
- All four French and English PDFs are installed and remain available from the application.

2. Safety principles

- Work on a copy of the exported XML and use Save as.
- The guard tracks devices by stable technical identity, blocks unknown paths, and protects Dante IDs, mediaType, and instance_id.
- The destination is replaced atomically. The source and any existing destination receive a copy in DanteConfigEditor_Backups.
- A successful import into Dante Controller is the final validation before operation.

3. Open a project

Click Open XML, choose the file, then review device, TX/RX channel, and active subscription counts. XML files with a default namespace are supported. Language and theme can be changed at any time.

4. Configuration page

The Configuration page combines the selected device, its channels, global actions, and the device table.

Selected device

- Apply the name, network mode, latency, and Preferred Master state together with Apply settings.
- Double-click a row or use Device details to edit IP settings, sample rate, bits per sample, TX/RX names, and subscriptions for its Rx inputs.
- A complete Device details change is grouped into one model rebuild.
- Clear actions can disconnect Rx inputs, remove subscriptions using Tx channels, or do both.
- Deleting a device also removes subscription points that reference it.

Device table

- Multiple selection defines the Selected unlocked target. The Lock column protects devices from global actions.
- Preferred Master can be toggled directly. Hide settings enlarges the table.

Search, filters, and global actions

- Search finds devices, channels, and subscription references after at least two characters.
- Quick lists filter network modes, latencies, sample rates, bits, static IPs, and Preferred Masters.
- Modified only shows changed devices; Before / after lists every difference.
- Choose all unlocked, selected unlocked, or visible unlocked devices. A preview is shown before application.

5. Navigable alerts

The Items to check banner reports mixed redundant/daisychain modes, static IPs, multiple sample rates, and multiple bit depths.

- Click Show devices, choose an alert, then review the filtered devices.
- After correcting an item, verify that the alert disappears and review File health.

6. Quick profiles

Profile	Applied settings
48 kHz / 24 bit / 1 ms	Automatic IP
48 kHz / 24 bit / 2 ms	Automatic IP
96 kHz / 24 bit / 1 ms	Automatic IP
96 kHz / 24 bit / 2 ms	Automatic IP
48 kHz / 24 bit / 1 ms / Redundant	Redundant mode and automatic IP
48 kHz / 24 bit / 1 ms / Daisychain	Daisychain mode and automatic IP

Verify that every device supports the requested sample rate, bit depth, latency, and network mode.

7. Automatic recovery

After a change, the application waits briefly and writes recovery data in the background without blocking the interface or replacing the source XML.

- When reopening the same XML, choose whether to restore or discard the previous session.
- After Save as, the new file becomes the reference for later edits and recovery data.
- The copy is deleted after saving or reverting; copies older than 30 days are cleaned automatically.

8. Channels and subscriptions

- TX/RX channels can be renamed individually or by range with {00}, {000}, {n}, and {device}.
- Renaming a Tx channel updates every recognized subscription alias in the project.
- Dante IDs are not renumbered. The local subscribed_device="." marker is preserved.
- Visual patch / matrix opens a workspace filtered to one Tx device and one Rx device without relying on drag and drop.
- Select equal Tx and Rx counts for one-to-one mapping, or one Tx to feed several Rx channels.
- Several Tx channels to one Rx and unequal multiple selections are blocked.
- Range patching requires a first Tx, first Rx, and exact count; an incomplete range is blocked as a whole.
- The preview classifies rows as create, replace, or unchanged. For conflicts, choose cancel, skip, or replace.
- In the matrix, Rx channels are rows and Tx channels are columns. Clicking a cell assigns its source; clicking the active cell stages a disconnection.
- Changes remain pending until Apply to project. They are then executed as one batch and one undo step.

9. Add XML to project

- Devices with unique names are always imported.
- Only conflicting names are offered for automatic or manual rename.
- Imported subscriptions follow renamed imported devices.

10. IP and audio formats

- Automatic or static IP is editable per device or through a global action.
- Only the primary IPv4 interface, network=0 when available, is targeted. A secondary interface is not changed.
- DNS is not rewritten implicitly. Gateway changes only when the action provides a value.
- Sample rate and bits per sample are editable per device, globally, or through a profile.

Incorrect settings can make a device unreachable or incompatible. Verify actual hardware capabilities.

11. File health, comparison, and exports

- File health combines statistics, errors, warnings, free/local subscriptions, and compatibility checks.
- XML comparison displays differences in a table.
- TXT/PDF exports include the application version and the By Mamat signature.

12. Save and final validation

Use Save as. The temporary XML is reloaded, protected changes are checked, and the destination is replaced atomically. A failure before replacement leaves the previous destination intact.

Check	Recommended action
Items to check	Open affected devices and explain or correct every unexpected difference.
Modified only	Verify that only the intended devices appear.
Before / after	Review every changed setting, channel, and subscription.
Dante Controller	Import the file into a working copy before any field operation.

13. Regression tests

The V3.08 Beta suite runs 84 Core and Windows contract tests covering technical identities, unknown paths, atomic save, recovery, IPv4 interfaces, subscription aliases, default namespaces, synthetic presets, Tx/Rx selection, ranges, conflicts, rollback, persistence, matrix actions, and Device details integration. GitHub Actions reruns them on Windows.

14. Known limitations

- No real-time Dante control and no communication with devices.
- No Audinate SDK/API and no proprietary protocol bypass.
- Compatibility depends on the XML structure; only an official import confirms the final file.
- Undo keeps at most 10 states to limit memory use.
- The matrix displays only the two selected devices to preserve performance on large presets.
- V3.08 Beta is distributed only on Windows; the Mac version remains stable V3.07.
- Duplicate Tx names are ambiguous in Dante subscriptions and must be renamed before visual patching.

15. Help and information

Quick start and Full guide automatically open the French or English PDF for the active language.

Public project: github.com/Mamat79/DanteConfigEditorV3
Credit: By Mamat