

Dante Config Editor V3.08 Beta

Quick start - offline editing of Dante XML files

Third-party tool, not an official Audinate product. V3.08 is a Windows beta. V3.07 remains the recommended stable release. Work on a copy and always validate the final XML by importing it into the appropriate official Dante tool before real use.

Recommended workflow

- 1** Open XML
Choose a Dante export. The application works offline and does not access the network.
- 2** Review alerts
Show affected devices and verify every reported item.
- 3** Edit
Use Device details, Visual patch, or global actions. Lock devices that must be excluded.
- 4** Review
Use Modified only and Before / after. Unknown technical changes are blocked.
- 5** Save as
Choose a new name. The destination is replaced atomically and backed up when it already exists.
- 6** Test the import
Import the result into Dante Controller on a working copy before any field operation.

Useful features

Visual patch Select Tx and Rx channels, preview the batch, then choose how to handle already patched Rx channels. Ranges are strict and the matrix remains available.	Recovery A copy is written in the background after a short delay. Save as makes the new destination the session reference.
Sub-project Add XML to project imports unique devices and only asks about conflicting names.	IPv4 Only the primary interface is targeted. DNS and the secondary interface are not rewritten implicitly.

Remember: no real-time control, no Audinate API, and no guarantee for every XML format. Import validation in official tools remains mandatory.

Public repository: github.com/Mamat79/DanteConfigEditorV3