



PROFESSIONAL USER GUIDE

StageDesk v2026

Save My Time

Transfer labels and essential settings between audio consoles and software.

One source. One working table. One destination. StageDesk avoids retyping and adapts each transfer to the selected model.

Retrieve

Choose a displayed source mode, then open the offered project file and state.

Convert

Edit labels, colours, icons, and essential settings in one common grid.

Transfer

Use the mode and target state actually offered by the connector.

Windows x64 - macOS - Français and English - v2026 edition

SiLeMI/O by Mamat
----□--



Interactive contents

Select a chapter to open it. PDF viewer bookmarks use the same structure, and every page links back to these contents.

- 1. StageDesk in one minute 3
- One project, several tools 4
- 2. Prepare a reliable transfer 5
- 3. Retrieve the source 6
- 4. Work in the universal table 7
- 5. Choose the target 8
- 6. Scenes, snapshots, and cues 9
- 7. Adapt data to the target 10
- 8. Backups and non-destructive writing 11
- 9. Project profiles available in StageDesk - 1/2 12
- 10. Project profiles available in StageDesk - 2/2 13
- 11. Software and exchange formats 14
- 12. Conversion recipes 15
- 13. Work faster every day 16
- 14. Delivery checklist 17
- 15. Updates, help, and licensing 18
- 16. Fast reference 19

Recommended path: prepare the source, retrieve data, review the table, choose the target, adapt, and validate the result.



1. StageDesk in one minute

StageDesk centralizes labels and essential audio-project settings in a universal table, then adapts and transfers them to the selected console or software.

1 Retrieve Choose the source, model, then the source mode and state actually offered.	2 Edit Review the universal table and adjust only the data that should change.	3 Send Choose the target, then one of the modes actually shown for that profile and one of its offered target states.
No retyping Names, colours, icons, and useful settings follow your preparation.	Source preserved Import keeps the source file intact. Writes use the output you choose.	Right-sized The table follows the imported project and projection respects target capacity.

StageDesk transfers channel data and essential settings. It does not replace complete artistic mix preparation or validation in the target's official editor.

Working data

- Channel labels, colours, and icons when the format exposes them.
- DCA assignments, high-pass filter, mute, and fader level when the target accepts them.
- Per-channel inclusion or exclusion, with optional per-parameter detail.
- Scene, snapshot, cue, or Current state according to the system's terminology.



One project, several tools

StageDesk manages two complete projects: a standalone StageDesk .smtshow project and a Local StageFlow .stageflow project. Both can be created, opened, and saved directly in StageDesk; StageFlow remains optional.

StageFlow Patch + stage plan	<-->	.stageflow project One Local StageFlow project Common UUIDs and patch Separate app domains
StageDesk Console preparation	<-->	
Dante Config Editor Dante network	<-->	
StageMark Placement + projection	<-->	
StageMon Two live monitors	<-->	
AutoCAD Technical plan	<-->	

- New/Open a StageDesk project uses a fully standalone .smtshow file.
- New/Open a local StageFlow project uses a .stageflow folder; Save updates the common patch and the smt/smt.json domain.
- Existing .smt files remain importable.
- The portable StageFlow V3 workbook imports and exports both ways with stable UUIDs, common values, overrides, and suppressions.
- Each application preserves every other domain byte for byte and shares the patch UUIDs.
- The status dot and text clearly distinguish Standalone, Local StageFlow project, StageFlow LIVE session available or synchronized, connection lost, and conflict.
- A StageFlow LIVE session is joined explicitly after LAN discovery, project and host-computer selection, and entry of a six-digit code that is never stored.
- A joined StageFlow LIVE session immediately merges every valid external patch into the table without recalling the snapshot. The following preference applies only to a Local StageFlow project.
- Label-alert reception is enabled by default. A persistent banner shows the previous and current values until local acknowledgement; disabling reception acknowledges only this computer's backlog.
- Without a valid StageFlow LIVE session, StageDesk remains fully manual; Reload applies a Local StageFlow project change only on request when its following is disabled.
- Opening a project never starts a console, network, or DAW connection; stored paths must be explicitly selected again.

StageFlow is free and optional. StageDesk detects an existing LIVE session but never creates it and never sends hardware commands.



2. Prepare a reliable transfer

Two minutes of preparation prevent ambiguity at export time.

Prepare	Decision	Example
Source	System, model, displayed mode, then the offered file or state.	DM7 - .dm7f project - Scene 1.00
Data	Channels to include and parameters to transfer.	Labels, colours, DCA, HPF
Target	Exact model and target capacity.	Yamaha CL5 - CL5 profile
Mode	One of the modes actually displayed for the profile.	Existing project with automatic backup
Destination	Project and target state offered by the connector.	CL5_Project - Balance scene

Always keep the source project. If you explicitly overwrite an existing file, StageDesk first creates a non-timestamped backup in the same folder, prefixed Bckp_, then Bckp2_ if needed.

File names

- Use a short, descriptive name without characters forbidden by the target.
- StageDesk sanitizes the final name and applies the native extension, for example .tar.gz for recognised Allen & Heath shows.
- The proposed name follows the interface language: Nouvelle préparation or New preparation.

Before writing a project

- Select the exact model and keep the source project unchanged.
- Export to a copy or confirm replacement only after the Bckp_ backup is created.



3. Retrieve the source

Control	Action
System	Choose an exposed family: Yamaha, Allen & Heath, Avid, Midas, Soundcraft, SSL, software, or table exchange.
Model	Choose the exact model. It defines capacity, label length, and available values.
Mode	Choose the file mode actually presented for the selected source.
Source file	Choose the project to read. StageDesk detects its available scenes or snapshots.
Scene / snapshot	Select the state to retrieve. Imported data appears in the universal table.
Import	Start reading. The source file remains untouched.

Change the source

You can open another console family or software session without restarting StageDesk. The new choice replaces the active source, while the prepared table remains your conversion workspace until the next import.

Always review the import summary: channel count, selected scene, and retrieved data. Table size must follow project content, not a fixed number.

Local source

- Open the project in its manufacturer editor before import when its integrity must be confirmed.
- Give the StageDesk preparation a clear name after the read.
- StageDesk readback preserves the source file and does not replace show archiving.



4. Work in the universal table

The table is the heart of StageDesk. It preserves retrieved data while you change targets and keeps edits fast even in large projects.

Area	Use
Include	The only checkbox visible by default. It decides whether the channel participates in the transfer.
Source scene / snapshot	Recalls the source state for that row.
Original data	Labels, colours, and icons read from the source.
Working data	Values to adapt before export: label, colour, icon, DCA, HPF, mute, and fader.
Details	Displays per-parameter Apply boxes. Fields actually retrieved and transferable are selected; absent or unsupported fields remain unselected.

Select all Includes all visible channels or checks the chosen detail column.	Copy / Paste Exchanges one cell, a range, or rows with a spreadsheet.	Validate Checks values before selecting the target.
---	--	--

Smart fill

- Enter Mic 1 and drag the handle to create Mic 2, Mic 3, and Mic 4.
- For a stereo series, FX1L continues with FX1R, FX2L, FX2R, then FX3L and FX3R.
- The same rule applies to text ending in a number or a number followed by L/R.

Keep Details closed for speed. Open it only when a transfer must exclude one precise parameter without excluding the whole channel.



5. Choose the target

The Send panel uses the same logic for each connector: choose the system, model, then one of the target modes actually exposed for that destination.

Mode	When to use it	Result
New project	The connector exposes this mode.	StageDesk asks for a folder, project name, initial state when offered, and sometimes a validated local native template.
Existing project	The connector can write the target format.	StageDesk opens the project and offers only states it can actually modify.

Create a new project

- Choose New project, then the parent folder.
- Enter the project name. It becomes the file or session-folder name according to the target.
- Enter the initial scene or snapshot name when offered.
- Use only the New Project modes offered by StageDesk for the selected profile.
- Select Export. StageDesk displays the path and summary; Nuendo and Harrison add detailed opening steps.

Write into an existing project

- Choose the target project: its scenes and snapshots are listed separately from the source states.
- Select an existing target or create a new one only when the connector exposes that action.
- If the same output path is selected, confirm overwrite; the automatic backup is created before writing.



6. Scenes, snapshots, and cues

Console states are not a Yamaha-only concept. StageDesk displays each state only on the side where its read or write operation is proven.

Term	Typical families	What StageDesk does
Scene	Yamaha, SQ, Qu, GLD, Soundcraft Vi, HD96, and X32/M32	Lists scenes and exposes a target only when writing is bounded by the native format.
Snapshot	dLive, Avantis, WING, DiGiCo SD/Quantum, and Harrison/Ardour sessions	Avantis and dLive write Current or snapshots and can create a snapshot or New Project for the proposed variants.
Cue	SSL Live	Displays a cue only when the connector can read or write it; VENUE S6L remains limited to Current.
Current	Current state in a file	Reads or writes the active state only when the local format and connector expose it.

Source and target are independent choices. StageDesk presents the scenes, snapshots, cues, and transfer modes that match the selected profile.

CL / QL example

Choose a recognised .CLF scene or create a project from one of the five CL1, CL3, CL5, QL1, or QL5 profiles. StageDesk adapts the data to the model and recalculates the output file's MEMAPI checksum.

Allen & Heath example

A Bridge-3/4/5 Avantis, Avantis dPack, Avantis Solo, or Avantis Solo dPack show can feed the table. StageDesk writes Current or a snapshot and creates a new snapshot or show from the matching standard/dPack template. For dLive, the table can feed Current, an existing snapshot, or a named new snapshot; the common 128-input engine serves the proposed variants.



7. Adapt data to the target

Consoles do not share the same palettes, label lengths, or icon families. StageDesk turns these differences into explicit decisions instead of blocking the workflow.

Situation	StageDesk proposal	Your choice
Unknown colour	Closest allowed colour or a neutral value.	Accept, choose another colour, or skip that parameter.
Missing icon	Equivalent icon or Blank.	Choose the clearest equivalent on the console.
Label too long	Compatible truncation with preview.	Edit the name or accept the proposal.
Too many channels	Projection limited to model capacity.	Exclude, reorder, or choose a larger model.
Parameter not exposed	The value remains in the StageDesk project but is not written to this target.	Continue transferring compatible data.

Remember a substitution

- Select Remember to apply the same replacement the next time it occurs.
- The rule is linked to the target type and affected parameter.
- Open Tools > Saved substitutions to edit or delete a rule.

The purpose of adaptation is a usable export. Review the final summary: adapted values, excluded channels, and transferred parameters.



8. Backups and non-destructive writing

StageDesk separates the source, working table, and target. This makes it possible to repeat a conversion without changing the original preparation.

Action	Protection
Import	Read-only access to the source project.
Create project	Writes a new file or folder with the chosen name.
Existing project	Warning, confirmation, same-folder Bckp_ backup (then Bckp2_) without a timestamp, then replacement of the selected project.
Cancel	The StageDesk table remains available until a new preparation is created.

After export

- Record the full path displayed by StageDesk.
- Open the generated file in the console or software's official editor.
- Open or recall the result when applicable, then check several representative channels.
- On physical hardware, compare before any rehearsal or transmission.

An automatic backup protects the previous file; it does not replace your production archive. Keep a separate copy of the validated show.



9. Project profiles available in StageDesk - 1/2

Always choose the exact model in StageDesk: capacity and constraints are applied during projection.

Manufacturer	Available families and models
Allen & Heath	Avantis, dPack, Solo, and Solo dPack: import, Current/snapshot write, snapshot creation, and standard/dPack New Project. dLive C1500/CTi1500/C2500/C3500/S3000/S5000/S7000 and DM0/32/48/64, CDM32/48/64 MixRacks: import, snapshots, and New Project. GLD-80/112; SQ-5/6/7/Rack. Qu-16/24/32/Pac/SB: import, label writing, and scene creation.
Avid VENUE S6L	Six E6L/E6LX 112/128/144/176/192/256 engine profiles for Current MicLine label import and copy/new-project transfer in .dsh files. All six capacities were loaded natively in VENUE Offline 8.2.
Behringer	WING, WING Compact, and WING Rack; X32, X32 Compact, X32 Producer, X32 Rack, and X32 Core.
DiGiCo	V2242 range: SD5/5CS/8/9/10/11/12 and Quantum 1/2/3/5/7/8. Current/snapshot import, backed-up snapshot writing, and New Project from the exact seed; 32 to 108 inputs by model.
Midas	M32, M32 LIVE, M32R, M32R LIVE, and M32C; Heritage-D HD96-16, HD96-24, and HD96-AIR for native-show scene import/write in a copy plus manufacturer Excel import/export.

For families with several engines, surfaces, or capacities, the selected profile limits projected channels and written values.



10. Project profiles available in StageDesk - 2/2

Manufacturer	Available families and models
Soundcraft	Vi1000, Vi200, Vi2000, Vi3000, Vi400, Vi5000, Vi600, and Vi7000.
SSL on Windows	Native Live shows through SOLSA 6.x: L100/Plus, L200/Plus, L300, L350/Plus/Plus E, L450, L500/Plus, L550/Plus, and L650. System T: T25, T80, TE1, and TE2 at 48/96 kHz; VTE1 and VTE2 at 48 kHz.
Yamaha CL / QL	CL1, CL3, CL5, QL1, and QL5: local .CLF project import, creation, and transfer.
Yamaha DM	DM3, DM3 Standard, DM7, and DM7 Compact: native project import, transfer, and creation.
Yamaha RIVAGE PM	PM7/CSD-R7; PM3/CS-R3 and PM5/CS-R5 with DSP-R10, DSP-RX, or DSP-RX-EX; PM10/CS-R10 and PM10/CS-R10-S with the same three engines: local project import, creation, and transfer.
Yamaha TF	TF1, TF3, TF5, and TF-RACK: native project/scene import, transfer, and creation.

Available target modes

- Choose only one of the modes actually displayed for the selected profile.
- New project: choose the folder, name, initial state when offered, and a local native template when StageDesk asks for one.
- Existing project: choose the file and an offered state; create a new state only when that action is displayed.

The displayed choices follow the selected profile: StageDesk automatically applies its capacity, extension, and opening workflow.



11. Software and exchange formats

Target	Exchange mode	Open the result
Ableton Live 12	Update an existing Live Set with backup, or create a two-track audio-only New Project from the bundled template.	The two-track set was opened, closed, and reopened in Live 12.4, with both labels read back.
Dante Config Editor (DCE)	Native DCE XML: machine-specific Rx import; creation from the bank or replacement/addition of a machine in a target project. Rx labels are updated while Tx remains identical.	Creation and replacement were read back in Dante Config Editor. If Dante Config Editor is not installed, StageDesk offers its official download.
Excel / CSV	Portable table for checking, editing, or archiving.	Open in Excel or a compatible spreadsheet.
Harrison LiveTrax 3	New session or existing-session update with backup, compatible labels, colours, and settings.	Open the session from the LiveTrax start screen.
Harrison Mixbus 10	New session or existing Ardour/Mixbus project.	Open the .ardour session file.
MAGIX Sequoia Pro 17	VIP project prepared from the StageDesk table.	Open the .VIP file in Sequoia.
REAPER	.rpp project with tracks, names, colours, and compatible metadata.	File > Open project.
Steinberg Nuendo 14	DAWproject exchange sized to the source.	File > Import > DAWproject. Do not use Open Project.

After every export, StageDesk displays the output path and a result summary. Nuendo and Harrison additionally display detailed import or opening steps.



12. Conversion recipes

Need	Recommended workflow
DM7 to dLive	Import the .dm7f and source scene > review labels and colours > choose dLive > choose New Project or Existing Project > select or create the target snapshot > adapt colours > export the .tar.gz. In Existing Project mode, StageDesk backs up and replaces the selected show.
Avantis to LiveTrax	Import the .tar.gz show and scene > exclude unused channels > choose LiveTrax 3 > New project > enter parent folder and session name > export and open the session.
Table to CL5	Import the table > choose Yamaha CL/QL and CL5 > New project > export the .CLF > open it in CL Editor.
Console to Nuendo	Import the scene > select channels > choose Nuendo 14 > export DAWproject > in Nuendo, use File > Import > DAWproject.
Console to DCE	Import the console project > choose DCE > create an XML from the bank or open an existing XML > choose or add the machine > export channels to its Rx side; existing Tx channels are preserved.
One table to several targets	Import once > save a standalone StageDesk .smtshow or a Local StageFlow .stageflow project > export to the first target > change only the Send panel > adapt > export again.

The universal table remains the reference between exports. Save the .stageflow project before a batch of deliverables so the exact work can be resumed.



13. Work faster every day

Selection
Select all, Clear all, and channel ranges speed up projection.

Spreadsheet
Copy and paste cells or blocks from Excel, with validation before export.

Series
Automatic numbering and L/R pairs such as FX1L, FX1R, FX2L, FX2R.

Command	Use
File > New StageDesk project	Create a standalone preparation to save as .smtshow.
File > Open a StageDesk project	Resume a standalone .smtshow file directly.
File > New local StageFlow project	Create a Local StageFlow .stageflow folder without requiring StageFlow.
File > Open a StageFlow project	Resume a .stageflow folder with its shared patch and StageDesk context.
File > Import a legacy project	Import a historical .smt file.
File > Save	Keep edits in the format of the currently open project.
Edit > Undo / Redo	Reverse a table entry or operation.
View > Theme	Choose light or dark mode. The setting is remembered.
View > Language	Switch between French and English. Labels and proposed names follow the language.
Details	Show or hide every per-parameter Apply checkbox.

Run several exports

After an export, change the system, model, or target mode without importing the source again. To start over, use File > New to reset all three steps cleanly.



14. Delivery checklist

Check	Question
Source	Were the correct file and scene or snapshot imported?
Channels	Does the row count match the project, and are unwanted channels excluded?
Data	Are labels, colours, icons, and essential settings coherent?
Target	Are the exact model and its capacity selected?
Destination	Are the correct project and destination scene or snapshot selected?
Adaptations	Are proposed substitutions clear and appropriate?
File	Are path, name, and extension correct?
Readback	Was the result opened in the official editor and compared on representative channels?

Never load an unchecked file directly on a console used in production. Validate the offline copy first, and keep a route back to the previous show.

File check

- Open the output in the official editor before transferring it to a production console.
- Check representative channels and the target state before a complete review.
- Keep the StageDesk output and Bckp_ backup with the production folder.



15. Updates, help, and licensing

StageDesk can check the latest published version without changing your open project.

Action	Procedure
Manual check	Open Help > Check for updates.
Startup check	StageDesk checks the published version quietly. A notification appears only when a newer package is available.
Download	Confirm the Windows x64 package download. A macOS release will follow after validation.
Integrity	The downloaded package is compared with its official SHA-256 checksum before it is presented.
Installation	StageDesk opens the verified package location. Save and close projects, then replace the version when ready.

Official links

Resource	Link
Download StageDesk	https://github.com/Mamat79/StageDesk/releases/latest
Project page	https://github.com/Mamat79/StageDesk
Download StageFlow - free	https://github.com/Mamat79/StageFlow/releases/latest
Download Dante Config Editor (DCE)	https://github.com/Mamat79/Dante-Config-Editor/releases/latest
Download StageMark	https://github.com/Mamat79/StageMark/releases/latest
Download StageMon	https://github.com/Mamat79/StageMon/releases/latest
StageDesk permanent license - EUR 29 including tax	https://smt-license.mamat79-dce.workers.dev/buy

After 30 reminder-free days, StageDesk remains fully usable. The reminder waits 10 seconds before continuing. A license allows 3 installations by default, shows the counter and can deactivate this computer. After initial activation, validation works offline.

Download StageDesk only from the official page. The built-in SHA-256 check confirms that the received package matches the publication.



16. Fast reference

The complete workflow fits into nine decisions.

#	Decision
1	Choose the source system and model.
2	Choose a displayed source mode, then the offered file or state.
3	Import and check the channel count.
4	Edit labels and essential settings; exclude unused channels.
5	Choose the target system and model.
6	Choose one of the modes actually displayed for the profile.
7	Name the project or target state when StageDesk asks for it.
8	Validate substitutions and export.
9	Open, review, archive, and only then use the result.

Retrieve
The right source and state.

Convert
A clear, fast, reusable table.

Transfer
A compatible, reviewed target.

StageDesk
Transfer labels and essential settings. Keep control of the project.
SiLeMI/O by Mamat - ----[]--