Kestrel K-300 - Quick start

Acme Devices, Novi Sad

1. Rinse the water tank, fill it up to MAX and seat it firmly (E1 if not seated).
2. Fill the bean hopper with whole beans. Never use ground or flavoured coffee.
3. Switch on at the back, then press the standby button on the front.
4. Choose the language and the water hardness from the test strip.
5. The machine heats up and rinses the outlet. Water in the drip tray is normal.

Water tank: 1.8 L. Bean hopper: 250 g. Grounds container: 12 portions.

Kestrel K-300 - Drinks and care

Drinks: Espresso, Lungo, Americano, Cappuccino, Latte macchiato, Hot water.
Strength 1 to 5 beans. Grind dial 1 (fine) to 7 (coarse), only while grinding.
Milk: connect the milk tube, put the other end in the carafe, choose the drink.
Rinse the milk system when the display asks.

Every day: empty the drip tray and the grounds container (E4).
Every week: rinse the brew unit under lukewarm water (E5 if not locked).
Every 3 months or at E3: descale with DS-100 (Menu > Care > Descale).

Warranty: 2 years from the date of purchase.
Help: chat in the Acme shop or support@example.com