Motor control – closed loop controller

{Learn, Create, Innovate};








Introduction

This challenge is intended for the student to review the concepts introduced in this course.

The activity consists in controlling the speed of a DC Motor.

- The motor speed, must be controlled using an external computer, a microcontroller, and a motor driver.
 - See following slide for requirements.







- The "/Controller" node must run on the MCU.
- It should receive a signal in the [-1,1] interval. Such signal is the duty cycle.
 - The setpoint should be written in a /setpoint topic.
 - The sign represents the direction of the motor, i.e., (+) CCW rotation, and (-) CW rotation of the motor.
 - The controller can be "P", "PI" or "PID" controller (other controllers can be accepted upon agreement with the professor.).
 - The duty cycle percentage (%) range $[0,100]\% \rightarrow [0,1]$.
- The node should publish:
 - The estimated in the range $[-\omega_{max}, \omega_{max}]$ in $\left[\frac{rad}{s}\right]$ /angular_speed.
 - The sign (+.-) represents the direction of rotation obtained from the dual encoder channel
 - The ω is the angular speed, obtained by the pulses.





- The /Setpoint node runs in a computer generates an input signal in the form of a
 - Constant, sine, square or sawtooth waves.
 - NOTE: Beware of abrupt changes in the current. It might hurt your H-Bridge
- The control node, must use a parameter file, for all the required signal generation variables.
- The sampling time and rate must be defined by the student.
- It is encouraged to use original and disrupting solutions in Python and MATLAB.
- You must be able to plot the reference and actual signal in rqt_plot.





Closed loop motor control




- Develop a closed loop motor speed control.
- Modify the previous minichallenges to implement this challenge.
- You will need a motor with an encoder, and a power supply or battery pack.
- Determine an appropriate sampling time depending on your encoder.
 - Encoders can be read by certain communication protocols or by GPIO interruptions.
- Use different timers to publish and to sample data.






Structure

- To perform this task, at least two nodes must be developed: /Setpoint, and /Controller.
- The /Setpoint nodes must run in the external computing unit, whilst the / Controller node must run in the microcontroller.










- *R* resistor
- *L* inductance
- ω angular velocity
- *J* moment of inertia
- $\int_{\omega(t)}^{J} \omega(t)$ β friction coefficient
 - k_m torque/power ratio
 - *e* coil voltage





$$e = k_m \omega$$

$$v = L\frac{di}{dt} + Ri + e$$

$$v = L\frac{di}{dt} + Ri + k_m \omega$$


$$\tau = k_m i$$

$$\tau = J\frac{d\omega}{dt} + \beta\omega$$

$$k_m i = J \frac{d\omega}{dt} + \beta \omega$$

MCR





$$v = L\frac{di}{dt} + Ri + k_m \omega$$

 \mathcal{L}


$$v = Lsi + Ri + k_m \omega$$

$$k_m i = J \frac{d\omega}{dt} + \beta \omega$$

 \mathcal{L}

$$k_m i = Js\omega + \beta\omega$$






$$v = Lsi + Ri + k_m \omega$$

$$v = i(Ls + R) + k_m \omega$$

$$i = \frac{\omega}{k_m} (Js + \beta)$$

$$v = \frac{\omega}{k_m} (Js + \beta)(Ls + R) + k_m \omega$$






$$v = \frac{\omega}{k_m} (Js + \beta)(Ls + R) + k_m \omega$$

$$v = \frac{\omega}{k_m} ((Js + \beta)(Ls + R) + k_m^2)$$

$$\frac{v}{\omega} = \frac{(Js + \beta)(Ls + R) + k_m^2}{k_m}$$






$$\frac{\omega}{v} = \frac{k_m}{(Js + \beta)(Ls + R) + k_m^2}$$

$$\frac{\omega}{v} = \frac{k_m}{JLs^2 + s(\beta L + JR) + RB + k_m^2}$$

$$\frac{\omega}{v} = \frac{k_m}{JL} \frac{1}{s^2 + \left(\frac{\beta}{J} + \frac{R}{L}\right)s + \frac{RB + k_m^2}{JL}}$$





$$\frac{\omega}{v} = \frac{k_m}{JL} \frac{1}{s^2 + \left(\frac{\beta}{J} + \frac{R}{L}\right)s + \frac{RB + k_m^2}{JL}}$$


$$\frac{R}{L} \gg \frac{\beta}{J}$$

$$RB \ll k_m^2$$





$$\frac{\omega}{v} = \frac{k_m}{JL} \frac{1}{s^2 + \frac{R}{L}s + \frac{k_m^2}{JL}}$$







- Configuring & Handling ESP32 GPIO Interrupts In Arduino IDE (lastminuteengineers.com)
- Double check to perform operations with the same units.
- Check your data types
- Validate that there is no overflow in your PWM registry.
- Error

$$\varepsilon_n = v_{ref} - v_{medido}$$


PID Controller

$$G_n = K_p \varepsilon_n + \frac{K_D}{T_S} (\varepsilon_n - \varepsilon_{n-1}) + K_I T_S (\varepsilon_n + \varepsilon_{n-1})$$





ESP32 Wroom DevKit Full Pinout






Micro-ROS Activity



- Connect a H-bridge (L298) and a DC motor to the previous activity. The behavior of the motor should mimic the LED.
- Check the proper connections of the H-Bridge and the motor
- OUT1: DC motor A + terminal
- OUT2: DC motor A terminal
- OUT3: DC motor B + terminal
- OUT4: DC motor B termina
- IN1: Input 1 for Motor A
- IN2: Input 2 for Motor A
- IN3: Input 1 for Motor B
- IN4: Input 2 for Motor B
- EN1: Enable pin for Motor A (PWM)
- EN2: Enable pin for Motor B (PWM)





Micro-ROS Activity - Extra



Input port


1 2	1、RPWM	Forward level or PWM signal input, active high
	2、LPWM	Inversion level or PWM signal input, active high
000	3、R_EN	:Forward drive enable input , high enable , low close
00	4, L_EN	Reverse drive enable input , high enable , low close
00	5、R_IS	Forward drive -side current alarm output
00	6, LIS	: Reverse drive -side current alarm output
00	7. VCC	: +5 V power input, connected to the microcontroller 5V power supply
7 8	8、GND	: Signal common ground terminal

Usage one:

VCC pick MCU 5V power supply, GND connected microcontroller GND R_EN and L_EN shorted and connected to 5V level, the drive to work. L_PWM, input PWM signal or high motor forward R_PWM, input PWM signal or high motor reversal

Usage two:

VCC pick MCU 5V power supply , GND connected microcontroller GND R_EN and L_EN short circuit and PWM signal input connected to high-speed L_PWM, pin input 5V level motor is transferred R_PWM, pin input 5V level motor reversal





Motor with encoder



PINOUT GM 25-370 Encoder 12 V DC 140RPM





Thank you

{Learn, Create, Innovate};



T&C

Terms and conditions

{Learn, Create, Innovate};





Terms and conditions



- THE PIECES, IMAGES, VIDEOS, DOCUMENTATION, ETC. SHOWN HERE ARE FOR INFORMATIVE PURPOSES ONLY. THE DESIGN IS PROPRIETARY

 AND CONFIDENTIAL TO MANCHESTER ROBOTICS LTD. (MCR2). THE INFORMATION, CODE, SIMULATORS, DRAWINGS, VIDEOS PRESENTATIONS

 ETC. CONTAINED IN THIS PRESENTATION IS THE SOLE PROPERTY OF MANCHESTER ROBOTICS LTD. ANY REPRODUCTION, RESELL,

 REDISTRIBUTION OR USAGE IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF MANCHESTER ROBOTICS LTD. IS STRICTLY

 PROHIBITED.
- THIS PRESENTATION MAY CONTAIN LINKS TO OTHER WEBSITES OR CONTENT BELONGING TO OR ORIGINATING FROM THIRD PARTIES OR
 LINKS TO WEBSITES AND FEATURES IN BANNERS OR OTHER ADVERTISING. SUCH EXTERNAL LINKS ARE NOT INVESTIGATED, MONITORED, OR
 CHECKED FOR ACCURACY, ADEQUACY, VALIDITY, RELIABILITY, AVAILABILITY OR COMPLETENESS BY US.
- WE DO NOT WARRANT, ENDORSE, GUARANTEE, OR ASSUME RESPONSIBILITY FOR THE ACCURACY OR RELIABILITY OF ANY INFORMATION

 OFFERED BY THIRD-PARTY WEBSITES LINKED THROUGH THE SITE OR ANY WEBSITE OR FEATURE LINKED IN ANY BANNER OR OTHER

 ADVERTISING.