

User Manual for

WisTrio LoRa Tracker

96Boards IoT Standardization RAK5205

Version V1.6 | January 2019



www.RAKwireless.com

Visit our website for more document.



Table of Contents

1 Overview	
1.1 Introduction	
1.2 Package Contents	5
2 WisTrio LoRa Tracker RAK5205	
2.1 Overview	
2.2 Functional Diagram	
2.3 Interfaces	
2.4 Operating Frequencies	
2.5 Board Pin Out	
2.5.1 P1	
2.5.2 P2	8
2.5.3 J11	
2.5.4 J12	
2.5.5 J22	
2.5.6 J25	
2.6 Micro-B USB Interface	
2.7 LEDs	
2.8 RESET Push Button	11
2.9 Working Mode	
2.10 Power Requirements	
2.11 Environmental Requirements	13
2.12 Mechanical Dimensions	13
3 LoRa Antenna	14
3.1 Overview	14
3.2 LoRa Antenna Dimension	14
3.3 LoRa Antenna Parameter	14
4 GPS Antenna	15
4.1 Overview	
4.2 GPS Antenna Dimensions	15
4.3 GPS Environmental Requirements	
4.4 GPS Antenna Parameter	16
5 Schematics	17
6 Usage and Examples	21
6.1 Source Code	
6.2 Required Software	
6.2.1 USB Driver	
6.2.2 Keil_MDK	21
6.2.3 Flash Loader	21
6.2.4 Tool Chain	21



6.3 Importing Source Code	22
6.4 Uploading Firmware	
6.4.1 Install the "CP210x_windows_Drivers" driver	
6.4.2 Install the Flash Loader Demonstrator	
6.4.3 Connect the BOOT jumper	26
6.4.4 Upgrade the firmware	
7 Contact Information	30
8 Revision History	30
9 Document Summary	31
List of Tables	
Table 1 Operating Frequencies	8
Table 2 Pin Descriptions	
Table 3 Micro-B USB Pin Descriptions	
Table 4 Power consumption	12
Table 5 Electrical Characteristics	
Table 6 LoRa Antenna Parameter	15
Table 7 GPS Environmental Requirements	16
Table 8 GPS Antenna Parameter	16
Table 9 Amplifier Specifications	16
Table 10 Environmental Test Performance	17
List of Images	
Image 1 Package Contents	
Image 2 RAK5205 Board Interface	
Image 3 RAK5205 Board Dimension	
Image 4 Functional Diagram	
Image 5 Powered by Micro USB	
Image 6 Charging with 5V Solar	
Image 7 Mechanical Dimensions	
Image 8 RP-SMA Male connector of LoRa Antenna	
Image 9 iPEX connector of LoRa Antenna	
Image 10 LoRa Antenna Dimension	
Image 11 SMA Female connector of GPS Antenna	
Image 12 iPEX connector of GPS Antenna	
Image 13 GPS Antenna Dimensions	
Image 14 Connect the boot jumper	26



List of Screenshots

Screenshot 1 Download Source code from Github	22
Screenshot 2 Open Project in Keil_MDK	
Screenshot 3 Project Directory	
Screenshot 4 HF Build Project	
Screenshot 5 Build Status	
Screenshot 6 Bin Directory	
Screenshot 11 Download to Device	28
Screenshot 12 Downloading progress	



Overview

1.1 Introduction

The RAK5205 LoRa tracker board is built on SX1276 LoRaWAN modem with low power microcontroller STM32L1, integrated the GPS module. It is a feature-packed sensor board that provides various interfaces for featured applications development.

This is the best sensor board available in the market, ideal as a quick prototyping tool for Internet-of-Things and LoRaWAN Network integration. It is perfect for IoT applications such as asset tracking, smart vehicle management and location-based services. Most importantly, application development environments such as the CooCox IDE and Kiel are all supported, users can quickly develop own applications.

The main features are listed below:

- Compatible with 96Boards IoT Edition Specification.
- With SX1276 LoRa long range and Ublox Max 7Q GPS modems which allow to enable the GPS low power mode.
- Integrated the ultra-low power microcontroller ARM Cortex-M3 STM32L1.
- Built-in environmental sensor BME680 (gas, pressure, humidity, temperature) and
 3-axis MEMS sensor LIS3DH (accelerometer).
- SMA/iPEX antenna optional for LoRa and GPS.
- Supports latest LoRaWAN 1.0.2 protocol, activation by OTAA/ABP.
- Supports programmable bit rate up to 300kbps.
- Supports rechargeable battery through micro USB or 5V solar charging ports.
- Supports sleep mode, the power consumption down to 14.5µA.
- Supports global license-free ISM band (EU433, CN470, EU868, US915, AS923, AU915, KR920, IN865 and AS920).
- Supports I2C, GPIOs, UART and ADC interfaces.

1.2 Package Contents



RAK5205 board



LoRa Modem Antenna (1x)



GPS Antenna (1x)



Micro USB cable



WisTrio LoRa Tracker RAK5205

2.1 Overview

The picture below shows the top view and external interfaces of the RAK5205 LoRa tracker board.




Image 2 | RAK5205 Board Interface

The dimension and underside of the board is shown below. Sensor ICs are also labeled for your reference.






Image 3 | RAK5205 Board Dimension

2.2 Functional Diagram

The block diagram below shows internal architecture and external interfaces:




Image 4 | Functional Diagram

2.3 Interfaces

It is built around RAK811 module and compatible with 96Boards. It provides the following interfaces, headers, jumpers, button and connectors:

- Micro USB
- 30-pin 96Boards Headers (UART, RESET, GPIOS, I2C, ADC)
- 2-pin USB Boot jumper
- 3-pin UART RX jumper
- 2-pin Battery female interface
- 2-pin Solar Panel female interface
- LEDs
- Reset Button

It has two Antenna connectors:

- RP-SMA Male connector of LoRa Antenna(optional iPEX connector)
- SMA Female connector of GPS Antenna(optional iPEX connector)



2.4 Operating Frequencies

The board supports all LoRaWAN frequency channels as below. Which is easy to configure while building the firmware from the source code.

LF firmware support regions:EU433,CN470. HF firmware support other regions.

Region	Frequency (MHz)
Europe	EU433, EU868
China	CN470
North America	US915
Asia	AS920, AS923
Australia	AU915
Korea	KR920
Indian	IN865

Table 1 | Operating Frequencies

2.5 **Board Pin Out**

Here are the six connectors for RAK5205 tracker board: P1, P2, J11, J12, J22 and J25.

2.5.1 **P1**

(Pin1 connected to VBATT, Pin2 connected to GND) Li-ion battery connector.

2.5.2 **P2**

(Pin1 connected to VBUS, Pin2 connected to GND) Solar cell interface.

2.5.3 **J11**

Pin1 is connected to VBUS. Pin2 is connected to VBIN. Without a battery connection, the J11 needs to be short-circuited with a jumper. Instead, the J11 needs to be kept open. In other words, J11 short connection solar panels directly supply power to trackerboard, J11 no connection solar panels charge batteries.



2.5.4 **J12**

Pin1 is connected to BOOT0. Pin2 is connected to VDD. Enter flash mode through jumper short circuit and open into normal mode.

2.5.5 **J22**

30pins, follow the 96Board's pin definition.

Pin	Pin Name	Description
1-2	NC	NC
3	UART1_TX	UART1_TX
4	NC	NC
5	UART1_RX1	UART1_RX1 (need to connect RX pin and RX1 pin of J25 via jumper if user wants to use this UART interface).
6-8	NC	NC
9-10	GND	GND
11	VCC _{IN}	5V _{OUT}
12	VCC_3V3	3V3 OUT
13	PA8	GPIO Pin
14	PB3	GPIO Pin
15	NC	NC
16	PB5	GPIO Pin
17	SWD_TMS	GPIO Pin / R21, R22 pull-up 10K resistor
18	SWD_CLK	can be used as JTAG interface
19	LED1_PA12	GPIO Pin
20	LED2_PB4	GPIO Pin
21	NC	NC
22	SCL	I2C
23	NC	NC
24	SDA	I2C
25	NC	NC
26	PB12	ADC Interface
27-28	NC	NC
29	RST	Reset Pin
30	NC	NC

Table 2 | Pin Descriptions

10



2.5.6 **J25**

(RX1, RX, RXCP) J22 and USB UART share. If you use the UART of J22, you need to connect Rx and RX1 pins. If you use USB UART, you need to connect Rx and RXCP pins.



2.6 Micro-B USB Interface

A Standard Micro-B USB compliant with USB 2.0 standard specification is used to provide an interface to connect to a PC for control of the board and firmware upgrade. The Micro-B USB pin definition is shown below:

Pin	Description
1	USB_VBUS (+5V)
2	USB_DM
3	USB_DP
4	NC
5	GND



Table 3 | Micro-B USB Pin Descriptions

27 LEDs

Three LEDs are used to indicate operating status, here are their functions:

Green LED: STATUS – Defined by user.

Blue LED: STATUS – Defined by user.

Red LED: Charging Status – indicates the Li-ion Battery is charging.

28 RESET Push Button

Reset Push Button is used to reset the RAK811 module. To reset the module push the Reset Button for 1 second.

2.9 Working Mode

The board supports to enable the GPS low power mode, it has a 3-axis MEMS Sensor LIS3DH, which can detect the user's motion status, when the device is stationary, it will enter the low power sleep mode, reducing the overall power consumption and increase battery life. The power consumption as shown in the following table.

Mode	Power consumption
Sleep mode	14.5µA (Min)
Normal mode	174mA (Max) @ 20dBm and GPS enable



Table 4 | Power consumption

2.10 Power Requirements

The RAK5205 LoRa tracker board has an operating voltage of 3.7V. It can be powered by micro USB with 5V Max.



Image 5 | Powered by Micro USB

The board can also be powered by a 3.7V Li-lon battery. You can connect a 5V solar panel charger to recharge the Li-lon battery.




Image 6 | Charging with 5V Solar



2.11 Environmental Requirements

The table below lists the operation and storage temperature requirements:

Parameter	Min.	Typical	Max.
Operation Temp. Range	-35 °C	+25 °C	+60 °C
Extended Temp. Range	-40 °C		+80 °C
Storage Temp. Range	-40 °C		+80 °C

Table 5 | Electrical Characteristics

2.12 Mechanical Dimensions

Here is the detailed dimension of RAK5205 LoRa tracker:




Image 7 | Mechanical Dimensions



LoRa Antenna

3.1 Overview

The LoRa antenna and interfaces are shown below.




Image 8 | RP-SMA Male connector of LoRa Antenna

Here is the iPEX LoRa Antenna interface:



Image 9 | iPEX connector of LoRa Antenna

3.2 LoRa Antenna Dimension

The antenna's mechanical dimension is shown below:



Image 10 | LoRa Antenna Dimension

3.3 LoRa Antenna Parameter

Items	Specifications
VSWR (Voltage Standard Wave Radio)	1:1.5
Gain	2.0dbm
Working Temperature & Humidity	T:-35 °C ~ +80 °C, H: 0% ~ 95%
Storage Temperature & Humidity	T:-40 °C ~ +85 °C, H: 0% ~ 95%



Table 6 | LoRa Antenna Parameter

4 GPS Antenna

4.1 Overview

The GPS antenna and interfaces for RAK5205 tracker board is shown below.




Image 11 | SMA Female connector of GPS Antenna

Here is the iPEX GPS Antenna interface:



Image 12 | iPEX connector of GPS Antenna

4.2 **GPS Antenna Dimensions**




Image 13 | GPS Antenna Dimensions

4.3 GPS Environmental Requirements

The antenna environmental requirements are listed in the table below:

Conditions	Temperature	Humidity
Working	-35 °C ~ +80 °C	0% ~ 95%
Storage	-40 °C ~ +85 °C	0% ~ 95%



Table 7 | GPS Environmental Requirements

4.4 GPS Antenna Parameter

Antenna specifications are listed in the table below:

Item	Specifications	PET
Range of Receiving Frequency	1575.42±1.1	±2.5
Center Frequency (MHz) w/ 30mm2 GND plane	1575.42	±3.0
Bandwidth (MHz) (Return Loss ≤ -10dB)	≥10	±0.5
VSWR (in Center Frequency)	≤2.0	±0.5
Gain (Zenith) (dBi Typ) w/ 70mm2 GND Plane	4.5	±0.5
Axial Ratio (dB) w/ 70mm2 GND Plane	3.0	±0.2
Polarization	Righ-Handed Circular	-
Impedance (Ω)	50	-
Frequency Temparature Coefficient (ppm/°C)	0±10	-

Table 8 | GPS Antenna Parameter

Amplifier Specifications are listed in the table below:

Item	Specifications
Frequency Range	1575.42 MHz
Gain	27 dB
VSWR	≤ 2.0 V
Noise Coefficient	≤ 2.0 dBm
DC Voltage	3 ~ 5 V
DC Current	5 ± 2 mA

Table 9 | Amplifier Specifications

Environmental test performance specifications are listed below:

Item	Normal Temp.	High Temp. ¹	Low Temp. ²
Amplifier Gain	27dB ± 2.0	27dB ± 2.0	27dB ± 2.0
VSWR	≤ 2.0	≤ 2.0	≤ 2.0
Noise Coefficient	≤ 2.0	≤ 2.0	≤ 2.0


High temperature test: soap in temperature (85° C) and humidity (95%) chamber for 24-hour and return normal temperature (at least for 1-hour) without visual shape change.
 Low temperature test: soap in temperature (-40° C) chamber for 24-hour and return to normal temperature (at least for 1-hour) without visual shape change.





Table 10 | Environmental Test Performance

5 Schematics

The Component schematics diagram of the RAK5205 are shown below:





































Usage and Examples

We are going to use CooCox IDE to view and build the firmware. Download the source code from the provided GIT repository. All the necessary software should be installed earlier.

6.1 Source Code

All application source codes are available on GIT repository.

If you want to develop your own applications, you can either download the source zip from the GIT repository or you can clone it. The source code link is:

https://github.com/RAKWireless/RAK5205-WisTrio-LoRa

Note: The preloaded firmware in the board is not open at present.

6.2 Required Software

To start with developing the application over the RAK5205 LoRa tracker board you may need to download the following software. All the software provided below are based on Windows operating system.

6.2.1 USB Driver

WisTrio-LoRa-RAK5205/Tools/CP210x Windows Drivers.zip

6.2.2 Keil_MDK

WisTrio-LoRa-RAK5205/Tools/Keil v5.exe

6.2.3 Flash Loader

WisTrio-LoRa-RAK5205/Tools/Flash Loader Demonstrator.zip

6.2.4 Tool Chain

WisTrio-LoRa-RAK5205/Tools/gcc-arm-none-eabi-5_4-2016q3-20160926-win32.exe



6.3 Importing Source Code

Download it from the GIT URL indicated in Source Code Section of this manual.



Screenshot 1 | Download Source code from Github


Extract the downloaded ZIP file and Open the RAK811.uvprojx file in the directory as following with Keil MDK.



Screenshot 2 | Open Project in Keil_MDK




After opening the project, you will see the following project structure in Keil_MDK:



Screenshot 3 | Project Directory




Config the current project with the target frequency band of HF(high frequency) for example:Simply choose RAK5205_HF as the following red box(It had defined LORA_HF_BOARD macro,default region is EU868).



Screenshot 4 | HF Build Project


Build or Rebuild the current project and the following window will appear together with the build status.




Screenshot 5 | Build Status



To find the build executable file, click the project folder as shown below. Follow the path to the bin directory where you can find the executable files.



Notice:If you want to generate the target frequency band of LF(low frequency) board firmware, you should simply choose RAK5205_LF as the following red box(It had configured with LF, the remaining steps are the same as above, default region is CN470).



Screenshot 7 | LF Build Project



6.4 Uploading Firmware

6.4.1 Install the "CP210x windows Drivers" driver

Connect the board to the computer via a Micro USB cable and you'll find the COM port for RAK5205 LoRa tracker in the device manager.

6.4.2 Install the Flash Loader Demonstrator

It is recommended to use Flash Loader Demonstrator to upgrade the RAK5205 LoRa tracker board to the latest version.

6.4.3 Connect the BOOT jumper


The bootpin of the board needs to be raised to 3.3V when upgrading, so you need to connect the BOOT0 and VDD pin of J12 by using a jumper. Also, make sure that the RX pin of J25 is connected to the RXCP pin.



Image 14 | Connect the boot jumper

6.4.4 Upgrade the firmware

Select the COM Port for the board, the Baud Rate is "115200", as shown in the following figure.



Screenshot 8 | Install Flash Loader Demonstrator

Reconnect the RAK5205 or press the reset button if prompted.



Screenshot 9 | Reconnect then click Next



Select "STM32L1_Cat2-128K" then click "Next".




Screenshot 10 | Select device

Select "Download to device" then navigate to location of bin file. Click "Next" when finished. This will start the download process:



Screenshot 11 | Download to Device





Screenshot 12 | Downloading progress

After finishing the download, close the Demonstrator program, disconnect the RAK5205 and remove the jumper of J12.



7 Contact Information

Shenzhen Business

- ken.yu@rakwireless.com
- Room 506, Bldg. 3, Minqi Technology Park, No.65 Taoyuan Road, Xili Block, Nanshan District, Shenzhen

Shenzhen Technical

- steven.tang@rakwireless.com
- 0755-86108311
- Room 506, Bldg. 3, Minqi Technology Park, No.65 Taoyuan Road, Xili Block, Nanshan District, Shenzhen

Revision History

Revision	Description	Date
1.0	Initial version	2018-09-10
1.1	Improved Layout and content	2018-11-06
1.2	Modify the picture and the context	2018-11-10
1.3	Add the iPEX Antenna interface picture	2018-11-14
1.4	Modify the picture for updated GPS module	2018-12-20
1.5	J11 explanation and Hardware annotation	2019-01-14
1.6	Modify IDE to Keil_MDK	2019-01-31

Table 11 | Revision History



Document Summary

Document Name: WisTrio LoRa Tracker RAK5205 User Manual

Product Name: RAK5205

Release Date: January 2019

Revision Number: V1.6

Prepared by	Checked by:	Approved by:
Hairui & Penn	Nicholas	Leopold



About RAKwireless:

RAKwireless is the pioneer in providing innovative and diverse cellular and LoRa connectivity solutions for IoT edge devices. It's easy and modular design can be used in different IoT applications and accelerate time-to-market turnover. For more information, please visit RAKwireless website at www.rakwireless.com.

Copyright © 2018 Shenzhen RAKwireless Technology Co., Ltd. (Update: June-2018)