

You can switch different printing modes by LCD screen, When printing in duplicate mode or symmetric mode, you may need to adjust the bed slightly by below 4 nuts, cause auto bed leveling is not workable any more in duplicate or symmetric mode. meanwhile, please ensure X axis aluminum extrusion be parallel to print bed.



Choose "IDEX Mode" -> "Duplication", printer will auto home as below, then choose a file from SD card for printing. We have configuration profiles for different printing modes, please kindly check the Instruction for how to load profile in folder "Configuration Profiles".



the same way to Symmetric printing.

Note: If you have adjusted the bed manually when duplicate or symmetric printing, please execute Unified Bed Leveling (UBL) again before using other printing modes.