# User Guide



# SIC4340 Tools APP User Guide

Rev 1.0 (July 2020)

This document describes how to use SIC4340 Tools Android and IOS application with SIC4340 Dev Kit board.

# **Revision History**

Revision	Date	Software Version	Description
1.0	July 2020	1.0.0	1 <sup>st</sup> Release

The information herein is for product information purposes. While the contents in this publication have been carefully checked; no responsibility, however, is assumed for inaccuracies. Silicon Craft Technology PLC. reserves the right to make changes to the products contained in this publication to improve design, performance, or reliability.

### **Contents**

SIC4340 Tools APP User Guide	
Revision History	
Contents	3
List of Figures	4
1. Introduction	5
2. Instruments	5
3. Installation	6
3.1 Installation on Android	
4. Application Demonstration	8
4.1 Setting	9
5. Legal Information	13
5.1 Disclaimer	13

# **List of Figures**

Figure 1: Detail of SIC4340 Dev kit board	5
Figure 2: SIC4340 Tools APP on Google Play Store	6
Figure 3: SIC4340 Tools APP on IOS App Store	
Figure 4: Setting in SIC4340 Tools	
Figure 5: Bias current setting	9
Figure 6: Start NFC Session	9
Figure 7: Please tap a tag status	10
Figure 8: Success Status	10
Figure 9: Error status	11
Figure 10: Result page	12

### 1. Introduction

SIC4340 is NFC tag type 2 with built-in ADC for physical sensor measurement for 3-channels selectable. These built-in ADC can drive the current from 1µA to 504µA and measure the electrical value (e.g. voltage, resistance, and capacitance). The measured value is provided with 10-bit resolution. SIC4340 Tools application is developed to help the user learn how to use SIC4340 features with many sensors such as light sensor, gas sensor or temperature sensor. In this app, the user can set the bias current for each channel and measure the result from SIC4340 IC. The voltage and resistance result will be displayed on the app after measurement.

Silicon Craft Technology PLC. (SIC) creates this document to describe how to install and use SIC4340 Tools application on both Android and IOS platform.

### 2. Instruments

To use this application, there are some instruments required as below.

- 1. NFC Mobile which can be a. or b.
  - a. Android mobile with Android operation version 4.1 (Jelly Bean) or above.
  - b. iPhone with IOS13 or above.
- 2. SIC4340 Dev Kit board as Figure 1




Figure 1: Detail of SIC4340 Dev kit board

### 3. Installation

There are SIC4340 Tools application available on both Android and IOS Platform.

#### 3.1 Installation on Android

For SIC4340 Tools application on Android. It can be downloaded and installed from Google Store link: <a href="https://play.google.com/store/apps/details?id=com.sic.sic4340rmeas">https://play.google.com/store/apps/details?id=com.sic.sic4340rmeas</a> or search for 'SIC4340 Tools' in Google Play Store.




Figure 2: SIC4340 Tools APP on Google Play Store

#### 3.2 Installation on IOS

For SIC4340 Tools application on IOS, It can be downloaded and installed from App Store link: <a href="https://apps.apple.com/us/app/sic4340-tools/id1518973827">https://apps.apple.com/us/app/sic4340-tools/id1518973827</a> or search for 'SIC4340 Tools' in IOS App Store.




Figure 3: SIC4340 Tools APP on IOS App Store

## 4. Application Demonstration

This part demonstrates how to use SIC4340 Dev Kit with SIC4340 Tools application. The content in this part includes setting, NFC communication and result display.

#### 4.1 Setting

In the setting page of SIC4340 Tools, user can enable or disable each pin and set the bias current separately for each pin as shown in Figure 4.




Figure 4: Setting in SIC4340 Tools

The bias current can be set from slider bar or click the value on the top of slider bar to directly type the value as shown in Figure 5.




Figure 5: Bias current setting

#### 4.2 NFC Communication

After finished the setting, push 'PROCESS' button to start the NFC session as shown in Figure 6.




Figure 6: Start NFC Session

After the NFC session has started, the NFC dialog will show the status as in Figure 7 (a) for Android and Figure 7 (b) for iPhone.




Figure 7: Please tap a tag status

After the status has shown as in Figure 7, user have to tap and hold the mobile on the antenna of SIC4340 Dev Kit board until the status changed to success as in Figure 8 (a) for Android and Figure 8 (b) for iPhone




Figure 8: Success Status

If something went wrong before finished an NFC communication, the error status will be shown as in Figure 9 (a) for Android and Figure 9 (b) for iPhone. If this error status has shown, user can tap mobile on the board again.




Figure 9: Error status

### 4.3 Result Display

After finished an NFC communication and status shown 'Success' as Figure 8, the page in application will be automatically change to result page.

In the Result page bias current, voltage and resistance for each enabled pin will be displayed. The bottom bar contains 2 buttons, one for go back to setting page and one for measuring again with the same setting as shown in Figure 10




Figure 10: Result page

### 5. Legal Information

#### 5.1 Disclaimer

- The information described herein is subject to change without notice.
- Although the IC contains a static electricity protection circuit, static electricity or voltage that exceeds the limit of the protection circuit should not be applied.
- SIC assumes no responsibility for how this IC is used in products created using this IC or for the specifications of that product, nor does SIC. Assume any responsibility for any infringement of patents or copyrights by-products that include this IC either in Thailand or in other countries.
- SIC is not responsible for any problems caused by circuits or diagrams described herein whose related industrial properties, patents, or other rights belong to third parties. The application circuit examples explain typical applications of the products and do not guarantee the success of any specific mass-production design.
- The use of the information described herein for other purposes and/or reproduction or copying without the express permission of SIC is strictly prohibited.
- The products described herein cannot be used as part of any device or equipment affecting the human body, such as exercise equipment, medical equipment, security systems, gas equipment, or any apparatus installed in airplanes and other vehicles, without prior written permission of SIC.
- Although SIC exerts the greatest possible effort to ensure high quality and reliability, the failure or malfunction of semiconductor products may occur. The user of these products should, therefore, give thorough consideration to safety design, including redundancy, fire-prevention measures, and malfunction prevention, to prevent any accidents, fires, or community damage that may ensue.