

Note: ATC will issue the Flight Level clearance in meters. Pilots shall use the China FLAS Diagram to determine the corresponding flight level in feet. The aircraft shall be flown using the flight level in FEET. Pilots should be aware that due to the rounding differences, the metric readout of the onboard avionics will not necessarily correspond to the cleared Flight Level in meters however the difference will never be

ISOGONIC INFORMATION 2010
LAMBERT CONFORMAL CONIC PROJECTION Standard Parallels 24° and 40°