
8

EUM 530, EUM 531





| EUM 530 | | |
|----------|----------------------------|--------------------------------|
| | | Description |
| Line | Item No. | Description |
| 1 | 663 548 200 | Cowling-orange |
| 5 | 661 300 049 | Bearing Shell |
| 6 | 661 300 820 661 300 844 | Tension Spring Link Bar |
| 8 | 661 300 101 | Bearing Plate |
| 9 | 663 510 468 | Screw |
| 10 | 663 546 128 | Axle Front |
| 11 | 661 300 831 | Spacer Sleeve |
| 12 | 661 300 028 | Wheel Front |
| 13 | 663 701 083 | Washer |
| 14 | 663 546 137 | Wheel Cover |
| 15 | 663 701 124 661 300 821 | Space Nut Cover Plate |
| 16 | 663 525 779 | Screw |
| 18 | 663 700 390 | Woodruff Key |
| 19 | 663 512 463 | Blade Hub |
| 20 | 663 548 144 | Spacer Washer |
| 21 | 663 531 487 | Blade |
| 22 | 663 316 913 | Washer |
| 23 | 663 700 202 | Washer |
| 24 | 663 700 139 | Washer |
| 25 | 663 329 907 | Screw |
| 39 | 663 529 550 | Screw |
| 44 | 663 527 695 663 548 256 | Gear Box Return Spring |
| 46 | 663 548 170 | V Belt |
| 50 | 663 531 821 | Cable |
| 52 | 663 531 850 | Engine Brake Cable |
| 55 | 661 300 029 | Wheel |
| 56 | 663 524 725 | Grass Deflector |
| 57 | 661 301 721 | Spring left |
| 58 | 661 301 720 | Spring right |
| 59 | 661 300 853 | Bearing Shell |
| 60 | 663 700 489 663 526 745 | Retainer Ring Pinion comp left |
| 62 | 661 300 005 | Pinion Pinion |
| 63 | 663 348 875 | Slide Sleeve |
| 64 | 663 526 746 | Pinion comp right |
| 65 | 661 300 011 | Thrust Washer |
| 66 | 663 510 923 | Ball Bearing |
| 67 | 663 546 130 | Axle Rear |
| 70 | 663 700 122 | Self Lock Nut |
| 71 | 661 300 095 | Return Spring |
| 72 | 661 300 048 661 300 848 | Lever Spacer Sleeve |
| 73 74 | 663 703 565 | Spacer Sieeve Screw |
| 75 | 663 543 554 | Screw |
| 76 | 661 300 623 | Axle Clamp |
| 77 | 663 548 202 | Chute/Axle Tunnel |
| 85 | 663 548 257 | Drive Clutch Bowden Cable |
| 86 | 663 512 721 | Pivot Unit right |
| 87 | 663 512 722 | Pivot Unit left |
| 88 | 663 512 576 | Break Release Bracket Left |
| 89 91 | 663 512 723 663 543 556 | Plate Screw |
| 91 | 663 548 210 | Clutch Release |
| 93 | 663 548 208 | Break Release |
| 96 | 663 703 697 | Scrwe |
| 97 | 663 703 005 | Washer |
| 98 | 663 500 073 | Secure Nut |
| 99 | 663 375 953 | Screw |
| 100 | 663 702 849 | Self Lock Nut |
| 101 | 663 703 703 | Screw |
| 102 | 663 531 818 | Handle |

| EUM 530 | | | |
|---------|-------------|----------------------|--|
| Line | Item No. | Description | |
| 103 | 661 300 806 | Adjusting Lock | |
| 104 | 663 544 675 | Wing Nut | |
| 105 | 661 300 904 | Compression Spring | |
| 106 | 661 300 805 | Holder | |
| 108 | 661 300 838 | Transfer Rod | |
| 109 | 661 300 020 | Hight Adjust Release | |
| 110 | 661 300 019 | Hand Grip | |
| 111 | 661 300 017 | Aperture Blind | |
| 113 | 663 703 704 | Screw | |
| 115 | 661 013 101 | Grass Collecting Bag | |
| 116 | 661 301 092 | Frame | |
| 117 | 663 701 322 | Screw | |
| 129 | 663 548 229 | Bearing Bush | |
| 131 | 663 702 387 | Washer | |
| 132 | 663 700 303 | Screw | |
| 133 | 663 525 433 | Plate | |
| 137 | 663 548 217 | Starter Rope | |
| 138 | 663 373 264 | Screw | |
| 139 | 663 505 322 | Cable Retainer | |
| 140 | 663 531 819 | Gear Change Lever | |
| 143 | 663 300 161 | Disk | |
| 144 | 663 700 656 | Washer | |