

SHEET 02

Wall Assembly on the Ground

Every joint is easier at knee height than over your head.

PREP

Pre-lube every connector thread with zinc anti-seize. Playa dust seizes set screws permanently and you will never get the structure apart on Friday.

PROCEDURE

- 1 Lay out the run**
For each wall, lay out its verticals, its top rails, and the correct connector for every node: blue 3-way inline or corner, green 4-way where an interior wall tees in, purple 5-way where four walls cross, gray 2-way only at a true dead end.
- 2 Orient every connector before tightening**
Sight through the connection so the open ports point exactly where the next pipe will run. A rotated connector cannot be corrected once the wall is standing.
- 3 Seat and tighten**
Push each pipe fully home into the fitting, then tighten the set screw snug plus a firm quarter turn. Do not strip it.
- 4 Flange every vertical**
Fit a base flange to the bottom of every vertical pole while the wall is still flat.
- 5 Build long walls first**
Assemble the two 50 ft walls (6 verticals + 5 top rails each), then the two 30 ft end walls (4 verticals + 3 rails each).

Count your connectors against the plan before you raise anything. A missing 4-way found at height costs the crew an hour.