Item	Qty	Reference(s)	Value	Datasheet Hersteller Nr.	Mouser Nr.
	1	1 AE1	Antenna_Shield	https://www.mouser.ch/ CONUFL001-SMD-T	712-CONUFL001-SMD-T
	2	18 C1, C2, C3, C4, C5, C6, C10, C11, C20, C21, C23, C24, C25, C26, C27, C28, C29, C30	100n	https://www.mouser.ch/ CL10B104KB8NNWC	187-CL10B104KB8NNWC
	3	2 C7, C9	1u	https://www.mouser.ch/ CL10A105KA8NFNC	187-CL10A105KA8NFNC
	4	4 C8, C18, C19, C22	10u	https://www.mouser.ch/ CL10A106MA8NRNC	187-CL10A106MA8NRNC
	5	4 C12, C13, C16, C17	22u	https://www.mouser.ch/ CL21A226MAYNNNE	187-CL21A226MAYNNNE
	6	2 C14, C15	47u	https://www.mouser.ch/ EEE-FT1V470AR	667-EEE-FT1V470AR
	7	1 D1	LED_R	150060RS75000	710-150060RS75000
	8	1 D2	LED_G	150060VS75000	710-150060VS75000
	9	4 D3, D4, D6, D7	SD0603	https://www.mouser.ch/SD0603S040S0R2	581-SD0603S040S0R2
	11	8 F1, F2, F3, F4, F5, F6, F7, F8	30mA	https://www.mouser.ch/0ZCM0003FF2G	530-0ZCM0003FF2G
	13	1 J1	USB_B_Micro	https://www.mouser.ch/ 614105150721	710-614105150721
	20	1 L1	3.3u	https://www.mouser.ch/IMC0805ER3R3J01	70-IMC0805ER3R3J01
	21	1 L2	10uH	https://www.mouser.ch/LQM18DH100M70L	81-LQM18DH100M70L
	22	1 Q1	SI7309D	https://www.mouser.ch/SI7309DN-T1-E3	781-SI7309DN-T1-E3
	23	8 Q2, Q3, Q6, Q7, Q10, Q11, Q14, Q15	~	https://assets.nexperia.c/BC846A,235	771-BC846A235
	24	8 Q4, Q5, Q8, Q9, Q12, Q13, Q16, Q17	~	https://www.diodes.com DMC2700UDM-7	621-DMC2700UDM-7
	25	1 R1 R2, R20, R22, R28, R30, R32, R33, R34, R35, R36, R37, R38, R39, R40, R42, R44, R46, R52, R53, R54, R56, R58, R59, R60, R61, R62, R63, R68, R69, R70, R71, R72, R73, R74, R75, R80, R81, R82,	100k	https://www.mouser.ch/ CRCW0603100KFKEAC	71-CRCW0603100KFKEAC
	26	43 R83, R84, R85, R86, R87	10k	https://www.mouser.ch/RT0603FRE0710KL	603-RT0603FRE0710KL
	27	3 R3, R9, R10	15k	https://www.mouser.ch/ERJ-3EKF1502V	667-ERJ-3EKF1502V
	28	2 R4, R5	240	https://www.mouser.ch/RC0603FR-13240RL	603-RC0603FR-13240RL
	29	9 R6, R29, R31, R41, R43, R45, R47, R55, R57	1.5k	https://www.mouser.ch/RT0603FRE101K5L	603-RT0603FRE101K5L
	30	2 R7, R8	68	https://www.mouser.ch/ CRCW060368R0FKEA	603-RC0603JR-0768RL
	31	1 R11	2	https://www.mouser.ch/ CR0603-J/-2R0ELF	652-CR0603-J/-2R0ELF
	32	2 R12, R13	1M	https://www.mouser.ch/ ERJ-3GEYJ105V	667-ERJ-3GEYJ105V
	33	2 R14, R18	10k 0.1%	https://www.mouser.ch/ APC0603B10K0N	284-APC0603B10K0N
	34	6 R15, R16, R17, R19, R21, R23	4.7k	https://www.mouser.ch/RT0603FRE074K7	603-RT0603FRE074K7L
	35	16 R24, R25, R26, R27, R48, R49, R50, R51, R64, R65, R66, R67, R76, R77, R78, R79	1k	https://www.mouser.ch/RT0603FRE071KL	603-RT0603FRE071KL
	37	1 U1	STM32L433RCTxP	https://www.mouser.ch/STM32L433RCT6P	511-STM32L433RCT6P
	38	1 U2	USBLC6-2SC6	http://www2.st.com/rescUSBLC6-2SC6	511-USBLC6-2SC6
	39	1 U3	RFM95W-868S2	https://www.mouser.ch/ RFM95W-868S2	223-RFM95W-868S2
	40	1 U4	AP63203WU	https://www.mouser.ch/ AP63203WU-7	621-AP63203WU-7
	41	2 U5, U6	OPA990	https://www.ti.com/lit/d OPA990IDBVR	595-OPA990IDBVR