

How to use TV PLUS MEDIA CENTER

Some of the Basics to get you Started

TV PLUS MEDIA CENTER IS NOT AFFILIATED WITH THE MANUFACTURER OF ANY DEVICE. For instructions on how to use your device we suggest your refer to the device manufacturers instructions, however all Android based media streaming systems behave similarly to a Smart Phone or Tablet. Navigate the icons, click OK to Enter or Activate a feature then use the Return Key/Back to Cancel or Back Out to the previous screen. These are the basic steps! Arrows, OK & Back or Return.

The Android Operating System and all Applications and/or Software including TV PLUS MEDIA CENTER on your device operate on the "BREAD CRUMB" System. Every Screen you Enter or Activate by clicking OK, you must Back Out of using the Back or Return Key. If you click OK 5 screens deep, you will come Back/Return out the same 5 screens! Please be aware that some Android softwares and or features will require the MOUSE pointer Function to access certain on screen features or options. Be sure to Activate the mouse feature to access them THEN Deactivate the mouse pointer from your screen anytime that it is not required to go back to Regular Navigation

For most people who have just purchased GET-WICKED and TV PLUS MEDIA CENTER for the first time you will want to jump right in to and navigate to click on the TVPMC icon found either in your Favourites or Apps section.

TVPMC has an array of Media Streaming Possibilities. Add-Ons found within TV PLUS MEDIA CENTER stream your personal media as well as will provide different kinds of media options. Addons are categorized as for streaming Video, Music and Picture types of media files. In essence all Add-Ons function the very same way and as follows: Pick an Add-On, Click OK on the selected Add-On, Within the Add-On choose & Click OK on a Category (if required), Next choose a Media File or Title & Click OK, Wait for a list of providers or hosts to be presented if required...

When the list returns (as required) select a provider or host for your File or Title, Wait for a response from the Host or Provider. There is no exact science, if the stream fails, try the next host or Provider. (if you get repeated errors on different files & host or providers choices, **RED FLAG!** there is an issue with your Internet! Constant buffering on different Titles & hosts/providers, again, Check Your Internet!

99% OF CUSTOMER ISSUES ARE DUE TO WEAK WI-FI OR BAD INTERNET, PLEASE CONTACT YOUR INTERNET PROVIDER DIRECTLY, WE DO NOT PROVIDE SUPPORT FOR ANY INTERNET

While Playing a Stream, click OK, a menu will pop up allowing you to Pause & Stop and control the stream. TIP: Always stop the stream when you are done or before navigating to a new choice (it just makes things a lot faster & prevents possible freezing of your system)

When done using TV PLUS MEDIA CENTER, always navigate to the far right on the TVPMC Main Menu Bar and use the **Quit Function** when done. Always "**QUIT**" TVPMC before shutting down or putting your system to sleep. Please remember to reboot/restart your system regularly to refresh the Android Operating System. If your system is misbehaving a rebooting/restarting is the trick!

Give yourself some time, this is a new and exciting technology... Within a week & some trial & error, you'll quickly become TVPMC Rock Star!