

What do I do Next? How to use TV PLUS Media Center? Some of the Basics to get you Started

On the ULTRA-BOXX Home Screen, your device is a "WICKED" Smart TV and behaves just like a Smart Phone or Tablet. Navigate the icons, click OK to Enter or Activate a feature then use the Return Key/Back to Cancel or Back Out to the previous screen.

The Android Operating System and all Applications and/or Software including TV PLUS Media Center on your device operate on the "BREAD CRUMB" System. Every Screen you Enter or Activate by clicking OK, you must Back Out of using the Return Key. If you go 5 screens deep, you will come back out 5 screens! Please be aware that some Android features will require the MOUSE Function.

For most people who have just purchased TV PLUS for the first time you will want to Jump Right In to the Good Stuff & navigate to click on TV PLUS. This is where you will find an array of Media Streaming Possibilities and the heart of a highly Customized & Polished version of XBMC/KODI

Add-Ons found within TV PLUS software stream your personal media as well as will provide different kinds of media choices, ranging from Kids to Adult and everything in between. In Essence all Add-Ons function the very same way and as follows:

Pick an Add-On, Click OK on the selected Add-On, Within the Add-On choose & Click OK on a Category (if required), Next choose a Media File or Title & Click OK, Wait for a list to be prepared...

When the list returns and If required select a host or server for your File or Title, Wait for a response from the Host or Server. There is no exact science, if the stream fails, try the next host or server. (if you get repeated errors on different files & host/sever choices, RED FLAG! there is an issue with your Internet! Constant buffering on different Titles & hosts/servers, again, Check Your Internet!

While Playing a Stream, click OK, a menu will pop up allowing you to Pause & Stop and control the stream. TIP: Always stop the stream when you are done or before navigating to a new choice (it just makes things a lot faster & prevents possible freezing of your system)

When done using TV PLUS Media Center, always navigate to the far right on the TV PLUS Main Menu Bar and use the **Quit Function** before going back to the X ACT TV Home Page. **IMPORTANT:** Always "**QUIT**" TV PLUS before shutting down or putting your system to sleep. Please remember to reboot your system regularly to refresh the Android Operating System. If your system is misbehaving a reboot is the trick!

Give yourself some time, this is a new and exciting technology...
Within a week & some trial & error, you'll quickly become TV PLUS Media Rock Star!

For The ADULT Section password enter the number 277 (remember the word ASS)

TVPLUSMEDIA.COM