

MINIMUM CREW

Minimum Flight Crew PILOT AND
COPILOT

MANEUVERING FLIGHT LOAD FACTORS

These corresponding accelerations limit the bank angle during turns and limit the pull-up maneuvers.

LOAD FACTOR LIMIT	FLAPS UP	FLAPS DOWN (9°, 18°, 22° and 45°)
Positive	2.50 g	2.00 g
Negative	-1.00 g	0 g

RUNWAY

Runway Slope -2% TO +2%
Runway Surface Type PAVED

FUEL

AIRPLANE MODEL	STD/ER/ EP/MP	LR
Maximum usable quantity per tank	679.8 US Gal (4600 lb)	844.9 US Gal (5717 lb)
Unusable quantity per tank	7.1 US Gal (48 lb)	5.8 US Gal (39 lb)

Maximum permitted imbalance between tanks 800 lb

- NOTE:** - When the EICAS fuel quantity is zero in level flight, any fuel remaining in the tanks can not be used safely in flight.
- Unusable fuel increases to 266 lb (STD, ER, EP and MP models) or 365 lb (LR model) in each tank if any of the associated electric fuel pumps is inoperative.
 - The values above have been determined for an adopted fuel density of 6.767 lb/US Gal.
 - When performing pressure refueling, the usable fuel quantity in each tank may be reduced by 7.9 US Gal (STD, ER, EP and MP models) or 13.2 US Gal (LR model) maximum.

ANAC APPROVED
REVISION 66