	1 2	3	4	5	6	7	8
A	TOUCH KEY KEY EXIT/22D TO VS R19 PO PROX/22B 1k PO PO R19 R19 PO R19 R1	\$ ∧ \$ ∧ \$ 14	U\$16	REY_4_MENU/2.28 PROX2.28 1k	U\$18 TOUT CX VSS VDDHI POUT VREG IQS227	<u> </u>	ODE MENU. U\$17
C	REY 2 UP/23A) PROX/22B) 1k	100p 1u		REY 3 DOWN/2 20 PROX/2 2B 1k GND	VSS VDDHI POUT VREG IQS227		U\$20
D							D
E	1 2	3	4	5	INT	ERFACE 18	E-1002_5_A 3.11.2019 10:45 neet: 3/4