




## COMPONENTS LOCATED ON ENGINE

### LEGEND:


|      |                                     |
|------|-------------------------------------|
| AS_  | - AUXILIARY SHUTDOWN SWITCH         |
| BA   | - BRUSH ASSEMBLY                    |
| BATT | - BATTERY                           |
| BCH  | - BATTERY CHARGER                   |
| CB1  | - CIRCUIT BREAKER, MAIN OUTPUT      |
| CB2  | - CIRCUIT BREAKER, DPE (AUTO RESET) |
| CSS  | - CONDITIONED STATOR SIGNALS        |
| FS   | - FUEL SOLENOID                     |
| GND  | - GROUND                            |
| HOT  | - HIGH OIL TEMP SWITCH              |
| IM_  | - IGNITION MODULE                   |
| J_   | - MAIN CONTROLLER CONNECTIONS       |
| LED  | - LED BOARD                         |
| LOP  | - LOW OIL PRESSURE SWITCH           |
| MAG  | - MAGNETO                           |
| NEU  | - NEUTRAL                           |
| R    | - RESISTOR                          |
| SC   | - STARTER CONTACTOR                 |
| SCR  | - STARTER CONTROL RELAY             |
| SM   | - STARTER MOTOR                     |
| SP_  | - SPARK PLUG                        |
| STR  | - STATOR                            |
| TB_  | - TERMINAL BLOCK                    |
| WM   | - WIRELESS MODULE                   |




NOTE: ALL WIRES 18 AWG 300V UL LISTED UNLESS SHOWN OTHERWISE.

AWG SIZE


## COMPONENTS LOCATED IN CONTROL PANEL












## COMPONENTS LOCATED IN CONTROL PANEL



PAGE 3 OF 6







## LEGEND:

|     |   |                                   |
|-----|---|-----------------------------------|
| AS_ | - | AUXILIARY SHUTDOWN SWITCH         |
| BA  | - | BRUSH ASSEMBLY                    |
| CB1 | - | CIRCUIT BREAKER, MAIN OUTPUT      |
| CB2 | - | CIRCUIT BREAKER, DPE (AUTO RESET) |
| FS  | - | FUEL SOLENOID                     |
| HOT | - | HIGH OIL TEMP SWITCH              |
| IM_ | - | IGNITION MODULE                   |
| J_  | - | MAIN CONTROLLER CONNECTIONS       |
| LED | - | LED BOARD                         |
| LOP | - | LOW OIL PRESSURE SWITCH           |
| R   | - | RESISTOR                          |
| SC  | - | STARTER CONTACTOR                 |
| SCR | - | STARTER CONTROL RELAY             |
| SM  | - | STARTER MOTOR                     |
| SP_ | - | SPARK PLUG                        |
| TR  | - | TRANSFORMER                       |
| WM  | - | WIRELESS MODULE                   |