




AS	-	AUXILIARY SHUTDOWN SWITCH
BA	-	BRUSH ASSEMBLY
BATT	-	BATTERY
BCH	-	BATTERY CHARGER
CB	-	CIRCUIT BREAKER, MAIN OUTPUT
CT_	-	CURRENT TRANSFORMER
FS	-	FUEL SOLENOID
GND	-	GROUND
HOT	-	HIGH OIL TEMP SWITCH
IM_	-	IGNITION MODULE
J_	-	MAIN CONTROLLER CONNECTIONS
LED	-	LED BOARD
LOP	-	LOW OIL PRESSURE SWITCH
MAG	-	MAGNETO
NEU	-	NEUTRAL
R	-	RESISTOR
SC	-	STARTER CONTACTOR
SCR	-	STARTER CONTROL RELAY
SM	-	STARTER MOTOR
SP_	-	SPARK PLUG
STR	-	STATOR
TB_	-	TERMINAL BLOCK
WM	-	WIRELESS MODULE




DRAWING #: 10000018465

COMPONENTS LOCATED IN CONTROL PANEL



COMPONENTS LOCATED IN CONTROL PANEL



PAGE 3 OF 6

WIRING - DIAGRAM

AC HSB EVO2 60HZ 530


DRAWING #: 10000018465


REVISION: B







DATE: 03/20/24

PAGE 3 OF 6

COMPONENTS LOCATED IN CUSTOMER CONNECTION AREA







LEGEND:

AS	—	AUXILIARY SHUTDOWN SWITCH
BA	—	BRUSH ASSEMBLY
CB	—	CIRCUIT BREAKER, MAIN OUTPUT
CT	—	CURRENT TRANSFORMER
FS	—	FUEL SOLENOID
HOT	—	HIGH OIL TEMP SWITCH
IM	—	IGNITION MODULE
J	—	MAIN CONTROLLER CONNECTIONS
LED	—	LED BOARD
LOP	—	LOW OIL PRESSURE SWITCH
R	—	RESISTOR
SC	—	STARTER CONTACTOR
SCR	—	STARTER CONTROL RELAY
SM	—	STARTER MOTOR
SP	—	SPARK PLUG
WM	—	WIRELESS MODULE

