

## Installation Instructions

**NOTE:** Read the entire instruction manual before starting the installation.

|                                                                     |    |
|---------------------------------------------------------------------|----|
| 1. Safety Considerations .....                                      | 1  |
| 2. Relearn Process for ecobee Thermostats.....                      | 3  |
| 2.1. ecobee3 lite/Smart Thermostat LITE .....                       | 3  |
| 2.2. ecobee Premium .....                                           | 22 |
| 3. Relearn Process for Carrier, Bryant, Ion Smart Thermostats ..... | 40 |
| 3.1. Smart Thermostat .....                                         | 40 |
| 3.2. Smart Thermostat Advanced.....                                 | 43 |

### 1. Safety Considerations

Read and follow manufacturer instructions carefully. Follow all local electrical codes during installation. All wiring must conform to local and national electrical codes. Improper wiring or installation may damage the thermostat and equipment.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the equipment and in the instruction manual, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which will result in severe personal injury or death. WARNING signifies a hazard which could result in personal

injury or death. CAUTION is used to identify unsafe practices which may result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which will result in enhanced installation, reliability, or operation.

This document outlines the instructions required to initiate the relearning process for the thermostat part numbers listed in [Table 1](#) whenever any equipment control board shown in [Table 2](#) is replaced.

These instructions should also be used after firmware updates are made via a USB-based reprogramming interface to hardware which supports IntelliSense™/SmartSense™.

**Table 1 – Thermostats**

| <b>Thermostat P/Ns</b> | <b>Description</b>                                       |
|------------------------|----------------------------------------------------------|
| EB-STATE3LTICR-01      | ecobee for Carrier ecobee3 lite                          |
| EB-STATE3LTICB-01      | ecobee for Carrier ecobee3 lite Builder                  |
| EB-STATE3LTIBR-01      | ecobee for Bryant ecobee3 lite                           |
| EB-STATE3LTIBB-01      | ecobee for Bryant ecobee3 lite Builder                   |
| EB-STATE7ICR-01        | ecobee for Carrier Smart Thermostat Lite                 |
| EB-STATE7IBR-01        | ecobee for Bryant Smart Thermostat Lite                  |
| EB-STATE6ICR-01        | ecobee for Carrier Smart Thermostat Premium              |
| EB-STATE6IBR-01        | ecobee for Bryant Smart Thermostat Premium               |
| TSTATCCIEWF-01         | Carrier Smart Thermostat featuring IntelliSense          |
| TSTATBBIEWF-01         | Bryant Smart Thermostat featuring IntelliSense           |
| TSTATIIIEWF-01         | ION Gray Smart Thermostat featuring SmartSense           |
| TSTATCCIAWF-01         | Carrier Smart Thermostat Advanced featuring IntelliSense |
| TSTATBBIAWF-01         | Bryant Smart Thermostat Advanced featuring IntelliSense  |
| TSTATIIIAWF-01         | ION Blue Smart Thermostat featuring SmartSense           |

**Table 2 – Equipment Boards**

| <b>Board P/N</b> | <b>Description</b>                                                                |
|------------------|-----------------------------------------------------------------------------------|
| HK42FZ114        | Control Board - 1-STG IntelliSense Furnace                                        |
| HK42FZ116        | Control Board - 2-STG IntelliSense Furnace                                        |
| HK38EA060        | Control Board - IntelliSense Fan Coil (R-410A)<br>*** Superseded by HK38EA071 *** |
| HK38EA071        | Control Board - IntelliSense Fan Coil (R-410A, R-454B)                            |
| HK32EA013        | AC HP SCM                                                                         |
| HK42FZ126        | Control Board - 1-STG Mid-tier Furnace                                            |
| HK42FZ127        | Control Board - 2-STG Mid-tier Furnace                                            |
| HK42FZ128        | Control Board - 1-STG Entry-tier Furnace                                          |
| HK42FZ129        | Control Board - 1-STG ULN Furnace                                                 |
| HR46VP007        | 2/3T Control Board (VFD and PCM)                                                  |
| HR46VR006        | 4/5T Control Board (VFD and PCM)                                                  |
| HK38EA076        | Control Board - Mid Tier                                                          |
| HK38EA079        | Control Board - Entry Tier                                                        |

**NOTE:** Please confirm that all the connectors to the control board are fully seated and that all sensors are properly connected.

## **2. Relearn Process for ecobee Thermostats**


To initiate the relearning process, follow the steps below.

**NOTE:** The screens provided are for a 2-stage furnace control board, but the steps apply to all boards listed in [Table 2](#).

### **2.1. ecobee3 lite/Smart Thermostat LITE**

(SKU<sub>s</sub> EB-STATE3LTICR-01, EB-STATE3LTICB-01, EB-STATE3LTIBR-01, EB-STATE3LTIBB-01, EB-STATE7ICR-01, EB-STATE7IBR-01)


1. From the Home screen, press the hamburger menu, to transition to the Main Menu System screen. On the Smart Thermostat Lite models, pressing the hamburger menu button will take you directly to the Main Menu screen where the Settings option can be selected. Proceed to Step 3.



**Fig. 1 – Home Screen**

A230178


2. From the Main Menu System screen, press the settings button which will launch the Main Menu General screen.



**Fig. 2 – Main Menu System Screen**

A230179


3. From the Main Menu General screen, select the Settings option to launch the Settings screen.



**Fig. 3 – Main Menu General Screen**

A230180


4. From the Settings screen, press the Installation Settings option.



**Fig. 4 – Settings Screen**

A230181

5. From this Installation Settings screen, press the Equipment option.



**Fig. 5 – Installation Settings Screen**

A230182




6. From the Equipment screen, press the Reconfigure Equipment option and follow the steps to define the equipment configuration. After completing these steps, return to the Home screen to begin the steps to learn the outdoor unit (if applicable).



**Fig. 6 – Equipment Screen**

A230183


7. To continue the process, from the Home Screen, press the hamburger menu to transition to the Main Menu System screen. On the Smart Thermostat Lite models, pressing the hamburger menu button will take you directly to the Main Menu screen where the Settings option can be selected. Proceed to Step 9.



**Fig. 7 – Home Screen**

A230178


8. From the Main Menu System screen, press the Settings button which will launch the Main Menu General screen.



**Fig. 8 – Main Menu System Screen**

A230179


9. From the Main Menu General screen, select the Settings option to launch the Settings screen.



**Fig. 9 – Main Menu General Screen**

A230180


10. From the Settings screen, press the Installation Settings option.



**Fig. 10 – System Screen**

A230181

11. From the Installation Settings screen, press the Test Equipment option. When the Warning screen is displayed, press OK.



**Fig. 11 – Test Equipment Option Screen**

A230309

## ← Test Equipment

Warning! These tests are designed to be run by a qualified HVAC contractor ONLY. All equipment will be turned off when you press OK. Please note: The compressor protection feature is not available during these tests.


Cancel

OK

**Fig. 12 – Test Equipment Screen**

A230308

12. Based on the type of outdoor equipment installed, select the option that will engage the Y1 signal to turn on the outdoor unit's compressor. Run the test for approximately 10 seconds and then turn Off. Return to the Home screen to confirm the equipment has been releared.




**Fig. 13 – Test Equipment Selector Screen**

A230310 A230312




13. To confirm the relearn process was successful, from the Home screen, press the hamburger menu, to transition to the Main Menu System screen. On the Smart Thermostat Lite models, pressing the hamburger menu button will take you directly to the Main Menu screen where the System option can be selected. Proceed to Step 15.



**Fig. 14 – Home Screen**

A230178


14. From the Main Menu System screen, press the Settings button which will launch the Main Menu General screen.



**Fig. 15 – Main Menu System Screen**

A230179


15. From the Main Menu General screen, select the System option.



**Fig. 16 – Main Menu General Screen**

A230186


16. From the System screen, select the Equipment option.



**Fig. 17 – System Screen**

A230187

17. The learned equipment will be displayed on the screen. Completing these steps will ensure equipment data is reported to the IntelliSense cloud.




**Fig. 18 – Equipment Screen**

A230307

## 2.2. ecobee Premium

(SKUs EB-STATE6ICR-01, EB-STATE6IBR-01)


1. From the home screen, press the hamburger menu, to transition to the Main Menu System screen.



**Fig. 19 – Home Screen**

A230205


2. From the Main Menu System screen, press the Settings button which will launch the Main Menu General screen.



**Fig. 20 – Main Menu System Screen**

A230189

3. From the Main Menu General screen, select the Settings option to launch the Settings screen.




A230190

**Fig. 21 – Main Menu General Screen**




4. From the Settings screen, select the Installation Settings option.



**Fig. 22 – Settings Screen**

A230191


5. From this Installation Settings screen, select the Equipment option.



**Fig. 23 – Installation Settings Screen**

A230192


6. From the Equipment screen, press the Reconfigure Equipment option and follow the steps to define the equipment configuration. After completing these steps, return to the Home screen to begin the steps to learn the outdoor unit (if applicable).



**Fig. 24 – Equipment Screen**

A230193


7. To continue the process, from the Home Screen, press the hamburger menu to transition to the Main Menu System screen.



**Fig. 25 – Home Screen**

A230205


8. From the Main Menu System screen, press the Settings button which will launch the Main Menu General screen.



A230189

**Fig. 26 – Main Menu System Screen**


9. From the Main Menu General screen, select the Settings option to launch the Settings screen.



A230190

**Fig. 27 – Main Menu General Screen**


10. From the Settings screen, press the Installation Settings option.



**Fig. 28 – Settings Screen**

A230191


11. From the Installation Settings screen, press the Test Equipment option. When the Warning screen is displayed, press OK.



**Fig. 29 – Test Equipment Screen**

A230302






A230303

**Fig. 30 – Test Equipment Screen**


12. Based on the type of outdoor equipment installed, select the option that will engage the Y1 signal to turn on the outdoor unit's compressor. Run the test for approximately 10 seconds and then turn Off. Return to the Home screen to confirm the equipment has been released.



A230304 A230313

**Fig. 31 – Test Equipment Selector Screen**


13. To confirm the relearn process was successful, from the Home screen, press the hamburger menu, to transition to the Main Menu System screen.



**Fig. 32 – Home Screen**

A230194


14. From the Main Menu System screen, press the Settings button which will launch the Main Menu General screen.



A230195

**Fig. 33 – Main Menu System Screen**


15. From the Main Menu General screen, select the System option.



A230196

**Fig. 34 – Main Menu General Screen**


16. From the System screen, select the Equipment option.



**Fig. 35 – System Screen**

A230197

17. The learned equipment will be displayed on the screen. Completing these steps will ensure equipment data is reported to the IntelliSense cloud.



**Fig. 36 – Equipment Screen**

A230301

### **3. Relearn Process for Carrier, Bryant, Ion Smart Thermostats**

#### **3.1. Smart Thermostat**

**(SKUs TSTATCCIEWF-01, TSTATBBIEWF-01, TSTATIIIIEWF-01)**

1. Press and Hold the Mode and Fan buttons simultaneously for 10 seconds to access the reset menu.





A260596

**Fig. 37 – Thermostat Rendering**

2. Thermostat will initially display "NR". Use the Up/Down arrows until "Ir" displays.



A260579


**Fig. 38 – Reset Option**

3. Press the Fan button once to initiate relearning the equipment.

## 3.2. Smart Thermostat Advanced

(SKUs TSTATCCIAWF-01, TSTATBBIAWF-01, TSTATIIIAWF-01)


1. From the Main Screen, press the hamburger menu to transition to the Menu screen.



**Fig. 39 – Main Screen**

A260597


2. From the Menu screen, scroll until you reach the System option and select it.



**Fig. 40 – Menu Screen**

A260598

3. From the System screen, scroll until you reach the Reset option and select it.



**Fig. 41 – System Screen**

A260580

4. From the Reset menu, select the IntelliSense Reset option for Carrier or Bryant Thermostats or the SmartSense Reset option for Ion Thermostats.



A260581 A260582

**Fig. 42 – Reset Menu**


5. Press the Reset Now button and allow the device to complete the process.



A260583 A260584 A260585

**Fig. 43 – IntelliSense/SmartSense Reset Process Screens**

6. To confirm the relearn process was successful, press the hamburger menu on the Main screen, to transition to the Menu screen.




**Fig. 44 – Main Screen**

A260586




7. From the Menu screen, scroll until you reach System and select it.



**Fig. 45 – Menu Screen**

A260587


8. From the System screen, scroll until you reach the IntelliSense Equipment or SmartSense Equipment option and select it.



A260588 A260588I

**Fig. 46 – System Screen**

9. Equipment that includes IntelliSense/SmartSense capabilities will display as 'Found'. If those capabilities are not detected, the status will display as 'Not Found'.



**Fig. 47 – IntelliSense/SmartSense Equipment Screen** A260589 A260589I

© 2026 Carrier. All rights reserved.  
A Proud Member of the Carrier Family  
**Catalog No: IM-HK-05**  
Edition Date: 06/26 Replaces: IM-HK-04

**Manufacturer reserves the right to change, at any time, specifications and designs without notice and without obligations.**