#### TCPWM: Counter



## Description:

- This example is used to demonstrate Counter test of PWM
  - 1. If short Capture port and PWM line the interrupt will be occur.
  - 2. Get the Counter value.

## Target Device:

Traveo-II CYT2Bx devices

#### > CPU Board:

CYTVII-B-E-176-CPU BOARD REV.C (REV\_C)

#### TCPWM: Counter



## Dependency:

Please short Port 6.1 and Port 6.3 on Base Board.

Port 6.1 :BB\_LIN3\_TX

Port 6.3: BB\_CAN8\_RXD

## Expectation:

 Short Port6.1 and Port6.3, then Interrupt will be occur. Then get the counter value.

# Trigger MUX: DMA-UART







## Legend:

Red block for power, debug and USB (Mandatory)