IPC: Using Pipe Interface



Description:

- This example demonstrates
 - 1. IPC using pipe interface between the two cores (CM0+ and CM4).
 - 2. Transfer of a word message from IPC Server (CM0+ core) to IPC Client (CM4 core).

Target Device:

Traveo-II CYT2B6x devices

CPU Board:

- CYTVII-B-E-1M-176-CPU Rev. C Board
- CYTVII-B-E-BB Rev.A Board

IPC: Using Pipe Interface



Dependency:

- Jumper J80 to be short on position 1-2 on Base Board
- CYTVII-B-E-1M-176-CPU board should be connected on CYTVII-B-E-BB board.

> Expectation:

 CM4 core toggle LED6 (message id 1) or LED7 (message id 2) or LED8 (message id 3) or LED9 (message id 4) on the Base Board as per the received message from CM0+ core.

On CM4 core


Get received message interrupt and toggle LED based on the message Release the IPC lock and notify Server (CM0+ core)

On CM0+ core

Wait until CM4 core release lock (received data)
Send LED id to CM4 core using IPC channel

IPC: Using Pipe Interface





Legend:

- Red block for power, debug and USB (Mandatory)
- Yellow block for the example specific connections