Helpfiles > "System" menu > "Devices" window > Milking station > "Milking" > "Kicked-off detection"

"Kicked-off detection"

"Kicked-off detection"

Item	Description
"Number of times to double-check a possible kick-off":	Enter how many times the system should check if a teat cup has been dislodged from a teat.
	A check is only carried out if there are indications that a teat cup has been dislodged.