PZL KOLIBER 160A CHECK LIST

(extracted from the Pilots Operating Handbook [POH] and translated into better English - 4 PAGES)

BEFORE STARTING ENGINE

- 1. WHEEL CHOCKS, TIE DOWNS & INTERNAL & EXTERNAL LOCKS, & PITOT COVER REMOVED
- 2. SEATS ADJUSTED & SEAT BELTS ON
- 3. BRAKES ON & LOCKED COVER TOE BRAKES
- 4. CANOPY CLOSED & LOCKED

STARTING THE ENGINE

- 1. FUEL SELECTOR SELECT LEFT or RIGHT TANK ON
- 2. CARB HEAT OFF
- 3. MIXTURE FULL RICH
- 4. MASTER SWITCH ON -CHECK ALTERNATOR LIGHT ON
- 5. FUEL PUMP ON
- 6. PRIME 3 PUMPS
- 7. THROTTLE SET SLIGHTLY OPEN & COVERED
- 8. CHECK CLEAR ALL AROUND AIRCRAFT CALL "CLEAR PROP"
- 9. START ENGINE
- 10. OILPRESSURE CHECK RISING
- 11. ALTERNATIOR SWITCH ON CHECK LIGHT OUT

ENGINE TEST & BEFORE TAKE OFF CHECKS (carried out at the hold at Cranfield)

ENGINE:

- 1. PARKING BRAKE ON
- 2. CONTROL STICK HOLD BACKWARDS
- 3. FUEL PRESSURE -CHANGE TANKS CHECK WITHIN GREEN RANGE
- 4. OIL PRESSURE CHECK WITHIN GREEN RANGE
- 5. OIL TEMPERATURE CHECK WITHIN GREEN RANGE
- 6. MIXTURE FULL RICH
- 7. CARB HEAT OFF
- 8. MAG DROP CHECK LEFT THEN RIGHT BACK TO BOTH (AT 2000 RPM 50 /100 RPM DROP)
- 9. DO NOT EXCEED 2300 RPM ON GROUND RUN

BEFORE TAKE OFF

- 1. FUEL SELECTOR SET RIGHT OR LEFT (CAUTION MIDWAY = OFF !)
- 2. MAGNETOS ON BOTH
- 3. CARB HEAT OFF
- 4. MIXTURE -CHECK SET FULL RICH
- 5. ENGINE TS & PS WITHIN GREEN RANGES
- 6. FUEL PUMP ON
- 7. CONTROL STICK & RUDDER PEDALS FULLY FREE & LOGICAL OPERATION
- 8. TRIM TAB –SET TO TAKE OFF (T/O) POSITION
- 9. FLGHT INSTRUMENTS SET
- 10. AVIONICS SET

TAKE OFF

- 1. PARKING BRAKE OFF
- 2. FLAPS FULLY RETRACTED
- 3. POWER SET FULL THROTTLE GRADUALLY & SMOOTHLY
- 4. RAISE NOSE WHEEL AT 49-53 KNOTS
- 5. LIFT OFF AT 54KTS MINIMUM AIR SPEED
- 6. CLIMB TO 500FT QFE AT 70 KNOTS
- 7. FUEL PUMP OFF

CLIMB

- 1. AIRSPEED INCREASE TO CLOSE LEADING EDGE SLATS
- 2. CLIMB AT 79 KNOTS
- 3. POWER SETTING FULL TROTTLE
- 4. TEMPERATURES & PRESSURES CHECK
- 5. MXTURE FULL RICH

BEST ANGLE OF CLIMB

- 1. AIRSPEED- 61 KNOTS
- 2. POWER SETTING-FULL THROTTLE
- 3. TEMPERATURES & PRESSURES CHECK
- 4. MXTURE –FULL RICH

CRUISE

- 1. POWER SET
- 2. TRIM
- 3. MIXTURE ADJUST

APPROACH TO LANDING

- 1. MIXTURE FULL RICH
- 2. FUEL PUMP ON
- 3. FUEL SELECT FULLEST TANK
- 4. FLAPS DOWN BELOW 79 KNOTS
- 5. CARB HEAT ON
- 6. AIRSPEED TURNING ONTO FINAL 70 KNOTS
- 7. AIRSPEED FINAL FLAPS FULL OUT 65 KNOTS
- 8. CARB HEAT –SELECT OFF AT 300 FT AGL

LANDING

- 1. FLARE SLATS OPEN AUTOMATICALLY
- 2. TOUCH DOWN MAIN WHEELS 55 TO 64 KNOTS
- 3. LANDING ROLL NOSE WHEEL DOWN 52-61 KNOTS

BAULKED LANDING / GO AROUND

- 1. POWER FULL ON
- 2. CARB HEAT CHECK OFF
- 3. AIRSPEED 65 KNOTS
- 4. FLAPS RETRACT WITH CAUTION AT POSITIVE RATE OF CLIMB

TAXIING AFTER LANDING

- 1. FUEL PUMP- OFF
- 2. FLAPS UP
- 3. TRIM TAB TO T/O POSITION
- 4. CARB HEAT OFF

ENGINE SHUT DOWN

- 1. PARKING BRAKE ON
- 2. ELECTRICAL EQUIPMENT OFF
- 3. RADIO OFF
- 4. ENGINE RPM 800-900 RPM
- 5. MIXTURE FULLY LEAN
- 6. MAGNETOS OFF
- 7. ALTERNATOR OFF
- 8. MASTER SWITCH OFF
- 9. FUEL SELECTOR OFF

PARKING

- 1. CHECK ALL SWITCHES OFF
- 2. PUSH BACK TO PARKING POSITION- LEAVE BRAKES OFF
- 3. TIE DOWN
- 4. INSTALL CONTROL LOCKS INTERNAL & EXTERNAL AND PITOT COVER
- 5. LOCK CANOPY
- 6. REPLACE COVERS & LOOP UP FREE ENDS OF TIES (TO PREVENT PAINT CHAFE)