S1 Choke : WE-FLEX wiring							
Example parameter of the WE-FLEX transformer, used as a choke							
circuit	Α	В	С	D	Е	F	
IR	6	5,5	3	1,5	0,666	0,1666	x RP1
IL	6	5	4	3	2	1	IL ² x L
l _{sat}	1	1,2	1,5	2	3	6	x I _{sat base}
I _N	1	1	1	2	3	6	x I _{base}

15.10.2012 / SBa page 1 / 1