



Answers:

1. **C. multiple or coaxial leads are used**
2. **B. Ferrite isolator.**
3. **B. BWO**
4. **D. traveling wave tube**
5. **A. prevent mode jumping**
6. **A. capable of longer duty cycle**
7. **D. Isolator.**
8. **D. CFA**
9. **D. ensure electrons will orbit around the cathode**
10. **D. Acts as a buffer between a microwave oscillator coupled to a waveguide and acts as a buffer to protect a microwave oscillator from variations in line load changes.**
11. **A. easier integration with semiconductor devices**
12. **C. higher power handling capability**
13. **C. Keep antenna away from your eyes when RF is applied**
14. **A. noise figure increases**
15. **D. VTM**
16. **D. rising sun**
17. **A. is not a good low level amplifier because of noise**
18. **B. reduce the axial velocity of the RF field**
19. **B. has a greater bandwidth**
20. **C. avoid the bulk of an electromagnet**
21. **D. stripline**
22. **C. Allows one antenna to feed two separate microwave transmitters and receivers at the same time.**
23. **B. returning electron give energy to gap oscillations**
24. **B. prevent oscillations**
25. **A. prevent the oscillations that occur in two cavity klystron**

END