CreepCluster v2d BOM 2022

Resistors 2K 10K	Placement R1, R2 R3, R4, R6, R8, R9, R10	# 2 6	
1K	R5, R12, R17, R22	4	
470R 100K	R11 R13, R14,	1 2	
750K	R15	1	
10M	R18	1	
470K	R19	1	
17 013	1110	•	
Diodes			
1n914	D1, D2 D3,D4	4	
1n4001	D5	1	
Capacitors		_	
220NF 5mm spacing	C1, C3, C3	3	
100NF 2.5mm spacing	C4, C9, C10, C12, C13	5	104
1NF 2.5mm spacing	C6, C8	2	102
470NF 5mm spacing	C14	1	
1UF Electrolythic	C11, C15	2	Lay flat on the PCB
220UF	C5, C7	2	Lay flat on the PCB
Sockets			
16pin	ic1, ic2	2	
14pin	ic3	1	
8pin	ic4	1	
Opin	104	•	
IC			
CD4049	ic1	1	
CD4053	ic2	1	
CD4093	ic3	1	
TL071	ic4	1	
Pots	Direct A Direct O	^	
b10k	Pitch1, Pitch2	2	
b100k	Rate	1 1	
b100k or c100k	Cutoff	1 8	two rings below the namel
rings		ŏ	two rings below the panel on each potmeter
Knobs		4	on each polineter
Switch			
mini SPDT right-angle	SW1	1	
submicro SPDT on-off-on	Rate_speed, LDR_SW	1	one nut below the panel
LED & LDR			
Yellow led	LED1	1	solder after panel is mounted
I GIIOW IGU	LLDI	1	Solder after pariet is illourited
Power			
2.1mm PJ-102A		1	

Blad1

Output

Stereojack PJ-307 3 or 5 pin X1 1

Standoffs and screws

5mm hex with m3 mount Bottom panel 4 for bottom panel 11mm hex m3 Top panel 4

4mm M3 Bottom panel 4 for bottom panel

6mm M3 black Top panel 4 Rubber feet, round Bottom panel 4

Power adapter

9 or 12volt adapter, center negative, 200mA, 2,1mm barrel 1 NOT INCLUDED in kit Alternatively, you can solder a 9v battery cable to the two pads next to the DC Barrel

2022 Reverselandfill for questions mail me at martijn@reverselandfill.org