F3K "Simple" Score Keeping Cheat Sheet

Timing and score keeping - window timer is <u>not</u> running:

Browse saved scores

DIGITAL TELEMETRY RADIO SYSTEM
MENU H. 1-2-3-4 in any order   5.3V 02:00 1/3 +

1. 03:05   QR   Target 04:00
PAGE 2. 01:00
3. 00:15   EoW Window 05:37 −
4. 00:06
EXIT   JF F3K Score Keeper   ENT

TARANIS ACCST 2.4GHz

Change F3K task
(Prompt to save scores)

Start window timer

Timing and score keeping - window timer <u>is</u> running:

Stop flight timer and score a zero

DIGITAL TELEMETRY RADIO SYSTEM
MENU H. 1-2-3-4 in any order   5.3V 01:56 1/3 +

1. 01:00   QR   Flight 02:06
PAGE 2. - - -
3. - - -   EoW Window 07:14 −
4. - - -
EXIT   JF F3K Score Keeper   ENT

TARANIS ACCST 2.4GHz

Toggle QR

Toggle EoW

Stop window timer
(Flight timer not running)

Score browsing:

Back to timing and score keeping

DIGITAL TELEMETRY RADIO SYSTEM
MENU Just Fly!   5.3V 02:02 2/3 +

1. 01:42 5. 01:25   NXT 1
PAGE 2. 03:10 6. 05:45
3. 07:30 7. 02:08   2016-11-13 15:49 −
4. 00:43 8. 15:27
EXIT   JF F3K Score Browser   ENT

TARANIS ACCST 2.4GHz

Browse scores