Comunication Spy

Options

Trace Options	X
General Settings	
General File settings General File Name: Trace.txt General File Path: C:\WINNT\Profiles\PodlechC.000\Desktop	
Max numer of lines in file : 500 ▼	
Enable/Disable Trace	
Create General Trace File:	П
Trace SPS Communication : ▼	П
Trace MICO Communication:	
Trace Host Communication : 🔽	
OK Cancel Help	

General File Name

Name of Tracefile

General File Path

Path where Tracefile is saved. This path has to exist it will <u>not</u> be created by the ComSpy. Path can be changed by clicking on the Button Next to General File Name.

Trace SPS Communication

Will Trace the Communication between SPS and Laser PC (mostly used by Axes)


Trace MICO Communication

Will Trace the Mico Communication between Laser PC and Hardware Mico. (Serial Communication)

Trace Host Communication

Will Trace Host Communication between Handler and VMC_HK

Using the ComSpy



Trace activate starts the Monitoring of the Communication.

To save the Trace File deactivate Trace again. (The File will not be saved automatically)