

PatchHold · Small rig · mode expansion

Planning output only. Verify fixture and console modes, addresses, mapping and cues before use. No hardware, compatibility or live-show safety guarantee.

Plan v1 · engine 0.1.0 · minimum_proven · 1 existing address changes. Logical universe labels only; verify output mapping. This status concerns the supported numerical model only.

Front left

A · Stage left · mode/footprint

U1 · 1-6

Mode: 6ch · 6 channels · unlocked

Previous: U1 · 1 · 4ch

Set fixture and console mode/footprint; verify mapping and cues

- ☐ Fixture settings checked
- ☐ Console settings and cues checked

Front right

B · Stage right · readdress

U1 · 7-10

Mode: 4ch · 4 channels · unlocked

Previous: U1 · 5 · 4ch

Set fixture and console address; verify mapping and cues

- ☐ Fixture settings checked
- ☐ Console settings and cues checked

Back wash

C · Upstage · unchanged

U1 · 12-16

Mode: 5ch · 5 channels · ADDRESS LOCKED

Previous: U1 · 12 · 5ch

Verify fixture and console settings

- ☐ Fixture settings checked
- ☐ Console settings and cues checked

New accent

D · Center · new

U1 · 11-11

Mode: 1ch · 1 channels · unlocked

Previous: new fixture

Set fixture and console mode/address; verify mapping and cues

- ☐ Fixture settings checked
- ☐ Console settings and cues checked