User's Guide Rev. 2, 12 July 2022

EdgeFast BT PAL Documentation



Document identifier: EFBTPALAPIRM

CONTENTS:

1	Bluet	tooth 1
	1.1	Scope
	1.2	Start Reading
		1.2.1 Pairing and Bonding
		1.2.2 Data Length and PHY Update Procedures
	1.3	Connection Management
		1.3.1 API Reference
	1.4	Data Buffers
		1.4.1 API Reference
	1.5	Generic Access Profile (GAP)
		1.5.1 API Reference
	1.6	Generic Attribute Profile (GATT)
		1.6.1 API Reference
		1.6.1.1 GATT Server
		1.6.1.2 GATT Client
	1.7	Hands Free Profile (HFP)
		1.7.1 API Reference
	1.8	Logical Link Control and Adaptation Protocol (L2CAP)
		1.8.1 API Reference
	1.9	Serial Port Emulation (RFCOMM)
		1.9.1 API Reference
	1.10	Service Discovery Protocol (SDP)
		1.10.1 API Reference
	1.11	Advance Audio Distribution Profile (A2DP)
		1.11.1 API Reference
	1.12	Serial Port Profile (SPP)
		1.12.1 API Reference
	1.13	Audio/Video Remote Control Profile (AVRCP)
		1.13.1 API Reference
	1.14	Universal Unique Identifiers (UUIDs)
		1.14.1 API Reference
	1.15	services
		1.15.1 HTTP Proxy Service (HPS)
		1.15.1.1 API Reference
		1.15.2 Health Thermometer Service (HTS)
		1.15.2.1 API Reference
		1.15.3 Internet Protocol Support Profile (IPSP)
		1.15.3.1 API Reference
		1.15.4 Proximity Reporter (PXR)
		1.15.4.1 API Reference

Index 319

CHAPTER

ONE

BLUETOOTH

1.1 Scope

This document contains the descriptions of BLE and BR/EDR. Please ignore the BR/EDR part if the board doesn't support BR/EDR. Please check whether the board support BR/EDR based on the board package (<package>/boards/<board>/edgefast_bluetooth_examples).

1.2 Start Reading

In edgefast bluetooth stack, features are controlled by macros defined or configured in "app_bluetooth_config.h", so that the related features can be disabled or enabled.

1.2.1 Pairing and Bonding

Some macros can be configured to enable or disable "pairinig and bonding" feature in edgefast bluetooth stack. The macro "CONFIG_BT_SMP" configs whether the stack supports SMP. When the macro is set to 1, SMP is enabled, otherwise disabled. It is advised that these three related macros should be configured as follows:

```
Case1 when "CONFIG_BT_SMP" is set to 1:
CONFIG_BT_CONN_DISABLE_SECURITY=0;
```

CONFIG_BT_SETTINGS=1;

CONFIG_BT_HFP_HF=1.

Case2 when "CONFIG_BT_SMP" is set to 0:

CONFIG_BT_CONN_DISABLE_SECURITY=1;

CONFIG_BT_SETTINGS=0;

CONFIG_BT_HFP_HF=0.

1.2.2 Data Length and PHY Update Procedures

The data length and PHY update procedures should not be performed in the context of the connection callback. The data length and PHY update procedures could be performed in application task context after the connection is established.

The suggested process are as follows:

- 1. In connection callback, send the connection established event to the application task.
- 2. When the connection established event flag is set, perform the data length and phy update procedures in the application task.

1.3 Connection Management

The Zephyr Bluetooth stack uses an abstraction called bt_conn to represent connections to other devices. The internals of this struct are not exposed to the application, but a limited amount of information (such as the remote address) can be acquired using the $bt_conn_get_info()$ API. Connection objects are reference counted, and the application is expected to use the $bt_conn_ref()$ API whenever storing a connection pointer for a longer period of time, since this ensures that the object remains valid (even if the connection would get disconnected). Similarly the $bt_conn_unref()$ API is to be used when releasing a reference to a connection.

An application may track connections by registering a *bt_conn_cb* struct using the *bt_conn_cb_register()* API. This struct lets the application define callbacks for connection & disconnection events, as well as other events related to a connection such as a change in the security level or the connection parameters. When acting as a central the application will also get hold of the connection object through the return value of the bt_conn_create_le() API.

1.3.1 API Reference

group bt_conn

Connection management.

Defines

BT_LE_CONN_PARAM_INIT(int_min, int_max, lat, to)

Initialize connection parameters.

Parameters

- int min Minimum Connection Interval (N * 1.25 ms)
- int_max Maximum Connection Interval (N * 1.25 ms)
- lat Connection Latency
- to Supervision Timeout (N * 10 ms)

BT_LE_CONN_PARAM(int_min, int_max, lat, to)

Helper to declare connection parameters inline

Parameters

- int_min Minimum Connection Interval (N * 1.25 ms)
- int_max Maximum Connection Interval (N * 1.25 ms)
- lat Connection Latency

• to – Supervision Timeout (N * 10 ms)

BT_LE_CONN_PARAM_DEFAULT

Default LE connection parameters: Connection Interval: 30-50 ms Latency: 0 Timeout: 4 s

BT_CONN_LE_PHY_PARAM_INIT(_pref_tx_phy, _pref_rx_phy)

Initialize PHY parameters

Parameters

- _pref_tx_phy Bitmask of preferred transmit PHYs.
- _pref_rx_phy Bitmask of preferred receive PHYs.

BT_CONN_LE_PHY_PARAM(_pref_tx_phy, _pref_rx_phy)

Helper to declare PHY parameters inline

Parameters

- _pref_tx_phy Bitmask of preferred transmit PHYs.
- _pref_rx_phy Bitmask of preferred receive PHYs.

BT_CONN_LE_PHY_PARAM_1M

Only LE 1M PHY

BT_CONN_LE_PHY_PARAM_2M

Only LE 2M PHY

BT_CONN_LE_PHY_PARAM_CODED

Only LE Coded PHY.

BT_CONN_LE_PHY_PARAM_ALL

All LE PHYs.

BT_CONN_LE_DATA_LEN_PARAM_INIT(_tx_max_len, _tx_max_time)

Initialize transmit data length parameters

Parameters

- _tx_max_len Maximum Link Layer transmission payload size in bytes.
- _tx_max_time Maximum Link Layer transmission payload time in us.

BT_CONN_LE_DATA_LEN_PARAM(_tx_max_len, _tx_max_time)

Helper to declare transmit data length parameters inline

Parameters

- _tx_max_len Maximum Link Layer transmission payload size in bytes.
- **_tx_max_time** Maximum Link Layer transmission payload time in us.

BT_LE_DATA_LEN_PARAM_DEFAULT

Default LE data length parameters.

BT_LE_DATA_LEN_PARAM_MAX

Maximum LE data length parameters.

BT_CONN_INTERVAL_TO_MS (interval)

Convert connection interval to milliseconds.

Multiply by 1.25 to get milliseconds.

Note that this may be inaccurate, as something like 7.5 ms cannot be accurately presented with integers.

BT_CONN_INTERVAL_TO_US (interval)

Convert connection interval to microseconds.

Multiply by 1250 to get microseconds.

BT_CONN_ROLE_MASTER

Connection role (central or peripheral)

BT_CONN_ROLE_SLAVE

BT_CONN_LE_CREATE_PARAM_INIT(_options, _interval, _window)

Initialize create connection parameters.

Parameters

- **_options** Create connection options.
- **_interval** Create connection scan interval (N * 0.625 ms).
- **_window** Create connection scan window (N * 0.625 ms).

BT_CONN_LE_CREATE_PARAM(_options, _interval, _window)

Helper to declare create connection parameters inline

Parameters

- **_options** Create connection options.
- _interval Create connection scan interval (N * 0.625 ms).
- _window Create connection scan window (N * 0.625 ms).

BT_CONN_LE_CREATE_CONN

Default LE create connection parameters. Scan continuously by setting scan interval equal to scan window.

BT_CONN_LE_CREATE_CONN_AUTO

Default LE create connection using filter accept list parameters. Scan window: 30 ms. Scan interval: 60 ms.

BT_CONN_CB_DEFINE(_name)

Register a callback structure for connection events.

Parameters

• _name - Name of callback structure.

BT_PASSKEY_INVALID

Special passkey value that can be used to disable a previously set fixed passkey.

BT_BR_CONN_PARAM_INIT(role_switch)

Initialize BR/EDR connection parameters.

Parameters

• role switch - True if role switch is allowed

BT_BR_CONN_PARAM(role_switch)

Helper to declare BR/EDR connection parameters inline

Parameters

• role_switch - True if role switch is allowed

BT_BR_CONN_PARAM_DEFAULT

Default BR/EDR connection parameters: Role switch allowed

Typedefs

```
typedef enum _bt_security bt_security_t
```

Enums

Connection PHY options

Values:

enumerator BT_CONN_LE_PHY_OPT_NONE

Convenience value when no options are specified.

enumerator BT_CONN_LE_PHY_OPT_CODED_S2

LE Coded using S=2 coding preferred when transmitting.

enumerator BT_CONN_LE_PHY_OPT_CODED_S8

LE Coded using S=8 coding preferred when transmitting.

enum bt_conn_type

Connection Type

Values:

enumerator BT_CONN_TYPE_LE

LE Connection Type

enumerator BT_CONN_TYPE_BR

BR/EDR Connection Type

```
enumerator BT_CONN_TYPE_SCO
         SCO Connection Type
     enumerator BT_CONN_TYPE_ISO
         ISO Connection Type
     enumerator BT_CONN_TYPE_ALL
         All Connection Type
     Values:
     enumerator BT_CONN_ROLE_CENTRAL
     enumerator BT_CONN_ROLE_PERIPHERAL
enum bt_conn_state
     Values:
     enumerator BT_CONN_STATE_DISCONNECTED
         Channel disconnected
     enumerator BT_CONN_STATE_CONNECTING
         Channel in connecting state
     enumerator BT_CONN_STATE_CONNECTED
         Channel connected and ready for upper layer traffic on it
     enumerator BT_CONN_STATE_DISCONNECTING
         Channel in disconnecting state
enum _bt_security
    Security level.
     Values:
     enumerator BT_SECURITY_L0
         Level 0: Only for BR/EDR special cases, like SDP
     enumerator BT_SECURITY_L1
         Level 1: No encryption and no authentication.
     enumerator BT_SECURITY_L2
         Level 2: Encryption and no authentication (no MITM).
```

enumerator BT_SECURITY_L3

Level 3: Encryption and authentication (MITM).

enumerator BT_SECURITY_L4

Level 4: Authenticated Secure Connections and 128-bit key.

enumerator BT_SECURITY_FORCE_PAIR

Bit to force new pairing procedure, bit-wise OR with requested security level.

enum bt_security_flag

Security Info Flags.

Values:

enumerator BT_SECURITY_FLAG_SC

Paired with Secure Connections.

enumerator BT_SECURITY_FLAG_00B

Paired with Out of Band method.

enum bt_conn_le_tx_power_phy

Values:

enumerator BT_CONN_LE_TX_POWER_PHY_NONE

Convenience macro for when no PHY is set.

enumerator BT_CONN_LE_TX_POWER_PHY_1M

LE 1M PHY

enumerator BT_CONN_LE_TX_POWER_PHY_2M

LE 2M PHY

enumerator BT_CONN_LE_TX_POWER_PHY_CODED_S8

LE Coded PHY using S=8 coding.

enumerator BT_CONN_LE_TX_POWER_PHY_CODED_S2

LE Coded PHY using S=2 coding.

enum bt_conn_auth_keypress

Passkey Keypress Notification type.

The numeric values are the same as in the Core specification for Pairing Keypress Notification PDU.

Values:

enumerator BT_CONN_AUTH_KEYPRESS_ENTRY_STARTED

enumerator BT_CONN_AUTH_KEYPRESS_DIGIT_ENTERED

enumerator BT_CONN_AUTH_KEYPRESS_DIGIT_ERASED

enumerator BT_CONN_AUTH_KEYPRESS_CLEARED

enumerator BT_CONN_AUTH_KEYPRESS_ENTRY_COMPLETED

Values:

enumerator BT_CONN_LE_OPT_NONE

Convenience value when no options are specified.

enumerator BT_CONN_LE_OPT_CODED

Enable LE Coded PHY.

Enable scanning on the LE Coded PHY.

enumerator BT_CONN_LE_OPT_NO_1M

Disable LE 1M PHY.

Disable scanning on the LE 1M PHY.

@note Requires @ref BT_CONN_LE_OPT_CODED.

enum bt_security_err

Values:

enumerator BT_SECURITY_ERR_SUCCESS

Security procedure successful.

enumerator BT_SECURITY_ERR_AUTH_FAIL

Authentication failed.

enumerator BT_SECURITY_ERR_PIN_OR_KEY_MISSING

PIN or encryption key is missing.

enumerator BT_SECURITY_ERR_OOB_NOT_AVAILABLE

OOB data is not available.

enumerator BT_SECURITY_ERR_AUTH_REQUIREMENT

The requested security level could not be reached.

enumerator BT_SECURITY_ERR_PAIR_NOT_SUPPORTED

Pairing is not supported

enumerator BT_SECURITY_ERR_PAIR_NOT_ALLOWED

Pairing is not allowed.

enumerator BT_SECURITY_ERR_INVALID_PARAM

Invalid parameters.

enumerator BT_SECURITY_ERR_KEY_REJECTED

Distributed Key Rejected

enumerator BT_SECURITY_ERR_UNSPECIFIED

Pairing failed but the exact reason could not be specified.

Functions

struct bt_conn *bt_conn_ref(struct bt_conn *conn)

Increment a connection's reference count.

Increment the reference count of a connection object.

Note: Will return NULL if the reference count is zero.

Parameters

• **conn** – Connection object.

Returns Connection object with incremented reference count, or NULL if the reference count is zero.

void bt_conn_unref(struct bt conn *conn)

Decrement a connection's reference count.

Decrement the reference count of a connection object.

Parameters

• conn – Connection object.

void **bt_conn_foreach**(enum *bt_conn_type* type, void (*func)(struct bt_conn *conn, void *data), void *data)

Iterate through all bt_conn objects.

Iterates trough all bt_conn objects that are alive in the Host allocator.

To find established connections, combine this with $bt_conn_get_info$. Check that bt_conn_info ::state is $BT_CONN_STATE_CONNECTED$.

Thread safety: This API is thread safe, but it does not guarantee a sequentially-consistent view for objects allocated during the current invocation of this API. E.g. If preempted while allocations A then B then C happen then results may include A and C but miss B.

Parameters

- **type** Connection Type
- **func** Function to call for each connection.
- data Data to pass to the callback function.

```
struct bt_conn *bt_conn_lookup_addr_le(uint8_t id, const bt_addr_le_t *peer)
```

Look up an existing connection by address.

Look up an existing connection based on the remote address.

The caller gets a new reference to the connection object which must be released with *bt_conn_unref()* once done using the object.

Parameters

- id Local identity (in most cases BT_ID_DEFAULT).
- **peer** Remote address.

Returns Connection object or NULL if not found.

```
const bt_addr_le_t *bt_conn_get_dst(const struct bt_conn *conn)
```

Get destination (peer) address of a connection.

Parameters

• conn – Connection object.

Returns Destination address.

```
const bt addr t *bt_conn_get_dst_br(const struct bt conn *conn)
```

Get destination (peer) address of a BR connection.

Parameters

• conn – Connection object.

Returns Destination address.

```
uint8_t bt_conn_index(const struct bt_conn *conn)
```

Get array index of a connection.

This function is used to map bt_conn to index of an array of connections. The array has CON-FIG_BT_MAX_CONN elements.

Parameters

• conn – Connection object.

Returns Index of the connection object. The range of the returned value is 0..CONFIG_BT_MAX_CONN-1

int bt_conn_get_info(const struct bt_conn *conn, struct bt_conn_info *info)

Get connection info.

Parameters

- **conn** Connection object.
- info Connection info object.

Returns Zero on success or (negative) error code on failure.

int **bt_conn_get_remote_info**(struct bt_conn *conn, struct *bt_conn_remote_info* *remote_info)

Get connection info for the remote device.

Note: In order to retrieve the remote version (version, manufacturer and subversion) @kconfig{CONFIG_BT_REMOTE_VERSION} must be enabled

Note: The remote information is exchanged directly after the connection has been established. The application can be notified about when the remote information is available through the remote_info_available callback.

Parameters

- **conn** Connection object.
- **remote_info** Connection remote info object.

Returns Zero on success or (negative) error code on failure.

Returns -EBUSY The remote information is not yet available.

int **bt_conn_le_get_tx_power_level**(struct bt_conn *conn, struct *bt_conn_le_tx_power* *tx_power_level)

Get connection transmit power level.

Parameters

- conn Connection object.
- tx_power_level Transmit power level descriptor.

Returns Zero on success or (negative) error code on failure.

Returns -ENOBUFS HCI command buffer is not available.

int **bt_conn_le_enhanced_get_tx_power_level**(struct bt_conn *conn, struct bt_conn_le_tx_power *tx_power)

Get local enhanced connection transmit power level.

Parameters

- **conn** Connection object.
- **tx_power** Transmit power level descriptor.

Return values -ENOBUFS - HCI command buffer is not available.

Returns Zero on success or (negative) error code on failure.

int **bt_conn_le_get_remote_tx_power_level**(struct bt_conn *conn, enum bt_conn_le_tx_power_phy phy)

Get remote (peer) transmit power level.

Parameters

- conn Connection object.
- **phy** PHY information.

Return values -ENOBUFS – HCI command buffer is not available.

Returns Zero on success or (negative) error code on failure.

int bt_conn_le_set_tx_power_report_enable(struct bt_conn *conn, bool local_enable, bool remote enable)

Enable transmit power reporting.

Parameters

- conn Connection object.
- **local_enable** Enable/disable reporting for local.
- **remote_enable** Enable/disable reporting for remote.

Return values -ENOBUFS – HCI command buffer is not available.

Returns Zero on success or (negative) error code on failure.

int **bt_conn_le_param_update**(struct bt_conn *conn, const struct bt_le_conn_param *param)

Update the connection parameters.

If the local device is in the peripheral role then updating the connection parameters will be delayed. This delay can be configured by through the @kconfig{CONFIG_BT_CONN_PARAM_UPDATE_TIMEOUT} option.

Parameters

- conn Connection object.
- param Updated connection parameters.

Returns Zero on success or (negative) error code on failure.

int **bt_conn_le_data_len_update**(struct bt_conn *conn, const struct *bt_conn_le_data_len_param* *param)

Update the connection transmit data length parameters.

Parameters

- conn Connection object.
- **param** Updated data length parameters.

Returns Zero on success or (negative) error code on failure.

int **bt_conn_le_phy_update**(struct bt_conn *conn, const struct bt_conn_le_phy_param *param)

Update the connection PHY parameters.

Update the preferred transmit and receive PHYs of the connection. Use *BT_GAP_LE_PHY_NONE* to indicate no preference.

Parameters

- conn Connection object.
- param Updated connection parameters.

Returns Zero on success or (negative) error code on failure.

int **bt_conn_disconnect**(struct bt_conn *conn, uint8_t reason)

Disconnect from a remote device or cancel pending connection.

Disconnect an active connection with the specified reason code or cancel pending outgoing connection.

The disconnect reason for a normal disconnect should be: BT_HCI_ERR_REMOTE_USER_TERM_CONN.

The following disconnect reasons are accepted:

• BT_HCI_ERR_AUTH_FAIL

- BT_HCI_ERR_REMOTE_USER_TERM_CONN
- BT_HCI_ERR_REMOTE_LOW_RESOURCES
- BT_HCI_ERR_REMOTE_POWER_OFF
- BT_HCI_ERR_UNSUPP_REMOTE_FEATURE
- BT HCI ERR PAIRING NOT SUPPORTED
- BT HCI ERR UNACCEPT CONN PARAM

Parameters

- conn Connection to disconnect.
- **reason** Reason code for the disconnection.

Returns Zero on success or (negative) error code on failure.

int **bt_conn_le_create**(const *bt_addr_le_t* *peer, const struct *bt_conn_le_create_param* *create_param, const struct *bt_le_conn_param* *conn_param, struct bt_conn **conn)

Initiate an LE connection to a remote device.

Allows initiate new LE link to remote peer using its address.

The caller gets a new reference to the connection object which must be released with $bt_conn_unref()$ once done using the object.

This uses the General Connection Establishment procedure.

The application must disable explicit scanning before initiating a new LE connection.

Parameters

- **peer** [in] Remote address.
- **create_param [in]** Create connection parameters.
- conn_param [in] Initial connection parameters.
- conn [out] Valid connection object on success.

Returns Zero on success or (negative) error code on failure.

```
int bt_conn_le_create_synced(const struct bt_le_ext_adv *adv, const struct bt_conn_le_create_synced_param *synced_param, const struct bt_le_conn_param *conn_param, struct bt_conn **conn)
```

Create a connection to a synced device.

Initiate a connection to a synced device from a Periodic Advertising with Responses (PAwR) train.

The caller gets a new reference to the connection object which must be released with $bt_conn_unref()$ once done using the object.

This uses the Periodic Advertising Connection Procedure.

Parameters

- adv [in] The adverting set the PAwR advertiser belongs to.
- **synced_param [in]** Create connection parameters.
- conn_param [in] Initial connection parameters.
- conn [out] Valid connection object on success.

Returns Zero on success or (negative) error code on failure.

```
int bt_conn_le_create_auto(const struct bt_conn_le_create_param *create_param, const struct bt_le_conn_param *conn_param)
```

Automatically connect to remote devices in the filter accept list.

This uses the Auto Connection Establishment procedure. The procedure will continue until a single connection is established or the procedure is stopped through *bt_conn_create_auto_stop*. To establish connections to all devices in the the filter accept list the procedure should be started again in the connected callback after a new connection has been established.

Parameters

- **create_param** Create connection parameters
- **conn_param** Initial connection parameters.

Returns Zero on success or (negative) error code on failure.

Returns -ENOMEM No free connection object available.

```
int bt_conn_create_auto_stop(void)
```

Stop automatic connect creation.

Returns Zero on success or (negative) error code on failure.

```
int bt_le_set_auto_conn(const bt_addr_le_t *addr, const struct bt_le_conn_param *param)
```

Automatically connect to remote device if it's in range.

This function enables/disables automatic connection initiation. Every time the device loses the connection with peer, this connection will be re-established if connectable advertisement from peer is received.

Note: Auto connect is disabled during explicit scanning.

Parameters

- addr Remote Bluetooth address.
- param If non-NULL, auto connect is enabled with the given parameters. If NULL, auto connect is disabled.

Returns Zero on success or error code otherwise.

```
int bt_conn_set_security(struct bt_conn *conn, bt_security_t sec)
```

Set security level for a connection.

This function enable security (encryption) for a connection. If the device has bond information for the peer with sufficiently strong key encryption will be enabled. If the connection is already encrypted with sufficiently strong key this function does nothing.

If the device has no bond information for the peer and is not already paired then the pairing procedure will be initiated. Note that sec has no effect on the security level selected for the pairing process. The selection is instead controlled by the values of the registered $bt_conn_auth_cb$. If the device has bond information or is already paired and the keys are too weak then the pairing procedure will be initiated.

This function may return an error if the required level of security defined using sec is not possible to achieve due to local or remote device limitation (e.g., input output capabilities), or if the maximum number of paired devices has been reached.

This function may return an error if the pairing procedure has already been initiated by the local device or the peer device.

Note: When @kconfig{CONFIG_BT_SMP_SC_ONLY} is enabled then the security level will always be level 4.

Note: When @kconfig{CONFIG_BT_SMP_OOB_LEGACY_PAIR_ONLY} is enabled then the security level will always be level 3.

Note: When *BT_SECURITY_FORCE_PAIR* within sec is enabled then the pairing procedure will always be initiated.

Parameters

- conn Connection object.
- **sec** Requested minimum security level.

Returns 0 on success or negative error

bt_security_t bt_conn_get_security(const struct bt_conn *conn)

Get security level for a connection.

Returns Connection security level

uint8_t bt_conn_enc_key_size(const struct bt_conn *conn)

Get encryption key size.

This function gets encryption key size. If there is no security (encryption) enabled 0 will be returned.

Parameters

• conn – Existing connection object.

Returns Encryption key size.

void bt_conn_cb_register(struct bt conn cb *cb)

Register connection callbacks.

Register callbacks to monitor the state of connections.

Parameters

• **cb** – Callback struct. Must point to memory that remains valid.

int bt_conn_cb_unregister(struct bt_conn_cb *cb)

Unregister connection callbacks.

Unregister the state of connections callbacks.

Parameters

• cb – Callback struct point to memory that remains valid.

Return values

• **0** – Success

- -EINVAL If cb is NULL
- -ENOENT if cb was not registered

void bt_set_bondable(bool enable)

Enable/disable bonding.

Set/clear the Bonding flag in the Authentication Requirements of SMP Pairing Request/Response data. The initial value of this flag depends on BT_BONDABLE Kconfig setting. For the vast majority of applications calling this function shouldn't be needed.

Parameters

• **enable** – Value allowing/disallowing to be bondable.

int bt_conn_set_bondable(struct bt_conn *conn, bool enable)

Set/clear the bonding flag for a given connection.

Set/clear the Bonding flag in the Authentication Requirements of SMP Pairing Request/Response data for a given connection.

The bonding flag for a given connection cannot be set/cleared if security procedures in the SMP module have already started. This function can be called only once per connection.

If the bonding flag is not set/cleared for a given connection, the value will depend on global configuration which is set using bt_set_bondable. The default value of the global configuration is defined using CONFIG_BT_BONDABLE Kconfig option.

Parameters

- conn Connection object.
- enable Value allowing/disallowing to be bondable.

void bt_le_oob_set_sc_flag(bool enable)

Allow/disallow remote LE SC OOB data to be used for pairing.

Set/clear the OOB data flag for LE SC SMP Pairing Request/Response data.

Parameters

• **enable** – Value allowing/disallowing remote LE SC OOB data.

void bt_le_oob_set_legacy_flag(bool enable)

Allow/disallow remote legacy OOB data to be used for pairing.

Set/clear the OOB data flag for legacy SMP Pairing Request/Response data.

Parameters

• enable – Value allowing/disallowing remote legacy OOB data.

int bt_le_oob_set_legacy_tk(struct bt_conn *conn, const uint8_t *tk)

Set OOB Temporary Key to be used for pairing.

This function allows to set OOB data for the LE legacy pairing procedure. The function should only be called in response to the oob_data_request() callback provided that the legacy method is user pairing.

Parameters

- **conn** Connection object
- **tk** Pointer to 16 byte long TK array

Returns Zero on success or -EINVAL if NULL

int **bt_le_oob_set_sc_data**(struct bt_conn *conn, const struct bt_le_oob_sc_data *oobd_local, const struct bt_le_oob_sc_data *oobd_remote)

Set OOB data during LE Secure Connections (SC) pairing procedure.

This function allows to set OOB data during the LE SC pairing procedure. The function should only be called in response to the oob_data_request() callback provided that LE SC method is used for pairing.

The user should submit OOB data according to the information received in the callback. This may yield three different configurations: with only local OOB data present, with only remote OOB data present or with both local and remote OOB data present.

Parameters

- conn Connection object
- oobd_local Local OOB data or NULL if not present
- **oobd_remote** Remote OOB data or NULL if not present

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

int **bt_le_oob_get_sc_data**(struct bt_conn *conn, const struct *bt_le_oob_sc_data* **oobd_local, const struct *bt_le_oob_sc_data* **oobd_remote)

Get OOB data used for LE Secure Connections (SC) pairing procedure.

This function allows to get OOB data during the LE SC pairing procedure that were set by the $bt_le_oob_set_sc_data()$ API.

Note: The OOB data will only be available as long as the connection object associated with it is valid.

Parameters

- conn Connection object
- oobd_local Local OOB data or NULL if not set
- **oobd_remote** Remote OOB data or NULL if not set

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

int bt_passkey_set(unsigned int passkey)

Set a fixed passkey to be used for pairing.

This API is only available when the CONFIG_BT_FIXED_PASSKEY configuration option has been enabled.

Sets a fixed passkey to be used for pairing. If set, the pairing_confirm() callback will be called for all incoming pairings.

Parameters

• **passkey** – A valid passkey (0 - 999999) or BT_PASSKEY_INVALID to disable a previously set fixed passkey.

Returns 0 on success or a negative error code on failure.

int **bt_conn_auth_cb_register**(const struct *bt_conn_auth_cb* *cb)

Register authentication callbacks.

Register callbacks to handle authenticated pairing. Passing NULL unregisters a previous callbacks structure.

Parameters

• cb - Callback struct.

Returns Zero on success or negative error code otherwise

```
int bt_conn_auth_cb_overlay(struct bt_conn *cons, const struct bt_conn_auth_cb *cb)
```

Overlay authentication callbacks used for a given connection.

This function can be used only for Bluetooth LE connections. The @kconfig{CONFIG_BT_SMP} must be enabled for this function.

The authentication callbacks for a given connection cannot be overlaid if security procedures in the SMP module have already started. This function can be called only once per connection.

Parameters

- **conn** Connection object.
- **cb** Callback struct.

Returns Zero on success or negative error code otherwise

```
int bt_conn_auth_info_cb_register(struct bt_conn_auth_info_cb *cb)
```

Register authentication information callbacks.

Register callbacks to get authenticated pairing information. Multiple registrations can be done.

Parameters

• cb - Callback struct.

Returns Zero on success or negative error code otherwise

```
int bt_conn_auth_info_cb_unregister(struct bt_conn_auth_info_cb *cb)
```

Unregister authentication information callbacks.

Unregister callbacks to stop getting authenticated pairing information.

Parameters

• cb – Callback struct.

Returns Zero on success or negative error code otherwise

int bt_conn_auth_passkey_entry(struct bt_conn *conn, unsigned int passkey)

Reply with entered passkey.

This function should be called only after passkey_entry callback from bt_conn_auth_cb structure was called.

Parameters

- conn Connection object.
- passkey Entered passkey.

Returns Zero on success or negative error code otherwise

int **bt_conn_auth_keypress_notify**(struct bt_conn *conn, enum bt_conn_auth_keypress type)

Send Passkey Keypress Notification during pairing.

This function may be called only after passkey_entry callback from bt_conn_auth_cb structure was called.

Requires @kconfig{CONFIG BT PASSKEY KEYPRESS}.

See also:

bt_conn_auth_keypress.

Parameters

- conn Destination for the notification.
- **type** What keypress event type to send.

Return values

- 0 Success
- **-EINVAL** Improper use of the API.
- **-ENOMEM** Failed to allocate.
- **-ENOBUFS** Failed to allocate.

int bt_conn_auth_cancel(struct bt conn *conn)

Cancel ongoing authenticated pairing.

This function allows to cancel ongoing authenticated pairing.

Parameters

• conn – Connection object.

Returns Zero on success or negative error code otherwise

int bt_conn_auth_passkey_confirm(struct bt_conn *conn)

Reply if passkey was confirmed to match by user.

This function should be called only after passkey_confirm callback from *bt_conn_auth_cb* structure was called.

Parameters

• conn – Connection object.

Returns Zero on success or negative error code otherwise

int bt_conn_auth_pairing_confirm(struct bt_conn *conn)

Reply if incoming pairing was confirmed by user.

This function should be called only after pairing_confirm callback from *bt_conn_auth_cb* structure was called if user confirmed incoming pairing.

Parameters

• conn – Connection object.

Returns Zero on success or negative error code otherwise

int bt_conn_auth_pincode_entry(struct bt_conn *conn, const char *pin)

Reply with entered PIN code.

This function should be called only after PIN code callback from *bt_conn_auth_cb* structure was called. It's for legacy 2.0 devices.

Parameters

- conn Connection object.
- **pin** Entered PIN code.

Returns Zero on success or negative error code otherwise

```
struct bt_conn *bt_conn_create_br(const bt_addr_t *peer, const struct bt_br_conn_param *param)
```

Initiate an BR/EDR connection to a remote device.

Allows initiate new BR/EDR link to remote peer using its address.

The caller gets a new reference to the connection object which must be released with $bt_conn_unref()$ once done using the object.

Parameters

- **peer** Remote address.
- param Initial connection parameters.

Returns Valid connection object on success or NULL otherwise.

```
struct bt_conn *bt_conn_create_sco(const bt_addr_t *peer)
```

Initiate an SCO connection to a remote device.

Allows initiate new SCO link to remote peer using its address.

The caller gets a new reference to the connection object which must be released with $bt_conn_unref()$ once done using the object.

Parameters

• **peer** – Remote address.

Returns Valid connection object on success or NULL otherwise.

struct bt_le_conn_param

#include <conn.h> Connection parameters for LE connections

struct bt_conn_le_phy_info

#include <conn.h> Connection PHY information for LE connections

Public Members

```
uint8_t rx_phy
```

Connection transmit PHY

struct bt_conn_le_phy_param

#include <conn.h> Preferred PHY parameters for LE connections

uint8_t pref_tx_phy

Connection PHY options.

uint8_t pref_rx_phy

Bitmask of preferred transmit PHYs

struct bt_conn_le_data_len_info

#include <conn.h> Connection data length information for LE connections

Public Members

uint16 t tx_max_len

Maximum Link Layer transmission payload size in bytes.

uint16_t tx_max_time

Maximum Link Layer transmission payload time in us.

uint16_t rx_max_len

Maximum Link Layer reception payload size in bytes.

uint16 trx_max_time

Maximum Link Layer reception payload time in us.

struct bt_conn_le_data_len_param

#include <conn.h> Connection data length parameters for LE connections

Public Members

uint16_t **tx_max_len**

Maximum Link Layer transmission payload size in bytes.

uint16_t **tx_max_time**

Maximum Link Layer transmission payload time in us.

struct bt_conn_le_info

#include <conn.h> LE Connection Info Structure

```
const bt_addr_le_t *src
         Source (Local) Identity Address
     const bt_addr_le_t *dst
         Destination (Remote) Identity Address or remote Resolvable Private Address (RPA) before identity
         has been resolved.
     const bt_addr_le_t *local
         Local device address used during connection setup.
     const bt_addr_le_t *remote
         Remote device address used during connection setup.
     uint16_t interval
         Connection interval
     uint16_t latency
         Connection peripheral latency
     uint16 t timeout
         Connection supervision timeout
struct bt_conn_br_info
     #include <conn.h> BR/EDR Connection Info Structure
struct bt_security_info
     #include <conn.h> Security Info Structure.
     Public Members
     bt_security_t level
         Security Level.
     uint8_t enc_key_size
         Encryption Key Size.
     enum bt_security_flag flags
         Flags.
struct bt_conn_info
     #include <conn.h> Connection Info Structure
```

```
enum bt_conn_type type
```

Connection Type.

uint8_t role

Connection Role.

uint8_t id

Which local identity the connection was created with

union bt_conn_info

Connection Type specific Info.

enum bt_conn_state state

Connection state.

struct bt_security_info security

Security specific info.

struct bt_conn_le_remote_info

#include <conn.h> LE Connection Remote Info Structure

Public Members

```
const uint8_t *features
```

Remote LE feature set (bitmask).

struct bt_conn_br_remote_info

#include <conn.h> BR/EDR Connection Remote Info structure

Public Members

```
const uint8_t *features
```

Remote feature set (pages of bitmasks).

uint8_t num_pages

Number of pages in the remote feature set.

$struct \ \textbf{bt_conn_remote_info}$

#include <conn.h> Connection Remote Info Structure.

Note: The version, manufacturer and subversion fields will only contain valid data if @kconfig{CONFIG_BT_REMOTE_VERSION} is enabled.

uint8_t type

Connection Type

uint8_t version

Remote Link Layer version

uint16_t manufacturer

Remote manufacturer identifier

uint16_t subversion

Per-manufacturer unique revision

struct bt_conn_le_tx_power

#include <conn.h> LE Transmit Power Level Structure

Public Members

uint8_t phy

Input: 1M, 2M, Coded S2 or Coded S8

int8 t current_level

Output: current transmit power level

int8_t max_level

Output: maximum transmit power level

struct bt_conn_le_tx_power_report

#include <conn.h> LE Transmit Power Reporting Structure

Public Members

uint8_t reason

Reason for Transmit power reporting, as documented in Core Spec. Version 5.4 Vol. 4, Part E, 7.7.65.33.

enum bt_conn_le_tx_power_phy **phy**

Phy of Transmit power reporting.

int8_t tx_power_level

Transmit power level

- 0xXX Transmit power level
 - Range: -127 to 20
 - Units: dBm

- 0x7E Remote device is not managing power levels on this PHY.
- 0x7F Transmit power level is not available

uint8_t tx_power_level_flag

Bit 0: Transmit power level is at minimum level. Bit 1: Transmit power level is at maximum level.

int8_t delta

Change in transmit power level

- 0xXX Change in transmit power level (positive indicates increased power, negative indicates decreased power, zero indicates unchanged) Units: dB
- 0x7F Change is not available or is out of range.

struct bt_conn_le_create_param

#include <conn.h>

Public Members

uint32_t options

Bit-field of create connection options.

uint16_t interval

Scan interval (N * 0.625 ms)

uint16 t window

Scan window (N * 0.625 ms)

uint16_t interval_coded

Scan interval LE Coded PHY (N * 0.625 MS)

Set zero to use same as LE 1M PHY scan interval

uint16_t window_coded

Scan window LE Coded PHY (N * 0.625 MS)

Set zero to use same as LE 1M PHY scan window.

uint16_t timeout

Connection initiation timeout (N * 10 MS)

Set zero to use the default @kconfig{CONFIG_BT_CREATE_CONN_TIMEOUT} timeout.

Note: Unused in *bt_conn_le_create_auto*

struct bt_conn_le_create_synced_param

#include <conn.h>

const bt_addr_le_t *peer

Remote address.

The peer must be synchronized to the PAwR train.

uint8 t subevent

The subevent where the connection will be initiated.

struct bt_conn_cb

#include <conn.h> Connection callback structure.

This structure is used for tracking the state of a connection. It is registered with the help of the $bt_conn_cb_register()$ API. It's permissible to register multiple instances of this bt_conn_cb type, in case different modules of an application are interested in tracking the connection state. If a callback is not of interest for an instance, it may be set to NULL and will as a consequence not be used for that instance.

Public Members

void (*connected)(struct bt_conn *conn, uint8_t err)

A new connection has been established.

This callback notifies the application of a new connection. In case the err parameter is non-zero it means that the connection establishment failed.

err can mean either of the following:

- BT_HCI_ERR_UNKNOWN_CONN_ID Creating the connection started by bt_conn_le_create was canceled either by the user through bt_conn_disconnect or by the timeout in the host through bt_conn_le_create_param timeout parameter, which defaults to @kcon-fig{CONFIG_BT_CREATE_CONN_TIMEOUT} seconds.
- BT_HCI_ERR_ADV_TIMEOUT High duty cycle directed connectable advertiser started by bt_le_adv_start failed to be connected within the timeout.

Note: If the connection was established from an advertising set then the advertising set cannot be restarted directly from this callback. Instead use the connected callback of the advertising set.

Param conn New connection object.

Param err HCI error. Zero for success, non-zero otherwise.

void (*disconnected)(struct bt conn *conn, uint8 t reason)

A connection has been disconnected.

This callback notifies the application that a connection has been disconnected.

When this callback is called the stack still has one reference to the connection object. If the application in this callback tries to start either a connectable advertiser or create a new connection this might fail because there are no free connection objects available. To avoid this issue it is recommended to either start connectable advertise or create a new connection using k_work_submit or increase @kconfig{CONFIG_BT_MAX_CONN}.

Param conn Connection object.

Param reason BT_HCI_ERR_* reason for the disconnection.

void (*recycled)(void)

A connection object has been returned to the pool.

This callback notifies the application that it might be able to allocate a connection object. No guarantee, first come, first serve.

Use this to e.g. re-start connectable advertising or scanning.

Treat this callback as an ISR, as it originates from *bt_conn_unref* which is used by the BT stack. Making Bluetooth API calls in this context is error-prone and strongly discouraged.

bool (*le_param_req)(struct bt_conn *conn, struct bt_le_conn_param *param)

LE connection parameter update request.

This callback notifies the application that a remote device is requesting to update the connection parameters. The application accepts the parameters by returning true, or rejects them by returning false. Before accepting, the application may also adjust the parameters to better suit its needs.

It is recommended for an application to have just one of these callbacks for simplicity. However, if an application registers multiple it needs to manage the potentially different requirements for each callback. Each callback gets the parameters as returned by previous callbacks, i.e. they are not necessarily the same ones as the remote originally sent.

If the application does not have this callback then the default is to accept the parameters.

Param conn Connection object.

Param param Proposed connection parameters.

Return true to accept the parameters, or false to reject them.

void (*le_param_updated)(struct bt_conn *conn, uint16_t interval, uint16_t latency, uint16_t timeout)

The parameters for an LE connection have been updated.

This callback notifies the application that the connection parameters for an LE connection have been updated.

Param conn Connection object.

Param interval Connection interval.

Param latency Connection latency.

Param timeout Connection supervision timeout.

void (*identity_resolved)(struct bt_conn *conn, const bt_addr_le_t *rpa, const bt_addr_le_t
*identity)

Remote Identity Address has been resolved.

This callback notifies the application that a remote Identity Address has been resolved

Param conn Connection object.

Param rpa Resolvable Private Address.

Param identity Identity Address.

void (*security_changed)(struct bt_conn *conn, bt_security_t level, enum bt_security_err err)

The security level of a connection has changed.

This callback notifies the application that the security of a connection has changed.

The security level of the connection can either have been increased or remain unchanged. An increased security level means that the pairing procedure has been performed or the bond information from a previous connection has been applied. If the security level remains unchanged this means that the encryption key has been refreshed for the connection.

Param conn Connection object.

Param level New security level of the connection.

Param err Security error. Zero for success, non-zero otherwise.

```
void (*remote_info_available)(struct bt conn *conn, struct bt conn remote info *remote info)
```

Remote information procedures has completed.

This callback notifies the application that the remote information has been retrieved from the remote peer.

Param conn Connection object.

Param remote_info Connection information of remote device.

```
void (*le_phy_updated)(struct bt_conn *conn, struct bt_conn_le_phy_info *param)
```

The PHY of the connection has changed.

This callback notifies the application that the PHY of the connection has changed.

Param conn Connection object.

Param info Connection LE PHY information.

```
void (*le_data_len_updated)(struct bt_conn *conn, struct bt_conn_le_data_len_info *info)
```

The data length parameters of the connection has changed.

This callback notifies the application that the maximum Link Layer payload length or transmission time has changed.

Param conn Connection object.

Param info Connection data length information.

struct bt_conn_oob_info

#include <conn.h> Info Structure for OOB pairing

Public Types

```
Type of OOB pairing method
```

Values:

enumerator BT_CONN_OOB_LE_LEGACY

LE legacy pairing

enumerator BT_CONN_OOB_LE_SC

LE SC pairing

```
enum bt_conn_oob_info type
```

Type of OOB pairing method

struct bt_conn_pairing_feat

#include <conn.h> Pairing request and pairing response info structure.

This structure is the same for both smp_pairing_req and smp_pairing_rsp and a subset of the packet data, except for the initial Code octet. It is documented in Core Spec. Vol. 3, Part H, 3.5.1 and 3.5.2.

Public Members

```
uint8_t io_capability
IO Capability, Core Spec. Vol 3, Part H, 3.5.1, Table 3.4

uint8_t oob_data_flag
OOB data flag, Core Spec. Vol 3, Part H, 3.5.1, Table 3.5

uint8_t auth_req
AuthReq, Core Spec. Vol 3, Part H, 3.5.1, Fig. 3.3

uint8_t max_enc_key_size
Maximum Encryption Key Size, Core Spec. Vol 3, Part H, 3.5.1

uint8_t init_key_dist
Initiator Key Distribution/Generation, Core Spec. Vol 3, Part H, 3.6.1, Fig. 3.11

uint8_t resp_key_dist
Responder Key Distribution/Generation, Core Spec. Vol 3, Part H 3.6.1, Fig. 3.11
```

struct bt_conn_auth_cb

#include <conn.h> Authenticated pairing callback structure

Public Members

```
enum bt_security_err (*pairing_accept)(struct bt_conn *conn, const struct bt_conn_pairing_feat *const feat)
```

Query to proceed incoming pairing or not.

On any incoming pairing req/rsp this callback will be called for the application to decide whether to allow for the pairing to continue.

The pairing info received from the peer is passed to assist making the decision.

As this callback is synchronous the application should return a response value immediately. Otherwise it may affect the timing during pairing. Hence, this information should not be conveyed to the user to take action.

The remaining callbacks are not affected by this, but do notice that other callbacks can be called during the pairing. Eg. if pairing_confirm is registered both will be called for Just-Works pairings.

This callback may be unregistered in which case pairing continues as if the Kconfig flag was not set.

This callback is not called for BR/EDR Secure Simple Pairing (SSP).

Param conn Connection where pairing is initiated.

Param feat Pairing req/resp info.

void (*passkey_display)(struct bt_conn *conn, unsigned int passkey)

Display a passkey to the user.

When called the application is expected to display the given passkey to the user, with the expectation that the passkey will then be entered on the peer device. The passkey will be in the range of 0 - 999999, and is expected to be padded with zeroes so that six digits are always shown. E.g. the value 37 should be shown as 000037.

This callback may be set to NULL, which means that the local device lacks the ability do display a passkey. If set to non-NULL the cancel callback must also be provided, since this is the only way the application can find out that it should stop displaying the passkey.

Param conn Connection where pairing is currently active.

Param passkey Passkey to show to the user.

void (*passkey_entry)(struct bt_conn *conn)

Request the user to enter a passkey.

When called the user is expected to enter a passkey. The passkey must be in the range of 0 - 999999, and should be expected to be zero-padded, as that's how the peer device will typically be showing it (e.g. 37 would be shown as 000037).

Once the user has entered the passkey its value should be given to the stack using the $bt_conn_auth_passkey_entry()$ API.

This callback may be set to NULL, which means that the local device lacks the ability to enter a passkey. If set to non-NULL the cancel callback must also be provided, since this is the only way the application can find out that it should stop requesting the user to enter a passkey.

Param conn Connection where pairing is currently active.

void (*passkey_confirm)(struct bt_conn *conn, unsigned int passkey)

Request the user to confirm a passkey.

When called the user is expected to confirm that the given passkey is also shown on the peer device.. The passkey will be in the range of 0 - 999999, and should be zero-padded to always be six digits (e.g. 37 would be shown as 000037).

Once the user has confirmed the passkey to match, the $bt_conn_auth_passkey_confirm()$ API should be called. If the user concluded that the passkey doesn't match the $bt_conn_auth_cancel()$ API should be called.

This callback may be set to NULL, which means that the local device lacks the ability to confirm a passkey. If set to non-NULL the cancel callback must also be provided, since this is the only way the application can find out that it should stop requesting the user to confirm a passkey.

Param conn Connection where pairing is currently active.

Param passkey Passkey to be confirmed.

void (*oob_data_request)(struct bt_conn *conn, struct bt_conn_oob_info *info)

Request the user to provide Out of Band (OOB) data.

When called the user is expected to provide OOB data. The required data are indicated by the information structure.

For LE Secure Connections OOB pairing, the user should provide local OOB data, remote OOB data or both depending on their availability. Their value should be given to the stack using the $bt_le_oob_set_sc_data()$ API.

This callback must be set to non-NULL in order to support OOB pairing.

Param conn Connection where pairing is currently active.

Param info OOB pairing information.

void (*cancel)(struct bt conn *conn)

Cancel the ongoing user request.

This callback will be called to notify the application that it should cancel any previous user request (passkey display, entry or confirmation).

This may be set to NULL, but must always be provided whenever the passkey_display, passkey_entry passkey_confirm or pairing_confirm callback has been provided.

Param conn Connection where pairing is currently active.

void (*pairing_confirm)(struct bt conn *conn)

Request confirmation for an incoming pairing.

This callback will be called to confirm an incoming pairing request where none of the other user callbacks is applicable.

If the user decides to accept the pairing the $bt_conn_auth_pairing_confirm()$ API should be called. If the user decides to reject the pairing the $bt_conn_auth_cancel()$ API should be called.

This callback may be set to NULL, which means that the local device lacks the ability to confirm a pairing request. If set to non-NULL the cancel callback must also be provided, since this is the only way the application can find out that it should stop requesting the user to confirm a pairing request.

Param conn Connection where pairing is currently active.

void (*pincode_entry)(struct bt_conn *conn, bool highsec)

Request the user to enter a passkey.

This callback will be called for a BR/EDR (Bluetooth Classic) connection where pairing is being performed. Once called the user is expected to enter a PIN code with a length between 1 and 16 digits. If the *highsec* parameter is set to true the PIN code must be 16 digits long.

Once entered, the PIN code should be given to the stack using the bt conn auth pincode entry() API.

This callback may be set to NULL, however in that case pairing over BR/EDR will not be possible. If provided, the cancel callback must be provided as well.

Param conn Connection where pairing is currently active.

Param highsec true if 16 digit PIN is required.

struct bt_conn_auth_info_cb

#include <conn.h> Authenticated pairing information callback structure

```
void (*pairing_complete)(struct bt_conn *conn, bool bonded)
         notify that pairing procedure was complete.
         This callback notifies the application that the pairing procedure has been completed.
             Param conn Connection object.
             Param bonded Bond information has been distributed during the pairing procedure.
     void (*pairing_failed)(struct bt_conn *conn, enum bt_security_err reason)
         notify that pairing process has failed.
             Param conn Connection object.
             Param reason Pairing failed reason
     void (*bond_deleted)(uint8_t id, const bt_addr_le_t *peer)
         Notify that bond has been deleted.
         This callback notifies the application that the bond information for the remote peer has been deleted
             Param id Which local identity had the bond.
             Param peer Remote address.
     sys_snode_t node
         Internally used field for list handling
struct bt_br_conn_param
     #include <conn.h> Connection parameters for BR/EDR connections
union __unnamed37__
     Connection Type specific Info.
     Public Members
     struct bt_conn_le_info le
         LE Connection specific Info.
     struct bt_conn_br_info br
         BR/EDR Connection specific Info.
union __unnamed39__
```

```
struct bt_conn_le_remote_info le

LE connection remote info

struct bt_conn_br_remote_info br

BR/EDR connection remote info

union __unnamed42__

Public Members

struct bt_conn_oob_info lesc

LE Secure Connections OOB pairing parameters

struct lesc

LE Secure Connections OOB pairing parameters
```

Public Members

enum *bt_conn_oob_info* **oob_config**OOB data configuration

1.4 Data Buffers

1.4.1 API Reference

```
group bt_buf
Data buffers .

Defines
```

```
BT_BUF_RESERVE

BT_BUF_SIZE(size)

Helper to include reserved HCI data in buffer calculations

BT_BUF_ACL_SIZE(size)

Helper to calculate needed buffer size for HCI ACL packets

BT_BUF_EVT_SIZE(size)
```

Helper to calculate needed buffer size for HCI Event packets.

1.4. Data Buffers 33

```
BT_BUF_CMD_SIZE(size)
```

Helper to calculate needed buffer size for HCI Command packets.

BT_BUF_ISO_SIZE(size)

Helper to calculate needed buffer size for HCI ISO packets.

BT_BUF_ACL_RX_SIZE

Data size needed for HCI ACL RX buffers

BT_BUF_EVT_RX_SIZE

Data size needed for HCI Event RX buffers

BT_BUF_ISO_RX_SIZE

BT_BUF_ISO_RX_COUNT

BT_BUF_RX_SIZE

Data size needed for HCI ACL, HCI ISO or Event RX buffers

BT_BUF_RX_COUNT

Buffer count needed for HCI ACL, HCI ISO or Event RX buffers

BT_BUF_CMD_TX_SIZE

Data size needed for HCI Command buffers.

Enums

enum bt_buf_type

Possible types of buffers passed around the Bluetooth stack

Values:

enumerator BT_BUF_CMD

HCI command

enumerator BT_BUF_EVT

HCI event

enumerator BT_BUF_ACL_OUT

Outgoing ACL data

enumerator BT_BUF_ACL_IN

Incoming ACL data

enumerator BT_BUF_ISO_OUT

Outgoing ISO data

```
enumerator BT_BUF_ISO_IN
Incoming ISO data
enumerator BT_BUF_H4
```

H:4 data

Functions

struct net_buf *bt_buf_get_rx(enum bt_buf_type type, k_timeout_t timeout)

Allocate a buffer for incoming data

This will set the buffer type so $bt_buf_set_type()$ does not need to be explicitly called before bt_recv_prio().

Parameters

- type Type of buffer. Only BT_BUF_EVT, BT_BUF_ACL_IN and BT_BUF_ISO_IN are allowed.
- **timeout** Non-negative waiting period to obtain a buffer or one of the special values K_NO_WAIT and K_FOREVER.

Returns A new buffer.

struct net_buf *bt_buf_get_tx(enum bt_buf_type type, k_timeout_t timeout, const void *data, size_t size)
Allocate a buffer for outgoing data

This will set the buffer type so $bt_buf_set_type()$ does not need to be explicitly called before bt_send().

Parameters

- **type** Type of buffer. Only BT_BUF_CMD, BT_BUF_ACL_OUT or BT_BUF_H4, when operating on H:4 mode, are allowed.
- **timeout** Non-negative waiting period to obtain a buffer or one of the special values K_NO_WAIT and K_FOREVER.
- data Initial data to append to buffer.
- size Initial data size.

Returns A new buffer.

struct net_buf *bt_buf_get_evt(uint8_t evt, bool discardable, k_timeout_t timeout)

Allocate a buffer for an HCI Event

This will set the buffer type so $bt_buf_set_type()$ does not need to be explicitly called before bt_recv_prio() or bt_recv().

Parameters

- evt HCI event code
- **discardable** Whether the driver considers the event discardable.
- **timeout** Non-negative waiting period to obtain a buffer or one of the special values K_NO_WAIT and K_FOREVER.

Returns A new buffer.

1.4. Data Buffers 35

static inline void **bt_buf_set_type**(struct net_buf *buf, enum *bt_buf_type* type)

Set the buffer type

Parameters

- **buf** Bluetooth buffer
- type The BT_* type to set the buffer to

static inline enum bt_buf_type bt_buf_get_type(struct net_buf *buf)

Get the buffer type

Parameters

• buf - Bluetooth buffer

Returns The BT_* type to of the buffer

struct bt_buf_data

#include <buf.h> This is a base type for bt_buf user data.

1.5 Generic Access Profile (GAP)

1.5.1 API Reference

group bt_gap

Generic Access Profile (GAP).

Defines

BT_ID_DEFAULT

Convenience macro for specifying the default identity. This helps make the code more readable, especially when only one identity is supported.

BT_DATA_SERIALIZED_SIZE(data_len)

Bluetooth data serialized size.

Get the size of a serialized bt_data given its data length.

Size of 'AD Structure'->'Length' field, equal to 1. Size of 'AD Structure'->'Data'->'AD Type' field, equal to 1. Size of 'AD Structure'->'Data'->'AD Data' field, equal to data_len.

See Core Specification Version 5.4 Vol. 3 Part C, 11, Figure 11.1.

BT_DATA(_type, _data, _data_len)

Helper to declare elements of *bt_data* arrays.

This macro is mainly for creating an array of struct bt_data elements which is then passed to e.g. $bt_le_adv_start()$.

Parameters

- **_type** Type of advertising data field
- _data Pointer to the data field payload

• _data_len - Number of bytes behind the _data pointer

BT_DATA_BYTES(_type, _bytes...)

Helper to declare elements of *bt_data* arrays.

This macro is mainly for creating an array of struct bt_data elements which is then passed to e.g. $bt_le_adv_start()$.

Parameters

- _type Type of advertising data field
- _bytes Variable number of single-byte parameters

BT_LE_ADV_PARAM_INIT(_options, _int_min, _int_max, _peer)

Initialize advertising parameters.

Parameters

- **_options** Advertising Options
- _int_min Minimum advertising interval
- _int_max Maximum advertising interval
- _peer Peer address, set to NULL for undirected advertising or address of peer for directed advertising.

BT_LE_ADV_PARAM(_options, _int_min, _int_max, _peer)

Helper to declare advertising parameters inline.

Parameters

- **_options** Advertising Options
- _int_min Minimum advertising interval
- _int_max Maximum advertising interval
- _peer Peer address, set to NULL for undirected advertising or address of peer for directed advertising.

BT_LE_ADV_CONN_DIR(_peer)

BT_LE_ADV_CONN

BT_LE_ADV_CONN_NAME

BT_LE_ADV_CONN_NAME_AD

BT_LE_ADV_CONN_DIR_LOW_DUTY(_peer)

BT_LE_ADV_NCONN

Non-connectable advertising with private address

BT_LE_ADV_NCONN_NAME

Non-connectable advertising with BT_LE_ADV_OPT_USE_NAME

BT_LE_ADV_NCONN_IDENTITY

Non-connectable advertising with BT_LE_ADV_OPT_USE_IDENTITY

BT_LE_EXT_ADV_CONN_NAME

Connectable extended advertising with BT_LE_ADV_OPT_USE_NAME

BT_LE_EXT_ADV_SCAN_NAME

Scannable extended advertising with BT_LE_ADV_OPT_USE_NAME

BT_LE_EXT_ADV_NCONN

Non-connectable extended advertising with private address

BT_LE_EXT_ADV_NCONN_NAME

Non-connectable extended advertising with BT_LE_ADV_OPT_USE_NAME

BT_LE_EXT_ADV_NCONN_IDENTITY

Non-connectable extended advertising with BT_LE_ADV_OPT_USE_IDENTITY

BT_LE_EXT_ADV_CODED_NCONN

Non-connectable extended advertising on coded PHY with private address

BT_LE_EXT_ADV_CODED_NCONN_NAME

Non-connectable extended advertising on coded PHY with BT_LE_ADV_OPT_USE_NAME

BT_LE_EXT_ADV_CODED_NCONN_IDENTITY

Non-connectable extended advertising on coded PHY with BT_LE_ADV_OPT_USE_IDENTITY

BT_LE_EXT_ADV_START_PARAM_INIT(_timeout, _n_evts)

Helper to initialize extended advertising start parameters inline

Parameters

- _timeout Advertiser timeout
- _n_evts Number of advertising events

BT_LE_EXT_ADV_START_PARAM(_timeout, _n_evts)

Helper to declare extended advertising start parameters inline

Parameters

- _timeout Advertiser timeout
- _n_evts Number of advertising events

BT_LE_EXT_ADV_START_DEFAULT

BT_LE_PER_ADV_PARAM_INIT(int min, int max, options)

Helper to declare periodic advertising parameters inline

Parameters

• _int_min – Minimum periodic advertising interval

- _int_max Maximum periodic advertising interval
- **_options** Periodic advertising properties bitfield.

BT_LE_PER_ADV_PARAM(_int_min, _int_max, _options)

Helper to declare periodic advertising parameters inline

Parameters

- _int_min Minimum periodic advertising interval
- _int_max Maximum periodic advertising interval
- **_options** Periodic advertising properties bitfield.

BT_LE_PER_ADV_DEFAULT

BT_LE_SCAN_OPT_FILTER_WHITELIST

BT_LE_SCAN_PARAM_INIT(_type, _options, _interval, _window)

Initialize scan parameters.

Parameters

- _type Scan Type, BT_LE_SCAN_TYPE_ACTIVE or BT_LE_SCAN_TYPE_PASSIVE.
- **_options** Scan options
- _interval Scan Interval (N * 0.625 ms)
- **_window** Scan Window (N * 0.625 ms)

BT_LE_SCAN_PARAM(_type, _options, _interval, _window)

Helper to declare scan parameters inline.

Parameters

- _type Scan Type, BT_LE_SCAN_TYPE_ACTIVE or BT_LE_SCAN_TYPE_PASSIVE.
- **_options** Scan options
- _interval Scan Interval (N * 0.625 ms)
- _window Scan Window (N * 0.625 ms)

BT_LE_SCAN_ACTIVE

Helper macro to enable active scanning to discover new devices.

BT_LE_SCAN_PASSIVE

Helper macro to enable passive scanning to discover new devices.

This macro should be used if information required for device identification (e.g., UUID) are known to be placed in Advertising Data.

BT_LE_SCAN_CODED_ACTIVE

Helper macro to enable active scanning to discover new devices. Include scanning on Coded PHY in addition to 1M PHY.

BT_LE_SCAN_CODED_PASSIVE

Helper macro to enable passive scanning to discover new devices. Include scanning on Coded PHY in addition to 1M PHY.

This macro should be used if information required for device identification (e.g., UUID) are known to be placed in Advertising Data.

Typedefs

```
typedef void (*bt_ready_cb_t)(int err)
```

Callback for notifying that Bluetooth has been enabled.

Param err zero on success or (negative) error code otherwise.

```
typedef void bt_le_scan_cb_t(const bt_addr_le_t *addr, int8_t rssi, uint8_t adv_type, struct net_buf_simple *buf)
```

Callback type for reporting LE scan results.

A function of this type is given to the $bt_le_scan_start()$ function and will be called for any discovered LE device.

Param addr Advertiser LE address and type.

Param rssi Strength of advertiser signal.

Param adv_type Type of advertising response from advertiser. Uses the BT_GAP_ADV_TYPE_* values.

Param buf Buffer containing advertiser data.

```
typedef void bt_br_discovery_cb_t(struct bt_br_discovery_result *results, size_t count)
```

Callback type for reporting BR/EDR discovery (inquiry) results.

A callback of this type is given to the $bt_br_discovery_start()$ function and will be called at the end of the discovery with information about found devices populated in the results array.

Param results Storage used for discovery results

Param count Number of valid discovery results.

Enums

Advertising options

Values:

```
enumerator BT_LE_ADV_OPT_NONE
```

Convenience value when no options are specified.

```
enumerator BT_LE_ADV_OPT_CONNECTABLE
```

Advertise as connectable.

Advertise as connectable. If not connectable then the type of advertising is determined by providing scan response data. The advertiser address is determined by the type of advertising and/or enabling privacy @kconfig{CONFIG_BT_PRIVACY}.

enumerator BT_LE_ADV_OPT_ONE_TIME

Advertise one time.

Don't try to resume connectable advertising after a connection. This option is only meaningful when used together with BT_LE_ADV_OPT_CONNECTABLE. If set the advertising will be stopped when $bt_le_adv_stop()$ is called or when an incoming (peripheral) connection happens. If this option is not set the stack will take care of keeping advertising enabled even as connections occur. If Advertising directed or the advertiser was started with $bt_le_ext_adv_start$ then this behavior is the default behavior and this flag has no effect.

enumerator BT_LE_ADV_OPT_USE_IDENTITY

Advertise using identity address.

Advertise using the identity address as the advertiser address.

Note: The address used for advertising will not be the same as returned by $bt_le_oob_get_local$, instead bt_id_get should be used to get the LE address.

Warning: This will compromise the privacy of the device, so care must be taken when using this option.

enumerator BT_LE_ADV_OPT_USE_NAME

Advertise using GAP device name.

Include the GAP device name automatically when advertising. By default the GAP device name is put at the end of the scan response data.

When advertising using @ref BT_LE_ADV_OPT_EXT_ADV and not @ref BT_LE_ADV_OPT_SCANNABLE then it will be put at the end of the advertising data.

If the GAP device name does not fit into advertising data it will be converted to a shortened name if possible.

@ref BT_LE_ADV_OPT_FORCE_NAME_IN_AD can be used to force the device name to appear in the advertising data of an advert with scan response data.

The application can set the device name itself by including the following in the advertising data.

@code

BT_DATA(BT_DATA_NAME_COMPLETE, name, sizeof(name) - 1)
@endcode

enumerator BT_LE_ADV_OPT_DIR_MODE_LOW_DUTY

Low duty cycle directed advertising.

Use low duty directed advertising mode, otherwise high duty mode will be used.

enumerator BT_LE_ADV_OPT_DIR_ADDR_RPA

Directed advertising to privacy-enabled peer.

Enable use of Resolvable Private Address (RPA) as the target address in directed advertisements. This is required if the remote device is privacy-enabled and supports address resolution of the target address in directed advertisement. It is the responsibility of the application to check that the remote device supports address resolution of directed advertisements by reading its Central Address Resolution characteristic.

enumerator BT_LE_ADV_OPT_FILTER_SCAN_REQ

Use filter accept list to filter devices that can request scan response data.

enumerator BT_LE_ADV_OPT_FILTER_CONN

Use filter accept list to filter devices that can connect.

enumerator BT_LE_ADV_OPT_NOTIFY_SCAN_REQ

Notify the application when a scan response data has been sent to an active scanner.

enumerator BT_LE_ADV_OPT_SCANNABLE

Support scan response data.

When used together with $BT_LE_ADV_OPT_EXT_ADV$ then this option cannot be used together with the $BT_LE_ADV_OPT_CONNECTABLE$ option. When used together with $BT_LE_ADV_OPT_EXT_ADV$ then scan response data must be set.

enumerator BT_LE_ADV_OPT_EXT_ADV

Advertise with extended advertising.

This options enables extended advertising in the advertising set. In extended advertising the advertising set will send a small header packet on the three primary advertising channels. This small header points to the advertising data packet that will be sent on one of the 37 secondary advertising channels. The advertiser will send primary advertising on LE 1M PHY, and secondary advertising on LE 2M PHY. Connections will be established on LE 2M PHY.

Without this option the advertiser will send advertising data on the three primary advertising channels.

Note: Enabling this option requires extended advertising support in the peer devices scanning for advertisement packets.

Note: This cannot be used with *bt_le_adv_start()*.

enumerator BT_LE_ADV_OPT_NO_2M

Disable use of LE 2M PHY on the secondary advertising channel.

Disabling the use of LE 2M PHY could be necessary if scanners don't support the LE 2M PHY. The advertiser will send primary advertising on LE 1M PHY, and secondary advertising on LE 1M PHY. Connections will be established on LE 1M PHY.

Note: Cannot be set if BT_LE_ADV_OPT_CODED is set.

Note: Requires *BT_LE_ADV_OPT_EXT_ADV*.

enumerator BT_LE_ADV_OPT_CODED

Advertise on the LE Coded PHY (Long Range).

The advertiser will send both primary and secondary advertising on the LE Coded PHY. This gives the advertiser increased range with the trade-off of lower data rate and higher power consumption. Connections will be established on LE Coded PHY.

Note: Requires BT_LE_ADV_OPT_EXT_ADV

enumerator BT_LE_ADV_OPT_ANONYMOUS

Advertise without a device address (identity or RPA).

Note: Requires BT LE ADV OPT EXT ADV

enumerator BT_LE_ADV_OPT_USE_TX_POWER

Advertise with transmit power.

Note: Requires *BT_LE_ADV_OPT_EXT_ADV*

enumerator BT_LE_ADV_OPT_DISABLE_CHAN_37

Disable advertising on channel index 37.

enumerator BT_LE_ADV_OPT_DISABLE_CHAN_38

Disable advertising on channel index 38.

enumerator BT_LE_ADV_OPT_DISABLE_CHAN_39

Disable advertising on channel index 39.

enumerator BT_LE_ADV_OPT_FORCE_NAME_IN_AD

Put GAP device name into advert data.

Will place the GAP device name into the advertising data rather than the scan response data.

Note: Requires *BT_LE_ADV_OPT_USE_NAME*

enumerator BT_LE_ADV_OPT_USE_NRPA

Advertise using a Non-Resolvable Private Address.

A new NRPA is set when updating the advertising parameters.

This is an advanced feature; most users will want to enable @kconfig{CONFIG_BT_EXT_ADV} instead.

Note: Not implemented when @kconfig{CONFIG_BT_PRIVACY}.

Note: Mutually exclusive with BT_LE_ADV_OPT_USE_IDENTITY.

Periodic Advertising options

Values:

enumerator BT_LE_PER_ADV_OPT_NONE

Convenience value when no options are specified.

enumerator BT_LE_PER_ADV_OPT_USE_TX_POWER

Advertise with transmit power.

Note: Requires *BT_LE_ADV_OPT_EXT_ADV*

enumerator BT_LE_PER_ADV_OPT_INCLUDE_ADI

Advertise with included AdvDataInfo (ADI).

Note: Requires *BT_LE_ADV_OPT_EXT_ADV*

Periodic advertising sync options

Values:

enumerator BT_LE_PER_ADV_SYNC_OPT_NONE

Convenience value when no options are specified.

enumerator BT_LE_PER_ADV_SYNC_OPT_USE_PER_ADV_LIST

Use the periodic advertising list to sync with advertiser.

When this option is set, the address and SID of the parameters are ignored.

enumerator BT_LE_PER_ADV_SYNC_OPT_REPORTING_INITIALLY_DISABLED

Disables periodic advertising reports.

No advertisement reports will be handled until enabled.

enumerator BT_LE_PER_ADV_SYNC_OPT_FILTER_DUPLICATE

Filter duplicate Periodic Advertising reports

enumerator BT_LE_PER_ADV_SYNC_OPT_DONT_SYNC_AOA

Sync with Angle of Arrival (AoA) constant tone extension

enumerator BT_LE_PER_ADV_SYNC_OPT_DONT_SYNC_AOD_1US

Sync with Angle of Departure (AoD) 1 us constant tone extension

enumerator BT_LE_PER_ADV_SYNC_OPT_DONT_SYNC_AOD_2US

Sync with Angle of Departure (AoD) 2 us constant tone extension

enumerator BT_LE_PER_ADV_SYNC_OPT_SYNC_ONLY_CONST_TONE_EXT

Do not sync to packets without a constant tone extension

Periodic Advertising Sync Transfer options

Values:

enumerator BT_LE_PER_ADV_SYNC_TRANSFER_OPT_NONE

Convenience value when no options are specified.

enumerator BT_LE_PER_ADV_SYNC_TRANSFER_OPT_SYNC_NO_AOA

No Angle of Arrival (AoA)

Do not sync with Angle of Arrival (AoA) constant tone extension

enumerator BT_LE_PER_ADV_SYNC_TRANSFER_OPT_SYNC_NO_AOD_1US

No Angle of Departure (AoD) 1 us.

Do not sync with Angle of Departure (AoD) 1 us constant tone extension

enumerator BT_LE_PER_ADV_SYNC_TRANSFER_OPT_SYNC_NO_AOD_2US

No Angle of Departure (AoD) 2.

Do not sync with Angle of Departure (AoD) 2 us constant tone extension

enumerator BT_LE_PER_ADV_SYNC_TRANSFER_OPT_SYNC_ONLY_CTE

Only sync to packets with constant tone extension

enumerator BT_LE_PER_ADV_SYNC_TRANSFER_OPT_REPORTING_INITIALLY_DISABLED

Sync to received PAST packets but don't generate sync reports.

This option must not be set at the same time as $BT_LE_PER_ADV_SYNC_TRANSFER_OPT_FILTER_DUPLICATES$.

enumerator BT_LE_PER_ADV_SYNC_TRANSFER_OPT_FILTER_DUPLICATES

Sync to received PAST packets and generate sync reports with duplicate filtering.

This option must not be set at the same time as BT_LE_PER_ADV_SYNC_TRANSFER_OPT_REPORTING_INITIALLY_

Values:

enumerator BT_LE_SCAN_OPT_NONE

Convenience value when no options are specified.

enumerator BT_LE_SCAN_OPT_FILTER_DUPLICATE

Filter duplicates.

enumerator BT_LE_SCAN_OPT_FILTER_ACCEPT_LIST

Filter using filter accept list.

enumerator BT_LE_SCAN_OPT_CODED

Enable scan on coded PHY (Long Range).

enumerator BT_LE_SCAN_OPT_NO_1M

Disable scan on 1M phy.

Note: Requires *BT_LE_SCAN_OPT_CODED*.

Values:

enumerator BT_LE_SCAN_TYPE_PASSIVE

Scan without requesting additional information from advertisers.

enumerator BT_LE_SCAN_TYPE_ACTIVE

Scan and request additional information from advertisers.

Using this scan type will automatically send scan requests to all devices. Scan responses are received in the same manner and using the same callbacks as advertising reports.

Functions

int bt_enable(bt_ready_cb_t cb)

Enable Bluetooth.

Enable Bluetooth. Must be the called before any calls that require communication with the local Bluetooth hardware.

When @kconfig{CONFIG_BT_SETTINGS} is enabled, the application must load the Bluetooth settings after this API call successfully completes before Bluetooth APIs can be used. Loading the settings before calling this function is insufficient. Bluetooth settings can be loaded with settings_load() or settings_load_subtree() with argument "bt". The latter selectively loads only Bluetooth settings and is recommended if settings_load() has been called earlier.

Parameters

• **cb** – Callback to notify completion or NULL to perform the enabling synchronously.

Returns Zero on success or (negative) error code otherwise.

bool bt_is_ready(void)

Check if Bluetooth is ready.

Returns true when Bluetooth is ready, false otherwise

int bt_set_name(const char *name)

Set Bluetooth Device Name.

Set Bluetooth GAP Device Name.

When advertising with device name in the advertising data the name should be updated by calling $bt_le_adv_update_data$ or $bt_le_ext_adv_set_data$.

See also:

@kconfig{CONFIG_BT_DEVICE_NAME_MAX}.

Note: Requires @kconfig{CONFIG_BT_DEVICE_NAME_DYNAMIC}.

Parameters

• name - New name

Returns Zero on success or (negative) error code otherwise.

const char *bt_get_name(void)

Get Bluetooth Device Name.

Get Bluetooth GAP Device Name.

Returns Bluetooth Device Name

uint16_t bt_get_appearance(void)

Get local Bluetooth appearance.

Bluetooth Appearance is a description of the external appearance of a device in terms of an Appearance Value.

See also:

https://specificationrefs.bluetooth.com/assigned-values/Appearance%20Values.pdf

Returns Appearance Value of local Bluetooth host.

int bt_set_appearance(uint16_t new_appearance)

Set local Bluetooth appearance.

Automatically preserves the new appearance across reboots if @kconfig{CONFIG_BT_SETTINGS} is enabled.

This symbol is linkable if @kconfig{CONFIG_BT_DEVICE_APPEARANCE_DYNAMIC} is enabled.

Parameters

• new_appearance - Appearance Value

Return values

- 0 Success.
- other Persistent storage failed. Appearance was not updated.

```
void bt_id_get(bt_addr_le_t *addrs, size_t *count)
```

Get the currently configured identities.

Returns an array of the currently configured identity addresses. To make sure all available identities can be retrieved, the number of elements in the *addrs* array should be CONFIG_BT_ID_MAX. The identity identifier that some APIs expect (such as advertising parameters) is simply the index of the identity in the *addrs* array.

If *addrs* is passed as NULL, then returned *count* contains the count of all available identities that can be retrieved with a subsequent call to this function with non-NULL *addrs* parameter.

Note: Deleted identities may show up as *BT_ADDR_LE_ANY* in the returned array.

Parameters

- addrs Array where to store the configured identities.
- **count** Should be initialized to the array size. Once the function returns it will contain the number of returned identities.

```
int bt_id_create(bt_addr_le_t *addr, uint8_t *irk)
```

Create a new identity.

Create a new identity using the given address and IRK. This function can be called before calling $bt_enable()$. However, the new identity will only be stored persistently in flash when this API is used after $bt_enable()$. The reason is that the persistent settings are loaded after $bt_enable()$ and would therefore cause potential conflicts with the stack blindly overwriting what's stored in flash. The identity will also not be written to flash in case a pre-defined address is provided, since in such a situation the app clearly has some place it got the address from and will be able to repeat the procedure on every power cycle, i.e. it would be redundant to also store the information in flash.

Generating random static address or random IRK is not supported when calling this function before $bt_enable()$.

If the application wants to have the stack randomly generate identities and store them in flash for later recovery, the way to do it would be to first initialize the stack (using bt_enable), then call settings_load(), and after that check with $bt_id_get()$ how many identities were recovered. If an insufficient amount of identities were recovered the app may then call $bt_id_get()$ to create new ones.

If supported by the HCI driver (indicated by setting @kconfig{CONFIG_BT_HCI_SET_PUBLIC_ADDR}), the first call to this function can be used to set the controller's public identity address. This call must happen before calling *bt_enable()*. Subsequent calls always add/generate random static addresses.

Parameters

- addr Address to use for the new identity. If NULL or initialized to BT_ADDR_LE_ANY the stack will generate a new random static address for the identity and copy it to the given parameter upon return from this function (in case the parameter was non-NULL).
- **irk** Identity Resolving Key (16 bytes) to be used with this identity. If set to all zeroes or NULL, the stack will generate a random IRK for the identity and copy it back to the parameter upon return from this function (in case the parameter was non-NULL). If privacy @kconfig{CONFIG BT PRIVACY} is not enabled this parameter must be NULL.

Returns Identify identifier (>= 0) in case of success, or a negative error code on failure.

```
int bt_id_reset(uint8_t id, bt_addr_le_t *addr, uint8_t *irk)
```

Reset/reclaim an identity for reuse.

The semantics of the *addr* and *irk* parameters of this function are the same as with *bt_id_create()*. The difference is the first *id* parameter that needs to be an existing identity (if it doesn't exist this function will return an error). When given an existing identity this function will disconnect any connections created using it, remove any pairing keys or other data associated with it, and then create a new identity in the same slot, based on the *addr* and *irk* parameters.

Note: the default identity (BT_ID_DEFAULT) cannot be reset, i.e. this API will return an error if asked to do that.

Parameters

- **id** Existing identity identifier.
- addr Address to use for the new identity. If NULL or initialized to BT_ADDR_LE_ANY the stack will generate a new static random address for the identity and copy it to the given parameter upon return from this function (in case the parameter was non-NULL).
- **irk** Identity Resolving Key (16 bytes) to be used with this identity. If set to all zeroes or NULL, the stack will generate a random IRK for the identity and copy it back to the parameter upon return from this function (in case the parameter was non-NULL). If privacy @kconfig{CONFIG_BT_PRIVACY} is not enabled this parameter must be NULL.

Returns Identity identifier (>= 0) in case of success, or a negative error code on failure.

int bt_id_delete(uint8_t id)

Delete an identity.

When given a valid identity this function will disconnect any connections created using it, remove any pairing keys or other data associated with it, and then flag is as deleted, so that it can not be used for any operations. To take back into use the slot the identity was occupying the $bt_id_reset()$ API needs to be used.

Note: the default identity (BT_ID_DEFAULT) cannot be deleted, i.e. this API will return an error if asked to do that.

Parameters

• **id** – Existing identity identifier.

Returns 0 in case of success, or a negative error code on failure.

size_t bt_data_get_len(const struct bt_data data[], size_t data_count)

Get the total size (in bytes) of a given set of *bt_data* structures.

Parameters

- data [in] Array of bt_data structures.
- data_count [in] Number of *bt_data* structures in data.

Returns Size of the concatenated data, built from the *bt_data* structure set.

size_t **bt_data_serialize**(const struct *bt_data* *input, uint8_t *output)

Serialize a *bt_data* struct into an advertising structure (a flat byte array).

The data are formatted according to the Bluetooth Core Specification v. 5.4, vol. 3, part C, 11.

Parameters

- **input [in]** Single *bt data* structure to read from.
- **output [out]** Buffer large enough to store the advertising structure in input. The size of it must be at least the size of the input->data_len + 2 (for the type and the length).

Returns Number of bytes written in output.

int **bt_le_adv_start**(const struct *bt_le_adv_param* *param, const struct *bt_data* *ad, size_t ad_len, const struct *bt_data* *sd, size_t sd_len)

Start advertising.

Set advertisement data, scan response data, advertisement parameters and start advertising.

When the advertisement parameter peer address has been set the advertising will be directed to the peer. In this case advertisement data and scan response data parameters are ignored. If the mode is high duty cycle the timeout will be $BT_GAP_ADV_HIGH_DUTY_CYCLE_MAX_TIMEOUT$.

This function cannot be used with *BT_LE_ADV_OPT_EXT_ADV* in the param.options. For extended advertising, the bt_le_ext_adv_* functions must be used.

Parameters

- param Advertising parameters.
- **ad** Data to be used in advertisement packets.
- ad_len Number of elements in ad
- **sd** Data to be used in scan response packets.
- sd_len Number of elements in sd

Returns Zero on success or (negative) error code otherwise.

Returns -ENOMEM No free connection objects available for connectable advertiser.

Returns -ECONNREFUSED When connectable advertising is requested and there is already maximum number of connections established in the controller. This error code is only guaranteed when using Zephyr controller, for other controllers code returned in this case may be -EIO.

int **bt_le_adv_update_data**(const struct *bt_data* *ad, size_t ad_len, const struct *bt_data* *sd, size_t sd_len)
Update advertising.

Update advertisement and scan response data.

Parameters

- **ad** Data to be used in advertisement packets.
- ad_len Number of elements in ad
- sd Data to be used in scan response packets.
- sd_len Number of elements in sd

Returns Zero on success or (negative) error code otherwise.

int bt_le_adv_stop(void)

Stop advertising.

Stops ongoing advertising.

Returns Zero on success or (negative) error code otherwise.

int **bt_le_ext_adv_create**(const struct *bt_le_adv_param* *param, const struct *bt_le_ext_adv_cb* *cb, struct bt_le_ext_adv **adv)

Create advertising set.

Create a new advertising set and set advertising parameters. Advertising parameters can be updated with $bt_le_ext_adv_update_param$.

Parameters

- param [in] Advertising parameters.
- **cb [in]** Callback struct to notify about advertiser activity. Can be NULL. Must point to valid memory during the lifetime of the advertising set.
- adv [out] Valid advertising set object on success.

Returns Zero on success or (negative) error code otherwise.

int **bt_le_ext_adv_start**(struct bt_le_ext_adv *adv, struct bt_le_ext_adv_start_param *param)

Start advertising with the given advertising set.

If the advertiser is limited by either the timeout or number of advertising events the application will be notified by the advertiser sent callback once the limit is reached. If the advertiser is limited by both the timeout and the number of advertising events then the limit that is reached first will stop the advertiser.

Parameters

- adv Advertising set object.
- param Advertise start parameters.

int bt_le_ext_adv_stop(struct bt_le_ext_adv *adv)

Stop advertising with the given advertising set.

Stop advertising with a specific advertising set. When using this function the advertising sent callback will not be called.

Parameters

• adv – Advertising set object.

Returns Zero on success or (negative) error code otherwise.

int **bt_le_ext_adv_set_data**(struct bt_le_ext_adv *adv, const struct *bt_data* *ad, size_t ad_len, const struct *bt_data* *sd, size_t sd_len)

Set an advertising set's advertising or scan response data.

Set advertisement data or scan response data. If the advertising set is currently advertising then the advertising data will be updated in subsequent advertising events.

When both $BT_LE_ADV_OPT_EXT_ADV$ and $BT_LE_ADV_OPT_SCANNABLE$ are enabled then advertising data is ignored. When $BT_LE_ADV_OPT_SCANNABLE$ is not enabled then scan response data is ignored.

If the advertising set has been configured to send advertising data on the primary advertising channels then the maximum data length is BT_GAP_ADV_MAX_ADV_DATA_LEN bytes. If the advertising set has been

configured for extended advertising, then the maximum data length is defined by the controller with the maximum possible of BT_GAP_ADV_MAX_EXT_ADV_DATA_LEN bytes.

Note: Not all scanners support extended data length advertising data.

Note: When updating the advertising data while advertising the advertising data and scan response data length must be smaller or equal to what can be fit in a single advertising packet. Otherwise the advertiser must be stopped.

Parameters

- adv Advertising set object.
- ad Data to be used in advertisement packets.
- ad_len Number of elements in ad
- **sd** Data to be used in scan response packets.
- sd_len Number of elements in sd

Returns Zero on success or (negative) error code otherwise.

int **bt_le_ext_adv_update_param**(struct bt_le_ext_adv *adv, const struct bt_le_adv_param *param)

Update advertising parameters.

Update the advertising parameters. The function will return an error if the advertiser set is currently advertising. Stop the advertising set before calling this function.

Note: When changing the option $BT_LE_ADV_OPT_USE_NAME$ then $bt_le_ext_adv_set_data$ needs to be called in order to update the advertising data and scan response data.

Parameters

- adv Advertising set object.
- **param** Advertising parameters.

Returns Zero on success or (negative) error code otherwise.

int bt_le_ext_adv_delete(struct bt le ext adv *adv)

Delete advertising set.

Delete advertising set. This will free up the advertising set and make it possible to create a new advertising set

Returns Zero on success or (negative) error code otherwise.

uint8_t bt_le_ext_adv_get_index(struct bt_le_ext_adv *adv)

Get array index of an advertising set.

This function is used to map bt_adv to index of an array of advertising sets. The array has CON-FIG_BT_EXT_ADV_MAX_ADV_SET elements.

Parameters

• adv – Advertising set.

Returns Index of the advertising set object. The range of the returned value is 0..CONFIG_BT_EXT_ADV_MAX_ADV_SET-1

int **bt_le_ext_adv_get_info** (const struct bt_le_ext_adv *adv, struct bt_le_ext_adv_info *info)

Get advertising set info.

Parameters

- adv Advertising set object
- **info** Advertising set info object

Returns Zero on success or (negative) error code on failure.

int bt_le_per_adv_set_param(struct bt_le_ext_adv *adv, const struct bt_le_per_adv_param *param)

Set or update the periodic advertising parameters.

The periodic advertising parameters can only be set or updated on an extended advertisement set which is neither scannable, connectable nor anonymous.

Parameters

- adv Advertising set object.
- param Advertising parameters.

Returns Zero on success or (negative) error code otherwise.

int bt_le_per_adv_set_data(const struct bt_le_ext_adv *adv, const struct bt_data *ad, size_t ad_len)

Set or update the periodic advertising data.

The periodic advertisement data can only be set or updated on an extended advertisement set which is neither scannable, connectable nor anonymous.

Parameters

- adv Advertising set object.
- ad Advertising data.
- ad_len Advertising data length.

Returns Zero on success or (negative) error code otherwise.

int **bt_le_per_adv_set_subevent_data**(const struct bt_le_ext_adv *adv, uint8_t num_subevents, const struct *bt_le_per_adv_subevent_data_params* *params)

Set the periodic advertising with response subevent data.

Set the data for one or more subevents of a Periodic Advertising with Responses Advertiser in reply data request.

Parameters

- adv The extended advertiser the PAwR train belongs to.
- **num_subevents** The number of subevents to set data for.
- params Subevent parameters.

Pre There are num_subevents elements in params.

Pre The controller has requested data for the subevents in params.

Returns Zero on success or (negative) error code otherwise.

int bt_le_per_adv_start(struct bt_le_ext_adv *adv)

Starts periodic advertising.

Enabling the periodic advertising can be done independently of extended advertising, but both periodic advertising and extended advertising shall be enabled before any periodic advertising data is sent. The periodic advertising and extended advertising can be enabled in any order.

Once periodic advertising has been enabled, it will continue advertising until $bt_le_per_adv_stop()$ has been called, or if the advertising set is deleted by $bt_le_ext_adv_delete()$. Calling $bt_le_ext_adv_stop()$ will not stop the periodic advertising.

Parameters

• adv – Advertising set object.

Returns Zero on success or (negative) error code otherwise.

```
int bt_le_per_adv_stop(struct bt_le_ext_adv *adv)
```

Stops periodic advertising.

Disabling the periodic advertising can be done independently of extended advertising. Disabling periodic advertising will not disable extended advertising.

Parameters

• **adv** – Advertising set object.

Returns Zero on success or (negative) error code otherwise.

```
uint8_t bt_le_per_adv_sync_get_index(struct bt_le_per_adv_sync *per_adv_sync)
```

Get array index of an periodic advertising sync object.

This function is get the index of an array of periodic advertising sync objects. The array has CON-FIG_BT_PER_ADV_SYNC_MAX elements.

Parameters

• **per_adv_sync** – The periodic advertising sync object.

Returns Index of the periodic advertising sync object. The range of the returned value is 0..CONFIG_BT_PER_ADV_SYNC_MAX-1

```
struct bt_le_per_adv_sync *bt_le_per_adv_sync_lookup_index(uint8_t index)
```

Get a periodic advertising sync object from the array index.

This function is to get the periodic advertising sync object from the array index. The array has CON-FIG_BT_PER_ADV_SYNC_MAX elements.

Parameters

• **index** – The index of the periodic advertising sync object. The range of the index value is 0..CONFIG_BT_PER_ADV_SYNC_MAX-1

Returns The periodic advertising sync object of the array index or NULL if invalid index.

```
int bt_le_per_adv_sync_get_info(struct bt_le_per_adv_sync *per_adv_sync, struct bt_le_per_adv_sync_info *info)
```

Get periodic adv sync information.

Parameters

- per_adv_sync Periodic advertising sync object.
- **info** Periodic advertising sync info object

Returns Zero on success or (negative) error code on failure.

```
struct bt_le_per_adv_sync *bt_le_per_adv_sync_lookup_addr(const bt_addr_le_t *adv_addr, uint8_t sid)
```

Look up an existing periodic advertising sync object by advertiser address.

Parameters

- adv_addr Advertiser address.
- **sid** The advertising set ID.

Returns Periodic advertising sync object or NULL if not found.

```
int bt_le_per_adv_sync_create(const struct bt_le_per_adv_sync_param *param, struct bt_le_per_adv_sync **out_sync)
```

Create a periodic advertising sync object.

Create a periodic advertising sync object that can try to synchronize to periodic advertising reports from an advertiser. Scan shall either be disabled or extended scan shall be enabled.

This function does not timeout, and will continue to look for an advertiser until it either finds it or $bt_le_per_adv_sync_delete()$ is called. It is thus suggested to implement a timeout when using this, if it is expected to find the advertiser within a reasonable timeframe.

Parameters

- param [in] Periodic advertising sync parameters.
- out_sync [out] Periodic advertising sync object on.

Returns Zero on success or (negative) error code otherwise.

```
int bt_le_per_adv_sync_delete(struct bt_le_per_adv_sync *per_adv_sync)
```

Delete periodic advertising sync.

Delete the periodic advertising sync object. Can be called regardless of the state of the sync. If the syncing is currently syncing, the syncing is cancelled. If the sync has been established, it is terminated. The periodic advertising sync object will be invalidated afterwards.

If the state of the sync object is syncing, then a new periodic advertising sync object may not be created until the controller has finished canceling this object.

Parameters

• **per_adv_sync** – The periodic advertising sync object.

Returns Zero on success or (negative) error code otherwise.

```
void bt_le_per_adv_sync_cb_register(struct bt_le_per_adv_sync_cb *cb)
```

Register periodic advertising sync callbacks.

Adds the callback structure to the list of callback structures for periodic advertising syncs.

This callback will be called for all periodic advertising sync activity, such as synced, terminated and when data is received.

Parameters

• **cb** – Callback struct. Must point to memory that remains valid.

```
int bt_le_per_adv_sync_recv_enable(struct bt le per adv sync *per adv sync)
```

Enables receiving periodic advertising reports for a sync.

If the sync is already receiving the reports, -EALREADY is returned.

Parameters

• per_adv_sync - The periodic advertising sync object.

Returns Zero on success or (negative) error code otherwise.

int bt_le_per_adv_sync_recv_disable(struct bt_le_per_adv_sync *per_adv_sync)

Disables receiving periodic advertising reports for a sync.

If the sync report receiving is already disabled, -EALREADY is returned.

Parameters

• **per_adv_sync** – The periodic advertising sync object.

Returns Zero on success or (negative) error code otherwise.

int **bt_le_per_adv_sync_transfer**(const struct bt_le_per_adv_sync *per_adv_sync, const struct bt_conn *conn, uint16_t service_data)

Transfer the periodic advertising sync information to a peer device.

This will allow another device to quickly synchronize to the same periodic advertising train that this device is currently synced to.

Parameters

- **per_adv_sync** The periodic advertising sync to transfer.
- conn The peer device that will receive the sync information.
- **service_data** Application service data provided to the remote host.

Returns Zero on success or (negative) error code otherwise.

int **bt_le_per_adv_set_info_transfer**(const struct bt_le_ext_adv *adv, const struct bt_conn *conn, uint16_t service_data)

Transfer the information about a periodic advertising set.

This will allow another device to quickly synchronize to periodic advertising set from this device.

Parameters

- adv The periodic advertising set to transfer info of.
- conn The peer device that will receive the information.
- **service_data** Application service data provided to the remote host.

Returns Zero on success or (negative) error code otherwise.

int **bt_le_per_adv_sync_transfer_subscribe**(const struct bt_conn *conn, const struct bt_le_per_adv_sync_transfer_param *param)

Subscribe to periodic advertising sync transfers (PASTs).

Sets the parameters and allow other devices to transfer periodic advertising syncs.

Parameters

- **conn** The connection to set the parameters for. If NULL default parameters for all connections will be set. Parameters set for specific connection will always have precedence.
- param The periodic advertising sync transfer parameters.

Returns Zero on success or (negative) error code otherwise.

int bt_le_per_adv_sync_transfer_unsubscribe(const struct bt_conn *conn)

Unsubscribe from periodic advertising sync transfers (PASTs).

Remove the parameters that allow other devices to transfer periodic advertising syncs.

Parameters

• **conn** – The connection to remove the parameters for. If NULL default parameters for all connections will be removed. Unsubscribing for a specific device, will still allow other devices to transfer periodic advertising syncs.

Returns Zero on success or (negative) error code otherwise.

```
int bt_le_per_adv_list_add(const bt_addr_le_t *addr, uint8_t sid)
```

Add a device to the periodic advertising list.

Add peer device LE address to the periodic advertising list. This will make it possibly to automatically create a periodic advertising sync to this device.

Parameters

- addr Bluetooth LE identity address.
- sid The advertising set ID. This value is obtained from the bt_le_scan_recv_info in the scan callback.

Returns Zero on success or (negative) error code otherwise.

```
int bt_le_per_adv_list_remove(const bt addr le t*addr, uint8 t sid)
```

Remove a device from the periodic advertising list.

Removes peer device LE address from the periodic advertising list.

Parameters

- addr Bluetooth LE identity address.
- **sid** The advertising set ID. This value is obtained from the *bt_le_scan_recv_info* in the scan callback.

Returns Zero on success or (negative) error code otherwise.

int bt_le_per_adv_list_clear(void)

Clear the periodic advertising list.

Clears the entire periodic advertising list.

Returns Zero on success or (negative) error code otherwise.

```
int bt_le_scan_start(const struct bt le scan param *param, bt le scan cb t cb)
```

Start (LE) scanning.

Start LE scanning with given parameters and provide results through the specified callback.

Note: The LE scanner by default does not use the Identity Address of the local device when @kconfig{CONFIG_BT_PRIVACY} is disabled. This is to prevent the active scanner from disclosing the identity information when requesting additional information from advertisers. In order to enable directed advertiser reports then @kconfig{CONFIG_BT_SCAN_WITH_IDENTITY} must be enabled.

Parameters

• param – Scan parameters.

• **cb** – Callback to notify scan results. May be NULL if callback registration through $bt_le_scan_cb_register$ is preferred.

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

int bt_le_scan_stop(void)

Stop (LE) scanning.

Stops ongoing LE scanning.

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

void bt_le_scan_cb_register(struct bt_le_scan_cb *cb)

Register scanner packet callbacks.

Adds the callback structure to the list of callback structures that monitors scanner activity.

This callback will be called for all scanner activity, regardless of what API was used to start the scanner.

Parameters

• **cb** – Callback struct. Must point to memory that remains valid.

void bt_le_scan_cb_unregister(struct bt_le_scan_cb *cb)

Unregister scanner packet callbacks.

Remove the callback structure from the list of scanner callbacks.

Parameters

• **cb** – Callback struct. Must point to memory that remains valid.

```
int bt_le_filter_accept_list_add(const bt_addr_le_t *addr)
```

Add device (LE) to filter accept list.

Add peer device LE address to the filter accept list.

Note: The filter accept list cannot be modified when an LE role is using the filter accept list, i.e advertiser or scanner using a filter accept list or automatic connecting to devices using filter accept list.

Parameters

• addr – Bluetooth LE identity address.

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

static inline int **bt_le_whitelist_add**(const *bt_addr_le_t* *addr)

```
int bt_le_filter_accept_list_remove(const bt_addr_le_t *addr)
```

Remove device (LE) from filter accept list.

Remove peer device LE address from the filter accept list.

Note: The filter accept list cannot be modified when an LE role is using the filter accept list, i.e advertiser or scanner using a filter accept list or automatic connecting to devices using filter accept list.

Parameters

• addr – Bluetooth LE identity address.

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

static inline int **bt_le_whitelist_rem**(const *bt_addr_le_t* *addr)

int bt_le_filter_accept_list_clear(void)

Clear filter accept list.

Clear all devices from the filter accept list.

Note: The filter accept list cannot be modified when an LE role is using the filter accept list, i.e advertiser or scanner using a filter accept list or automatic connecting to devices using filter accept list.

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

static inline int bt_le_whitelist_clear(void)

int bt_le_set_chan_map(uint8_t chan_map[5])

Set (LE) channel map.

Parameters

• chan_map - Channel map.

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

int bt_le_set_rpa_timeout(uint16_t new_rpa_timeout)

Set the Resolvable Private Address timeout in runtime.

The new RPA timeout value will be used for the next RPA rotation and all subsequent rotations until another override is scheduled with this API.

Initially, the if @kconfig{CONFIG_BT_RPA_TIMEOUT} is used as the RPA timeout.

This symbol is linkable if @kconfig{CONFIG BT RPA TIMEOUT DYNAMIC} is enabled.

Parameters

• new_rpa_timeout - Resolvable Private Address timeout in seconds

Return values

- **0** Success.
- **-EINVAL** RPA timeout value is invalid. Valid range is 1s 3600s.

void **bt_data_parse**(struct net_buf_simple *ad, bool (*func)(struct *bt_data* *data, void *user_data), void *user_data)

Helper for parsing advertising (or EIR or OOB) data.

A helper for parsing the basic data types used for Extended Inquiry Response (EIR), Advertising Data (AD), and OOB data blocks. The most common scenario is to call this helper on the advertising data received in the callback that was given to $bt_{-}le_{-}scan_{-}start()$.

Warning: This helper function will consume ad when parsing. The user should make a copy if the original data is to be used afterwards

Parameters

- ad Advertising data as given to the bt_le_scan_cb_t callback.
- **func** Callback function which will be called for each element that's found in the data. The callback should return true to continue parsing, or false to stop parsing.
- **user_data** User data to be passed to the callback.

int bt_le_oob_get_local(uint8 t id, struct bt le oob *oob)

Get local LE Out of Band (OOB) information.

This function allows to get local information that are useful for Out of Band pairing or connection creation.

If privacy @kconfig{CONFIG_BT_PRIVACY} is enabled this will result in generating new Resolvable Private Address (RPA) that is valid for @kconfig{CONFIG_BT_RPA_TIMEOUT} seconds. This address will be used for advertising started by $bt_le_adv_start$, active scanning and connection creation.

Note: If privacy is enabled the RPA cannot be refreshed in the following cases:

- Creating a connection in progress, wait for the connected callback. In addition when extended advertising @kconfig{CONFIG_BT_EXT_ADV} is not enabled or not supported by the controller:
- Advertiser is enabled using a Random Static Identity Address for a different local identity.
- The local identity conflicts with the local identity used by other roles.

Parameters

- id [in] Local identity, in most cases BT_ID_DEFAULT.
- **oob [out]** LE OOB information

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

int **bt_le_ext_adv_oob_get_local**(struct bt_le_ext_adv *adv, struct bt_le_oob *oob)

Get local LE Out of Band (OOB) information.

This function allows to get local information that are useful for Out of Band pairing or connection creation.

If privacy @kconfig{CONFIG_BT_PRIVACY} is enabled this will result in generating new Resolvable Private Address (RPA) that is valid for @kconfig{CONFIG_BT_RPA_TIMEOUT} seconds. This address will be used by the advertising set.

Note: When generating OOB information for multiple advertising set all OOB information needs to be generated at the same time.

Note: If privacy is enabled the RPA cannot be refreshed in the following cases:

• Creating a connection in progress, wait for the connected callback.

Parameters

- adv [in] The advertising set object
- oob [out] LE OOB information

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

int **bt_br_discovery_start**(const struct *bt_br_discovery_param* *param, struct *bt_br_discovery_result* *results, size_t count, *bt_br_discovery_cb_t* cb)

Start BR/EDR discovery.

Start BR/EDR discovery (inquiry) and provide results through the specified callback. When bt_br_discovery_cb_t is called it indicates that discovery has completed. If more inquiry results were received during session than fits in provided result storage, only ones with highest RSSI will be reported.

Parameters

- param Discovery parameters.
- **results** Storage for discovery results.
- count Number of results in storage. Valid range: 1-255.
- **cb** Callback to notify discovery results.

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error

int bt_br_discovery_stop(void)

Stop BR/EDR discovery.

Stops ongoing BR/EDR discovery. If discovery was stopped by this call results won't be reported

Returns Zero on success or error code otherwise, positive in case of protocol error or negative (POSIX) in case of stack internal error.

int bt_br_oob_get_local(struct bt_br_oob *oob)

Get BR/EDR local Out Of Band information.

This function allows to get local controller information that are useful for Out Of Band pairing or connection creation process.

Parameters

• oob – Out Of Band information

int bt_br_set_discoverable(bool enable)

Enable/disable set controller in discoverable state.

Allows make local controller to listen on INQUIRY SCAN channel and responds to devices making general inquiry. To enable this state it's mandatory to first be in connectable state.

Parameters

• **enable** – Value allowing/disallowing controller to become discoverable.

Returns Negative if fail set to requested state or requested state has been already set. Zero if done successfully.

int bt_br_set_connectable(bool enable)

Enable/disable set controller in connectable state.

Allows make local controller to be connectable. It means the controller start listen to devices requests on PAGE SCAN channel. If disabled also resets discoverability if was set.

Parameters

• enable – Value allowing/disallowing controller to be connectable.

Returns Negative if fail set to requested state or requested state has been already set. Zero if done successfully.

int **bt_unpair**(uint8_t id, const *bt_addr_le_t* *addr)

Clear pairing information.

Parameters

- id Local identity (mostly just BT_ID_DEFAULT).
- addr Remote address, NULL or BT_ADDR_LE_ANY to clear all remote devices.

Returns 0 on success or negative error value on failure.

void **bt_foreach_bond**(uint8_t id, void (*func)(const struct *bt_bond_info* *info, void *user_data), void *user_data)

Iterate through all existing bonds.

Parameters

- **id** Local identity (mostly just BT_ID_DEFAULT).
- **func** Function to call for each bond.
- **user_data** Data to pass to the callback function.

int **bt_configure_data_path**(uint8_t dir, uint8_t id, uint8_t vs_config_len, const uint8_t *vs_config) Configure vendor data path.

Request the Controller to configure the data transport path in a given direction between the Controller and the Host.

Parameters

- **dir** Direction to be configured, BT_HCI_DATAPATH_DIR_HOST_TO_CTLR or BT_HCI_DATAPATH_DIR_CTLR_TO_HOST
- id Vendor specific logical transport channel ID, range [BT_HCI_DATAPATH_ID_VS..BT_HCI_DATAPATH_ID_VS_END]
- vs_config_len Length of additional vendor specific configuration data
- vs_config Pointer to additional vendor specific configuration data

Returns 0 in case of success or negative value in case of error.

```
int bt_le_per_adv_sync_subevent(struct bt_le_per_adv_sync *per_adv_sync, struct bt_le_per_adv_sync_subevent_params *params)
```

Synchronize with a subset of subevents.

Until this command is issued, the subevent(s) the controller is synchronized to is unspecified.

Parameters

• **per_adv_sync** – The periodic advertising sync object.

• params – Parameters.

Returns 0 in case of success or negative value in case of error.

Set the data for a response slot in a specific subevent of the PAwR.

This function is called by the application to set the response data. The data for a response slot shall be transmitted only once.

Parameters

- **per_adv_sync** The periodic advertising sync object.
- params Parameters.
- data The response data to send.

Returns Zero on success or (negative) error code otherwise.

struct bt_le_ext_adv_sent_info

#include <bluetooth.h>

Public Members

```
uint8_t num_sent
```

The number of advertising events completed.

struct bt_le_ext_adv_connected_info

#include <bluetooth.h>

Public Members

```
struct bt_conn *conn
```

Connection object of the new connection

struct bt_le_ext_adv_scanned_info

#include <bluetooth.h>

Public Members

```
bt_addr_le_t *addr
```

Active scanner LE address and type

struct bt_le_per_adv_data_request

#include <bluetooth.h>

Public Members

uint8_t start

The first subevent data can be set for

uint8_t count

The number of subevents data can be set for

struct bt_le_per_adv_response_info

#include <bluetooth.h>

Public Members

uint8 t subevent

The subevent the response was received in

uint8_t tx_status

Status of the subevent indication.

0 if subevent indication was transmitted. 1 if subevent indication was not transmitted. All other values RFU.

int8_t tx_power

The TX power of the response in dBm

int8_t rssi

The RSSI of the response in dBm

uint8_t cte_type

The Constant Tone Extension (CTE) of the advertisement (bt_df_cte_type)

uint8_t response_slot

The slot the response was received in

struct bt_le_ext_adv_cb

#include <bluetooth.h>

Public Members

```
void (*sent)(struct bt_le_ext_adv *adv, struct bt_le_ext_adv_sent_info *info)
```

The advertising set has finished sending adv data.

This callback notifies the application that the advertising set has finished sending advertising data. The advertising set can either have been stopped by a timeout or because the specified number of advertising events has been reached.

Param adv The advertising set object.

Param info Information about the sent event.

void (*connected)(struct bt_le_ext_adv *adv, struct bt_le_ext_adv_connected_info *info)

The advertising set has accepted a new connection.

This callback notifies the application that the advertising set has accepted a new connection.

Param adv The advertising set object.

Param info Information about the connected event.

void (*scanned)(struct bt_le_ext_adv *adv, struct bt_le_ext_adv_scanned_info *info)

The advertising set has sent scan response data.

This callback notifies the application that the advertising set has has received a Scan Request packet, and has sent a Scan Response packet.

Param adv The advertising set object.

Param addr Information about the scanned event.

struct bt_data

#include <bluetooth.h> Bluetooth data.

Description of different data types that can be encoded into advertising data. Used to form arrays that are passed to the $bt_le_adv_start()$ function.

struct bt_le_adv_param

#include <bluetooth.h> LE Advertising Parameters.

Public Members

uint8_t id

Local identity.

Note: When extended advertising @kconfig{CONFIG_BT_EXT_ADV} is not enabled or not supported by the controller it is not possible to scan and advertise simultaneously using two different random addresses.

uint8_t **sid**

Advertising Set Identifier, valid range 0x00 - 0x0f.

Note: Requires *BT_LE_ADV_OPT_EXT_ADV*

uint8_t **secondary_max_skip**

Secondary channel maximum skip count.

Maximum advertising events the advertiser can skip before it must send advertising data on the secondary advertising channel.

Note: Requires *BT_LE_ADV_OPT_EXT_ADV*

uint32_t options

Bit-field of advertising options

uint32_t interval_min

Minimum Advertising Interval (N * 0.625 milliseconds) Minimum Advertising Interval shall be less than or equal to the Maximum Advertising Interval. The Minimum Advertising Interval and Maximum Advertising Interval should not be the same value (as stated in Bluetooth Core Spec 5.2, section 7.8.5) Range: 0x0020 to 0x4000

uint32_t interval_max

Maximum Advertising Interval (N * 0.625 milliseconds) Minimum Advertising Interval shall be less than or equal to the Maximum Advertising Interval. The Minimum Advertising Interval and Maximum Advertising Interval should not be the same value (as stated in Bluetooth Core Spec 5.2, section 7.8.5) Range: 0x0020 to 0x4000

const bt_addr_le_t *peer

Directed advertising to peer.

When this parameter is set the advertiser will send directed advertising to the remote device.

The advertising type will either be high duty cycle, or low duty cycle if the BT_LE_ADV_OPT_DIR_MODE_LOW_DUTY option is enabled. When using BT_LE_ADV_OPT_EXT_ADV then only low duty cycle is allowed.

In case of connectable high duty cycle if the connection could not be established within the timeout the connected() callback will be called with the status set to BT_HCI_ERR_ADV_TIMEOUT.

struct bt_le_per_adv_param

#include <bluetooth.h>

Public Members

uint16_t interval_min

Minimum Periodic Advertising Interval (N * 1.25 ms)

Shall be greater or equal to BT_GAP_PER_ADV_MIN_INTERVAL and less or equal to interval_max.

uint16_t interval_max

Maximum Periodic Advertising Interval (N * 1.25 ms)

Shall be less or equal to BT_GAP_PER_ADV_MAX_INTERVAL and greater or equal to interval_min.

uint32_t options

Bit-field of periodic advertising options

struct bt_le_ext_adv_start_param

#include <bluetooth.h>

Public Members

uint16_t timeout

Advertiser timeout (N * 10 ms).

Application will be notified by the advertiser sent callback. Set to zero for no timeout.

When using high duty cycle directed connectable advertising then this parameters must be set to a non-zero value less than or equal to the maximum of BT_GAP_ADV_HIGH_DUTY_CYCLE_MAX_TIMEOUT.

If privacy @kconfig{CONFIG_BT_PRIVACY} is enabled then the timeout must be less than @kconfig{CONFIG_BT_RPA_TIMEOUT}.

uint8_t num_events

Number of advertising events.

Application will be notified by the advertiser sent callback. Set to zero for no limit.

struct bt_le_ext_adv_info

#include <bluetooth.h> Advertising set info structure.

Public Members

int8_t tx_power

Currently selected Transmit Power (dBM).

```
const bt_addr_le_t *addr
```

Current local advertising address used.

struct bt_le_per_adv_subevent_data_params

#include <bluetooth.h>

Public Members

uint8_t subevent

The subevent to set data for

uint8 t response_slot_start

The first response slot to listen to

uint8_t response_slot_count

The number of response slots to listen to

const struct net_buf_simple *data

The data to send

struct bt_le_per_adv_sync_synced_info

#include <bluetooth.h>

Public Members

```
const bt_addr_le_t *addr
```

Advertiser LE address and type.

$uint8_t$ **sid**

Advertiser SID

uint16 t interval

Periodic advertising interval (N * 1.25 ms)

uint8_t **phy**

Advertiser PHY

bool recv_enabled

True if receiving periodic advertisements, false otherwise.

uint16_t service_data

Service Data provided by the peer when sync is transferred.

Will always be 0 when the sync is locally created.

struct bt_conn *conn

Peer that transferred the periodic advertising sync.

Will always be 0 when the sync is locally created.

struct bt_le_per_adv_sync_term_info

#include <bluetooth.h>

Public Members

```
const bt_addr_le_t *addr
```

Advertiser LE address and type.

$uint8_t \; \textbf{sid}$

Advertiser SID

uint8_t reason

Cause of periodic advertising termination

struct bt_le_per_adv_sync_recv_info

#include <bluetooth.h>

Public Members

```
const bt_addr_le_t *addr
```

Advertiser LE address and type.

uint8_t sid

Advertiser SID

int8_t tx_power

The TX power of the advertisement.

int8 t rssi

The RSSI of the advertisement excluding any CTE.

uint8_t cte_type

The Constant Tone Extension (CTE) of the advertisement (bt_df_cte_type)

struct bt_le_per_adv_sync_state_info

#include <bluetooth.h>

Public Members

bool recv_enabled

True if receiving periodic advertisements, false otherwise.

struct bt_le_per_adv_sync_cb

#include <bluetooth.h>

Public Members

```
void (*synced)(struct bt_le_per_adv_sync *sync, struct bt_le_per_adv_sync_synced_info *info)
```

The periodic advertising has been successfully synced.

This callback notifies the application that the periodic advertising set has been successfully synced, and will now start to receive periodic advertising reports.

Param sync The periodic advertising sync object.

Param info Information about the sync event.

```
void (*term)(struct bt_le_per_adv_sync *sync, const struct bt_le_per_adv_sync_term_info *info)
```

The periodic advertising sync has been terminated.

This callback notifies the application that the periodic advertising sync has been terminated, either by local request, remote request or because due to missing data, e.g. by being out of range or sync.

Param sync The periodic advertising sync object.

void (***recv**)(struct bt_le_per_adv_sync *sync, const struct bt_le_per_adv_sync_recv_info *info, struct net buf simple *buf)

Periodic advertising data received.

This callback notifies the application of an periodic advertising report.

Param sync The advertising set object.

Param info Information about the periodic advertising event.

Param buf Buffer containing the periodic advertising data. NULL if the controller failed to receive a subevent indication. Only happens if @kconfig{CONFIG_BT_PER_ADV_SYNC_RSP} is enabled.

void (*state_changed)(struct bt_le_per_adv_sync *sync, const struct bt_le_per_adv_sync_state_info *info)

The periodic advertising sync state has changed.

This callback notifies the application about changes to the sync state. Initialize sync and termination is handled by their individual callbacks, and won't be notified here.

Param sync The periodic advertising sync object.

Param info Information about the state change.

void (*biginfo)(struct bt_le_per_adv_sync *sync, const struct bt_iso_biginfo *biginfo)

BIGInfo advertising report received.

This callback notifies the application of a BIGInfo advertising report. This is received if the advertiser is broadcasting isochronous streams in a BIG. See iso.h for more information.

Param sync The advertising set object.

Param biginfo The BIGInfo report.

```
void (*cte_report_cb)(struct bt_le_per_adv_sync *sync, struct
bt_df_per_adv_sync_iq_samples_report const *info)
```

Callback for IQ samples report collected when sampling CTE received with periodic advertising PDU.

Param sync The periodic advertising sync object.

Param info Information about the sync event.

struct bt_le_per_adv_sync_param

#include <bluetooth.h>

Public Members

```
bt_addr_le_t addr
```

Periodic Advertiser Address.

 $Only\ valid\ if\ not\ using\ the\ periodic\ advertising\ list\ (BT_LE_PER_ADV_SYNC_OPT_USE_PER_ADV_LIST)$

uint8_t sid

Advertiser SID.

Only valid if not using the periodic advertising list (BT_LE_PER_ADV_SYNC_OPT_USE_PER_ADV_LIST)

uint32_t options

Bit-field of periodic advertising sync options.

uint16_t skip

Maximum event skip.

Maximum number of periodic advertising events that can be skipped after a successful receive. Range: 0x0000 to 0x01F3

uint16_t timeout

Synchronization timeout (N * 10 ms)

Synchronization timeout for the periodic advertising sync. Range 0x000A to 0x4000 (100 ms to 163840 ms)

struct bt_le_per_adv_sync_info

#include <bluetooth.h> Advertising set info structure.

Public Members

bt_addr_le_t addr

Periodic Advertiser Address

uint8 t sid

Advertiser SID

uint16_t interval

Periodic advertising interval (N * 1.25 ms)

uint8_t **phy**

Advertiser PHY

struct bt_le_per_adv_sync_transfer_param

#include <bluetooth.h>

Public Members

uint16_t skip

Maximum event skip.

The number of periodic advertising packets that can be skipped after a successful receive.

$uint16_t \; \textbf{timeout}$

Synchronization timeout (N * 10 ms)

Synchronization timeout for the periodic advertising sync. Range 0x000A to 0x4000 (100 ms to 163840 ms)

uint32_t options

Periodic Advertising Sync Transfer options

struct bt_le_scan_param

#include <bluetooth.h> LE scan parameters

Public Members

uint8_t type

Scan type (BT_LE_SCAN_TYPE_ACTIVE or BT_LE_SCAN_TYPE_PASSIVE)

uint32_t options

Bit-field of scanning options.

uint16_t interval

Scan interval (N * 0.625 ms)

uint16_t window

Scan window (N * 0.625 ms)

uint16_t timeout

Scan timeout (N * 10 ms)

Application will be notified by the scan timeout callback. Set zero to disable timeout.

uint16_t interval_coded

Scan interval LE Coded PHY (N * 0.625 MS)

Set zero to use same as LE 1M PHY scan interval.

uint16 t window_coded

Scan window LE Coded PHY (N * 0.625 MS)

Set zero to use same as LE 1M PHY scan window.

struct bt_le_scan_recv_info

#include <bluetooth.h> LE advertisement and scan response packet information

Public Members

```
const bt_addr_le_t *addr
```

Advertiser LE address and type.

If advertiser is anonymous then this address will be *BT_ADDR_LE_ANY*.

uint8 t **sid**

Advertising Set Identifier.

int8_t **rssi**

Strength of advertiser signal.

int8_t tx_power

Transmit power of the advertiser.

uint8_t adv_type

Advertising packet type.

Uses the BT_GAP_ADV_TYPE_* value.

May indicate that this is a scan response if the type is $BT_GAP_ADV_TYPE_SCAN_RSP$.

uint16_t adv_props

Advertising packet properties bitfield.

Uses the BT_GAP_ADV_PROP_* values. May indicate that this is a scan response if the value contains the BT_GAP_ADV_PROP_SCAN_RESPONSE bit.

uint16_t interval

Periodic advertising interval.

If 0 there is no periodic advertising.

uint8_t primary_phy

Primary advertising channel PHY.

uint8_t secondary_phy

Secondary advertising channel PHY.

struct bt_le_scan_cb

#include <bluetooth.h> Listener context for (LE) scanning.

Public Members

void (***recv**)(const struct *bt_le_scan_recv_info* *info, struct net_buf_simple *buf)

Advertisement packet and scan response received callback.

Param info Advertiser packet and scan response information.

Param buf Buffer containing advertiser data.

void (*timeout)(void)

The scanner has stopped scanning after scan timeout.

struct bt_le_oob_sc_data

#include <bluetooth.h> LE Secure Connections pairing Out of Band data.

Public Members

```
uint8_t r[16]
Random Number.
uint8_t c[16]
Confirm Value.
```

struct bt_le_oob

#include <bluetooth.h> LE Out of Band information.

Public Members

```
bt addr le t addr
```

LE address. If privacy is enabled this is a Resolvable Private Address.

```
struct bt_le_oob_sc_data le_sc_data
```

LE Secure Connections pairing Out of Band data.

struct bt_br_discovery_result

#include <bluetooth.h> BR/EDR discovery result structure.

Public Members

```
uint8_t _priv[4]
    private

bt_addr_t addr
    Remote device address

int8_t rssi
    RSSI from inquiry

uint8_t cod[3]
    Class of Device

uint8_t eir[240]
    Extended Inquiry Response
```

struct bt_br_discovery_param

#include <bluetooth.h> BR/EDR discovery parameters

Public Members

uint8_t length

Maximum length of the discovery in units of 1.28 seconds. Valid range is 0x01 - 0x30.

bool limited

True if limited discovery procedure is to be used.

struct bt_br_oob

#include <bluetooth.h>

Public Members

```
bt addr t addr
```

BR/EDR address.

struct bt_bond_info

#include <bluetooth.h> Information about a bond with a remote device.

Public Members

```
bt_addr_le_t addr
```

Address of the remote device.

struct bt_le_per_adv_sync_subevent_params

#include <bluetooth.h>

Public Members

uint16_t properties

Periodic Advertising Properties.

Bit 6 is include TxPower, all others RFU.

uint8_t num_subevents

Number of subevents to sync to

uint8_t *subevents

The subevent(s) to synchronize with.

The array must have *num_subevents* elements.

struct bt_le_per_adv_response_params

#include <bluetooth.h>

Public Members

uint16_t request_event

The periodic event counter of the request the response is sent to.

```
bt_le_per_adv_sync_recv_info
```

Note: The response can be sent up to one periodic interval after the request was received.

uint8_t request_subevent

The subevent counter of the request the response is sent to.

```
bt_le_per_adv_sync_recv_info
```

uint8_t response_subevent

The subevent the response shall be sent in

uint8_t response_slot

The response slot the response shall be sent in

group bt_addr

Bluetooth device address definitions and utilities. .

Defines

BT_ADDR_LE_PUBLIC

BT_ADDR_LE_RANDOM

BT_ADDR_LE_PUBLIC_ID

BT_ADDR_LE_RANDOM_ID

BT_ADDR_LE_UNRESOLVED

BT_ADDR_LE_ANONYMOUS

BT_ADDR_SIZE

Length in bytes of a standard Bluetooth address

BT_ADDR_LE_SIZE

Length in bytes of an LE Bluetooth address. Not packed, so no sizeof()

BT_ADDR_ANY

Bluetooth device "any" address, not a valid address

BT_ADDR_NONE

Bluetooth device "none" address, not a valid address

BT_ADDR_LE_ANY

Bluetooth LE device "any" address, not a valid address

BT_ADDR_LE_NONE

Bluetooth LE device "none" address, not a valid address

BT_ADDR_IS_RPA(a)

Check if a Bluetooth LE random address is resolvable private address.

BT_ADDR_IS_NRPA(a)

Check if a Bluetooth LE random address is a non-resolvable private address.

BT_ADDR_IS_STATIC(a)

Check if a Bluetooth LE random address is a static address.

BT_ADDR_SET_RPA(a)

Set a Bluetooth LE random address as a resolvable private address.

BT_ADDR_SET_NRPA(a)

Set a Bluetooth LE random address as a non-resolvable private address.

BT_ADDR_SET_STATIC(a)

Set a Bluetooth LE random address as a static address.

BT_ADDR_STR_LEN

Recommended length of user string buffer for Bluetooth address.

The recommended length guarantee the output of address conversion will not lose valuable information about address being processed.

BT_ADDR_LE_STR_LEN

Recommended length of user string buffer for Bluetooth LE address.

The recommended length guarantee the output of address conversion will not lose valuable information about address being processed.

Functions

static inline int **bt_addr_cmp**(const *bt_addr_t* *a, const *bt_addr_t* *b)

Compare Bluetooth device addresses.

Parameters

- a First Bluetooth device address to compare
- **b** Second Bluetooth device address to compare

Returns negative value if a < b, 0 if a == b, else positive

```
static inline bool bt_addr_eq(const bt_addr_t *a, const bt_addr_t *b)
```

Determine equality of two Bluetooth device addresses.

Return values

- **#true** if the two addresses are equal
- **#false** otherwise

```
static inline int bt_addr_le_cmp(const bt_addr_le_t *a, const bt_addr_le_t *b)
```

Compare Bluetooth LE device addresses.

See also:

```
bt_addr_le_eq
```

Parameters

- a First Bluetooth LE device address to compare
- **b** Second Bluetooth LE device address to compare

Returns negative value if a < b, 0 if a == b, else positive

```
static inline bool bt_addr_le_eq(const bt_addr_le_t *a, const bt_addr_le_t *b)
```

Determine equality of two Bluetooth LE device addresses.

The Bluetooth LE addresses are equal iff both the types and the 48-bit addresses are numerically equal.

Return values

- #true if the two addresses are equal
- **#false** otherwise

static inline void **bt_addr_copy**(*bt_addr_t* *dst, const *bt_addr_t* *src)

Copy Bluetooth device address.

Parameters

- dst Bluetooth device address destination buffer.
- src Bluetooth device address source buffer.

static inline void **bt_addr_le_copy**(*bt_addr_le_t* *dst, const *bt_addr_le_t* *src)

Copy Bluetooth LE device address.

Parameters

- dst Bluetooth LE device address destination buffer.
- **src** Bluetooth LE device address source buffer.

```
int bt_addr_le_create_nrpa(bt_addr_le_t *addr)
```

Create a Bluetooth LE random non-resolvable private address.

```
int bt_addr_le_create_static(bt_addr_le_t *addr)
```

Create a Bluetooth LE random static address.

static inline bool **bt_addr_le_is_rpa**(const *bt_addr_le_t* *addr)

Check if a Bluetooth LE address is a random private resolvable address.

Parameters

• addr – Bluetooth LE device address.

Returns true if address is a random private resolvable address.

static inline bool **bt_addr_le_is_identity**(const *bt_addr_le_t* *addr)

Check if a Bluetooth LE address is valid identity address.

Valid Bluetooth LE identity addresses are either public address or random static address.

Parameters

• addr – Bluetooth LE device address.

Returns true if address is a valid identity address.

static inline int **bt_addr_to_str**(const *bt_addr_t* *addr, char *str, size_t len)

Converts binary Bluetooth address to string.

Parameters

- addr Address of buffer containing binary Bluetooth address.
- str Address of user buffer with enough room to store formatted string containing binary address.
- **len** Length of data to be copied to user string buffer. Refer to BT_ADDR_STR_LEN about recommended value.

Returns Number of successfully formatted bytes from binary address.

static inline int **bt_addr_le_to_str**(const *bt_addr_le_t* *addr, char *str, size_t len)

Converts binary LE Bluetooth address to string.

Parameters

- addr Address of buffer containing binary LE Bluetooth address.
- str Address of user buffer with enough room to store formatted string containing binary LE address.
- **len** Length of data to be copied to user string buffer. Refer to BT_ADDR_LE_STR_LEN about recommended value.

Returns Number of successfully formatted bytes from binary address.

int bt_addr_from_str(const char *str, bt addr t *addr)

Convert Bluetooth address from string to binary.

Parameters

- **str** [in] The string representation of a Bluetooth address.
- addr [out] Address of buffer to store the Bluetooth address

Return values 0 – Success. The parsed address is stored in addr.

Returns -EINVAL Invalid address string. str is not a well-formed Bluetooth address.

```
int bt_addr_le_from_str(const char *str, const char *type, bt_addr_le_t *addr)
```

Convert LE Bluetooth address from string to binary.

Parameters

- **str** [in] The string representation of an LE Bluetooth address.
- type [in] The string representation of the LE Bluetooth address type.
- addr [out] Address of buffer to store the LE Bluetooth address

Returns Zero on success or (negative) error code otherwise.

Variables

```
const bt_addr_t bt_addr_any
     const bt_addr_t bt_addr_none
     const bt_addr_le_t bt_addr_le_any
     const bt_addr_le_t bt_addr_le_none
     struct bt_addr_t
          #include <addr.h> Bluetooth Device Address
     struct bt_addr_le_t
          #include <addr.h> Bluetooth LE Device Address
group bt_gap_defines
     Bluetooth Generic Access Profile defines and Assigned Numbers. .
     Company Identifiers (see Bluetooth Assigned Numbers)
```

BT_COMP_ID_LF

The Linux Foundation

EIR/AD data type definitions

BT_DATA_FLAGS

AD flags

BT_DATA_UUID16_SOME

16-bit UUID, more available

BT_DATA_UUID16_ALL

16-bit UUID, all listed

BT_DATA_UUID32_SOME

32-bit UUID, more available

BT_DATA_UUID32_ALL

32-bit UUID, all listed

BT_DATA_UUID128_SOME

128-bit UUID, more available

BT_DATA_UUID128_ALL

128-bit UUID, all listed

BT_DATA_NAME_SHORTENED

Shortened name

BT_DATA_NAME_COMPLETE

Complete name

BT_DATA_TX_POWER

Tx Power

BT_DATA_SM_TK_VALUE

Security Manager TK Value

BT_DATA_SM_OOB_FLAGS

Security Manager OOB Flags

BT_DATA_PERIPHERAL_INT_RANGE

Peripheral Connection Interval Range

BT_DATA_SOLICIT16

Solicit UUIDs, 16-bit

BT_DATA_SOLICIT128

Solicit UUIDs, 128-bit

BT_DATA_SVC_DATA16

Service data, 16-bit UUID

BT_DATA_PUB_TARGET_ADDR

Public Target Address

BT_DATA_RAND_TARGET_ADDR

Random Target Address

BT_DATA_GAP_APPEARANCE

GAP appearance

BT_DATA_ADV_INT

Advertising Interval

BT_DATA_LE_BT_DEVICE_ADDRESS

LE Bluetooth Device Address

BT_DATA_LE_ROLE

LE Role

BT_DATA_SIMPLE_PAIRING_HASH

Simple Pairing Hash C256

BT_DATA_SIMPLE_PAIRING_RAND

Simple Pairing Randomizer R256

BT_DATA_SOLICIT32

Solicit UUIDs, 32-bit

BT_DATA_SVC_DATA32

Service data, 32-bit UUID

BT_DATA_SVC_DATA128

Service data, 128-bit UUID

BT_DATA_LE_SC_CONFIRM_VALUE

LE SC Confirmation Value

BT_DATA_LE_SC_RANDOM_VALUE

LE SC Random Value

BT_DATA_URI

URI

BT_DATA_INDOOR_POS

Indoor Positioning

BT_DATA_TRANS_DISCOVER_DATA

Transport Discovery Data

BT_DATA_LE_SUPPORTED_FEATURES

LE Supported Features

BT_DATA_CHANNEL_MAP_UPDATE_IND

Channel Map Update Indication

BT_DATA_MESH_PROV

Mesh Provisioning PDU

BT_DATA_MESH_MESSAGE

Mesh Networking PDU

BT_DATA_MESH_BEACON

Mesh Beacon

BT_DATA_BIG_INFO

BIGInfo

BT_DATA_BROADCAST_CODE

Broadcast Code

BT_DATA_CSIS_RSI

CSIS Random Set ID type

BT_DATA_ADV_INT_LONG

Advertising Interval long

BT_DATA_BROADCAST_NAME

Broadcast Name

BT_DATA_ENCRYPTED_AD_DATA

Encrypted Advertising Data

BT_DATA_3D_INFO

3D Information Data

BT_DATA_MANUFACTURER_DATA

Manufacturer Specific Data

BT_LE_AD_LIMITED

Limited Discoverable

BT_LE_AD_GENERAL

General Discoverable

${\tt BT_LE_AD_NO_BREDR}$

BR/EDR not supported

Appearance Values

Last Modified on 2023-01-05

BT_APPEARANCE_UNKNOWN

Generic Unknown

BT_APPEARANCE_GENERIC_PHONE

Generic Phone

BT_APPEARANCE_GENERIC_COMPUTER

Generic Computer

BT_APPEARANCE_COMPUTER_DESKTOP_WORKSTATION

Desktop Workstation

BT_APPEARANCE_COMPUTER_SERVER_CLASS

Server-class Computer

BT_APPEARANCE_COMPUTER_LAPTOP

Laptop

BT_APPEARANCE_COMPUTER_HANDHELD_PCPDA

Handheld PC/PDA (clamshell)

BT_APPEARANCE_COMPUTER_PALMSIZE_PCPDA

Palm-size PC/PDA

BT_APPEARANCE_COMPUTER_WEARABLE_COMPUTER

Wearable computer (watch size)

BT_APPEARANCE_COMPUTER_TABLET

Tablet

BT_APPEARANCE_COMPUTER_DOCKING_STATION

Docking Station

BT_APPEARANCE_COMPUTER_ALL_IN_ONE

All in One

BT_APPEARANCE_COMPUTER_BLADE_SERVER

Blade Server

BT_APPEARANCE_COMPUTER_CONVERTIBLE

Convertible

BT_APPEARANCE_COMPUTER_DETACHABLE

Detachable

BT_APPEARANCE_COMPUTER_IOT_GATEWAY

IoT Gateway

BT_APPEARANCE_COMPUTER_MINI_PC

Mini PC

BT_APPEARANCE_COMPUTER_STICK_PC

Stick PC

BT_APPEARANCE_GENERIC_WATCH

Generic Watch

BT_APPEARANCE_SPORTS_WATCH

Sports Watch

BT_APPEARANCE_SMARTWATCH

Smartwatch

BT_APPEARANCE_GENERIC_CLOCK

Generic Clock

BT_APPEARANCE_GENERIC_DISPLAY

Generic Display

BT_APPEARANCE_GENERIC_REMOTE

Generic Remote Control

BT_APPEARANCE_GENERIC_EYEGLASSES

Generic Eye-glasses

BT_APPEARANCE_GENERIC_TAG

Generic Tag

BT_APPEARANCE_GENERIC_KEYRING

Generic Keyring

BT_APPEARANCE_GENERIC_MEDIA_PLAYER

Generic Media Player

BT_APPEARANCE_GENERIC_BARCODE_SCANNER

Generic Barcode Scanner

BT_APPEARANCE_GENERIC_THERMOMETER

Generic Thermometer

BT_APPEARANCE_THERMOMETER_EAR

Ear Thermometer

BT_APPEARANCE_GENERIC_HEART_RATE

Generic Heart Rate Sensor

BT_APPEARANCE_HEART_RATE_BELT

Heart Rate Belt

BT_APPEARANCE_GENERIC_BLOOD_PRESSURE

Generic Blood Pressure

BT_APPEARANCE_BLOOD_PRESSURE_ARM

Arm Blood Pressure

BT_APPEARANCE_BLOOD_PRESSURE_WRIST

Wrist Blood Pressure

BT_APPEARANCE_GENERIC_HID

Generic Human Interface Device

BT_APPEARANCE_HID_KEYBOARD

Keyboard

BT_APPEARANCE_HID_MOUSE

Mouse

BT_APPEARANCE_HID_JOYSTICK

Joystick

BT_APPEARANCE_HID_GAMEPAD

Gamepad

BT_APPEARANCE_HID_DIGITIZER_TABLET

Digitizer Tablet

BT_APPEARANCE_HID_CARD_READER

Card Reader

BT_APPEARANCE_HID_DIGITAL_PEN

Digital Pen

BT_APPEARANCE_HID_BARCODE_SCANNER

Barcode Scanner

BT_APPEARANCE_HID_TOUCHPAD

Touchpad

BT_APPEARANCE_HID_PRESENTATION_REMOTE

Presentation Remote

BT_APPEARANCE_GENERIC_GLUCOSE

Generic Glucose Meter

BT_APPEARANCE_GENERIC_WALKING

Generic Running Walking Sensor

BT_APPEARANCE_WALKING_IN_SHOE

In-Shoe Running Walking Sensor

BT_APPEARANCE_WALKING_ON_SHOE

On-Shoe Running Walking Sensor

BT_APPEARANCE_WALKING_ON_HIP

On-Hip Running Walking Sensor

BT_APPEARANCE_GENERIC_CYCLING

Generic Cycling

BT_APPEARANCE_CYCLING_COMPUTER

Cycling Computer

BT_APPEARANCE_CYCLING_SPEED

Speed Sensor

BT_APPEARANCE_CYCLING_CADENCE

Cadence Sensor

BT_APPEARANCE_CYCLING_POWER

Power Sensor

BT_APPEARANCE_CYCLING_SPEED_CADENCE

Speed and Cadence Sensor

BT_APPEARANCE_GENERIC_CONTROL_DEVICE

Generic Control Device

BT_APPEARANCE_CONTROL_SWITCH

Switch

BT_APPEARANCE_CONTROL_MULTI_SWITCH

Multi-switch

BT_APPEARANCE_CONTROL_BUTTON

Button

BT_APPEARANCE_CONTROL_SLIDER

Slider

BT_APPEARANCE_CONTROL_ROTARY_SWITCH

Rotary Switch

BT_APPEARANCE_CONTROL_TOUCH_PANEL

Touch Panel

BT_APPEARANCE_CONTROL_SINGLE_SWITCH

Single Switch

BT_APPEARANCE_CONTROL_DOUBLE_SWITCH

Double Switch

BT_APPEARANCE_CONTROL_TRIPLE_SWITCH

Triple Switch

BT_APPEARANCE_CONTROL_BATTERY_SWITCH

Battery Switch

BT_APPEARANCE_CONTROL_ENERGY_HARVESTING_SWITCH

Energy Harvesting Switch

BT_APPEARANCE_CONTROL_PUSH_BUTTON

Push Button

BT_APPEARANCE_GENERIC_NETWORK_DEVICE

Generic Network Device

BT_APPEARANCE_NETWORK_ACCESS_POINT

Access Point

BT_APPEARANCE_NETWORK_MESH_DEVICE

Mesh Device

BT_APPEARANCE_NETWORK_MESH_PROXY

Mesh Network Proxy

BT_APPEARANCE_GENERIC_SENSOR

Generic Sensor

BT_APPEARANCE_SENSOR_MOTION

Motion Sensor

BT_APPEARANCE_SENSOR_AIR_QUALITY

Air quality Sensor

BT_APPEARANCE_SENSOR_TEMPERATURE

Temperature Sensor

BT_APPEARANCE_SENSOR_HUMIDITY

Humidity Sensor

BT_APPEARANCE_SENSOR_LEAK

Leak Sensor

BT_APPEARANCE_SENSOR_SMOKE

Smoke Sensor

BT_APPEARANCE_SENSOR_OCCUPANCY

Occupancy Sensor

BT_APPEARANCE_SENSOR_CONTACT

Contact Sensor

BT_APPEARANCE_SENSOR_CARBON_MONOXIDE

Carbon Monoxide Sensor

BT_APPEARANCE_SENSOR_CARBON_DIOXIDE

Carbon Dioxide Sensor

BT_APPEARANCE_SENSOR_AMBIENT_LIGHT

Ambient Light Sensor

BT_APPEARANCE_SENSOR_ENERGY

Energy Sensor

BT_APPEARANCE_SENSOR_COLOR_LIGHT

Color Light Sensor

BT_APPEARANCE_SENSOR_RAIN

Rain Sensor

BT_APPEARANCE_SENSOR_FIRE

Fire Sensor

BT_APPEARANCE_SENSOR_WIND

Wind Sensor

BT_APPEARANCE_SENSOR_PROXIMITY

Proximity Sensor

BT_APPEARANCE_SENSOR_MULTI

Multi-Sensor

BT_APPEARANCE_SENSOR_FLUSH_MOUNTED

Flush Mounted Sensor

BT_APPEARANCE_SENSOR_CEILING_MOUNTED

Ceiling Mounted Sensor

BT_APPEARANCE_SENSOR_WALL_MOUNTED

Wall Mounted Sensor

BT_APPEARANCE_MULTISENSOR

Multisensor

BT_APPEARANCE_SENSOR_ENERGY_METER

Energy Meter

BT_APPEARANCE_SENSOR_FLAME_DETECTOR

Flame Detector

BT_APPEARANCE_SENSOR_VEHICLE_TIRE_PRESSURE

Vehicle Tire Pressure Sensor

BT_APPEARANCE_GENERIC_LIGHT_FIXTURES

Generic Light Fixtures

BT_APPEARANCE_LIGHT_FIXTURES_WALL

Wall Light

BT_APPEARANCE_LIGHT_FIXTURES_CEILING

Ceiling Light

BT_APPEARANCE_LIGHT_FIXTURES_FLOOR

Floor Light

BT_APPEARANCE_LIGHT_FIXTURES_CABINET

Cabinet Light

BT_APPEARANCE_LIGHT_FIXTURES_DESK

Desk Light

BT_APPEARANCE_LIGHT_FIXTURES_TROFFER

Troffer Light

BT_APPEARANCE_LIGHT_FIXTURES_PENDANT

Pendant Light

BT_APPEARANCE_LIGHT_FIXTURES_IN_GROUND

In-ground Light

BT_APPEARANCE_LIGHT_FIXTURES_FLOOD

Flood Light

BT_APPEARANCE_LIGHT_FIXTURES_UNDERWATER

Underwater Light

BT_APPEARANCE_LIGHT_FIXTURES_BOLLARD_WITH

Bollard with Light

BT_APPEARANCE_LIGHT_FIXTURES_PATHWAY

Pathway Light

BT_APPEARANCE_LIGHT_FIXTURES_GARDEN

Garden Light

BT_APPEARANCE_LIGHT_FIXTURES_POLE_TOP

Pole-top Light

BT_APPEARANCE_SPOT_LIGHT

Spotlight

BT_APPEARANCE_LIGHT_FIXTURES_LINEAR

Linear Light

BT_APPEARANCE_LIGHT_FIXTURES_STREET

Street Light

BT_APPEARANCE_LIGHT_FIXTURES_SHELVES

Shelves Light

BT_APPEARANCE_LIGHT_FIXTURES_BAY

Bay Light

BT_APPEARANCE_LIGHT_FIXTURES_EMERGENCY_EXIT

Emergency Exit Light

BT_APPEARANCE_LIGHT_FIXTURES_CONTROLLER

Light Controller

BT_APPEARANCE_LIGHT_FIXTURES_DRIVER

Light Driver

BT_APPEARANCE_LIGHT_FIXTURES_BULB

Bulb

BT_APPEARANCE_LIGHT_FIXTURES_LOW_BAY

Low-bay Light

BT_APPEARANCE_LIGHT_FIXTURES_HIGH_BAY

High-bay Light

BT_APPEARANCE_GENERIC_FAN

Generic Fan

BT_APPEARANCE_FAN_CEILING

Ceiling Fan

BT_APPEARANCE_FAN_AXIAL

Axial Fan

BT_APPEARANCE_FAN_EXHAUST

Exhaust Fan

BT_APPEARANCE_FAN_PEDESTAL

Pedestal Fan

BT_APPEARANCE_FAN_DESK

Desk Fan

BT_APPEARANCE_FAN_WALL

Wall Fan

BT_APPEARANCE_GENERIC_HVAC

Generic HVAC

BT_APPEARANCE_HVAC_THERMOSTAT

Thermostat

BT_APPEARANCE_HVAC_HUMIDIFIER

Humidifier

BT_APPEARANCE_HVAC_DEHUMIDIFIER

De-humidifier

BT_APPEARANCE_HVAC_HEATER

Heater

BT_APPEARANCE_HVAC_RADIATOR

Radiator

BT_APPEARANCE_HVAC_BOILER

Boiler

BT_APPEARANCE_HVAC_HEAT_PUMP

Heat Pump

BT_APPEARANCE_HVAC_INFRARED_HEATER

Infrared Heater

BT_APPEARANCE_HVAC_RADIANT_PANEL_HEATER

Radiant Panel Heater

BT_APPEARANCE_HVAC_FAN_HEATER

Fan Heater

BT_APPEARANCE_HVAC_AIR_CURTAIN

Air Curtain

BT_APPEARANCE_GENERIC_AIR_CONDITIONING

Generic Air Conditioning

BT_APPEARANCE_GENERIC_HUMIDIFIER

Generic Humidifier

BT_APPEARANCE_GENERIC_HEATING

Generic Heating

BT_APPEARANCE_HEATING_RADIATOR

Radiator

BT_APPEARANCE_HEATING_BOILER

Boiler

BT_APPEARANCE_HEATING_HEAT_PUMP

Heat Pump

BT_APPEARANCE_HEATING_INFRARED_HEATER

Infrared Heater

BT_APPEARANCE_HEATING_RADIANT_PANEL_HEATER

Radiant Panel Heater

BT_APPEARANCE_HEATING_FAN_HEATER

Fan Heater

BT_APPEARANCE_HEATING_AIR_CURTAIN

Air Curtain

BT_APPEARANCE_GENERIC_ACCESS_CONTROL

Generic Access Control

BT_APPEARANCE_CONTROL_ACCESS_DOOR

Access Door

BT_APPEARANCE_CONTROL_GARAGE_DOOR

Garage Door

BT_APPEARANCE_CONTROL_EMERGENCY_EXIT_DOOR

Emergency Exit Door

BT_APPEARANCE_CONTROL_ACCESS_LOCK

Access Lock

BT_APPEARANCE_CONTROL_ELEVATOR

Elevator

BT_APPEARANCE_CONTROL_WINDOW

Window

BT_APPEARANCE_CONTROL_ENTRANCE_GATE

Entrance Gate

BT_APPEARANCE_CONTROL_DOOR_LOCK

Door Lock

BT_APPEARANCE_CONTROL_LOCKER

Locker

BT_APPEARANCE_GENERIC_MOTORIZED_DEVICE

Generic Motorized Device

BT_APPEARANCE_MOTORIZED_GATE

Motorized Gate

BT_APPEARANCE_MOTORIZED_AWNING

Awning

BT_APPEARANCE_MOTORIZED_BLINDS_OR_SHADES

Blinds or Shades

BT_APPEARANCE_MOTORIZED_CURTAINS

Curtains

BT_APPEARANCE_MOTORIZED_SCREEN

Screen

BT_APPEARANCE_GENERIC_POWER_DEVICE

Generic Power Device

BT_APPEARANCE_POWER_OUTLET

Power Outlet

BT_APPEARANCE_POWER_STRIP

Power Strip

BT_APPEARANCE_POWER_PLUG

Plug

BT_APPEARANCE_POWER_SUPPLY

Power Supply

BT_APPEARANCE_POWER_LED_DRIVER

LED Driver

${\tt BT_APPEARANCE_POWER_FLUORESCENT_LAMP_GEAR}$

Fluorescent Lamp Gear

BT_APPEARANCE_POWER_HID_LAMP_GEAR

HID Lamp Gear

BT_APPEARANCE_POWER_CHARGE_CASE

Charge Case

BT_APPEARANCE_POWER_POWER_BANK

Power Bank

BT_APPEARANCE_GENERIC_LIGHT_SOURCE

Generic Light Source

BT_APPEARANCE_LIGHT_SOURCE_INCANDESCENT_BULB

Incandescent Light Bulb

BT_APPEARANCE_LIGHT_SOURCE_LED_LAMP

LED Lamp

BT_APPEARANCE_LIGHT_SOURCE_HID_LAMP

HID Lamp

BT_APPEARANCE_LIGHT_SOURCE_FLUORESCENT_LAMP

Fluorescent Lamp

BT_APPEARANCE_LIGHT_SOURCE_LED_ARRAY

LED Array

BT_APPEARANCE_LIGHT_SOURCE_MULTICOLOR_LED_ARRAY

Multi-Color LED Array

BT_APPEARANCE_LIGHT_SOURCE_LOW_VOLTAGE_HALOGEN

Low voltage halogen

BT_APPEARANCE_LIGHT_SOURCE_OLED

Organic light emitting diode

BT_APPEARANCE_GENERIC_WINDOW_COVERING

Generic Window Covering

BT_APPEARANCE_WINDOW_SHADES

Window Shades

BT_APPEARANCE_WINDOW_BLINDS

Window Blinds

BT_APPEARANCE_WINDOW_AWNING

Window Awning

BT_APPEARANCE_WINDOW_CURTAIN

Window Curtain

BT_APPEARANCE_WINDOW_EXTERIOR_SHUTTER

Exterior Shutter

BT_APPEARANCE_WINDOW_EXTERIOR_SCREEN

Exterior Screen

BT_APPEARANCE_GENERIC_AUDIO_SINK

Generic Audio Sink

BT_APPEARANCE_AUDIO_SINK_STANDALONE_SPEAKER

Standalone Speaker

BT_APPEARANCE_AUDIO_SINK_SOUNDBAR

Soundbar

BT_APPEARANCE_AUDIO_SINK_BOOKSHELF_SPEAKER

Bookshelf Speaker

BT_APPEARANCE_AUDIO_SINK_STANDMOUNTED_SPEAKER

Standmounted Speaker

BT_APPEARANCE_AUDIO_SINK_SPEAKERPHONE

Speakerphone

BT_APPEARANCE_GENERIC_AUDIO_SOURCE

Generic Audio Source

BT_APPEARANCE_AUDIO_SOURCE_MICROPHONE

Microphone

BT_APPEARANCE_AUDIO_SOURCE_ALARM

Alarm

BT_APPEARANCE_AUDIO_SOURCE_BELL

Bell

BT_APPEARANCE_AUDIO_SOURCE_HORN

Horn

BT_APPEARANCE_AUDIO_SOURCE_BROADCASTING_DEVICE

Broadcasting Device

BT_APPEARANCE_AUDIO_SOURCE_SERVICE_DESK

Service Desk

BT_APPEARANCE_AUDIO_SOURCE_KIOSK

Kiosk

BT_APPEARANCE_AUDIO_SOURCE_BROADCASTING_ROOM

Broadcasting Room

BT_APPEARANCE_AUDIO_SOURCE_AUDITORIUM

Auditorium

BT_APPEARANCE_GENERIC_MOTORIZED_VEHICLE

Generic Motorized Vehicle

BT_APPEARANCE_VEHICLE_CAR

Car

BT_APPEARANCE_VEHICLE_LARGE_GOODS

Large Goods Vehicle

BT_APPEARANCE_VEHICLE_TWO_WHEELED

2-Wheeled Vehicle

BT_APPEARANCE_VEHICLE_MOTORBIKE

Motorbike

BT_APPEARANCE_VEHICLE_SCOOTER

Scooter

BT_APPEARANCE_VEHICLE_MOPED

Moped

BT_APPEARANCE_VEHICLE_THREE_WHEELED

3-Wheeled Vehicle

BT_APPEARANCE_VEHICLE_LIGHT

Light Vehicle

BT_APPEARANCE_VEHICLE_QUAD_BIKE

Quad Bike

BT_APPEARANCE_VEHICLE_MINIBUS

Minibus

BT_APPEARANCE_VEHICLE_BUS

Bus

BT_APPEARANCE_VEHICLE_TROLLEY

Trolley

BT_APPEARANCE_VEHICLE_AGRICULTURAL

Agricultural Vehicle

BT_APPEARANCE_VEHICLE_CAMPER_OR_CARAVAN

Camper/Caravan

BT_APPEARANCE_VEHICLE_RECREATIONAL

Recreational Vehicle/Motor Home

BT_APPEARANCE_GENERIC_DOMESTIC_APPLIANCE

Generic Domestic Appliance

BT_APPEARANCE_APPLIANCE_REFRIGERATOR

Refrigerator

BT_APPEARANCE_APPLIANCE_FREEZER

Freezer

BT_APPEARANCE_APPLIANCE_OVEN

Oven

BT_APPEARANCE_APPLIANCE_MICROWAVE

Microwave

BT_APPEARANCE_APPLIANCE_TOASTER

Toaster

BT_APPEARANCE_APPLIANCE_WASHING_MACHINE

Washing Machine

BT_APPEARANCE_APPLIANCE_DRYER

Dryer

BT_APPEARANCE_APPLIANCE_COFFEE_MAKER

Coffee maker

BT_APPEARANCE_APPLIANCE_CLOTHES_IRON

Clothes iron

BT_APPEARANCE_APPLIANCE_CURLING_IRON

Curling iron

BT_APPEARANCE_APPLIANCE_HAIR_DRYER

Hair dryer

BT_APPEARANCE_APPLIANCE_VACUUM_CLEANER

Vacuum cleaner

BT_APPEARANCE_APPLIANCE_ROBOTIC_VACUUM_CLEANER

Robotic vacuum cleaner

BT_APPEARANCE_APPLIANCE_RICE_COOKER

Rice cooker

BT_APPEARANCE_APPLIANCE_CLOTHES_STEAMER

Clothes steamer

BT_APPEARANCE_GENERIC_WEARABLE_AUDIO_DEVICE

Generic Wearable Audio Device

BT_APPEARANCE_WEARABLE_AUDIO_DEVICE_EARBUD

Earbud

BT_APPEARANCE_WEARABLE_AUDIO_DEVICE_HEADSET

Headset

BT_APPEARANCE_WEARABLE_AUDIO_DEVICE_HEADPHONES

Headphones

BT_APPEARANCE_WEARABLE_AUDIO_DEVICE_NECK_BAND

Neck Band

BT_APPEARANCE_GENERIC_AIRCRAFT

Generic Aircraft

BT_APPEARANCE_AIRCRAFT_LIGHT

Light Aircraft

BT_APPEARANCE_AIRCRAFT_MICROLIGHT

Microlight

BT_APPEARANCE_AIRCRAFT_PARAGLIDER

Paraglider

BT_APPEARANCE_AIRCRAFT_LARGE_PASSENGER

Large Passenger Aircraft

BT_APPEARANCE_GENERIC_AV_EQUIPMENT

Generic AV Equipment

BT_APPEARANCE_AV_EQUIPMENT_AMPLIFIER

Amplifier

BT_APPEARANCE_AV_EQUIPMENT_RECEIVER

Receiver

BT_APPEARANCE_AV_EQUIPMENT_RADIO

Radio

BT_APPEARANCE_AV_EQUIPMENT_TUNER

Tuner

BT_APPEARANCE_AV_EQUIPMENT_TURNTABLE

Turntable

BT_APPEARANCE_AV_EQUIPMENT_CD_PLAYER

CD Player

BT_APPEARANCE_AV_EQUIPMENT_DVD_PLAYER

DVD Player

BT_APPEARANCE_AV_EQUIPMENT_BLURAY_PLAYER

Bluray Player

BT_APPEARANCE_AV_EQUIPMENT_OPTICAL_DISC_PLAYER

Optical Disc Player

BT_APPEARANCE_AV_EQUIPMENT_SET_TOP_BOX

Set-Top Box

BT_APPEARANCE_GENERIC_DISPLAY_EQUIPMENT

Generic Display Equipment

BT_APPEARANCE_DISPLAY_EQUIPMENT_TELEVISION

Television

BT_APPEARANCE_DISPLAY_EQUIPMENT_MONITOR

Monitor

BT_APPEARANCE_DISPLAY_EQUIPMENT_PROJECTOR

Projector

BT_APPEARANCE_GENERIC_HEARING_AID

Generic Hearing aid

BT_APPEARANCE_HEARING_AID_IN_EAR

In-ear hearing aid

BT_APPEARANCE_HEARING_AID_BEHIND_EAR

Behind-ear hearing aid

BT_APPEARANCE_HEARING_AID_COCHLEAR_IMPLANT

Cochlear Implant

BT_APPEARANCE_GENERIC_GAMING

Generic Gaming

BT_APPEARANCE_HOME_VIDEO_GAME_CONSOLE

Home Video Game Console

BT_APPEARANCE_PORTABLE_HANDHELD_CONSOLE

Portable handheld console

BT_APPEARANCE_GENERIC_SIGNAGE

Generic Signage

BT_APPEARANCE_SIGNAGE_DIGITAL

Digital Signage

BT_APPEARANCE_SIGNAGE_ELECTRONIC_LABEL

Electronic Label

BT_APPEARANCE_GENERIC_PULSE_OXIMETER

Generic Pulse Oximeter

BT_APPEARANCE_PULSE_OXIMETER_FINGERTIP

Fingertip Pulse Oximeter

BT_APPEARANCE_PULSE_OXIMETER_WRIST

Wrist Worn Pulse Oximeter

102

BT_APPEARANCE_GENERIC_WEIGHT_SCALE

Generic Weight Scale

BT_APPEARANCE_GENERIC_PERSONAL_MOBILITY_DEVICE

Generic Personal Mobility Device

BT_APPEARANCE_MOBILITY_POWERED_WHEELCHAIR

Powered Wheelchair

BT_APPEARANCE_MOBILITY_SCOOTER

Mobility Scooter

BT_APPEARANCE_CONTINUOUS_GLUCOSE_MONITOR

Continuous Glucose Monitor

BT_APPEARANCE_GENERIC_INSULIN_PUMP

Generic Insulin Pump

BT_APPEARANCE_INSULIN_PUMP_DURABLE

Insulin Pump, durable pump

BT_APPEARANCE_INSULIN_PUMP_PATCH

Insulin Pump, patch pump

BT_APPEARANCE_INSULIN_PEN

Insulin Pen

BT_APPEARANCE_GENERIC_MEDICATION_DELIVERY

Generic Medication Delivery

BT_APPEARANCE_GENERIC_SPIROMETER

Generic Spirometer

BT_APPEARANCE_SPIROMETER_HANDHELD

Handheld Spirometer

BT_APPEARANCE_GENERIC_OUTDOOR_SPORTS

Generic Outdoor Sports Activity

BT_APPEARANCE_OUTDOOR_SPORTS_LOCATION

Location Display

BT_APPEARANCE_OUTDOOR_SPORTS_LOCATION_AND_NAV

Location and Navigation Display

BT_APPEARANCE_OUTDOOR_SPORTS_LOCATION_POD

Location Pod

BT_APPEARANCE_OUTDOOR_SPORTS_LOCATION_POD_AND_NAV

Location and Navigation Pod

Defined GAP timers

BT_GAP_SCAN_FAST_INTERVAL

BT_GAP_SCAN_FAST_WINDOW

BT_GAP_SCAN_SLOW_INTERVAL_1

BT_GAP_SCAN_SLOW_WINDOW_1

BT_GAP_SCAN_SLOW_INTERVAL_2

BT_GAP_SCAN_SLOW_WINDOW_2

BT_GAP_ADV_FAST_INT_MIN_1

BT_GAP_ADV_FAST_INT_MAX_1

BT_GAP_ADV_FAST_INT_MIN_2

BT_GAP_ADV_FAST_INT_MAX_2

BT_GAP_ADV_SLOW_INT_MIN

BT_GAP_ADV_SLOW_INT_MAX

BT_GAP_PER_ADV_FAST_INT_MIN_1

BT_GAP_PER_ADV_FAST_INT_MAX_1

BT_GAP_PER_ADV_FAST_INT_MIN_2

BT_GAP_PER_ADV_FAST_INT_MAX_2

BT_GAP_PER_ADV_SLOW_INT_MIN

BT_GAP_PER_ADV_SLOW_INT_MAX

BT_GAP_INIT_CONN_INT_MIN

BT_GAP_INIT_CONN_INT_MAX

Defines

BT_GAP_ADV_MAX_ADV_DATA_LEN

Maximum advertising data length.

BT_GAP_ADV_MAX_EXT_ADV_DATA_LEN

Maximum extended advertising data length.

Note: The maximum advertising data length that can be sent by an extended advertiser is defined by the controller.

BT_GAP_TX_POWER_INVALID

BT_GAP_RSSI_INVALID

BT_GAP_SID_INVALID

BT_GAP_NO_TIMEOUT

BT_GAP_ADV_HIGH_DUTY_CYCLE_MAX_TIMEOUT

BT_GAP_DATA_LEN_DEFAULT

Default data length

BT_GAP_DATA_LEN_MAX

Maximum data length

BT_GAP_DATA_TIME_DEFAULT

Default data time

BT_GAP_DATA_TIME_MAX

Maximum data time

BT_GAP_SID_MAX

Maximum advertising set number

BT_GAP_PER_ADV_MAX_SKIP

Maximum number of consecutive periodic advertisement events that can be skipped after a successful receive.

BT_GAP_PER_ADV_MIN_TIMEOUT

Minimum Periodic Advertising Timeout (N * 10 ms)

BT_GAP_PER_ADV_MAX_TIMEOUT

Maximum Periodic Advertising Timeout (N * 10 ms)

BT_GAP_PER_ADV_MIN_INTERVAL

Minimum Periodic Advertising Interval (N * 1.25 ms)

BT_GAP_PER_ADV_MAX_INTERVAL

Maximum Periodic Advertising Interval (N * 1.25 ms)

BT_GAP_PER_ADV_INTERVAL_TO_MS(interval)

Convert periodic advertising interval (N * 1.25 ms) to milliseconds.

5 / 4 represents 1.25 ms unit.

BT_LE_SUPP_FEAT_40_ENCODE (w64)

Encode 40 least significant bits of 64-bit LE Supported Features into array values in little-endian format.

Helper macro to encode 40 least significant bits of 64-bit LE Supported Features value into advertising data. The number of bits that are encoded is a number of LE Supported Features defined by BT 5.3 Core specification.

Example of how to encode the 0x000000DFF00DF00D into advertising data.

```
BT_DATA_BYTES(BT_DATA_LE_SUPPORTED_FEATURES, BT_LE_SUPP_FEAT_40_

DENCODE(0x0000000FF00DF00D))
```

Parameters

• w64 – LE Supported Features value (64-bits)

Returns The comma separated values for LE Supported Features value that may be used directly as an argument for *BT_DATA_BYTES*.

BT_LE_SUPP_FEAT_32_ENCODE(w64)

Encode 4 least significant bytes of 64-bit LE Supported Features into 4 bytes long array of values in little-endian format.

Helper macro to encode 64-bit LE Supported Features value into advertising data. The macro encodes 4 least significant bytes into advertising data. Other 4 bytes are not encoded.

Example of how to encode the 0x000000DFF00DF00D into advertising data.

```
BT_DATA_BYTES(BT_DATA_LE_SUPPORTED_FEATURES, BT_LE_SUPP_FEAT_32_

DENCODE(0x000000DFF00DF00D))
```

Parameters

• w64 – LE Supported Features value (64-bits)

Returns The comma separated values for LE Supported Features value that may be used directly as an argument for *BT_DATA_BYTES*.

BT_LE_SUPP_FEAT_24_ENCODE(w64)

Encode 3 least significant bytes of 64-bit LE Supported Features into 3 bytes long array of values in littleendian format.

Helper macro to encode 64-bit LE Supported Features value into advertising data. The macro encodes 3 least significant bytes into advertising data. Other 5 bytes are not encoded.

Example of how to encode the 0x000000DFF00DF00D into advertising data.

```
BT_DATA_BYTES(BT_DATA_LE_SUPPORTED_FEATURES, BT_LE_SUPP_FEAT_24_

→ENCODE(0x000000DFF00DF00D))
```

Parameters

• w64 – LE Supported Features value (64-bits)

Returns The comma separated values for LE Supported Features value that may be used directly as an argument for *BT_DATA_BYTES*.

BT_LE_SUPP_FEAT_16_ENCODE(w64)

Encode 2 least significant bytes of 64-bit LE Supported Features into 2 bytes long array of values in little-endian format.

Helper macro to encode 64-bit LE Supported Features value into advertising data. The macro encodes 3 least significant bytes into advertising data. Other 6 bytes are not encoded.

Example of how to encode the 0x000000DFF00DF00D into advertising data.

```
BT_DATA_BYTES(BT_DATA_LE_SUPPORTED_FEATURES, BT_LE_SUPP_FEAT_16_

ENCODE(0x000000DFF00DF00D))
```

Parameters

• **w64** – LE Supported Features value (64-bits)

Returns The comma separated values for LE Supported Features value that may be used directly as an argument for *BT_DATA_BYTES*.

BT_LE_SUPP_FEAT_8_ENCODE (w64)

Encode the least significant byte of 64-bit LE Supported Features into single byte long array.

Helper macro to encode 64-bit LE Supported Features value into advertising data. The macro encodes the least significant byte into advertising data. Other 7 bytes are not encoded.

Example of how to encode the $\tt 0x000000DFF00DF00D$ into advertising data.

```
BT_DATA_BYTES(BT_DATA_LE_SUPPORTED_FEATURES, BT_LE_SUPP_FEAT_8_

SENCODE(0x0000000FF00DF00D))
```

Parameters

• w64 – LE Supported Features value (64-bits)

Returns The value of least significant byte of LE Supported Features value that may be used directly as an argument for *BT_DATA_BYTES*.

BT_LE_SUPP_FEAT_VALIDATE(w64)

Validate whether LE Supported Features value does not use bits that are reserved for future use.

Helper macro to check if w64 has zeros as bits 40-63. The macro is compliant with BT 5.3 Core Specification where bits 0-40 has assigned values. In case of invalid value, build time error is reported.

Enums

```
LE PHY types
Values:
enumerator BT_GAP_LE_PHY_NONE
    Convenience macro for when no PHY is set.
enumerator BT_GAP_LE_PHY_1M
    LE 1M PHY
enumerator BT_GAP_LE_PHY_2M
    LE 2M PHY
enumerator BT_GAP_LE_PHY_CODED
    LE Coded PHY
Advertising PDU types
Values:
enumerator BT_GAP_ADV_TYPE_ADV_IND
    Scannable and connectable advertising.
enumerator BT_GAP_ADV_TYPE_ADV_DIRECT_IND
    Directed connectable advertising.
enumerator BT_GAP_ADV_TYPE_ADV_SCAN_IND
    Non-connectable and scannable advertising.
```

enumerator BT_GAP_ADV_TYPE_ADV_NONCONN_IND

Non-connectable and non-scannable advertising.

enumerator BT_GAP_ADV_TYPE_SCAN_RSP

Additional advertising data requested by an active scanner.

enumerator BT_GAP_ADV_TYPE_EXT_ADV

Extended advertising, see advertising properties.

Advertising PDU properties

Values:

enumerator BT_GAP_ADV_PROP_CONNECTABLE

Connectable advertising.

enumerator BT_GAP_ADV_PROP_SCANNABLE

Scannable advertising.

enumerator BT_GAP_ADV_PROP_DIRECTED

Directed advertising.

enumerator BT_GAP_ADV_PROP_SCAN_RESPONSE

Additional advertising data requested by an active scanner.

enumerator BT_GAP_ADV_PROP_EXT_ADV

Extended advertising.

Constant Tone Extension (CTE) types

Values:

enumerator BT_GAP_CTE_AOA

Angle of Arrival

enumerator BT_GAP_CTE_AOD_1US

Angle of Departure with 1 us slots

enumerator BT_GAP_CTE_AOD_2US

Angle of Departure with 2 us slots

enumerator BT_GAP_CTE_NONE

No extensions

```
Peripheral sleep clock accuracy (SCA) in ppm (parts per million)
Values:
enumerator BT_GAP_SCA_UNKNOWN
   Unknown
enumerator BT_GAP_SCA_251_500
   251 ppm to 500 ppm
enumerator BT_GAP_SCA_151_250
    151 ppm to 250 ppm
enumerator BT_GAP_SCA_101_150
    101 ppm to 150 ppm
enumerator BT_GAP_SCA_76_100
   76 ppm to 100 ppm
enumerator BT_GAP_SCA_51_75
   51 ppm to 75 ppm
enumerator BT_GAP_SCA_31_50
   31 ppm to 50 ppm
enumerator BT_GAP_SCA_21_30
   21 ppm to 30 ppm
enumerator BT_GAP_SCA_0_20
   0 ppm to 20 ppm
```

1.6 Generic Attribute Profile (GATT)

GATT layer manages the service database providing APIs for service registration and attribute declaration.

Services can be registered using bt_gatt_service_register() API which takes the bt_gatt_service struct that provides the list of attributes the service contains. The helper macro BT_GATT_SERVICE() can be used to declare a service.

Attributes can be declared using the *bt_gatt_attr* struct or using one of the helper macros:

```
BT_GATT_PRIMARY_SERVICE Declares a Primary Service.
BT_GATT_SECONDARY_SERVICE Declares a Secondary Service.
BT_GATT_INCLUDE_SERVICE Declares a Include Service.
BT_GATT_CHARACTERISTIC Declares a Characteristic.
BT_GATT_DESCRIPTOR Declares a Descriptor.
```

```
BT_GATT_ATTRIBUTE Declares an Attribute.
```

BT_GATT_CCC Declares a Client Characteristic Configuration.

BT_GATT_CEP Declares a Characteristic Extended Properties.

BT_GATT_CUD Declares a Characteristic User Format.

Each attribute contain a uuid, which describes their type, a read callback, a write callback and a set of permission. Both read and write callbacks can be set to NULL if the attribute permission don't allow their respective operations.

Note: Attribute read and write callbacks are called directly from RX Thread thus it is not recommended to block for long periods of time in them.

Attribute value changes can be notified using $bt_gatt_notify()$ API, alternatively there is $bt_gatt_notify_cb()$ where is is possible to pass a callback to be called when it is necessary to know the exact instant when the data has been transmitted over the air. Indications are supported by $bt_gatt_indicate()$ API.

Client procedures can be enabled with the configuration option: CONFIG_BT_GATT_CLIENT

Discover procedures can be initiated with the use of bt_gatt_discover() API which takes the bt_gatt_discover_params struct which describes the type of discovery. The parameters also serves as a filter when setting the uuid field only attributes which matches will be discovered, in contrast setting it to NULL allows all attributes to be discovered.

Note: Caching discovered attributes is not supported.

Read procedures are supported by $bt_gatt_read()$ API which takes the $bt_gatt_read_params$ struct as parameters. In the parameters one or more attributes can be set, though setting multiple handles requires the option: CONFIG_BT_GATT_READ_MULTIPLE

Write procedures are supported by $bt_gatt_write()$ API and takes $bt_gatt_write_params$ struct as parameters. In case the write operation don't require a response $bt_gatt_write_without_response()$ or $bt_gatt_write_without_response_cb()$ APIs can be used, with the later working similarly to $bt_gatt_notify_cb()$.

Subscriptions to notification and indication can be initiated with use of $bt_gatt_subscribe()$ API which takes $bt_gatt_subscribe_params$ as parameters. Multiple subscriptions to the same attribute are supported so there could be multiple notify callback being triggered for the same attribute. Subscriptions can be removed with use of $bt_gatt_unsubscribe()$ API.

Note: When subscriptions are removed notify callback is called with the data set to NULL.

1.6.1 API Reference

group bt_gatt

Generic Attribute Profile (GATT).

Defines

BT_GATT_ERR(att err)

Construct error return value for attribute read and write callbacks.

Parameters

• _att_err - ATT error code

Returns Appropriate error code for the attribute callbacks.

BT_GATT_CHRC_BROADCAST

Characteristic broadcast property.

Characteristic Properties Bit field values

If set, permits broadcasts of the Characteristic Value using Server Characteristic Configuration Descriptor.

BT_GATT_CHRC_READ

Characteristic read property.

If set, permits reads of the Characteristic Value.

BT_GATT_CHRC_WRITE_WITHOUT_RESP

Characteristic write without response property.

If set, permits write of the Characteristic Value without response.

BT_GATT_CHRC_WRITE

Characteristic write with response property.

If set, permits write of the Characteristic Value with response.

BT_GATT_CHRC_NOTIFY

Characteristic notify property.

If set, permits notifications of a Characteristic Value without acknowledgment.

BT_GATT_CHRC_INDICATE

Characteristic indicate property.

If set, permits indications of a Characteristic Value with acknowledgment.

BT_GATT_CHRC_AUTH

Characteristic Authenticated Signed Writes property.

If set, permits signed writes to the Characteristic Value.

BT_GATT_CHRC_EXT_PROP

Characteristic Extended Properties property.

If set, additional characteristic properties are defined in the Characteristic Extended Properties Descriptor.

BT_GATT_CEP_RELIABLE_WRITE

Characteristic Extended Properties Bit field values

BT_GATT_CEP_WRITABLE_AUX

BT_GATT_CCC_NOTIFY

Client Characteristic Configuration Notification.

Client Characteristic Configuration Values

If set, changes to Characteristic Value shall be notified.

BT_GATT_CCC_INDICATE

Client Characteristic Configuration Indication.

If set, changes to Characteristic Value shall be indicated.

BT_GATT_SCC_BROADCAST

Server Characteristic Configuration Broadcast.

Server Characteristic Configuration Values

If set, the characteristic value shall be broadcast in the advertising data when the server is advertising.

Typedefs

typedef ssize_t (*bt_gatt_attr_read_func_t)(struct bt_conn *conn, const struct bt_gatt_attr *attr, void *buf, uint16 t len, uint16 t offset)

Attribute read callback.

The callback can also be used locally to read the contents of the attribute in which case no connection will be set.

Param conn The connection that is requesting to read

Param attr The attribute that's being read

Param buf Buffer to place the read result in

Param len Length of data to read

Param offset Offset to start reading from

Return Number of bytes read, or in case of an error *BT_GATT_ERR()* with a specific BT_ATT_ERR_* error code.

typedef ssize_t (***bt_gatt_attr_write_func_t**)(struct bt_conn *conn, const struct *bt_gatt_attr* *attr, const void *buf, uint16_t len, uint16_t offset, uint8_t flags)

Attribute write callback.

Param conn The connection that is requesting to write

Param attr The attribute that's being written

Param buf Buffer with the data to write

Param len Number of bytes in the buffer

Param offset Offset to start writing from

Param flags Flags (BT_GATT_WRITE_FLAG_*)

Return Number of bytes written, or in case of an error *BT_GATT_ERR()* with a specific BT_ATT_ERR_* error code.

Enums

enum bt_gatt_perm

GATT attribute permission bit field values

Values:

enumerator BT_GATT_PERM_NONE

No operations supported, e.g. for notify-only

enumerator BT_GATT_PERM_READ

Attribute read permission.

enumerator BT_GATT_PERM_WRITE

Attribute write permission.

enumerator BT_GATT_PERM_READ_ENCRYPT

Attribute read permission with encryption.

If set, requires encryption for read access.

enumerator BT_GATT_PERM_WRITE_ENCRYPT

Attribute write permission with encryption.

If set, requires encryption for write access.

enumerator BT_GATT_PERM_READ_AUTHEN

Attribute read permission with authentication.

If set, requires encryption using authenticated link-key for read access.

enumerator BT_GATT_PERM_WRITE_AUTHEN

Attribute write permission with authentication.

If set, requires encryption using authenticated link-key for write access.

enumerator BT_GATT_PERM_PREPARE_WRITE

Attribute prepare write permission.

If set, allows prepare writes with use of BT_GATT_WRITE_FLAG_PREPARE passed to write callback.

enumerator BT_GATT_PERM_READ_LESC

Attribute read permission with LE Secure Connection encryption.

If set, requires that LE Secure Connections is used for read access.

enumerator BT_GATT_PERM_WRITE_LESC

Attribute write permission with LE Secure Connection encryption.

If set, requires that LE Secure Connections is used for write access.

GATT attribute write flags

Values:

enumerator BT_GATT_WRITE_FLAG_PREPARE

Attribute prepare write flag.

If set, write callback should only check if the device is authorized but no data shall be written.

enumerator BT_GATT_WRITE_FLAG_CMD

Attribute write command flag.

If set, indicates that write operation is a command (Write without response) which doesn't generate any response.

enumerator BT_GATT_WRITE_FLAG_EXECUTE

Attribute write execute flag.

If set, indicates that write operation is a execute, which indicates the end of a long write, and will come after 1 or more @ref BT_GATT_WRITE_FLAG_PREPARE.

```
struct \ \textbf{bt\_gatt\_attr}
     #include < gatt.h > GATT Attribute structure.
     Public Members
     const struct bt_uuid *uuid
         Attribute UUID
     bt_gatt_attr_write_func_t write
         Attribute write callback
     void *user_data
         Attribute user data
     uint16_t handle
         Attribute handle
     uint16_t perm
         Attribute permissions.
         Will be 0 if returned from bt_gatt_discover().
struct bt_gatt_service_static
     #include <gatt.h> GATT Service structure.
     Public Members
     const struct bt_gatt_attr *attrs
         Service Attributes
     size t attr_count
         Service Attribute count
struct bt_gatt_service
     #include <gatt.h> GATT Service structure.
     Public Members
     struct bt_gatt_attr *attrs
         Service Attributes
     size_t attr_count
         Service Attribute count
```

struct bt_gatt_service_val

#include <gatt.h> Service Attribute Value.

Public Members

```
const struct bt_uuid *uuid
```

Service UUID.

uint16_t end_handle

Service end handle.

struct bt_gatt_include

#include <gatt.h> Include Attribute Value.

Public Members

```
const struct bt uuid *uuid
```

Service UUID.

uint16 t start_handle

Service start handle.

uint16_t end_handle

Service end handle.

struct bt_gatt_cb

#include <gatt.h> GATT callback structure.

Public Members

```
void (*att_mtu_updated)(struct bt_conn *conn, uint16_t tx, uint16_t rx)
```

The maximum ATT MTU on a connection has changed.

This callback notifies the application that the maximum TX or RX ATT MTU has increased.

Param conn Connection object.

Param tx Updated TX ATT MTU.

Param rx Updated RX ATT MTU.

struct bt_gatt_authorization_cb

#include <gatt.h> GATT authorization callback structure.

Public Members

bool (***read_authorize**)(struct bt_conn *conn, const struct bt_gatt_attr *attr)

Authorize the GATT read operation.

This callback allows the application to authorize the GATT read operation for the attribute that is being read.

Param conn Connection object.

Param attr The attribute that is being read.

Retval true Authorize the operation and allow it to execute.

Retval false Reject the operation and prevent it from executing.

bool (*write_authorize)(struct bt_conn *conn, const struct bt_gatt_attr *attr)

Authorize the GATT write operation.

This callback allows the application to authorize the GATT write operation for the attribute that is being written.

Param conn Connection object.

Param attr The attribute that is being written.

Retval true Authorize the operation and allow it to execute.

Retval false Reject the operation and prevent it from executing.

struct bt_gatt_chrc

#include <gatt.h> Characteristic Attribute Value.

Public Members

const struct bt uuid *uuid

Characteristic UUID.

uint16 t value_handle

Characteristic Value handle.

uint8_t properties

Characteristic properties.

struct bt_gatt_cep

#include < gatt.h > Characteristic Extended Properties Attribute Value.

Public Members

uint16_t properties

Characteristic Extended properties

struct bt_gatt_ccc

#include < gatt.h > Client Characteristic Configuration Attribute Value

Public Members

uint16_t **flags**

Client Characteristic Configuration flags

struct bt_gatt_scc

#include <gatt.h> Server Characteristic Configuration Attribute Value

Public Members

uint16_t flags

Server Characteristic Configuration flags

struct bt_gatt_cpf

#include < gatt.h > GATT Characteristic Presentation Format Attribute Value.

Public Members

uint8_t format

Format of the value of the characteristic

int8_t exponent

Exponent field to determine how the value of this characteristic is further formatted

uint 16_t unit

Unit of the characteristic

uint8_t name_space

Name space of the description

uint16_t description

Description of the characteristic as defined in a higher layer profile

1.6.1.1 GATT Server

group bt_gatt_server

Defines

BT_GATT_SERVICE_DEFINE(name, ...)

Statically define and register a service.

Helper macro to statically define and register a service.

Parameters

• _name - Service name.

_BT_GATT_ATTRS_ARRAY_DEFINE(n, _instances, _attrs_def)

_BT_GATT_SERVICE_ARRAY_ITEM(n,)

BT_GATT_SERVICE_INSTANCE_DEFINE(_name, _instances, _instance_num, _attrs_def)

Statically define service structure array.

Helper macro to statically define service structure array. Each element of the array is linked to the service attribute array which is also defined in this scope using attrs def macro.

Parameters

- _name Name of service structure array.
- _instances Array of instances to pass as user context to the attribute callbacks.
- _instance_num Number of elements in instance array.
- _attrs_def Macro provided by the user that defines attribute array for the service. This macro should accept single parameter which is the instance context.

BT_GATT_SERVICE(attrs)

Service Structure Declaration Macro.

Helper macro to declare a service structure.

Parameters

• attrs – Service attributes.

BT_GATT_PRIMARY_SERVICE(service)

Primary Service Declaration Macro.

Helper macro to declare a primary service attribute.

Parameters

• _service - Service attribute value.

BT_GATT_SECONDARY_SERVICE(_service)

Secondary Service Declaration Macro.

Helper macro to declare a secondary service attribute.

Note: A secondary service is only intended to be included from a primary service or another secondary service or other higher layer specification.

Parameters

• _service – Service attribute value.

BT_GATT_INCLUDE_SERVICE(service incl)

Include Service Declaration Macro.

Helper macro to declare database internal include service attribute.

Parameters

• _service_incl - the first service attribute of service to include

BT_GATT_CHRC_INIT(_uuid, _handle, _props)

```
BT_GATT_CHARACTERISTIC(_uuid, _props, _perm, _read, _write, _user_data)
```

Characteristic and Value Declaration Macro.

Helper macro to declare a characteristic attribute along with its attribute value.

Parameters

- _uuid Characteristic attribute uuid.
- _props Characteristic attribute properties, a bitmap of BT_GATT_CHRC_* macros.
- _perm Characteristic Attribute access permissions, a bitmap of bt_gatt_perm values.
- **_read** Characteristic Attribute read callback (*bt_gatt_attr_read_func_t*).
- _write Characteristic Attribute write callback (bt_gatt_attr_write_func_t).
- _user_data Characteristic Attribute user data.

BT_GATT_CCC_MAX

BT_GATT_CCC_INITIALIZER(_changed, _write, _match)

Initialize Client Characteristic Configuration Declaration Macro.

Helper macro to initialize a Managed CCC attribute value.

Parameters

- _changed Configuration changed callback.
- _write Configuration write callback.
- _match Configuration match callback.

BT_GATT_CCC_MANAGED(_ccc, _perm)

Managed Client Characteristic Configuration Declaration Macro.

Helper macro to declare a Managed CCC attribute.

Parameters

- **_ccc** CCC attribute user data, shall point to a _bt_gatt_ccc.
- **_perm** CCC access permissions, a bitmap of *bt_gatt_perm* values.

BT_GATT_CCC(_changed, _perm)

Client Characteristic Configuration Declaration Macro.

Helper macro to declare a CCC attribute.

Parameters

- **_changed** Configuration changed callback.
- _perm CCC access permissions, a bitmap of bt_gatt_perm values.

BT_GATT_CEP(value)

Characteristic Extended Properties Declaration Macro.

Helper macro to declare a CEP attribute.

Parameters

• _value – Pointer to a struct bt_gatt_cep.

BT_GATT_CUD(_value, _perm)

Characteristic User Format Descriptor Declaration Macro.

Helper macro to declare a CUD attribute.

Parameters

- _value User description NULL-terminated C string.
- _perm Descriptor attribute access permissions, a bitmap of bt_gatt_perm values.

BT_GATT_CPF(_value)

Characteristic Presentation Format Descriptor Declaration Macro.

Helper macro to declare a CPF attribute.

Parameters

• _value – Pointer to a struct bt_gatt_cpf.

BT_GATT_DESCRIPTOR(_uuid, _perm, _read, _write, _user_data)

Descriptor Declaration Macro.

Helper macro to declare a descriptor attribute.

Parameters

- **_uuid** Descriptor attribute uuid.
- **_perm** Descriptor attribute access permissions, a bitmap of *bt_gatt_perm* values.
- **_read** Descriptor attribute read callback (*bt_gatt_attr_read_func_t*).
- **_write** Descriptor attribute write callback (*bt_gatt_attr_write_func_t*).
- _user_data Descriptor attribute user data.

BT_GATT_ATTRIBUTE(_uuid, _perm, _read, _write, _user_data)

Attribute Declaration Macro.

Helper macro to declare an attribute.

Parameters

- **_uuid** Attribute uuid.
- **_perm** Attribute access permissions, a bitmap of *bt_gatt_perm* values.
- **_read** Attribute read callback (*bt_gatt_attr_read_func_t*).
- **_write** Attribute write callback (*bt_gatt_attr_write_func_t*).
- _user_data Attribute user data.

Typedefs

```
typedef uint8_t (*bt_gatt_attr_func_t)(const struct bt_gatt_attr *attr, uint16_t handle, void *user_data)

Attribute iterator callback.
```

Param attr Attribute found.

Param handle Attribute handle found.

Param user_data Data given.

Return BT GATT ITER CONTINUE if should continue to the next attribute.

Return BT_GATT_ITER_STOP to stop.

typedef void (*bt_gatt_complete_func_t)(struct bt_conn *conn, void *user_data)

Notification complete result callback.

Param conn Connection object.

Param user_data Data passed in by the user.

typedef void (*bt_gatt_indicate_func_t)(struct bt_conn *conn, struct bt_gatt_indicate_params *params, uint8 t err)

Indication complete result callback.

Param conn Connection object.

Param params Indication params object.

Param err ATT error code

typedef void (*bt_gatt_indicate_params_destroy_t)(struct bt_gatt_indicate_params *params)

Enums

Values:

enumerator BT_GATT_ITER_STOP

enumerator BT_GATT_ITER_CONTINUE

Functions

void bt_gatt_cb_register(struct bt_gatt_cb *cb)

Register GATT callbacks.

Register callbacks to monitor the state of GATT. The callback struct must remain valid for the remainder of the program.

Parameters

• **cb** – Callback struct.

int **bt_gatt_authorization_cb_register**(const struct *bt_gatt_authorization_cb* *cb)

Register GATT authorization callbacks.

Register callbacks to perform application-specific authorization of GATT operations on all registered GATT attributes. The callback structure must remain valid throughout the entire duration of the Bluetooth subsys activity.

The @kconfig{CONFIG_BT_GATT_AUTHORIZATION_CUSTOM} Kconfig must be enabled to make this API functional.

This API allows the user to register only one callback structure concurrently. Passing NULL unregisters the previous set of callbacks and makes it possible to register a new one.

Parameters

• cb – Callback struct.

Returns Zero on success or negative error code otherwise

```
int bt_gatt_service_register(struct bt_gatt_service *svc)
```

Register GATT service.

Register GATT service. Applications can make use of macros such as BT_GATT_PRIMARY_SERVICE, BT_GATT_CHARACTERISTIC, BT_GATT_DESCRIPTOR, etc.

When using @kconfig{CONFIG_BT_SETTINGS} then all services that should have bond configuration loaded, i.e. CCC values, must be registered before calling settings_load.

When using @kconfig{CONFIG_BT_GATT_CACHING} and @kconfig{CONFIG_BT_SETTINGS} then all services that should be included in the GATT Database Hash calculation should be added before calling settings_load. All services registered after settings_load will trigger a new database hash calculation and a new hash stored.

There are two situations where this function can be called: either before bt_init() has been called, or after settings_load() has been called. Registering a service in the middle is not supported and will return an error.

Parameters

• svc – Service containing the available attributes

Returns 0 in case of success or negative value in case of error.

Returns -EAGAIN if bt_init() has been called but settings_load() hasn't yet.

int bt_gatt_service_unregister(struct bt_gatt_service *svc)

Unregister GATT service.

Parameters

• **svc** – Service to be unregistered.

Returns 0 in case of success or negative value in case of error.

bool bt_gatt_service_is_registered(const struct bt_gatt_service *svc)

Check if GATT service is registered.

Parameters

• **svc** – Service to be checked.

Returns true if registered or false if not register.

void **bt_gatt_foreach_attr_type**(uint16_t start_handle, uint16_t end_handle, const struct *bt_uuid* *uuid, const void *attr_data, uint16_t num_matches, *bt_gatt_attr_func_t* func, void *user data)

Attribute iterator by type.

Iterate attributes in the given range matching given UUID and/or data.

Parameters

- start handle Start handle.
- end handle End handle.
- uuid UUID to match, passing NULL skips UUID matching.
- attr_data Attribute data to match, passing NULL skips data matching.
- **num_matches** Number matches, passing 0 makes it unlimited.
- func Callback function.
- **user_data** Data to pass to the callback.

static inline void **bt_gatt_foreach_attr**(uint16_t start_handle, uint16_t end_handle, *bt_gatt_attr_func_t* func, void *user_data)

Attribute iterator.

Iterate attributes in the given range.

Parameters

- start_handle Start handle.
- end_handle End handle.
- func Callback function.
- **user_data** Data to pass to the callback.

struct bt_gatt_attr *bt_gatt_attr_next(const struct bt_gatt_attr *attr)

Iterate to the next attribute.

Iterate to the next attribute following a given attribute.

Parameters

• **attr** – Current Attribute.

Returns The next attribute or NULL if it cannot be found.

struct bt_gatt_attr *bt_gatt_find_by_uuid(const struct bt_gatt_attr *attr, uint16_t attr_count, const struct bt_uuid *uuid)

Find Attribute by UUID.

Find the attribute with the matching UUID. To limit the search to a service set the attr to the service attributes and the attr_count to the service attribute count .

Parameters

- attr Pointer to an attribute that serves as the starting point for the search of a match for the UUID. Passing NULL will search the entire range.
- attr_count The number of attributes from the starting point to search for a match for the UUID. Set to 0 to search until the end.
- uuid UUID to match.

uint16_t bt_gatt_attr_get_handle(const struct bt_gatt_attr *attr)

Get Attribute handle.

Parameters

• attr – Attribute object.

Returns Handle of the corresponding attribute or zero if the attribute could not be found.

uint16_t bt_gatt_attr_value_handle(const struct bt_gatt_attr *attr)

Get the handle of the characteristic value descriptor.

Note: The user_data of the attribute must of type *bt_gatt_chrc*.

Parameters

• attr - A Characteristic Attribute.

Returns the handle of the corresponding Characteristic Value. The value will be zero (the invalid handle) if attr was not a characteristic attribute.

ssize_t **bt_gatt_attr_read**(struct bt_conn *conn, const struct *bt_gatt_attr* *attr, void *buf, uint16_t buf_len, uint16_t offset, const void *value, uint16_t value_len)

Generic Read Attribute value helper.

Read attribute value from local database storing the result into buffer.

Parameters

- conn Connection object.
- attr Attribute to read.
- **buf** Buffer to store the value.
- buf_len Buffer length.
- offset Start offset.
- value Attribute value.
- value_len Length of the attribute value.

Returns number of bytes read in case of success or negative values in case of error.

ssize_t **bt_gatt_attr_read_service**(struct bt_conn *conn, const struct *bt_gatt_attr* *attr, void *buf, uint16_t len, uint16_t offset)

Read Service Attribute helper.

Read service attribute value from local database storing the result into buffer after encoding it.

Note: Only use this with attributes which user_data is a *bt_uuid*.

Parameters

- conn Connection object.
- attr Attribute to read.
- **buf** Buffer to store the value read.

- **len** Buffer length.
- **offset** Start offset.

Returns number of bytes read in case of success or negative values in case of error.

ssize_t bt_gatt_attr_read_included(struct bt_conn *conn, const struct bt_gatt_attr *attr, void *buf, uint16 t len, uint16 t offset)

Read Include Attribute helper.

Read include service attribute value from local database storing the result into buffer after encoding it.

Note: Only use this with attributes which user_data is a *bt_gatt_include*.

Parameters

- **conn** Connection object.
- attr Attribute to read.
- **buf** Buffer to store the value read.
- **len** Buffer length.
- offset Start offset.

Returns number of bytes read in case of success or negative values in case of error.

ssize_t **bt_gatt_attr_read_chrc**(struct bt_conn *conn, const struct *bt_gatt_attr* *attr, void *buf, uint16_t len, uint16_t offset)

Read Characteristic Attribute helper.

Read characteristic attribute value from local database storing the result into buffer after encoding it.

Note: Only use this with attributes which user_data is a *bt_gatt_chrc*.

Parameters

- conn Connection object.
- attr Attribute to read.
- **buf** Buffer to store the value read.
- **len** Buffer length.
- offset Start offset.

Returns number of bytes read in case of success or negative values in case of error.

ssize_t **bt_gatt_attr_read_ccc**(struct bt_conn *conn, const struct *bt_gatt_attr* *attr, void *buf, uint16_t len, uint16_t offset)

Read Client Characteristic Configuration Attribute helper.

Read CCC attribute value from local database storing the result into buffer after encoding it.

Note: Only use this with attributes which user data is a *bt gatt ccc*.

Parameters

- conn Connection object.
- attr Attribute to read.
- **buf** Buffer to store the value read.
- **len** Buffer length.
- offset Start offset.

Returns number of bytes read in case of success or negative values in case of error.

ssize_t **bt_gatt_attr_write_ccc**(struct bt_conn *conn, const struct *bt_gatt_attr* *attr, const void *buf, uint16_t len, uint16_t offset, uint8_t flags)

Write Client Characteristic Configuration Attribute helper.

Write value in the buffer into CCC attribute.

Note: Only use this with attributes which user_data is a _bt_gatt_ccc.

Parameters

- conn Connection object.
- attr Attribute to read.
- **buf** Buffer to store the value read.
- **len** Buffer length.
- offset Start offset.
- **flags** Write flags.

Returns number of bytes written in case of success or negative values in case of error.

ssize_t **bt_gatt_attr_read_cep**(struct bt_conn *conn, const struct *bt_gatt_attr* *attr, void *buf, uint16_t len, uint16_t offset)

Read Characteristic Extended Properties Attribute helper.

Read CEP attribute value from local database storing the result into buffer after encoding it.

Note: Only use this with attributes which user_data is a *bt_gatt_cep*.

Parameters

- conn Connection object
- attr Attribute to read
- **buf** Buffer to store the value read
- len Buffer length
- offset Start offset

Returns number of bytes read in case of success or negative values in case of error.

ssize_t **bt_gatt_attr_read_cud**(struct bt_conn *conn, const struct *bt_gatt_attr* *attr, void *buf, uint16_t len, uint16_t offset)

Read Characteristic User Description Descriptor Attribute helper.

Read CUD attribute value from local database storing the result into buffer after encoding it.

Note: Only use this with attributes which user_data is a NULL-terminated C string.

Parameters

- conn Connection object
- attr Attribute to read
- buf Buffer to store the value read
- **len** Buffer length
- offset Start offset

Returns number of bytes read in case of success or negative values in case of error.

ssize_t **bt_gatt_attr_read_cpf**(struct bt_conn *conn, const struct *bt_gatt_attr* *attr, void *buf, uint16_t len, uint16_t offset)

Read Characteristic Presentation format Descriptor Attribute helper.

Read CPF attribute value from local database storing the result into buffer after encoding it.

Note: Only use this with attributes which user data is a bt gatt pf.

Parameters

- **conn** Connection object
- attr Attribute to read
- buf Buffer to store the value read
- len Buffer length
- offset Start offset

Returns number of bytes read in case of success or negative values in case of error.

int **bt_gatt_notify_cb**(struct bt_conn *conn, struct *bt_gatt_notify_params* *params)

Notify attribute value change.

This function works in the same way as bt_gatt_notify . With the addition that after sending the notification the callback function will be called.

The callback is run from System Workqueue context. When called from the System Workqueue context this API will not wait for resources for the callback but instead return an error. The number of pending callbacks can be increased with the <code>@kconfig{CONFIG_BT_CONN_TX_MAX}</code> option.

Alternatively it is possible to notify by UUID by setting it on the parameters, when using this method the attribute if provided is used as the start range when looking up for possible matches.

Parameters

• **conn** – Connection object.

• params – Notification parameters.

Returns 0 in case of success or negative value in case of error.

int **bt_gatt_notify_multiple**(struct bt_conn *conn, uint16_t num_params, struct *bt_gatt_notify_params* params[])

Send multiple notifications in a single PDU.

The GATT Server will send a single ATT_MULTIPLE_HANDLE_VALUE_NTF PDU containing all the notifications passed to this API.

All params must have the same func and user_data (due to implementation limitation). But func(user_data) will be invoked for each parameter.

As this API may block to wait for Bluetooth Host resources, it is not recommended to call it from a cooperative thread or a Bluetooth callback.

The peer's GATT Client must write to this device's Client Supported Features attribute and set the bit for Multiple Handle Value Notifications before this API can be used.

Only use this API to force the use of the ATT_MULTIPLE_HANDLE_VALUE_NTF PDU. For standard applications, bt_gatt_notify_cb is preferred, as it will use this PDU if supported and automatically fallback to ATT_HANDLE_VALUE_NTF when not supported by the peer.

This API has an additional limitation: it only accepts valid attribute references and not UUIDs like bt_gatt_notify and bt_gatt_notify_cb.

Parameters

- **conn** Target client. Notifying all connected clients by passing NULL is not yet supported, please use bt_gatt_notify instead.
- **num_params** Element count of **params** array. Has to be greater than 1.
- params Array of notification parameters. It is okay to free this after calling this function.

Return values

- **0** Success. The PDU is queued for sending.
- -EINVAL -
 - One of the attribute handles is invalid.
 - Only one parameter was passed. This API expects 2 or more.
 - Not all func were equal or not all user_data were equal.
 - One of the characteristics is not notifiable.
 - An UUID was passed in one of the parameters.
- -ERANGE -
 - The notifications cannot all fit in a single ATT_MULTIPLE_HANDLE_VALUE_NTF.
 - They exceed the MTU of all open ATT bearers.
- **-EPERM** The connection has a lower security level than required by one of the attributes.
- **-EOPNOTSUPP** The peer hasn't yet communicated that it supports this PDU type.

static inline int **bt_gatt_notify**(struct bt_conn *conn, const struct *bt_gatt_attr* *attr, const void *data, uint16_t len)

Notify attribute value change.

Send notification of attribute value change, if connection is NULL notify all peer that have notification enabled via CCC otherwise do a direct notification only the given connection.

The attribute object on the parameters can be the so called Characteristic Declaration, which is usually declared with BT_GATT_CHARACTERISTIC followed by BT_GATT_CCC, or the Characteristic Value Declaration which is automatically created after the Characteristic Declaration when using BT GATT CHARACTERISTIC.

Parameters

- conn Connection object.
- attr Characteristic or Characteristic Value attribute.
- data Pointer to Attribute data.
- **len** Attribute value length.

Returns 0 in case of success or negative value in case of error.

static inline int **bt_gatt_notify_uuid**(struct bt_conn *conn, const struct *bt_uuid* *uuid, const struct *bt_gatt_attr* *attr, const void *data, uint16_t len)

Notify attribute value change by UUID.

Send notification of attribute value change, if connection is NULL notify all peer that have notification enabled via CCC otherwise do a direct notification only on the given connection.

The attribute object is the starting point for the search of the UUID.

Parameters

- **conn** Connection object.
- **uuid** The UUID. If the server contains multiple services with the same UUID, then the first occurrence, starting from the attr given, is used.
- attr Pointer to an attribute that serves as the starting point for the search of a match for the UUID.
- data Pointer to Attribute data.
- **len** Attribute value length.

Returns 0 in case of success or negative value in case of error.

int **bt_gatt_indicate**(struct bt_conn *conn, struct bt_gatt_indicate_params *params)

Indicate attribute value change.

Send an indication of attribute value change. if connection is NULL indicate all peer that have notification enabled via CCC otherwise do a direct indication only the given connection.

The attribute object on the parameters can be the so called Characteristic Declaration, which is usually declared with BT_GATT_CHARACTERISTIC followed by BT_GATT_CCC, or the Characteristic Value Declaration which is automatically created after the Characteristic Declaration when using BT_GATT_CHARACTERISTIC.

Alternatively it is possible to indicate by UUID by setting it on the parameters, when using this method the attribute if provided is used as the start range when looking up for possible matches.

Note: This procedure is asynchronous therefore the parameters need to remains valid while it is active. The procedure is active until the destroy callback is run.

Parameters

- conn Connection object.
- params Indicate parameters.

Returns 0 in case of success or negative value in case of error.

bool bt_gatt_is_subscribed(struct bt_conn *conn, const struct bt_gatt_attr *attr, uint16_t ccc_type)

Check if connection have subscribed to attribute.

Check if connection has subscribed to attribute value change.

The attribute object can be the so called Characteristic Declaration, which is usually declared with BT_GATT_CHARACTERISTIC followed by BT_GATT_CCC, or the Characteristic Value Declaration which is automatically created after the Characteristic Declaration when using BT_GATT_CHARACTERISTIC, or the Client Characteristic Configuration Descriptor (CCCD) which is created by BT_GATT_CCC.

Parameters

- conn Connection object.
- attr Attribute object.
- ccc_type The subscription type, $BT_GATT_CCC_NOTIFY$ and/or $BT_GATT_CCC_INDICATE$.

Returns true if the attribute object has been subscribed.

```
uint16_t bt_gatt_get_mtu(struct bt_conn *conn)
```

Get ATT MTU for a connection.

Get negotiated ATT connection MTU, note that this does not equal the largest amount of attribute data that can be transferred within a single packet.

Parameters

• **conn** – Connection object.

Returns MTU in bytes

struct bt_gatt_ccc_cfg

#include <gatt.h> GATT CCC configuration entry.

Public Members

uint8_t id

Local identity, BT_ID_DEFAULT in most cases.

bt_addr_le_t peer

Remote peer address.

uint16_t value

Configuration value.

struct _bt_gatt_ccc

#include <gatt.h> Internal representation of CCC value

Public Members

struct *bt_gatt_ccc_cfg* **cfg**[0]

Configuration for each connection

uint16_t value

Highest value of all connected peer's subscriptions

void (*cfg_changed)(const struct bt_gatt_attr_*attr, uint16_t value)

CCC attribute changed callback.

Param attr The attribute that's changed value

Param value New value

ssize_t (***cfg_write**)(struct bt_conn *conn, const struct bt_gatt_attr *attr, uint16_t value)

CCC attribute write validation callback.

Param conn The connection that is requesting to write

Param attr The attribute that's being written

Param value CCC value to write

Return Number of bytes to write, or in case of an error BT_GATT_ERR() with a specific error code.

bool (***cfg_match**)(struct bt_conn *conn, const struct bt_gatt_attr *attr)

CCC attribute match handler.

Indicate if it is OK to send a notification or indication to the subscriber.

Param conn The connection that is being checked

Param attr The attribute that's being checked

Return true if application has approved notification/indication, false if application does not approve.

struct bt_gatt_notify_params

#include <gatt.h>

Public Members

const struct bt uuid *uuid

Notification Attribute UUID type.

Optional, use to search for an attribute with matching UUID when the attribute object pointer is not known.

const struct bt_gatt_attr *attr

Notification Attribute object.

Optional if uuid is provided, in this case it will be used as start range to search for the attribute with the given UUID.

const void *data

Notification Value data

uint16_t len

Notification Value length

bt_gatt_complete_func_t func

Notification Value callback

void *user_data

Notification Value callback user data

struct bt_gatt_indicate_params

#include <gatt.h> GATT Indicate Value parameters.

Public Members

```
const struct bt_uuid *uuid
```

Indicate Attribute UUID type.

Optional, use to search for an attribute with matching UUID when the attribute object pointer is not known.

```
const struct bt_gatt_attr *attr
```

Indicate Attribute object.

Optional if uuid is provided, in this case it will be used as start range to search for the attribute with the given UUID.

```
bt_gatt_indicate_func_t func
```

Indicate Value callback

bt_gatt_indicate_params_destroy_t destroy

Indicate operation complete callback

const void *data

Indicate Value data

uint16_t len

Indicate Value length

uint8_t _ref

Private reference counter

1.6.1.2 GATT Client

group bt_gatt_client

Typedefs

typedef uint8_t (*bt_gatt_discover_func_t)(struct bt_conn *conn, const struct bt_gatt_attr *attr, struct bt_gatt_discover_params *params)

Discover attribute callback function.

If discovery procedure has completed this callback will be called with attr set to NULL. This will not happen if procedure was stopped by returning BT_GATT_ITER_STOP.

The attribute object as well as its UUID and value objects are temporary and must be copied to in order to cache its information. Only the following fields of the attribute contains valid information:

- uuid UUID representing the type of attribute.
- handle Handle in the remote database.
- user_data The value of the attribute, if the discovery type maps to an ATT operation that provides this
 information. NULL otherwise. See below.

The effective type of attr->user_data is determined by params. Note that the fields params->type and params->uuid are left unchanged by the discovery procedure.

params->type	params->uuid	Type of attr->user_data
BT_GATT_DISCOVER_PRIMARY	any	bt_gatt_service_val
BT_GATT_DISCOVER_SECONDARY	any	bt_gatt_service_val
BT_GATT_DISCOVER_INCLUDE	any	bt_gatt_include
BT_GATT_DISCOVER_CHARACTERISTIC	any	bt_gatt_chrc
BT_GATT_DISCOVER_STD_CHAR_DESC	BT_UUID_GATT_CEP	bt_gatt_cep
BT_GATT_DISCOVER_STD_CHAR_DESC	BT_UUID_GATT_CCC	bt_gatt_ccc
BT_GATT_DISCOVER_STD_CHAR_DESC	BT_UUID_GATT_SCC	bt_gatt_scc
BT_GATT_DISCOVER_STD_CHAR_DESC	BT_UUID_GATT_CPF	bt_gatt_cpf
BT_GATT_DISCOVER_DESCRIPTOR	any	NULL
BT_GATT_DISCOVER_ATTRIBUTE	any	NULL

Also consider if using read-by-type instead of discovery is more convenient. See bt_gatt_read with $bt_gatt_read_params::handle_count$ set to 0.

Param conn Connection object.

Param attr Attribute found, or NULL if not found.

Param params Discovery parameters given.

 $\textbf{Return} \ \ \text{BT_GATT_ITER_CONTINUE} \ to \ continue \ discovery \ procedure.$

Return BT_GATT_ITER_STOP to stop discovery procedure.

typedef uint8_t (*bt_gatt_read_func_t)(struct bt_conn *conn, uint8_t err, struct bt_gatt_read_params *params, const void *data, uint16_t length)

Read callback function.

When reading using by_uuid, params->start_handle is the attribute handle for this data item.

Param conn Connection object.

Param err ATT error code.

Param params Read parameters used.

Param data Attribute value data. NULL means read has completed.

Param length Attribute value length.

Return BT_GATT_ITER_CONTINUE if should continue to the next attribute.

Return BT_GATT_ITER_STOP to stop.

typedef void (*bt_gatt_write_func_t)(struct bt_conn *conn, uint8_t err, struct bt_gatt_write_params *params)

Write callback function.

Param conn Connection object.

Param err ATT error code.

Param params Write parameters used.

typedef uint8_t (***bt_gatt_notify_func_t**)(struct bt_conn *conn, struct *bt_gatt_subscribe_params* *params, const void *data, uint16_t length)

Notification callback function.

In the case of an empty notification, the data pointer will be non-NULL while the length will be 0, which is due to the special case where a data NULL pointer means unsubscribed.

Param conn Connection object. May be NULL, indicating that the peer is being unpaired

Param params Subscription parameters.

Param data Attribute value data. If NULL then subscription was removed.

Param length Attribute value length.

Return BT_GATT_ITER_CONTINUE to continue receiving value notifications. BT_GATT_ITER_STOP to unsubscribe from value notifications.

typedef void (*bt_gatt_subscribe_func_t)(struct bt_conn *conn, uint8_t err, struct bt_gatt_subscribe_params *params)

Subscription callback function.

Param conn Connection object.

Param err ATT error code.

Param params Subscription parameters used.

Enums

GATT Discover types

Values:

enumerator BT_GATT_DISCOVER_PRIMARY

Discover Primary Services.

enumerator BT_GATT_DISCOVER_SECONDARY

Discover Secondary Services.

enumerator BT_GATT_DISCOVER_INCLUDE

Discover Included Services.

enumerator BT_GATT_DISCOVER_CHARACTERISTIC

Discover Characteristic Values.

Discover Characteristic Value and its properties.

enumerator BT_GATT_DISCOVER_DESCRIPTOR

Discover Descriptors.

Discover Attributes which are not services or characteristics.

enumerator BT_GATT_DISCOVER_ATTRIBUTE

Discover Attributes.

Discover Attributes of any type.

enumerator BT_GATT_DISCOVER_STD_CHAR_DESC

Discover standard characteristic descriptor values.

Discover standard characteristic descriptor values and their properties.

Supported **descriptors**:

- Characteristic Extended Properties
- Client Characteristic Configuration
- Server Characteristic Configuration
- Characteristic Presentation Format

Subscription flags

Values:

enumerator BT_GATT_SUBSCRIBE_FLAG_VOLATILE

Persistence flag.

If set, indicates that the subscription is not saved on the GATT server side. Therefore, upon disconnection, the subscription will be automatically removed from the client's subscriptions list and when the client reconnects, it will have to issue a new subscription.

enumerator BT_GATT_SUBSCRIBE_FLAG_NO_RESUB

No resubscribe flag.

By **default** when BT_GATT_SUBSCRIBE_FLAG_VOLATILE is unset, the subscription will be automatically renewed when the client reconnects, as a workaround **for** GATT servers that **do** not persist subscriptions.

This flag will disable the automatic resubscription. It is useful if the application layer knows that the GATT server remembers subscriptions from previous connections and wants to avoid renewing the subscriptions.

enumerator BT_GATT_SUBSCRIBE_FLAG_WRITE_PENDING

Write pending flag.

If set, indicates write operation is pending waiting remote end to respond.

@note Internal use only.

enumerator BT_GATT_SUBSCRIBE_FLAG_SENT

Sent flag.

If set, indicates that a subscription request (CCC write) has already been sent in the active connection.

Used to avoid sending subscription requests multiple times when the @kconfig{CONFIG_BT_GATT_AUTO_RESUBSCRIBE} quirk is enabled.

@note Internal use only.

enumerator BT_GATT_SUBSCRIBE_NUM_FLAGS

Functions

int **bt_gatt_exchange_mtu**(struct bt_conn *conn, struct bt_gatt_exchange_params *params)

Exchange MTU.

This client procedure can be used to set the MTU to the maximum possible size the buffers can hold.

The Response comes in callback params->func. The callback is run from the context specified by 'config BT_RECV_CONTEXT'. params must remain valid until start of callback.

This function will block while the ATT request queue is full, except when called from the BT RX thread, as this would cause a deadlock.

Note: Shall only be used once per connection.

Parameters

- conn Connection object.
- params Exchange MTU parameters.

Return values

- **0** Successfully queued request. Will call params->func on resolution.
- **-ENOMEM** ATT request queue is full and blocking would cause deadlock. Allow a pending request to resolve before retrying, or call this function outside the BT RX thread to get blocking behavior. Queue size is controlled by @kconfig{CONFIG_BT_L2CAP_TX_BUF_COUNT}.
- **-EALREADY** The MTU exchange procedure has been already performed.

int **bt_gatt_discover**(struct bt_conn *conn, struct bt_gatt_discover_params *params)

GATT Discover function.

This procedure is used by a client to discover attributes on a server.

Primary Service Discovery: Procedure allows to discover primary services either by Discover All Primary Services or Discover Primary Services by Service UUID. Include Service Discovery: Procedure allows to discover all Include Services within specified range. Characteristic Discovery: Procedure allows to

discover all characteristics within specified handle range as well as discover characteristics with specified UUID. Descriptors Discovery: Procedure allows to discover all characteristic descriptors within specified range.

For each attribute found the callback is called which can then decide whether to continue discovering or stop.

The Response comes in callback params->func. The callback is run from the BT RX thread. params must remain valid until start of callback where iter attr is NULL or callback will return BT_GATT_ITER_STOP.

This function will block while the ATT request queue is full, except when called from the BT RX thread, as this would cause a deadlock.

Parameters

- **conn** Connection object.
- params Discover parameters.

Return values

- **0** Successfully queued request. Will call params->func on resolution.
- **-ENOMEM** ATT request queue is full and blocking would cause deadlock. Allow a pending request to resolve before retrying, or call this function outside the BT RX thread to get blocking behavior. Queue size is controlled by @kconfig{CONFIG_BT_L2CAP_TX_BUF_COUNT}.

int **bt_gatt_read**(struct bt_conn *conn, struct bt_gatt_read_params *params)

Read Attribute Value by handle.

This procedure read the attribute value and return it to the callback.

When reading attributes by UUID the callback can be called multiple times depending on how many instances of given the UUID exists with the start_handle being updated for each instance.

To perform a GATT Long Read procedure, start with a Characteristic Value Read (by setting offset 0 and handle_count 1) and then return $BT_GATT_ITER_CONTINUE$ from the callback. This is equivalent to calling bt_gatt_read again, but with the correct offset to continue the read. This may be repeated until the procedure is complete, which is signaled by the callback being called with data set to NULL.

Note that returning *BT_GATT_ITER_CONTINUE* is really starting a new ATT operation, so this can fail to allocate resources. However, all API errors are reported as if the server returned BT_ATT_ERR_UNLIKELY. There is no way to distinguish between this condition and a BT_ATT_ERR_UNLIKELY response from the server itself.

Note that the effect of returning *BT_GATT_ITER_CONTINUE* from the callback varies depending on the type of read operation.

The Response comes in callback params->func. The callback is run from the context specified by 'config BT_RECV_CONTEXT'. params must remain valid until start of callback.

This function will block while the ATT request queue is full, except when called from the BT RX thread, as this would cause a deadlock.

Parameters

- conn Connection object.
- **params** Read parameters.

Return values

• **0** – Successfully queued request. Will call params->func on resolution.

• **-ENOMEM** – ATT request queue is full and blocking would cause deadlock. Allow a pending request to resolve before retrying, or call this function outside the BT RX thread to get blocking behavior. Queue size is controlled by @kconfig{CONFIG_BT_ATT_TX_COUNT}.

int **bt_gatt_write**(struct bt_conn *conn, struct bt_gatt_write_params *params)

Write Attribute Value by handle.

The Response comes in callback params->func. The callback is run from the context specified by 'config BT RECV CONTEXT'. params must remain valid until start of callback.

This function will block while the ATT request queue is full, except when called from Bluetooth event context. When called from Bluetooth context, this function will instead instead return -ENOMEM if it would block to avoid a deadlock.

Parameters

- **conn** Connection object.
- params Write parameters.

Return values

- **0** Successfully queued request. Will call params->func on resolution.
- **-ENOMEM** ATT request queue is full and blocking would cause deadlock. Allow a pending request to resolve before retrying, or call this function outside Bluetooth event context to get blocking behavior. Queue size is controlled by @kconfig{CONFIG_BT_ATT_TX_COUNT}.

int **bt_gatt_write_without_response_cb**(struct bt_conn *conn, uint16_t handle, const void *data, uint16_t length, bool sign, bt_gatt_complete_func_t func, void *user data)

Write Attribute Value by handle without response with callback.

This function works in the same way as *bt_gatt_write_without_response*. With the addition that after sending the write the callback function will be called.

The callback is run from System Workqueue context. When called from the System Workqueue context this API will not wait for resources for the callback but instead return an error. The number of pending callbacks can be increased with the @kconfig{CONFIG_BT_CONN_TX_MAX} option.

This function will block while the ATT request queue is full, except when called from the BT RX thread, as this would cause a deadlock.

Note: By using a callback it also disable the internal flow control which would prevent sending multiple commands without waiting for their transmissions to complete, so if that is required the caller shall not submit more data until the callback is called.

Parameters

- conn Connection object.
- handle Attribute handle.
- data Data to be written.
- **length** Data length.

- **sign** Whether to sign data
- **func** Transmission complete callback.
- user_data User data to be passed back to callback.

Return values

- **0** Successfully queued request.
- **-ENOMEM** ATT request queue is full and blocking would cause deadlock. Allow a pending request to resolve before retrying, or call this function outside the BT RX thread to get blocking behavior. Queue size is controlled by @kconfig{CONFIG_BT_ATT_TX_COUNT}.

static inline int **bt_gatt_write_without_response**(struct bt_conn *conn, uint16_t handle, const void *data, uint16_t length, bool sign)

Write Attribute Value by handle without response.

This procedure write the attribute value without requiring an acknowledgment that the write was successfully performed

This function will block while the ATT request queue is full, except when called from the BT RX thread, as this would cause a deadlock.

Parameters

- conn Connection object.
- handle Attribute handle.
- data Data to be written.
- **length** Data length.
- sign Whether to sign data

Return values

- **0** Successfully queued request.
- **-ENOMEM** ATT request queue is full and blocking would cause deadlock. Allow a pending request to resolve before retrying, or call this function outside the BT RX thread to get blocking behavior. Queue size is controlled by @kconfig{CONFIG_BT_ATT_TX_COUNT}.

int **bt_gatt_subscribe**(struct bt_conn *conn, struct bt_gatt_subscribe_params *params)

Subscribe Attribute Value Notification.

This procedure subscribe to value notification using the Client Characteristic Configuration handle. If notification received subscribe value callback is called to return notified value. One may then decide whether to unsubscribe directly from this callback. Notification callback with NULL data will not be called if subscription was removed by this method.

The Response comes in callback params->subscribe. The callback is run from the context specified by 'config BT_RECV_CONTEXT'. The Notification callback params->notify is also called from the BT RX thread.

This function will block while the ATT request queue is full, except when called from the BT RX thread, as this would cause a deadlock.

Note: Notifications are asynchronous therefore the params must remain valid while subscribed and cannot be reused for additional subscriptions whilst active.

Parameters

- conn Connection object.
- params Subscribe parameters.

Return values

- **0** Successfully queued request. Will call params->write on resolution.
- **-ENOMEM** ATT request queue is full and blocking would cause deadlock. Allow a pending request to resolve before retrying, or call this function outside the BT RX thread to get blocking behavior. Queue size is controlled by @kconfig{CONFIG_BT_ATT_TX_COUNT}.
- **-EALREADY** if there already exist a subscription using the params.
- -EBUSY if params.ccc_handle is 0 and @kcon-fig{CONFIG_BT_GATT_AUTO_DISCOVER_CCC} is enabled and discovery for the params is already in progress.

int **bt_gatt_resubscribe**(uint8_t id, const *bt_addr_le_t* *peer, struct *bt_gatt_subscribe_params* *params)

Resubscribe Attribute Value Notification subscription.

Resubscribe to Attribute Value Notification when already subscribed from a previous connection. The GATT server will remember subscription from previous connections when bonded, so resubscribing can be done without performing a new subscribe procedure after a power cycle.

Note: Notifications are asynchronous therefore the parameters need to remain valid while subscribed.

Parameters

- id Local identity (in most cases BT_ID_DEFAULT).
- **peer** Remote address.
- params Subscribe parameters.

Returns 0 in case of success or negative value in case of error.

int **bt_gatt_unsubscribe**(struct bt_conn *conn, struct bt_gatt_subscribe_params *params)

Unsubscribe Attribute Value Notification.

This procedure unsubscribe to value notification using the Client Characteristic Configuration handle. Notification callback with NULL data will be called if subscription was removed by this call, until then the parameters cannot be reused.

The Response comes in callback params->func. The callback is run from the BT RX thread.

This function will block while the ATT request queue is full, except when called from the BT RX thread, as this would cause a deadlock.

Parameters

• conn – Connection object.

• params – Subscribe parameters.

Return values

- **0** Successfully queued request. Will call params->write on resolution.
- **-ENOMEM** ATT request queue is full and blocking would cause deadlock. Allow a pending request to resolve before retrying, or call this function outside the BT RX thread to get blocking behavior. Queue size is controlled by @kconfig{CONFIG_BT_ATT_TX_COUNT}.

void bt_gatt_cancel(struct bt_conn *conn, void *params)

Try to cancel the first pending request identified by params.

This function does not release params for reuse. The usual callbacks for the request still apply. A successful cancel simulates a BT_ATT_ERR_UNLIKELY response from the server.

This function can cancel the following request functions:

- bt_gatt_exchange_mtu
- bt_gatt_discover
- bt_gatt_read
- bt_gatt_write
- bt gatt subscribe
- bt_gatt_unsubscribe

Parameters

- **conn** The connection the request was issued on.
- params The address params used in the request function call.

struct bt_gatt_exchange_params

#include <gatt.h> GATT Exchange MTU parameters.

Public Members

```
void (*func)(struct bt_conn *conn, uint8_t err, struct bt_gatt_exchange_params *params)
Response callback
```

struct bt_gatt_discover_params

#include <gatt.h> GATT Discover Attributes parameters.

Public Members

```
const struct bt_uuid *uuid
```

Discover UUID type

bt_gatt_discover_func_t func

Discover attribute callback

uint16_t end_handle

Discover end handle

uint8_t type

Discover type

struct bt_gatt_read_params

#include < gatt.h > GATT Read parameters.

Public Members

```
bt_gatt_read_func_t func
```

Read attribute callback.

size_t handle_count

If equals to 1 single.handle and single.offset are used. If greater than 1 multiple.handles are used. If equals to 0 by_uuid is used for Read Using Characteristic UUID.

```
uint16_t _att_mtu
```

Internal

struct bt_gatt_write_params

#include <gatt.h> GATT Write parameters.

Public Members

```
bt_gatt_write_func_t func
```

Response callback

uint16_t handle

Attribute handle

uint16_t offset

Attribute data offset

```
const void *data
```

Data to be written

uint16_t length

Length of the data

struct bt_gatt_subscribe_params

#include < gatt.h > GATT Subscribe parameters.

Public Functions

ATOMIC_DEFINE (flags, BT_GATT_SUBSCRIBE_NUM_FLAGS)

Subscription flags

Public Members

```
bt_gatt_notify_func_t notify
```

Notification value callback

bt_gatt_subscribe_func_t subscribe

Subscribe CCC write request response callback If given, called with the subscription parameters given when subscribing

```
bt_gatt_write_func_t write
```

Deprecated:

uint16 t value_handle

Subscribe value handle

uint16_t ccc_handle

Subscribe CCC handle

uint16_t value

Subscribe value

bt_security_t min_security

Minimum required security for received notification. Notifications and indications received over a connection with a lower security level are silently discarded.

```
union __unnamed59__
```

Public Members

```
struct bt_gatt_discover_params _included
```

uint16_t start_handle

Discover start handle

struct _included

Public Members

```
uint16_t attr_handle
```

Include service attribute declaration handle

uint16_t start_handle

Included service start handle

uint16_t end_handle

Included service end handle

union __unnamed62__

Public Members

```
struct bt_gatt_read_params single
```

struct bt_gatt_read_params multiple

struct bt_gatt_read_params by_uuid

struct **single**

Public Members

uint16 t handle

Attribute handle.

uint16_t offset

Attribute data offset.

struct multiple

Public Members

uint16_t *handles

Attribute handles to read with Read Multiple Characteristic Values.

bool variable

If true use Read Multiple Variable Length Characteristic Values procedure. The values of the set of attributes may be of variable or unknown length. If false use Read Multiple Characteristic Values procedure. The values of the set of attributes must be of a known fixed length, with the exception of the last value that can have a variable length.

struct by_uuid

Public Members

```
uint16_t start_handle
```

First requested handle number.

uint16 t end_handle

Last requested handle number.

const struct bt_uuid *uuid

2 or 16 octet UUID.

1.7 Hands Free Profile (HFP)

1.7.1 API Reference

```
group bt_hfp
```

Hands Free Profile (HFP).

Hands Free Profile (HFP) .

Hands Free AG Profile (HFP AG) .

Defines

HFP_HF_DIGIT_ARRAY_SIZE

HFP_HF_MAX_OPERATOR_NAME_LEN

HFP_HF_CMD_OK

```
HFP_HF_CMD_ERROR
HFP_HF_CMD_CME_ERROR
HFP_HF_CMD_UNKNOWN_ERROR
Typedefs
typedef enum _hf_volume_type_t hf_volume_type_t
     bt hfp ag volume type
typedef enum _hfp_ag_call_status_t hfp_ag_call_status_t
     bt hf call status
typedef struct _hfp_ag_get_config hfp_ag_get_config
     bt ag configure setting
typedef struct _hfp_ag_cind_t hfp_ag_cind_t
     bt hf call status
typedef int (*bt_hfp_ag_discover_callback)(struct bt_conn *conn, uint8_t channel)
     hfp_ag discover callback function
         Param conn Pointer to bt conn structure.
         Param channel the server channel of hfp ag
typedef enum _hf_multiparty_call_option_t hf_multiparty_call_option_t
     bt hfp ag volume type
typedef struct _hf_waiting_call_state_t hf_waiting_call_state_t
Enums
enum _hf_volume_type_t
     bt hfp ag volume type
     Values:
     enumerator hf_volume_type_speaker
     enumerator hf_volume_type_mic
```

```
enum _hfp_ag_call_status_t
    bt hf call status
    Values:
    enumerator hfp_ag_call_call_end
    enumerator hfp_ag_call_call_active
    enumerator hfp_ag_call_call_incoming
    enumerator hfp_ag_call_call_outgoing
enum hfp_ag_call_setup_status_t
    bt ag call setup status
    Values:
    enumerator HFP_AG_CALL_SETUP_STATUS_IDLE
    enumerator HFP_AG_CALL_SETUP_STATUS_INCOMING
    enumerator HFP_AG_CALL_SETUP_STATUS_OUTGOING_DIALING
    enumerator HFP_AG_CALL_SETUP_STATUS_OUTGOING_ALERTING
enum bt_hfp_hf_at_cmd
    Values:
    enumerator BT_HFP_HF_ATA
    enumerator BT_HFP_HF_AT_CHUP
enum _hf_multiparty_call_option_t
    bt hfp ag volume type
    Values:
    enumerator hf_multiparty_call_option_one
    enumerator hf_multiparty_call_option_two
    enumerator hf_multiparty_call_option_three
    enumerator hf_multiparty_call_option_four
```

enumerator hf_multiparty_call_option_five

Functions

int bt_hfp_ag_init(void)

BT HFP AG Initialize

This function called to initialize bt hfp ag

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_deinit(void)

BT HFP AG Deinitialize

This function called to initialize bt hfp ag

Returns 0 in case of success or otherwise in case of error.

hfp ag Connect.

This function is to be called after the conn parameter is obtained by performing a GAP procedure. The API is to be used to establish hfp ag connection between devices. This function only establish RFCOM connection. After connection success, the callback that is registered by bt_hfp_ag_register_connect_callback is called.

Parameters

- conn Pointer to bt conn structure.
- **config** bt hfp ag congigure
- **cb** bt hfp ag congigure
- phfp_ag Pointer to pointer of bt hfp ag Connection object

Returns 0 in case of success or otherwise in case of error.

```
int bt_hfp_ag_disconnect(struct bt_hfp_ag *hfp_ag)
```

hfp ag DisConnect.

This function is to be called after the conn parameter is obtained by performing a GAP procedure. The API is to be used to establish hfp ag connection between devices. This function only establish RFCOM connection. After connection success, the callback that is registered by bt_hfp_ag_register_connect_callback is called.

Parameters

• phfp_ag - pointer to bt hfp ag connection object

Returns 0 in case of success or otherwise in case of error.

```
int bt_hfp_ag_discover(struct bt_conn *conn, bt_hfp_ag_discover_callback discoverCallback)
```

hfp ag discover

This function is to be called after the conn parameter is obtained by performing a GAP procedure. The API is to be used to establish hfp ag connection between devices.

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- discoverCallback pointer to discover callback function, defined in application

Returns 0 in case of success or otherwise in case of error.

void bt_hfp_ag_open_audio(struct bt_hfp_ag *hfp_ag, uint8_t codec)

hfp ag open audio for codec

This function is to open audio codec for hfp function

Parameters

• phfp_ag – pointer to bt hfp ag connection object

void bt_hfp_ag_close_audio(struct bt_hfp_ag *hfp_ag)

hfp ag close audio for codec

This function is to close audio codec for hfp funciton

Parameters

• **phfp_ag** – pointer to bt hfp ag connection object

int **bt_hfp_ag_register_supp_features**(struct bt_hfp_ag *hfp_ag, uint32_t supported_features)

configure hfp ag supported features.

if the function is not called, will use default supported features

hfp ag to configure hfp ag supported features

This function is to be configure hfp ag supported features. If the function is not called, will use default supported features

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- **supported_features** suppported features of hfp ag

Returns 0 in case of success or otherwise in case of error.

uint32 t bt_hfp_ag_get_peer_supp_features(struct bt_hfp_ag *hfp_ag)

hfp ag to get peer hfp hp support feautes

This function is to be called to get hfp hp support feautes

Parameters

• **phfp_ag** – pointer to bt hfp ag connection object

Returns the supported feature of hfp ag

int bt_hfp_ag_register_cind_features(struct bt_hfp_ag *hfp_ag, char *cind)

hfp ag to configure hfp ag supported features

This function is to be configure hfp ag cind setting supported features. If the function is not called, will use default supported features

Parameters

- phfp_ag pointer to bt hfp ag connection object
- cind pointer to hfp ag cwind

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_send_disable_voice_recognition(struct bt_hfp_ag *hfp_ag)

hfp ag to disable voice recognition

This function is o disabl voice recognition

Parameters

• phfp_ag – pointer to bt hfp ag connection object

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_send_enable_voice_recognition(struct bt_hfp_ag *hfp_ag)

hfp ag to enable voice recognition

This function is used to enable voice recognition

Parameters

• phfp_ag – pointer to bt hfp ag Connection object

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_send_disable_voice_ecnr(struct bt_hfp_ag *hfp_ag)

hfp ag to disable noise reduction and echo canceling

This function is o noise reduction and echo canceling

Parameters

• **phfp_ag** – pointer to bt hfp ag connection object

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_send_enable_voice_ecnr(struct bt_hfp_ag *hfp_ag)

hfp ag to enable noise reduction and echo canceling

This function is to enable noise reduction and echo canceling

Parameters

• **phfp_ag** – pointer to bt hfp ag connection object

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_set_cops(struct bt_hfp_ag *hfp_ag, char *name)

hfp ag to set the name of the currently selected Network operator by AG

This function is to set the name of the currently selected Network operator by AG

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- name the name of the currently selected Network operator by AG

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_set_volume_control(struct bt_hfp_ag *hfp_ag, hf_volume_type_t type, int value)

hfp ag to set volue of hfp hp

This function is to set volue of hfp hp

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- **type** the hfp hp volume type
- value the volue of volume

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_set_inband_ring_tone(struct bt_hfp_ag *hfp_ag, int value)

hfp ag to set inband ring tone support

This function is to set inband ring tone support

Parameters

- phfp_ag pointer to bt hfp ag connection object
- **value** the inband ring tone type

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_set_phnum_tag(struct bt_hfp_ag *hfp_ag, char *name)

hfp ag to set the attach a phone number to a voice Tag

This function is to set the attach a phone number to a voice Tag

Parameters

- phfp_ag pointer to bt hfp ag connection object
- name the name of attach a phone number to a voice Tag

Returns 0 in case of success or otherwise in case of error.

void **bt_hfp_ag_call_status_pl**(struct bt_hfp_ag *hfp_ag, hfp_ag_call_status_t status)

hfp ag to set the call status

This function is to set the call status

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- **status** the ag call status

Returns 0 in case of success or otherwise in case of error.

int **bt_hfp_ag_handle_btrh**(struct bt_hfp_ag *hfp_ag, uint8_t option)

hfp ag to set the status of the "Response and Hold" state of the AG.

This function is to hfp ag to set the status of the "Response and Hold" state of the AG.

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- option the hfp ag "Response and Hold" state of the AG

Returns 0 in case of success or otherwise in case of error.

int **bt_hfp_ag_handle_indicator_enable**(struct bt_hfp_ag *hfp_ag, uint8_t index, uint8_t enable)

hfp ag to set the status of the "Response and Hold" state of the AG.

This function is to hfp ag to set the status of the "Response and Hold" state of the AG.

Parameters

- phfp_ag pointer to bt hfp ag connection object
- item 1 for Enhanced Safety, 2 for Battery Level
- enable 1 for enable

Returns 0 in case of success or otherwise in case of error.

void bt_hfp_ag_send_callring(struct bt_hfp_ag *hfp_ag)

hfp ag to set ring command to hfp hp

This function is hfp ag to set ring command to hfp hp

Parameters

• phfp_ag – pointer to bt hfp ag connection object

int bt_hfp_ag_send_call_indicator(struct bt_hfp_ag *hfp_ag, uint8_t value)

hfp ag set call indicator to hfp hp

This function is hfp ag set call indicator to hfp hp

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- value value of call indicator

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_send_callsetup_indicator(struct bt_hfp_ag *hfp_ag, uint8_t value)

hfp ag set call setup indicator to hfp hp

This function is hfp ag set call setup indicator to hfp hp

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- value value of call setup indicator

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_send_service_indicator(struct bt_hfp_ag *hfp_ag, uint8_t value)

hfp ag set service indicator to hfp hp

This function is hfp ag set service indicator to hfp hp

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- value value of service indicator

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_send_signal_indicator(struct bt_hfp_ag *hfp_ag, uint8_t value)

hfp ag set signal strength indicator to hfp hp

This function is hfp ag set signal strength indicator to hfp hp

Parameters

- phfp_ag pointer to bt hfp ag connection object
- value value of signal strength indicator

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_send_roaming_indicator(struct bt_hfp_ag *hfp_ag, uint8_t value)

hfp ag set roaming indicator to hfp hp

This function is hfp ag set roaming indicator to hfp hp

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- value value of roaming indicator

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_send_battery_indicator(struct bt_hfp_ag *hfp_ag, uint8_t value)

hfp ag set battery level indicator to hfp hp

This function is hfp ag set battery level indicator to hfp hp

Parameters

- phfp_ag pointer to bt hfp ag connection object
- value value of battery level indicator

Returns 0 in case of success or otherwise in case of error.

int bt_hfp_ag_send_ccwa_indicator(struct bt_hfp_ag *hfp_ag, char *number)

hfp ag set ccwa indicator to hfp hp

This function is hfp ag set ccwa indicator to hfp hp for mutiple call

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- value value of battery level indicator

Returns 0 in case of success or otherwise in case of error.

```
int bt_hfp_ag_codec_selector(struct bt_hfp_ag *hfp_ag, uint8_t value)
```

hfp ag set codec selector to hfp hp

This function is hfp ag set odec selector to hfp hp for codec negotiation

Parameters

- phfp_ag pointer to bt hfp ag connection object
- value value of codec selector

Returns 0 in case of success or otherwise in case of error.

```
int bt_hfp_ag_unknown_at_response(struct bt_hfp_ag *hfp_ag, uint8_t *unknow_at_rsp, uint16_t unknow_at_rsplen)
```

hfp ag set unknown at command response to hfp fp

This function is hfp ag set unknown at command response to hfp fp, the command is not supported on hfp ag profile, Need handle the unknown command on application

Parameters

- **phfp_ag** pointer to bt hfp ag connection object
- **unknow_at_rsp** string of unknown at command response
- **unknow_at_rsplen** string length of unknown at command response

Returns 0 in case of success or otherwise in case of error.

int **bt_hfp_hf_register**(struct *bt_hfp_hf_cb* *cb)

Register HFP HF profile.

Register Handsfree profile callbacks to monitor the state and get the required HFP details to display.

Parameters

• **cb** – callback structure.

Returns 0 in case of success or negative value in case of error.

int **bt_hfp_hf_send_cmd**(struct bt_conn *conn, enum bt_hfp_hf_at_cmd cmd)

Handsfree client Send AT.

Send specific AT commands to handsfree client profile.

Parameters

- **conn** Connection object.
- **cmd** AT command to be sent.

Returns 0 in case of success or negative value in case of error.

int bt_hfp_hf_start_voice_recognition(struct bt_conn *conn)

Handsfree to enable voice recognition in the AG.

Parameters

• conn – Connection object.

Returns 0 in case of success or negative value in case of error.

int bt_hfp_hf_stop_voice_recognition(struct bt_conn *conn)

Handsfree to Disable voice recognition in the AG.

Parameters

• conn – Connection object.

Returns 0 in case of success or negative value in case of error.

int **bt_hfp_hf_volume_update**(struct bt_conn *conn, hf_volume_type_t type, int volume)

Handsfree to update Volume with AG.

Parameters

- conn Connection object.
- type volume control target, speaker or microphone
- **volume** gain of the speaker of microphone, ranges 0 to 15

Returns 0 in case of success or negative value in case of error.

int bt_hfp_hf_dial(struct bt_conn *conn, const char *number)

Place a call with a specified number, if number is NULL, last called number is called. As a precondition to use this API, Service Level Connection shall exist with AG.

Parameters

- **conn** Connection object.
- number number string of the call. If NULL, the last number is called(aka re-dial)

Returns 0 in case of success or negative value in case of error.

int bt_hfp_hf_dial_memory(struct bt_conn *conn, int location)

Place a call with number specified by location(speed dial). As a precondition, to use this API, Service Level Connection shall exist with AG.

Parameters

• conn – Connection object.

• **location** – location of the number in the memory

Returns 0 in case of success or negative value in case of error.

int bt_hfp_hf_last_dial(struct bt_conn *conn)

Place a call with number specified by location(speed dial). As a precondition, to use this API, Service Level connection shall exist with AG.

Parameters

• conn – Connection object.

Returns 0 in case of success or negative value in case of error.

int **bt_hfp_hf_multiparty_call_option**(struct bt_conn *conn, hf_multiparty_call_option_t option)

Place a call with number specified by location(speed dial). As a precondition, to use this API, Service Level Connection shall exist with AG.

Parameters

• **conn** – Connection object.

Returns 0 in case of success or negative value in case of error.

int bt_hfp_hf_enable_clip_notification(struct bt_conn *conn)

Enable the CLIP notification.

Parameters

• conn – Connection object.

Returns 0 in case of success or negative value in case of error.

int bt_hfp_hf_disable_clip_notification(struct bt_conn *conn)

Disable the CLIP notification.

Parameters

• conn – Connection object.

Returns 0 in case of success or negative value in case of error.

int bt_hfp_hf_enable_call_waiting_notification(struct bt_conn *conn)

Enable the call waiting notification.

Parameters

• conn – Connection object.

Returns 0 in case of success or negative value in case of error.

int bt_hfp_hf_disable_call_waiting_notification(struct bt_conn *conn)

Disable the call waiting notification.

Parameters

• **conn** – Connection object.

Returns 0 in case of success or negative value in case of error.

int bt_hfp_hf_get_last_voice_tag_number(struct bt_conn *conn)

Get the last voice tag nubmer, the mubmer will be fill callback event voicetag_phnum.

Parameters

• conn – Connection object.

Returns 0 in case of success or negative value in case of error.

struct _hfp_ag_get_config

#include <hfp_ag.h> bt ag configure setting

struct _hfp_ag_cind_t

#include <hfp ag.h> bt hf call status

struct bt_hfp_ag_cb

#include <hfp ag.h> HFP profile application callback.

Public Members

```
void (*connected)(struct bt_hfp_ag *hfp_ag)
```

AG connected callback to application

If this callback is provided it will be called whenever the connection completes.

Param hfp_ag bt hfp ag Connection object.

```
void (*disconnected)(struct bt_hfp_ag *hfp_ag)
```

AG disconnected callback to application

If this callback is provided it will be called whenever the connection gets disconnected, including when a connection gets rejected or cancelled or any error in SLC establisment.

Param hfp_ag bt hfp ag Connection object.

```
void (*volume_control)(struct bt_hfp_ag *hfp_ag, hf_volume_type_t type, int value)
```

AG volume_control Callback

This callback provides volume_control indicator value to the application

Param hfp ag bt hfp ag Connection object.

Param type the hfp volue type, for speaker or mic.

Param value service indicator value received from the AG.

```
void (*hfu_brsf)(struct bt_hfp_ag *hfp_ag, uint32_t value)
```

AG remote support feature Callback

This callback provides the remote hfp unit supported feature

Param hfp_ag bt hfp ag Connection object.

Param value call indicator he remote hfp unit supported feature received from the AG.

```
void (*ata_response)(struct bt hfp ag *hfp ag)
```

AG remote call is answered Callback

This callback provides call indicator the call is answered to the application

Param hfp_ag bt hfp ag Connection object.

```
void (*chup_response)(struct bt hfp ag *hfp ag)
```

AG remote call is answered Callback

This callback provides call indicator the call is rejected to the application

```
Param hfp_ag bt hfp ag Connection object.
```

void (*dial)(struct bt_hfp_ag *hfp_ag, char *number)

AG remote call is answered Callback

This callback provides call indicator the call is rejected to the application

Param hfp_ag bt hfp ag Connection object.

Param value call information.

void (*brva)(struct bt_hfp_ag *hfp_ag, uint32_t value)

AG remote voice recognition activation Callback

This callback provides call indicator voice recognition activation of peer HF to the application

Param hfp_ag bt hfp ag Connection object.

Param value voice recognition activation information.

void (*nrec)(struct bt_hfp_ag *hfp_ag, uint32_t value)

AG remote noise reduction and echo canceling Callback

This callback provides call indicator voice recognition activation of peer HF to the application

Param hfp_ag bt hfp ag Connection object.

Param value Noise Reduction and Echo Canceling information.

void (*codec_negotiate)(struct bt_hfp_ag *hfp_ag, uint32_t value)

AG remote codec negotiate Callback

This callback provides codec negotiate information of peer HF to the application

Param hfp ag bt hfp ag Connection object.

Param value codec index of peer HF.

void (*chld)(struct bt_hfp_ag *hfp_ag, uint8_t option, uint8_t index)

AG multiparty call status indicator Callback

This callback provides multiparty call status indicator Callback of peer HF to the application

Param hfp_ag bt hfp ag Connection object.

Param option Multiparty call option.

Param index Multiparty call index.

void (*unkown_at)(struct bt_hfp_ag *hfp_ag, char *value, uint32_t length)

AG unkown at Callback

This callback provides AG unkown at value to the application, the unkown at command could be handled by application

Param hfp ag bt hfp ag Connection object.

Param value unknow AT string buffer

Param length unknow AT string length.

struct bt_hfp_hf_cmd_complete

#include <hfp_hf.h> HFP HF Command completion field.

struct _hf_waiting_call_state_t

#include <hfp_hf.h>

struct bt_hfp_hf_cb

#include <hfp_hf.h> HFP profile application callback.

Public Members

void (*connected)(struct bt_conn *conn)

HF connected callback to application

If this callback is provided it will be called whenever the connection completes.

Param conn Connection object.

void (*disconnected)(struct bt_conn *conn)

HF disconnected callback to application

If this callback is provided it will be called whenever the connection gets disconnected, including when a connection gets rejected or cancelled or any error in SLC establishment.

Param conn Connection object.

void (*service)(struct bt_conn *conn, uint32_t value)

HF indicator Callback

This callback provides service indicator value to the application

Param conn Connection object.

Param value service indicator value received from the AG.

void (*call)(struct bt_conn *conn, uint32_t value)

HF indicator Callback

This callback provides call indicator value to the application

Param conn Connection object.

Param value call indicator value received from the AG.

void (*call_setup)(struct bt_conn *conn, uint32_t value)

HF indicator Callback

This callback provides call setup indicator value to the application

Param conn Connection object.

Param value call setup indicator value received from the AG.

void (*call_held)(struct bt_conn *conn, uint32_t value)

HF indicator Callback

This callback provides call held indicator value to the application

Param conn Connection object.

Param value call held indicator value received from the AG.

void (*signal)(struct bt_conn *conn, uint32_t value)

HF indicator Callback

This callback provides signal indicator value to the application

Param conn Connection object.

Param value signal indicator value received from the AG.

void (*roam)(struct bt_conn *conn, uint32_t value)

```
HF indicator Callback
    This callback provides roaming indicator value to the application
        Param conn Connection object.
        Param value roaming indicator value received from the AG.
void (*battery)(struct bt_conn *conn, uint32_t value)
    HF indicator Callback
    This callback battery service indicator value to the application
        Param conn Connection object.
        Param value battery indicator value received from the AG.
void (*voicetag_phnum)(struct bt_conn *conn, char *number)
    HF voice tag phnum indicator Callback
    This callback voice tag phnum indicator to the application
        Param conn Connection object.
        Param voice tag phnum value received from the AG.
void (*call_phnum)(struct bt_conn *conn, char *number)
    HF calling phone number string indication callback to application
    If this callback is provided it will be called whenever there is an incoming call and
    bt hfp hf enable clip notification is called.
        Param conn Connection object.
        Param char to phone number string.
void (*waiting_call)(struct bt conn *conn, hf waiting call state t *wcs)
    HF waiting call indication callback to application
    If this callback is provided it will be called in waiting call state
        Param conn Connection object.
        Param pointer to waiting call state information.
void (*ring_indication)(struct bt conn *conn)
    HF incoming call Ring indication callback to application
    If this callback is provided it will be called whenever there is an incoming call.
        Param conn Connection object.
void (*cmd_complete_cb)(struct bt_conn *conn, struct bt_hfp_hf_cmd_complete *cmd)
    HF notify command completed callback to application
    The command sent from the application is notified about its status
        Param conn Connection object.
        Param cmd structure contains status of the command including cme.
```

1.8 Logical Link Control and Adaptation Protocol (L2CAP)

L2CAP layer enables connection-oriented channels which can be enable with the configuration option: CONFIG_BT_L2CAP_DYNAMIC_CHANNEL. This channels support segmentation and reassembly transparently, they also support credit based flow control making it suitable for data streams.

Channels instances are represented by the bt_12cap_chan struct which contains the callbacks in the $bt_12cap_chan_ops$ struct to inform when the channel has been connected, disconnected or when the encryption has changed. In addition to that it also contains the recv callback which is called whenever an incoming data has been received. Data received this way can be marked as processed by returning 0 or using $bt_12cap_chan_recv_complete()$ API if processing is asynchronous.

Note: The recv callback is called directly from RX Thread thus it is not recommended to block for long periods of time.

For sending data the bt_12cap_chan_send() API can be used noting that it may block if no credits are available, and resuming as soon as more credits are available.

Servers can be registered using $bt_12cap_server_register()$ API passing the bt_12cap_server struct which informs what psm it should listen to, the required security level sec_level , and the callback accept which is called to authorize incoming connection requests and allocate channel instances.

Client channels can be initiated with use of $bt_12cap_chan_connect()$ API and can be disconnected with the $bt_12cap_chan_disconnect()$ API. Note that the later can also disconnect channel instances created by servers.

1.8.1 API Reference

group bt_12cap

L2CAP.

Defines

BT_L2CAP_HDR_SIZE

L2CAP PDU header size, used for buffer size calculations

BT_L2CAP_TX_MTU

Maximum Transmission Unit (MTU) for an outgoing L2CAP PDU.

BT_L2CAP_RX_MTU

Maximum Transmission Unit (MTU) for an incoming L2CAP PDU.

BT_L2CAP_BUF_SIZE(mtu)

Helper to calculate needed buffer size for L2CAP PDUs. Useful for creating buffer pools.

Parameters

• mtu – Needed L2CAP PDU MTU.

Returns Needed buffer size to match the requested L2CAP PDU MTU.

BT_L2CAP_SDU_HDR_SIZE

L2CAP SDU header size, used for buffer size calculations

BT_L2CAP_SDU_TX_MTU

Maximum Transmission Unit for an unsegmented outgoing L2CAP SDU.

The Maximum Transmission Unit for an outgoing L2CAP SDU when sent without segmentation, i.e. a single L2CAP SDU will fit inside a single L2CAP PDU.

The MTU for outgoing L2CAP SDUs with segmentation is defined by the size of the application buffer pool.

BT_L2CAP_SDU_RX_MTU

Maximum Transmission Unit for an unsegmented incoming L2CAP SDU.

The Maximum Transmission Unit for an incoming L2CAP SDU when sent without segmentation, i.e. a single L2CAP SDU will fit inside a single L2CAP PDU.

The MTU for incoming L2CAP SDUs with segmentation is defined by the size of the application buffer pool. The application will have to define an alloc_buf callback for the channel in order to support receiving segmented L2CAP SDUs.

BT_L2CAP_SDU_BUF_SIZE(mtu)

Helper to calculate needed buffer size for L2CAP SDUs. Useful for creating buffer pools.

Parameters

• mtu - Required BT_L2CAP_*_SDU.

Returns Needed buffer size to match the requested L2CAP SDU MTU.

BT_L2CAP_LE_CHAN(_ch)

Helper macro getting container object of type $bt_l2cap_le_chan$ address having the same container chan member address as object in question.

Parameters

• **_ch** – Address of object of *bt_l2cap_chan* type

Returns Address of in memory *bt_l2cap_le_chan* object type containing the address of in question object.

BT_L2CAP_CFG_OPT_MTU

configuration parameter options type

BT_L2CAP_CFG_OPT_FUSH_TIMEOUT

BT_L2CAP_CFG_OPT_QOS

BT_L2CAP_CFG_OPT_RETRANS_FC

BT_L2CAP_CFG_OPT_FCS

BT_L2CAP_CFG_OPT_EXT_FLOW_SPEC

BT_L2CAP_CFG_OPT_EXT_WIN_SIZE

BT_L2CAP_MODE_BASIC

L2CAP Operation Modes

BT_L2CAP_MODE_RTM

BT_L2CAP_MODE_FC

BT_L2CAP_MODE_ERTM

BT_L2CAP_MODE_SM

BT_L2CAP_FEATURE_FC

L2CAP Extended Feature Mask values

BT_L2CAP_FEATURE_RTM

BT_L2CAP_FEATURE_QOS

BT_L2CAP_FEATURE_ERTM

BT_L2CAP_FEATURE_SM

BT_L2CAP_FEATURE_FCS

BT_L2CAP_FEATURE_EFS_BR_EDR

BT_L2CAP_FEATURE_FIXED_CHANNELS

BT_L2CAP_FEATURE_EXTENDED_WINDOW_SIZE

BT_L2CAP_FEATURE_UCD

BT_L2CAP_CHAN_SEND_RESERVE

Headroom needed for outgoing L2CAP PDUs.

BT_L2CAP_SDU_CHAN_SEND_RESERVE

Headroom needed for outgoing L2CAP SDUs.

Typedefs

```
typedef void (*bt_12cap_chan_destroy_t)(struct bt_l2cap_chan *chan)
Channel destroy callback.

Param chan Channel object.

typedef enum bt_l2cap_chan_state bt_12cap_chan_state_t
```

typedef enum bt_l2cap_chan_status_t

Enums

enum bt_12cap_chan_state

Life-span states of L2CAP CoC channel.

Used only by internal APIs dealing with setting channel to proper state depending on operational context.

A channel enters the *BT_L2CAP_CONNECTING* state upon *bt_l2cap_chan_connect*, *bt_l2cap_ecred_chan_connect* or upon returning from *bt_l2cap_server::accept*.

When a channel leaves the BT_L2CAP_CONNECTING state, bt_l2cap_chan_ops::connected is called.

Values:

enumerator BT_L2CAP_DISCONNECTED

Channel disconnected

enumerator BT_L2CAP_CONNECTING

Channel in connecting state

enumerator BT_L2CAP_CONFIG

Channel in config state, BR/EDR specific

enumerator BT_L2CAP_CONNECTED

Channel ready for upper layer traffic on it

enumerator BT_L2CAP_DISCONNECTING

Channel in disconnecting state

enum bt_12cap_chan_status

Status of L2CAP channel.

Values:

enumerator BT_L2CAP_STATUS_OUT

Channel output status

enumerator BT_L2CAP_STATUS_SHUTDOWN

Channel shutdown status.

Once this status is notified it means the channel will no longer be able to transmit or receive data.

enumerator BT_L2CAP_STATUS_ENCRYPT_PENDING

Channel encryption pending status.

enumerator BT_L2CAP_NUM_STATUS

Functions

int **bt_l2cap_server_register**(struct *bt_l2cap_server* *server)

Register L2CAP server.

Register L2CAP server for a PSM, each new connection is authorized using the accept() callback which in case of success shall allocate the channel structure to be used by the new connection.

For fixed, SIG-assigned PSMs (in the range 0x0001-0x007f) the PSM should be assigned to server->psm before calling this API. For dynamic PSMs (in the range 0x0080-0x00ff) server->psm may be pre-set to a given value (this is however not recommended) or be left as 0, in which case upon return a newly allocated value will have been assigned to it. For dynamically allocated values the expectation is that it's exposed through a GATT service, and that's how L2CAP clients discover how to connect to the server.

Parameters

• **server** – Server structure.

Returns 0 in case of success or negative value in case of error.

```
int bt_l2cap_br_server_register(struct bt_l2cap_server *server)
```

Register L2CAP server on BR/EDR oriented connection.

Register L2CAP server for a PSM, each new connection is authorized using the accept() callback which in case of success shall allocate the channel structure to be used by the new connection.

Parameters

• **server** – Server structure.

Returns 0 in case of success or negative value in case of error.

int bt_l2cap_ecred_chan_connect(struct bt_conn *conn, struct bt_l2cap_chan **chans, uint16_t psm)

Connect Enhanced Credit Based L2CAP channels.

Connect up to 5 L2CAP channels by PSM, once the connection is completed each channel connected() callback will be called. If the connection is rejected disconnected() callback is called instead.

Parameters

- **conn** Connection object.
- **chans** Array of channel objects.
- psm Channel PSM to connect to.

Returns 0 in case of success or negative value in case of error.

int bt_12cap_ecred_chan_reconfigure(struct bt_12cap_chan **chans, uint16_t mtu, uint16_t mps)

Reconfigure Enhanced Credit Based L2CAP channels.

Reconfigure up to 5 L2CAP channels. Channels must be from the same bt_conn. Once reconfiguration is completed each channel reconfigured() callback will be called. MTU cannot be decreased on any of provided channels.

Parameters

- **chans** Array of channel objects. Null-terminated. Elements after the first 5 are silently ignored.
- mtu Channel MTU to reconfigure to.
- mps Channel MPS to reconfigure to

Returns 0 in case of success or negative value in case of error.

int bt_12cap_chan_connect(struct bt_conn *conn, struct bt_12cap_chan *chan, uint16_t psm)

Connect L2CAP channel.

Connect L2CAP channel by PSM, once the connection is completed channel connected() callback will be called. If the connection is rejected disconnected() callback is called instead. Channel object passed (over an address of it) as second parameter shouldn't be instantiated in application as standalone. Instead of, application should create transport dedicated L2CAP objects, i.e. type of $bt_l2cap_le_chan$ for LE and/or type of $bt_l2cap_br_chan$ for BR/EDR. Then pass to this API the location (address) of bt_l2cap_chan type object which is a member of both transport dedicated objects.

Parameters

- conn Connection object.
- **chan** Channel object.
- **psm** Channel PSM to connect to.

Returns 0 in case of success or negative value in case of error.

int bt_l2cap_chan_disconnect(struct bt_l2cap_chan *chan)

Disconnect L2CAP channel.

Disconnect L2CAP channel, if the connection is pending it will be canceled and as a result the channel disconnected() callback is called. Regarding to input parameter, to get details see reference description to $bt_l2cap_chan_connect()$ API above.

Parameters

• **chan** – Channel object.

Returns 0 in case of success or negative value in case of error.

int **bt_12cap_chan_send**(struct *bt_12cap_chan* *chan, struct net_buf *buf)

Send data to L2CAP channel.

Send data from buffer to the channel. If credits are not available, buf will be queued and sent as and when credits are received from peer. Regarding to first input parameter, to get details see reference description to $bt_l2cap_chan_connect()$ API above.

When sending L2CAP data over an BR/EDR connection the application is sending L2CAP PDUs. The application is required to have reserved *BT_L2CAP_CHAN_SEND_RESERVE* bytes in the buffer before sending. The application should use the *BT_L2CAP_BUF_SIZE()* helper to correctly size the buffers for the for the outgoing buffer pool.

When sending L2CAP data over an LE connection the application is sending L2CAP SDUs. The application shall reserve *BT_L2CAP_SDU_CHAN_SEND_RESERVE* bytes in the buffer before sending.

The application can use the BT_L2CAP_SDU_BUF_SIZE() helper to correctly size the buffer to account for the reserved headroom.

When segmenting an L2CAP SDU into L2CAP PDUs the stack will first attempt to allocate buffers from the channel's alloc_seg callback and will fallback on the stack's global buffer pool (sized @kconfig{CONFIG_BT_L2CAP_TX_BUF_COUNT}).

Note: Buffer ownership is transferred to the stack in case of success, in case of an error the caller retains the ownership of the buffer.

Returns 0 in case of success or negative value in case of error.

Returns -EINVAL if buf or chan is NULL.

Returns -EINVAL if chan is not either BR/EDR or LE credit-based.

Returns -EINVAL if buffer doesn't have enough bytes reserved to fit header.

Returns -EMSGSIZE if buf is larger than chan's MTU.

Returns -ENOTCONN if underlying conn is disconnected.

Returns -ESHUTDOWN if L2CAP channel is disconnected.

Returns -other (from lower layers) if chan is BR/EDR.

int bt_l2cap_chan_give_credits(struct bt_l2cap_chan *chan, uint16_t additional_credits)

Give credits to the remote.

Only available for channels using bt_l2cap_chan_ops.seg_recv. @kconfig{CONFIG_BT_L2CAP_SEG_RECV} must be enabled to make this function available.

Each credit given allows the peer to send one segment.

This function depends on a valid chan object. Make sure to default-initialize or memset chan when allocating or reusing it for new connections.

Adding zero credits is not allowed.

Credits can be given before entering the *BT_L2CAP_CONNECTING* state. Doing so will adjust the 'initial credits' sent in the connection PDU.

Must not be called while the channel is in BT_L2CAP_CONNECTING state.

Returns 0 in case of success or negative value in case of error.

int bt_l2cap_chan_recv_complete(struct bt_l2cap_chan *chan, struct net_buf *buf)

Complete receiving L2CAP channel data.

Complete the reception of incoming data. This shall only be called if the channel recv callback has returned -EINPROGRESS to process some incoming data. The buffer shall contain the original user_data as that is used for storing the credits/segments used by the packet.

Parameters

- chan Channel object.
- **buf** Buffer containing the data.

Returns 0 in case of success or negative value in case of error.

struct bt_12cap_chan

#include <l2cap.h> L2CAP Channel structure.

Public Members

```
struct bt conn *conn
```

Channel connection reference

const struct bt_l2cap_chan_ops *ops

Channel operations reference

struct bt_l2cap_le_endpoint

#include <l2cap.h> LE L2CAP Endpoint structure.

Public Members

```
uint16_t cid
```

Endpoint Channel Identifier (CID)

uint16_t mtu

Endpoint Maximum Transmission Unit

uint16_t mps

Endpoint Maximum PDU payload Size

uint16_t init_credits

Endpoint initial credits

atomic_t credits

Endpoint credits

struct bt_12cap_le_chan

#include <l2cap.h> LE L2CAP Channel structure.

Public Members

struct bt_l2cap_chan chan

Common L2CAP channel reference object

struct bt_l2cap_le_endpoint **rx**

Channel Receiving Endpoint.

If the application has set an alloc_buf channel callback for the channel to support receiving segmented L2CAP SDUs the application should initialize the MTU of the Receiving Endpoint. Otherwise the MTU of the receiving endpoint will be initialized to $BT_L2CAP_SDU_RX_MTU$ by the stack.

This is the source of the MTU, MPS and credit values when sending L2CAP_LE_CREDIT_BASED_CONNECTION_REQ/RSP and L2CAP_CONFIGURATION_REQ.

uint16_t pending_rx_mtu

Pending RX MTU on ECFC reconfigure, used internally by stack

struct bt_l2cap_le_endpoint tx

Channel Transmission Endpoint.

This is an image of the remote's rx.

The MTU and MPS is controlled by the remote by L2CAP_LE_CREDIT_BASED_CONNECTION_REQ/RSP or L2CAP_CONFIGURATION_REQ.

struct k_fifo tx_queue

Channel Transmission queue

struct net_buf *tx_buf

Channel Pending Transmission buffer

struct k work tx_work

Channel Transmission work

struct net buf *_sdu

Segment SDU packet from upper layer

struct bt_12cap_br_endpoint

#include <l2cap.h> BREDR L2CAP Endpoint structure.

Public Members

uint16_t cid

Endpoint Channel Identifier (CID)

uint16 t mtu

Endpoint Maximum Transmission Unit

uint 16_t mps

Endpoint Maximum PDU payload Size

uint16_t init_credits

Endpoint initial credits

atomic_t credits

Endpoint credits

struct bt_12cap_br_chan

#include <l2cap.h> BREDR L2CAP Channel structure.

Public Members

struct bt_l2cap_chan chan

Common L2CAP channel reference object

struct bt_l2cap_br_endpoint **rx**

Channel Receiving Endpoint

struct bt_l2cap_br_endpoint tx

Channel Transmission Endpoint

uint16_t pending_rx_mtu

Pending RX MTU on ECFC reconfigure, used internally by stack

uint16_t pending_rx_mps

Pending RX MPS on ECFC reconfigure, used internally by stack

uint16_t psm

Remote PSM to be connected

uint8 t ident

Helps match request context during CoC

struct bt_12cap_qos

#include <l2cap.h> QUALITY OF SERVICE (QOS) OPTION

struct bt_12cap_retrans_fc

#include <12cap.h> RETRANSMISSION AND FLOW CONTROL OPTION

struct bt_12cap_ext_flow_spec

#include <l2cap.h> EXTENDED FLOW SPECIFICATION OPTION

struct bt_12cap_cfg_options

#include <l2cap.h> L2CAP configuration parameter options.

struct bt_12cap_chan_ops

#include <l2cap.h> L2CAP Channel operations structure.

Public Members

void (*connected)(struct bt_l2cap_chan *chan)

Channel connected callback.

If this callback is provided it will be called whenever the connection completes.

Param chan The channel that has been connected

void (*disconnected)(struct bt l2cap chan *chan)

Channel disconnected callback.

If this callback is provided it will be called whenever the channel is disconnected, including when a connection gets rejected.

Param chan The channel that has been Disconnected

```
void (*encrypt_change)(struct bt_l2cap_chan *chan, uint8_t hci_status)
```

Channel encrypt_change callback.

If this callback is provided it will be called whenever the security level changed (indirectly link encryption done) or authentication procedure fails. In both cases security initiator and responder got the final status (HCI status) passed by related to encryption and authentication events from local host's controller.

Param chan The channel which has made encryption status changed.

Param status HCI status of performed security procedure caused by channel security requirements. The value is populated by HCI layer and set to 0 when success and to non-zero (reference to HCI Error Codes) when security/authentication failed.

```
struct net_buf *(*alloc_seg)(struct bt_l2cap_chan *chan)
```

Channel alloc_seg callback.

If this callback is provided the channel will use it to allocate buffers to store segments. This avoids wasting big SDU buffers with potentially much smaller PDUs. If this callback is supplied, it must return a valid buffer.

Param chan The channel requesting a buffer.

Return Allocated buffer.

```
struct net_buf *(*alloc_buf)(struct bt_l2cap_chan *chan)
```

Channel alloc_buf callback.

If this callback is provided the channel will use it to allocate buffers to store incoming data. Channels that requires segmentation must set this callback. If the application has not set a callback the L2CAP SDU MTU will be truncated to $BT_L2CAP_SDU_RX_MTU$.

Param chan The channel requesting a buffer.

Return Allocated buffer.

int (*recv)(struct bt_l2cap_chan *chan, struct net_buf *buf)

Channel recv callback.

Param chan The channel receiving data.

Param buf Buffer containing incoming data.

Return 0 in case of success or negative value in case of error.

Return -EINPROGRESS in case where user has to confirm once the data has been processed by calling *bt_l2cap_chan_recv_complete* passing back the buffer received with its original user_data which contains the number of segments/credits used by the packet.

```
void (*sent)(struct bt_l2cap_chan *chan)
```

Channel sent callback.

If this callback is provided it will be called whenever a SDU has been completely sent.

Param chan The channel which has sent data.

```
void (*status)(struct bt_l2cap_chan *chan, atomic_t *status)
```

Channel status callback.

If this callback is provided it will be called whenever the channel status changes.

Param chan The channel which status changed

Param status The channel status

```
void (*reconfigured)(struct bt_l2cap_chan *chan)
```

Channel reconfigured callback.

If this callback is provided it will be called whenever peer or local device requested reconfiguration. Application may check updated MTU and MPS values by inspecting chan->le endpoints.

Param chan The channel which was reconfigured

struct bt_12cap_server

#include <l2cap.h> L2CAP Server structure.

Public Members

uint16_t psm

Server PSM.

Possible values: 0 A dynamic value will be auto-allocated when bt_l2cap_server_register() is called.

0x0001-0x007f Standard, Bluetooth SIG-assigned fixed values.

0x0080-0x00ff Dynamically allocated. May be pre-set by the application before server registration (not recommended however), or auto-allocated by the stack if the app gave 0 as the value.

bt_security_t sec_level

Required minimum security level

```
int (*accept)(struct bt_conn *conn, struct bt_l2cap_server *server, struct bt_l2cap_chan **chan)
```

Server accept callback.

This callback is called whenever a new incoming connection requires authorization.

Param conn The connection that is requesting authorization

Param server Pointer to the server structure this callback relates to

Param chan Pointer to received the allocated channel

Return 0 in case of success or negative value in case of error.

Return -ENOMEM if no available space for new channel.

Return -EACCES if application did not authorize the connection.

Return -EPERM if encryption key size is too short.

1.9 Serial Port Emulation (RFCOMM)

1.9.1 API Reference

```
group bt_rfcomm
RFCOMM .

Typedefs

typedef enum bt_rfcomm_role bt_rfcomm_role_t
```

Enums

```
enumerator BT_RFCOMM_CHAN_HFP_HF
enumerator BT_RFCOMM_CHAN_HFP_AG
enumerator BT_RFCOMM_CHAN_HSP_AG
enumerator BT_RFCOMM_CHAN_HSP_HS
enumerator BT_RFCOMM_CHAN_SPP
enum bt_rfcomm_role
Role of RFCOMM session and dlc. Used only by internal APIs.
Values:
enumerator BT_RFCOMM_ROLE_ACCEPTOR
enumerator BT_RFCOMM_ROLE_INITIATOR
```

Functions

int **bt_rfcomm_server_register**(struct *bt_rfcomm_server* *server)

Register RFCOMM server.

(defined(CONFIG_BT_RFCOMM_ENABLE_CONTROL_CMD) && (CON-FIG_BT_RFCOMM_ENABLE_CONTROL_CMD > 0))

Register RFCOMM server for a channel, each new connection is authorized using the accept() callback which in case of success shall allocate the dlc structure to be used by the new connection.

Parameters

• **server** – Server structure.

Returns 0 in case of success or negative value in case of error.

int bt_rfcomm_dlc_connect(struct bt_conn *conn, struct bt_rfcomm_dlc *dlc, uint8_t channel)

Connect RFCOMM channel.

Connect RFCOMM dlc by channel, once the connection is completed dlc connected() callback will be called. If the connection is rejected disconnected() callback is called instead.

Parameters

- conn Connection object.
- **dlc** Dlc object.
- **channel** Server channel to connect to.

Returns 0 in case of success or negative value in case of error.

int **bt_rfcomm_dlc_send**(struct *bt_rfcomm_dlc* *dlc, struct net_buf *buf)

Send data to RFCOMM.

Send data from buffer to the dlc. Length should be less than or equal to mtu.

Parameters

- dlc Dlc object.
- buf Data buffer.

Returns Bytes sent in case of success or negative value in case of error.

int bt_rfcomm_dlc_disconnect(struct bt_rfcomm_dlc *dlc)

Disconnect RFCOMM dlc.

Disconnect RFCOMM dlc, if the connection is pending it will be canceled and as a result the dlc disconnected() callback is called.

Parameters

• dlc – Dlc object.

Returns 0 in case of success or negative value in case of error.

struct net buf *bt_rfcomm_create_pdu(struct net buf pool *pool)

Allocate the buffer from pool after reserving head room for RFCOMM, L2CAP and ACL headers.

(defined(CONFIG_BT_RFCOMM_ENABLE_CONTROL_CMD) && (CON-FIG_BT_RFCOMM_ENABLE_CONTROL_CMD > 0))

Parameters

```
• pool – Which pool to take the buffer from.
```

Returns New buffer.

```
struct bt_rfcomm_dlc_ops
```

#include <rfcomm.h> RFCOMM DLC operations structure.

Public Members

```
void (*connected)(struct bt_rfcomm_dlc *dlc)
```

DLC connected callback

If this callback is provided it will be called whenever the connection completes.

Param dlc The dlc that has been connected

```
void (*disconnected)(struct bt_rfcomm_dlc *dlc)
```

DLC disconnected callback

If this callback is provided it will be called whenever the dlc is disconnected, including when a connection gets rejected or cancelled (both incoming and outgoing)

Param dlc The dlc that has been Disconnected

```
void (*recv)(struct bt_rfcomm_dlc *dlc, struct net_buf *buf)
```

DLC recv callback

Param dlc The dlc receiving data.

Param buf Buffer containing incoming data.

```
void (*sent)(struct bt_rfcomm_dlc *dlc, struct net_buf *buf)
```

DLC sent callback

Param dlc The dlc receiving data.

Param buf Buffer containing sending data.

struct bt_rfcomm_dlc

#include <rfcomm.h> RFCOMM DLC structure.

struct bt_rfcomm_server

#include <rfcomm.h>

Public Members

uint8 t channel

Server Channel

int (*accept)(struct bt_conn *conn, struct bt_rfcomm_dlc **dlc)

Server accept callback

This callback is called whenever a new incoming connection requires authorization.

Param conn The connection that is requesting authorization

Param dlc Pointer to received the allocated dlc

Return 0 in case of success or negative value in case of error.

1.10 Service Discovery Protocol (SDP)

1.10.1 API Reference

group bt_sdp

Service class identifiers of standard services and service groups

BT_SDP_SDP_SERVER_SVCLASS

Service Discovery Server

BT_SDP_BROWSE_GRP_DESC_SVCLASS

Browse Group Descriptor

BT_SDP_PUBLIC_BROWSE_GROUP

Public Browse Group

BT_SDP_SERIAL_PORT_SVCLASS

Serial Port

BT_SDP_LAN_ACCESS_SVCLASS

LAN Access Using PPP

BT_SDP_DIALUP_NET_SVCLASS

Dialup Networking

BT_SDP_IRMC_SYNC_SVCLASS

IrMC Sync

BT_SDP_OBEX_OBJPUSH_SVCLASS

OBEX Object Push

BT_SDP_OBEX_FILETRANS_SVCLASS

OBEX File Transfer

BT_SDP_IRMC_SYNC_CMD_SVCLASS

IrMC Sync Command

BT_SDP_HEADSET_SVCLASS

Headset

BT_SDP_CORDLESS_TELEPHONY_SVCLASS

Cordless Telephony

BT_SDP_AUDIO_SOURCE_SVCLASS

Audio Source

BT_SDP_AUDIO_SINK_SVCLASS

Audio Sink

BT_SDP_AV_REMOTE_TARGET_SVCLASS

A/V Remote Control Target

BT_SDP_ADVANCED_AUDIO_SVCLASS

Advanced Audio Distribution

BT_SDP_AV_REMOTE_SVCLASS

A/V Remote Control

BT_SDP_AV_REMOTE_CONTROLLER_SVCLASS

A/V Remote Control Controller

BT_SDP_INTERCOM_SVCLASS

Intercom

BT_SDP_FAX_SVCLASS

Fax

BT_SDP_HEADSET_AGW_SVCLASS

Headset AG

BT_SDP_WAP_SVCLASS

WAP

BT_SDP_WAP_CLIENT_SVCLASS

WAP Client

BT_SDP_PANU_SVCLASS

Personal Area Networking User

BT_SDP_NAP_SVCLASS

Network Access Point

BT_SDP_GN_SVCLASS

Group Network

BT_SDP_DIRECT_PRINTING_SVCLASS

Direct Printing

BT_SDP_REFERENCE_PRINTING_SVCLASS

Reference Printing

BT_SDP_IMAGING_SVCLASS

Basic Imaging Profile

BT_SDP_IMAGING_RESPONDER_SVCLASS

Imaging Responder

BT_SDP_IMAGING_ARCHIVE_SVCLASS

Imaging Automatic Archive

BT_SDP_IMAGING_REFOBJS_SVCLASS

Imaging Referenced Objects

BT_SDP_HANDSFREE_SVCLASS

Handsfree

BT_SDP_HANDSFREE_AGW_SVCLASS

Handsfree Audio Gateway

BT_SDP_DIRECT_PRT_REFOBJS_SVCLASS

Direct Printing Reference Objects Service

BT_SDP_REFLECTED_UI_SVCLASS

Reflected UI

BT_SDP_BASIC_PRINTING_SVCLASS

Basic Printing

BT_SDP_PRINTING_STATUS_SVCLASS

Printing Status

BT_SDP_HID_SVCLASS

Human Interface Device Service

BT_SDP_HCR_SVCLASS

Hardcopy Cable Replacement

BT_SDP_HCR_PRINT_SVCLASS

HCR Print

BT_SDP_HCR_SCAN_SVCLASS

HCR Scan

BT_SDP_CIP_SVCLASS

Common ISDN Access

BT_SDP_VIDEO_CONF_GW_SVCLASS

Video Conferencing Gateway

BT_SDP_UDI_MT_SVCLASS

UDI MT

BT_SDP_UDI_TA_SVCLASS

UDI TA

BT_SDP_AV_SVCLASS

Audio/Video

BT_SDP_SAP_SVCLASS

SIM Access

BT_SDP_PBAP_PCE_SVCLASS

Phonebook Access Client

BT_SDP_PBAP_PSE_SVCLASS

Phonebook Access Server

BT_SDP_PBAP_SVCLASS

Phonebook Access

BT_SDP_MAP_MSE_SVCLASS

Message Access Server

BT_SDP_MAP_MCE_SVCLASS

Message Notification Server

BT_SDP_MAP_SVCLASS

Message Access Profile

BT_SDP_GNSS_SVCLASS

GNSS

BT_SDP_GNSS_SERVER_SVCLASS

GNSS Server

BT_SDP_MPS_SC_SVCLASS

MPS SC

BT_SDP_MPS_SVCLASS

MPS

BT_SDP_PNP_INFO_SVCLASS

PnP Information

BT_SDP_GENERIC_NETWORKING_SVCLASS

Generic Networking

BT_SDP_GENERIC_FILETRANS_SVCLASS

Generic File Transfer

BT_SDP_GENERIC_AUDIO_SVCLASS

Generic Audio

BT_SDP_GENERIC_TELEPHONY_SVCLASS

Generic Telephony

BT_SDP_UPNP_SVCLASS

UPnP Service

BT_SDP_UPNP_IP_SVCLASS

UPnP IP Service

BT_SDP_UPNP_PAN_SVCLASS

UPnP IP PAN

BT_SDP_UPNP_LAP_SVCLASS

UPnP IP LAP

BT_SDP_UPNP_L2CAP_SVCLASS

UPnP IP L2CAP

BT_SDP_VIDEO_SOURCE_SVCLASS

Video Source

BT_SDP_VIDEO_SINK_SVCLASS

Video Sink

BT_SDP_VIDEO_DISTRIBUTION_SVCLASS

Video Distribution

BT_SDP_HDP_SVCLASS

HDP

BT_SDP_HDP_SOURCE_SVCLASS

HDP Source

BT_SDP_HDP_SINK_SVCLASS

HDP Sink

BT_SDP_GENERIC_ACCESS_SVCLASS

Generic Access Profile

BT_SDP_GENERIC_ATTRIB_SVCLASS

Generic Attribute Profile

BT_SDP_APPLE_AGENT_SVCLASS

Apple Agent

Attribute identifier codes

Possible values for attribute-id are listed below. See SDP Spec, section "Service Attribute Definitions" for more details.

BT_SDP_ATTR_RECORD_HANDLE

Service Record Handle

BT_SDP_ATTR_SVCLASS_ID_LIST

Service Class ID List

BT_SDP_ATTR_RECORD_STATE

Service Record State

BT_SDP_ATTR_SERVICE_ID

Service ID

BT_SDP_ATTR_PROTO_DESC_LIST

Protocol Descriptor List

BT_SDP_ATTR_BROWSE_GRP_LIST

Browse Group List

BT_SDP_ATTR_LANG_BASE_ATTR_ID_LIST

Language Base Attribute ID List

BT_SDP_ATTR_SVCINFO_TTL

Service Info Time to Live

BT_SDP_ATTR_SERVICE_AVAILABILITY

Service Availability

BT_SDP_ATTR_PROFILE_DESC_LIST

Bluetooth Profile Descriptor List

BT_SDP_ATTR_DOC_URL

Documentation URL

BT_SDP_ATTR_CLNT_EXEC_URL

Client Executable URL

BT_SDP_ATTR_ICON_URL

Icon URL

BT_SDP_ATTR_ADD_PROTO_DESC_LIST

Additional Protocol Descriptor List

BT_SDP_ATTR_GROUP_ID

Group ID

BT_SDP_ATTR_IP_SUBNET

IP Subnet

BT_SDP_ATTR_VERSION_NUM_LIST

Version Number List

BT_SDP_ATTR_SUPPORTED_FEATURES_LIST

Supported Features List

BT_SDP_ATTR_GOEP_L2CAP_PSM

GOEP L2CAP PSM

BT_SDP_ATTR_SVCDB_STATE

Service Database State

BT_SDP_ATTR_MPSD_SCENARIOS

MPSD Scenarios

BT_SDP_ATTR_MPMD_SCENARIOS

MPMD Scenarios

BT_SDP_ATTR_MPS_DEPENDENCIES

Supported Profiles & Protocols

BT_SDP_ATTR_SERVICE_VERSION

Service Version

BT_SDP_ATTR_EXTERNAL_NETWORK

External Network

BT_SDP_ATTR_SUPPORTED_DATA_STORES_LIST

Supported Data Stores List

BT_SDP_ATTR_DATA_EXCHANGE_SPEC

Data Exchange Specification

BT_SDP_ATTR_NETWORK

Network

BT_SDP_ATTR_FAX_CLASS1_SUPPORT

Fax Class 1 Support

BT_SDP_ATTR_REMOTE_AUDIO_VOLUME_CONTROL

Remote Audio Volume Control

BT_SDP_ATTR_MCAP_SUPPORTED_PROCEDURES

MCAP Supported Procedures

BT_SDP_ATTR_FAX_CLASS20_SUPPORT

Fax Class 2.0 Support

BT_SDP_ATTR_SUPPORTED_FORMATS_LIST

Supported Formats List

BT_SDP_ATTR_FAX_CLASS2_SUPPORT

Fax Class 2 Support (vendor-specific)

BT_SDP_ATTR_AUDIO_FEEDBACK_SUPPORT

Audio Feedback Support

BT_SDP_ATTR_NETWORK_ADDRESS

Network Address

BT_SDP_ATTR_WAP_GATEWAY

WAP Gateway

BT_SDP_ATTR_HOMEPAGE_URL

Homepage URL

BT_SDP_ATTR_WAP_STACK_TYPE

WAP Stack Type

BT_SDP_ATTR_SECURITY_DESC

Security Description

BT_SDP_ATTR_NET_ACCESS_TYPE

Net Access Type

BT_SDP_ATTR_MAX_NET_ACCESSRATE

Max Net Access Rate

BT_SDP_ATTR_IP4_SUBNET

IPv4 Subnet

BT_SDP_ATTR_IP6_SUBNET

IPv6 Subnet

BT_SDP_ATTR_SUPPORTED_CAPABILITIES

BIP Supported Capabilities

BT_SDP_ATTR_SUPPORTED_FEATURES

BIP Supported Features

BT_SDP_ATTR_SUPPORTED_FUNCTIONS

BIP Supported Functions

BT_SDP_ATTR_TOTAL_IMAGING_DATA_CAPACITY

BIP Total Imaging Data Capacity

BT_SDP_ATTR_SUPPORTED_REPOSITORIES

Supported Repositories

BT_SDP_ATTR_MAS_INSTANCE_ID

MAS Instance ID

BT_SDP_ATTR_SUPPORTED_MESSAGE_TYPES

Supported Message Types

BT_SDP_ATTR_PBAP_SUPPORTED_FEATURES

PBAP Supported Features

BT_SDP_ATTR_MAP_SUPPORTED_FEATURES

MAP Supported Features

BT_SDP_ATTR_SPECIFICATION_ID

Specification ID

BT_SDP_ATTR_VENDOR_ID

Vendor ID

BT_SDP_ATTR_PRODUCT_ID

Product ID

BT_SDP_ATTR_VERSION

Version

BT_SDP_ATTR_PRIMARY_RECORD

Primary Record

BT_SDP_ATTR_VENDOR_ID_SOURCE

Vendor ID Source

BT_SDP_ATTR_HID_DEVICE_RELEASE_NUMBER

HID Device Release Number

BT_SDP_ATTR_HID_PARSER_VERSION

HID Parser Version

BT_SDP_ATTR_HID_DEVICE_SUBCLASS

HID Device Subclass

BT_SDP_ATTR_HID_COUNTRY_CODE

HID Country Code

BT_SDP_ATTR_HID_VIRTUAL_CABLE

HID Virtual Cable

BT_SDP_ATTR_HID_RECONNECT_INITIATE

HID Reconnect Initiate

BT_SDP_ATTR_HID_DESCRIPTOR_LIST

HID Descriptor List

BT_SDP_ATTR_HID_LANG_ID_BASE_LIST

HID Language ID Base List

BT_SDP_ATTR_HID_SDP_DISABLE

HID SDP Disable

BT_SDP_ATTR_HID_BATTERY_POWER

HID Battery Power

BT_SDP_ATTR_HID_REMOTE_WAKEUP

HID Remote Wakeup

BT_SDP_ATTR_HID_PROFILE_VERSION

HID Profile Version

BT_SDP_ATTR_HID_SUPERVISION_TIMEOUT

HID Supervision Timeout

BT_SDP_ATTR_HID_NORMALLY_CONNECTABLE

HID Normally Connectable

BT_SDP_ATTR_HID_BOOT_DEVICE

HID Boot Device

The Data representation in SDP PDUs (pps 339, 340 of BT SDP Spec)

These are the exact data type+size descriptor values that go into the PDU buffer.

The datatype (leading 5bits) + size descriptor (last 3 bits) is 8 bits. The size descriptor is critical to extract the right number of bytes for the data value from the PDU.

For most basic types, the datatype+size descriptor is straightforward. However for constructed types and strings, the size of the data is in the next "n" bytes following the 8 bits (datatype+size) descriptor. Exactly what the "n" is specified in the 3 bits of the data size descriptor.

TextString and URLString can be of size 2⁸ {8, 16, 32} bytes DataSequence and DataSequenceAlternates can be of size 2⁸ {8, 16, 32} The size are computed post-facto in the API and are not known apriori.

BT_SDP_DATA_NIL

Nil, the null type

BT_SDP_UINT8

Unsigned 8-bit integer

BT_SDP_UINT16

Unsigned 16-bit integer

BT_SDP_UINT32

Unsigned 32-bit integer

BT_SDP_UINT64

Unsigned 64-bit integer

BT_SDP_UINT128

Unsigned 128-bit integer

BT_SDP_INT8

Signed 8-bit integer

BT_SDP_INT16

Signed 16-bit integer

BT_SDP_INT32

Signed 32-bit integer

BT_SDP_INT64

Signed 64-bit integer

BT_SDP_INT128

Signed 128-bit integer

BT_SDP_UUID_UNSPEC

UUID, unspecified size

BT_SDP_UUID16

UUID, 16-bit

BT_SDP_UUID32

UUID, 32-bit

BT_SDP_UUID128

UUID, 128-bit

BT_SDP_TEXT_STR_UNSPEC

Text string, unspecified size

BT_SDP_TEXT_STR8

Text string, 8-bit length

BT_SDP_TEXT_STR16

Text string, 16-bit length

BT_SDP_TEXT_STR32

Text string, 32-bit length

BT_SDP_BOOL

Boolean

BT_SDP_SEQ_UNSPEC

Data element sequence, unspecified size

BT_SDP_SEQ8

Data element sequence, 8-bit length

BT_SDP_SEQ16

Data element sequence, 16-bit length

BT_SDP_SEQ32

Data element sequence, 32-bit length

BT_SDP_ALT_UNSPEC

Data element alternative, unspecified size

BT_SDP_ALT8

Data element alternative, 8-bit length

BT_SDP_ALT16

Data element alternative, 16-bit length

BT_SDP_ALT32

Data element alternative, 32-bit length

BT_SDP_URL_STR_UNSPEC

URL string, unspecified size

BT_SDP_URL_STR8

URL string, 8-bit length

BT_SDP_URL_STR16

URL string, 16-bit length

BT_SDP_URL_STR32

URL string, 32-bit length

Defines

BT_SDP_SERVER_RECORD_HANDLE

BT_SDP_PRIMARY_LANG_BASE

BT_SDP_ATTR_SVCNAME_PRIMARY

BT_SDP_ATTR_SVCDESC_PRIMARY

BT_SDP_ATTR_PROVNAME_PRIMARY

BT_SDP_TYPE_DESC_MASK

BT_SDP_SIZE_DESC_MASK

BT_SDP_SIZE_INDEX_OFFSET

BT_SDP_ARRAY_8(...)

Declare an array of 8-bit elements in an attribute.

BT_SDP_ARRAY_16(...)

Declare an array of 16-bit elements in an attribute.

BT_SDP_ARRAY_32(...)

Declare an array of 32-bit elements in an attribute.

BT_SDP_TYPE_SIZE(_type)

Declare a fixed-size data element header.

Parameters

• **_type** – Data element header containing type and size descriptors.

BT_SDP_TYPE_SIZE_VAR(_type, _size)

Declare a variable-size data element header.

Parameters

- **_type** Data element header containing type and size descriptors.
- _size The actual size of the data.

BT_SDP_DATA_ELEM_LIST(...)

Declare a list of data elements.

BT_SDP_NEW_SERVICE

SDP New Service Record Declaration Macro.

Helper macro to declare a new service record. Default attributes: Record Handle, Record State, Language Base, Root Browse Group

BT_SDP_LIST(_att_id, _type_size, _data_elem_seq)

Generic SDP List Attribute Declaration Macro.

Helper macro to declare a list attribute.

Parameters

- _att_id List Attribute ID.
- _data_elem_seq Data element sequence for the list.
- **_type_size** SDP type and size descriptor.

BT_SDP_SERVICE_ID(_uuid)

SDP Service ID Attribute Declaration Macro.

Helper macro to declare a service ID attribute.

Parameters

• **_uuid** – Service ID 16bit UUID.

BT SDP SERVICE NAME(name)

SDP Name Attribute Declaration Macro.

Helper macro to declare a service name attribute.

Parameters

• _name – Service name as a string (up to 256 chars).

BT_SDP_SUPPORTED_FEATURES(features)

SDP Supported Features Attribute Declaration Macro.

Helper macro to declare supported features of a profile/protocol.

Parameters

• **_features** – Feature mask as 16bit unsigned integer.

BT_SDP_RECORD(attrs)

SDP Service Declaration Macro.

Helper macro to declare a service.

Parameters

• _attrs – List of attributes for the service record.

Typedefs

 $typedef \ uint 8_t \ (*\textbf{bt_sdp_discover_func_t}) (struct \ bt_conn \ *conn, \ struct \ bt_sdp_client_result \ *result) \\$

Callback type reporting to user that there is a resolved result on remote for given UUID and the result record buffer can be used by user for further inspection.

A function of this type is given by the user to the *bt_sdp_discover_params* object. It'll be called on each valid record discovery completion for given UUID. When UUID resolution gives back no records then NULL is passed to the user. Otherwise user can get valid record(s) and then the internal hint 'next record' is set to false saying the UUID resolution is complete or the hint can be set by caller to true meaning that next record is available for given UUID. The returned function value allows the user to control retrieving follow-up resolved records if any. If the user doesn't want to read more resolved records for given UUID

since current record data fulfills its requirements then should return BT_SDP_DISCOVER_UUID_STOP. Otherwise returned value means more subcall iterations are allowable.

Param conn Connection object identifying connection to queried remote.

Param result Object pointing to logical unparsed SDP record collected on base of response driven by given UUID.

Return BT_SDP_DISCOVER_UUID_STOP in case of no more need to read next record data and continue discovery for given UUID. By returning BT_SDP_DISCOVER_UUID_CONTINUE user allows this discovery continuation.

Enums

Helper enum to be used as return value of bt_sdp_discover_func_t. The value informs the caller to perform further pending actions or stop them.

Values:

enumerator BT_SDP_DISCOVER_UUID_STOP

enumerator BT_SDP_DISCOVER_UUID_CONTINUE

enum bt_sdp_proto

Protocols to be asked about specific parameters.

Values:

enumerator BT_SDP_PROTO_RFCOMM

enumerator BT_SDP_PROTO_L2CAP

Functions

int **bt_sdp_register_service**(struct *bt_sdp_record* *service)

Register a Service Record.

Register a Service Record. Applications can make use of macros such as BT_SDP_DECLARE_SERVICE, BT_SDP_LIST, BT_SDP_SERVICE_ID, BT_SDP_SERVICE_NAME, etc. A service declaration must start with BT_SDP_NEW_SERVICE.

Parameters

• service – Service record declared using BT_SDP_DECLARE_SERVICE.

Returns 0 in case of success or negative value in case of error.

int bt_sdp_discover(struct bt conn *conn, const struct bt sdp_discover_params *params)

Allows user to start SDP discovery session.

The function performs SDP service discovery on remote server driven by user delivered discovery parameters. Discovery session is made as soon as no SDP transaction is ongoing between peers and if any then

this one is queued to be processed at discovery completion of previous one. On the service discovery completion the callback function will be called to get feedback to user about findings.

Parameters

- conn Object identifying connection to remote.
- params SDP discovery parameters.

Returns 0 in case of success or negative value in case of error.

int **bt_sdp_discover_cancel**(struct bt_conn *conn, const struct *bt_sdp_discover_params* *params)

Release waiting SDP discovery request.

It can cancel valid waiting SDP client request identified by SDP discovery parameters object.

Parameters

- **conn** Object identifying connection to remote.
- params SDP discovery parameters.

Returns 0 in case of success or negative value in case of error.

int **bt_sdp_get_proto_param**(const struct net_buf *buf, enum bt_sdp_proto proto, uint16_t *param)

Give to user parameter value related to given stacked protocol UUID.

API extracts specific parameter associated with given protocol UUID available in Protocol Descriptor List attribute.

Parameters

- **buf** Original buffered raw record data.
- proto Known protocol to be checked like RFCOMM or L2CAP.
- param On success populated by found parameter value.

Returns 0 on success when specific parameter associated with given protocol value is found, or negative if error occurred during processing.

int **bt_sdp_get_addl_proto_param**(const struct net_buf *buf, enum *bt_sdp_proto* proto, uint8_t param_index, uint16_t *param)

Get additional parameter value related to given stacked protocol UUID.

API extracts specific parameter associated with given protocol UUID available in Additional Protocol Descriptor List attribute.

Parameters

- **buf** Original buffered raw record data.
- **proto** Known protocol to be checked like RFCOMM or L2CAP.
- param_index There may be more than one parameter related to the given protocol UUID. This function returns the result that is indexed by this parameter. It's value is from 0, 0 means the first matched result, 1 means the second matched result.
- param [out] On success populated by found parameter value.

Returns 0 on success when a specific parameter associated with a given protocol value is found, or negative if error occurred during processing.

int bt_sdp_get_profile_version(const struct net_buf *buf, uint16_t profile, uint16_t *version)

Get profile version.

Helper API extracting remote profile version number. To get it proper generic profile parameter needs to be selected usually listed in SDP Interoperability Requirements section for given profile specification.

Parameters

- **buf** Original buffered raw record data.
- **profile** Profile family identifier the profile belongs.
- **version** On success populated by found version number.

Returns 0 on success, negative value if error occurred during processing.

int bt_sdp_get_features(const struct net_buf *buf, uint16_t *features)

Get SupportedFeatures attribute value.

Allows if exposed by remote retrieve SupportedFeature attribute.

Parameters

- **buf** Buffer holding original raw record data from remote.
- **features** On success object to be populated with SupportedFeature mask.

Returns 0 on success if feature found and valid, negative in case any error

struct bt_sdp_data_elem

#include <sdp.h> SDP Generic Data Element Value.

Public Members

uint8_t type

Type of the data element

uint32_t data_size

Size of the data element

uint32_t total_size

Total size of the data element

struct bt_sdp_attribute

#include <sdp.h> SDP Attribute Value.

```
uint16_t id
```

Attribute ID

struct bt_sdp_data_elem val

Attribute data

struct bt_sdp_record

#include <sdp.h> SDP Service Record Value.

Public Members

```
uint32 t handle
```

Redundant, for quick ref

struct bt_sdp_attribute *attrs

Base addr of attr array

size_t attr_count

Number of attributes

uint8 t index

Index of the record in LL

struct bt_sdp_record *next

Next service record

struct bt_sdp_client_result

#include <sdp.h> Generic SDP Client Query Result data holder.

Public Members

```
struct net_buf *resp_buf
```

buffer containing unparsed SDP record result for given UUID

bool next_record_hint

flag pointing that there are more result chunks for given UUID

const struct bt_uuid *uuid

Reference to UUID object on behalf one discovery was started

struct bt_sdp_discover_params

#include <sdp.h> Main user structure used in SDP discovery of remote.

const struct bt_uuid *uuid

UUID (service) to be discovered on remote SDP entity

bt_sdp_discover_func_t func

Discover callback to be called on resolved SDP record

struct net_buf_pool *pool

Memory buffer enabled by user for SDP query results

1.11 Advance Audio Distribution Profile (A2DP)

1.11.1 API Reference

group bt_a2dp

Advance Audio Distribution Profile (A2DP).

Defines

BT_A2DP_SBC_IE_LENGTH

SBC IE length

BT_A2DP_MPEG_1_2_IE_LENGTH

MPEG1,2 IE length

BT_A2DP_MPEG_2_4_IE_LENGTH

MPEG2,4 IE length

BT_A2DP_SOURCE_SBC_CODEC_BUFFER_SIZE

BT_A2DP_SOURCE_SBC_CODEC_BUFFER_NOCACHED_SIZE

BT_A2DP_SINK_SBC_CODEC_BUFFER_SIZE

BT_A2DP_SINK_SBC_CODEC_BUFFER_NOCACHED_SIZE

BT_A2DP_EP_CONTENT_PROTECTION_INIT

BT_A2DP_EP_RECOVERY_SERVICE_INIT

BT_A2DP_EP_REPORTING_SERVICE_INIT

BT_A2DP_EP_DELAY_REPORTING_INIT

BT_A2DP_EP_HEADER_COMPRESSION_INIT

BT_A2DP_EP_MULTIPLEXING_INIT

BT_A2DP_ENDPOINT_INIT(_role, _codec, _capability, _config, _codec_buffer, _codec_buffer_nocahced) define the audio endpoint

Parameters

- _role BT_A2DP_SOURCE or BT_A2DP_SINK.
- _codec value of enum bt_a2dp_codec_id.
- _capability the codec capability.
- **config** the default config to configure the peer same codec type endpoint.
- _codec_buffer the codec function used buffer.
- _codec_buffer_nocahced the codec function used nocached buffer.

BT_A2DP_SINK_ENDPOINT_INIT(_codec, _capability, _codec_buffer, _codec_buffer_nocahced) define the audio sink endpoint

Parameters

- _codec value of enum bt_a2dp_codec_id.
- _capability the codec capability.
- _codec_buffer the codec function used buffer.
- _codec_buffer_nocahced the codec function used nocached buffer.

BT_A2DP_SOURCE_ENDPOINT_INIT(_codec, _capability, _config, _codec_buffer, _codec_buffer_nocahced) define the audio source endpoint

Parameters

- _codec value of enum bt a2dp codec id.
- **_capability** the codec capability.
- _config the default config to configure the peer same codec type endpoint.
- _codec_buffer the codec function used buffer.
- _codec_buffer_nocahced the codec function used nocached buffer.

BT_A2DP_SBC_SINK_ENDPOINT(name)

define the default SBC sink endpoint that can be used as bt_a2dp_register_endpoint's parameter.

SBC is mandatory as a 2dp specification, $BT_A2DP_SBC_SINK_ENDPOINT$ is more convenient for user to register SBC endpoint.

Parameters

• _name – the endpoint variable name.

BT_A2DP_SBC_SOURCE_ENDPOINT(_name, _config_freq)

define the default SBC source endpoint that can be used as bt_a2dp_register_endpoint's parameter.

SBC is mandatory as a2dp specification, BT_A2DP_SBC_SOURCE_ENDPOINT is more convenient for user to register SBC endpoint.

Parameters

- _name the endpoint variable name.
- _config_freq the frequency to configure the peer same codec type endpoint.

Typedefs

```
typedef uint8_t (*bt_a2dp_discover_peer_endpoint_cb_t)(struct bt_a2dp *a2dp, struct bt_a2dp_endpoint *endpoint, int err)

Get peer's endpoints callback.
```

Enums

```
enum bt_a2dp_codec_id
    Codec ID.
    Values:
    enumerator BT_A2DP_SBC
        Codec SBC
    enumerator BT_A2DP_MPEG1
        Codec MPEG-1
    enumerator BT_A2DP_MPEG2
        Codec MPEG-2
    enumerator BT_A2DP_ATRAC
        Codec ATRAC
    enumerator BT_A2DP_VENDOR
        Codec Non-A2DP
enum MEDIA_TYPE
    Stream End Point Media Type.
    Values:
    enumerator BT_A2DP_AUDIO
```

Audio Media Type

enumerator BT_A2DP_VIDEO

Video Media Type

enumerator BT_A2DP_MULTIMEDIA

Multimedia Media Type

enum ROLE_TYPE

Stream End Point Role.

Values:

enumerator BT_A2DP_SOURCE

Source Role

enumerator BT_A2DP_SINK

Sink Role

Helper enum to be used as return value of bt_a2dp_discover_peer_endpoint_cb_t. The value informs the caller to perform further pending actions or stop them.

Values:

enumerator BT_A2DP_DISCOVER_ENDPOINT_STOP

enumerator BT_A2DP_DISCOVER_ENDPOINT_CONTINUE

Functions

struct bt_a2dp *bt_a2dp_connect(struct bt_conn *conn)

A2DP Connect.

This function is to be called after the conn parameter is obtained by performing a GAP procedure. The API is to be used to establish A2DP connection between devices. This function only establish AVDTP L2CAP connection. After connection success, the callback that is registered by bt_a2dp_register_connect_callback is called.

Parameters

• **conn** – Pointer to bt_conn structure.

Returns pointer to struct bt a2dp in case of success or NULL in case of error.

int bt_a2dp_disconnect(struct bt_a2dp *a2dp)

disconnect 12cap a2dp

Parameters

• **a2dp** – The a2dp instance.

Returns 0 in case of success and error code in case of error.

int **bt_a2dp_register_endpoint**(struct *bt_a2dp_endpoint* *endpoint, uint8_t media_type, uint8_t role) Endpoint Registration.

This function is used for registering the stream end points. The user has to take care of allocating the memory of the endpoint pointer and then pass the required arguments. Also, only one sep can be registered at a time. Multiple stream end points can be registered by calling multiple times. The endpoint registered first has a higher priority than the endpoint registered later. The priority is used in bt a2dp configure.

Parameters

- **endpoint** Pointer to *bt_a2dp_endpoint* structure.
- **media_type** Media type that the Endpoint is.
- role Role of Endpoint.

Returns 0 in case of success and error code in case of error.

int bt_a2dp_register_connect_callback(struct bt_a2dp_connect_cb *cb)

register connecting callback.

The cb is called when bt_a2dp_connect is called or it is connected by peer device.

Parameters

• **cb** – The callback function.

Returns 0 in case of success and error code in case of error.

int **bt_a2dp_configure**(struct bt_a2dp *a2dp, void (*result_cb)(int err))

configure control callback.

This function will get peer's all endpoints and select one endpoint based on the priority of registered endpoints, then configure the endpoint based on the "config" of endpoint. Note: (1) priority is described in bt_a2dp_register_endpoint; (2) "config" is the config field of struct bt_a2dp_endpoint that is registered by bt_a2dp_register_endpoint.

Parameters

- **a2dp** The a2dp instance.
- result_cb The result callback function.

Returns 0 in case of success and error code in case of error.

int **bt_a2dp_discover_peer_endpoints**(struct bt_a2dp *a2dp, bt_a2dp_discover_peer_endpoint_cb_t cb) get peer's endpoints.

bt_a2dp_configure can be called to configure a2dp. bt_a2dp_discover_peer_endpoints and bt_a2dp_configure_endpoint can be used too. In bt_a2dp_configure, the endpoint is selected automatically based on the prioriy. If bt_a2dp_configure fails, it means the default config of endpoint is not reasonal. bt_a2dp_discover_peer_endpoints and bt_a2dp_configure_endpoint can be used. bt_a2dp_discover_peer_endpoints is used to get peer endpoints. the peer endpoint is returned in the cb. then endpoint can be selected and configured by bt_a2dp_configure_endpoint. If user stops to discover more peer endpoins, return BT_A2DP_DISCOVER_ENDPOINT_STOP in the cb; if user wants to discover more peer endpoints, return BT_A2DP_DISCOVER_ENDPOINT_CONTINUE in the cb.

Parameters

- a2dp The a2dp instance.
- **cb** notify the result.

Returns 0 in case of success and error code in case of error.

int **bt_a2dp_configure_endpoint**(struct bt_a2dp *a2dp, struct bt_a2dp_endpoint *endpoint, struct bt_a2dp_endpoint *peer_endpoint, struct bt_a2dp_endpoint_config *config)

configure endpoint.

If the bt_a2dp_configure is failed or user want to change configured endpoint, user can call bt_a2dp_discover_peer_endpoints and this function to configure the selected endpoint.

Parameters

- **a2dp** The a2dp instance.
- **endpoint** The configured endpoint that is registered.
- **config** The config to configure the endpoint.

Returns 0 in case of success and error code in case of error.

int **bt_a2dp_deconfigure**(struct *bt_a2dp_endpoint* *endpoint)

revert the configuration, then it can be configured again.

Release the endpoint based on the endpoint's state. After this, the endpoint can be re-configured again.

Parameters

• **endpoint** – the registered endpoint.

Returns 0 in case of success and error code in case of error.

int **bt_a2dp_start**(struct *bt_a2dp_endpoint* *endpoint)

start a2dp streamer, it is source only.

Parameters

• **endpoint** – The endpoint.

Returns 0 in case of success and error code in case of error.

int **bt_a2dp_stop**(struct *bt_a2dp_endpoint* *endpoint)

stop a2dp streamer, it is source only.

Parameters

• **endpoint** – The registered endpoint.

Returns 0 in case of success and error code in case of error.

int **bt_a2dp_reconfigure**(struct *bt_a2dp_endpoint* *endpoint, struct *bt_a2dp_endpoint_config* *config) re-configure a2dp streamer

This function send the AVDTP_RECONFIGURE command

Parameters

- **a2dp** The a2dp instance.
- **endpoint** the endpoint.
- **config** The config to configure the endpoint.

Returns 0 in case of success and error code in case of error.

struct bt_a2dp_codec_ie

#include <a2dp.h> codec information elements for the endpoint

```
uint8_t len
```

Length of capabilities

uint8_t codec_ie[0]

codec information element

struct bt_a2dp_endpoint_config

#include <a2dp.h> The endpoint configuration.

Public Members

```
struct bt_a2dp_codec_ie *media_config
```

The media configuration content

struct bt_a2dp_endpoint_configure_result

#include <a2dp.h> The configuration result.

Public Members

int err

0 - success; other values - fail code

struct bt_a2dp *a2dp

which a2dp connection the endpoint is configured

struct bt_conn *conn

which conn the endpoint is configured

struct bt_a2dp_endpoint_config config

The configuration content

struct bt_a2dp_control_cb

#include <a2dp.h> The callback that is controlled by peer.

```
void (*configured)(struct bt_a2dp_endpoint_configure_result *config)
         a2dp is configured by peer.
             Param err a2dp configuration result.
     void (*deconfigured)(int err)
         a2dp is de-configured by peer.
             Param err a2dp configuration result.
     void (*start_play)(int err)
         The result of starting media streamer.
     void (*stop_play)(int err)
         the result of stopping media streaming.
     void (*sink_streamer_data)(uint8_t *data, uint32_t length)
         the media streaming data, only for sink.
             Param data the data buffer pointer.
             Param length the data length.
struct bt_a2dp_connect_cb
     #include < a2dp.h > The connecting callback.
     Public Members
     void (*connected)(struct bt_a2dp *a2dp, int err)
         A a2dp connection has been established.
         This callback notifies the application of a a2dp connection. It means the AVDTP L2CAP connection.
         In case the err parameter is non-zero it means that the connection establishment failed.
             Param a2dp a2dp connection object.
             Param err error code.
     void (*disconnected)(struct bt_a2dp *a2dp)
         A a2dp connection has been disconnected.
         This callback notifies the application that a a2dp connection has been disconnected.
             Param a2dp a2dp connection object.
struct bt_a2dp_endpoint
```

#include <a2dp.h> Stream End Point.

```
uint8_t codec_id

Code ID

struct bt_avdtp_seid_lsep info

Stream End Point Information

struct bt_a2dp_codec_ie *config

Pointer to codec default config

struct bt_a2dp_codec_ie *capabilities

Capabilities

struct bt_a2dp_control_cb control_cbs

endpoint control callbacks

uint8_t *codec_buffer

reserved codec related buffer (can be cacaheable ram)

uint8_t *codec_buffer_nocached

reserved codec related buffer (nocached)
```

1.12 Serial Port Profile (SPP)

1.12.1 API Reference

```
Serial Port Profile (SPP) .

Typedefs

typedef enum bt_spp_role bt_spp_role_t
    SPP Role Value.

typedef struct _bt_spp_callback bt_spp_callback
    spp application callback function
    (defined(CONFIG_BT_SPP_ENABLE_CONTROL_CMD) && (CONFIG_BT_SPP_ENABLE_CONTROL_CMD > 0))

typedef int (*bt_spp_discover_callback)(struct bt_conn *conn, uint8_t count, uint16_t *channel)
    spp sdp discover callback function
```

Enums

```
enum bt_spp_role
SPP Role Value.

Values:

enumerator BT_SPP_ROLE_SERVER

enumerator BT_SPP_ROLE_CLIENT
```

Functions

```
int bt_spp_server_register(uint8_t channel, bt_spp_callback *cb)
```

Register a SPP server.

Register a SPP server channel, wait for spp connection from SPP client. Once it's connected by spp client, will notify application by calling cb->connected.

Parameters

- **channel** Registered server channel.
- **cb** Application callback.

Returns 0 in case of success or negative value in case of error.

```
int bt_spp_discover(struct bt_conn *conn, discover_cb_t *cb)
```

Discover SPP server channel.

Discover peer SPP server channel after basic BR connection is created. Will notify application discover results by calling cb->cb.

Parameters

- conn BR connection handle.
- **cb** Discover callback.

Returns 0 in case of success or negative value in case of error.

Connect SPP server channel.

Create SPP connection with remote SPP server channel. Once connection is created successfully, will notify application by calling cb->connected.

Parameters

- conn Conn handle created with remote device.
- **channel** Remote server channel to be connected, if it's 0, will connect remote BT_RFCOMM_CHAN_SPP channel.
- cb Application callback.
- spp SPP handle.

Returns 0 in case of success or negative value in case of error.

int **bt_spp_data_send**(struct bt_spp *spp, uint8_t *data, uint16_t len)

Send data to peer SPP device.

Send data to connected peer spp. Once data is sent, will notify application by calling cb->data_sent, which is provided by bt_spp_server_register or bt_spp_client_connect. If peer spp receives data, will notify application by calling cb->data_received.

Parameters

- spp SPP handle.
- data Data buffer.
- len Data length.

Returns 0 in case of success or negative value in case of error.

int bt_spp_disconnect(struct bt_spp *spp)

Disconnect SPP connection.

Disconnect SPP connection. Once connection is disconnected, will notify application by calling cb->disconnected, which is provided by bt_spp_server_register or bt_spp_client_connect.

Parameters

• spp – SPP handle.

Returns 0 in case of success or negative value in case of error.

int bt_spp_get_channel(struct bt_spp *spp, uint8_t *channel)

Get channel of SPP handle.

Parameters

- spp SPP handle.
- **channel** Pointer to channel of spp handle.

Returns 0 in case of success or negative value in case of error.

int **bt_spp_get_role**(struct bt_spp *spp, bt_spp_role_t *role)

Get role of SPP handle.

Parameters

- **spp** SPP handle.
- role Pointer to role of spp handle.

Returns 0 in case of success or negative value in case of error.

int bt_spp_get_conn(struct bt_spp *spp, struct bt_conn **conn)

Get conn handle of SPP handle.

Parameters

- spp SPP handle.
- conn Pointer to conn handle of spp handle.

Returns 0 in case of success or negative value in case of error.

struct _bt_spp_callback

#include <spp.h> spp application callback function

(defined(CONFIG_BT_SPP_ENABLE_CONTROL_CMD)
FIG_BT_SPP_ENABLE_CONTROL_CMD > 0))

&& (CON-

struct discover_cb_t

#include <spp.h> bt_spp_discover callback parameter

1.13 Audio/Video Remote Control Profile (AVRCP)

1.13.1 API Reference

group bt_avrcp

Audio/Video Remote Control Profile (AVRCP).

Defines

BT_AVRCP_COVER_ART_PSM

AVRCP cover art PSM

BT_AVRCP_SUBUNIT_TYPE_UNIT

AVRCP SubUnit Types

BT_AVRCP_SUBUNIT_TYPE_PANEL

BT_AVRCP_OPCODE_UNIT_INFO

AVRCP Command Opcode Types

BT_AVRCP_OPCODE_SUBUNIT_INFO

BT_AVRCP_OPCODE_PASS_THROUGH

BT_AVRCP_OPCODE_VENDOR_DEPENDENT

BT_AVRCP_OP_ID_SELECT

AVRCP operation ID PASS THROUGH

BT_AVRCP_OP_ID_UP

BT_AVRCP_OP_ID_DOWN

BT_AVRCP_OP_ID_LEFT

BT_AVRCP_OP_ID_RIGHT

BT_AVRCP_OP_ID_RIGHT_UP

BT_AVRCP_OP_ID_RIGHT_DOWN

BT_AVRCP_OP_ID_LEFT_UP

BT_AVRCP_OP_ID_LEFT_DOWN

BT_AVRCP_OP_ID_ROOT_MENU

BT_AVRCP_OP_ID_SETUP_MENU

BT_AVRCP_OP_ID_CONTENTS_MENU

BT_AVRCP_OP_ID_FAVORITE_MENU

BT_AVRCP_OP_ID_EXIT

BT_AVRCP_OP_ID_0

BT_AVRCP_OP_ID_1

BT_AVRCP_OP_ID_2

BT_AVRCP_OP_ID_3

BT_AVRCP_OP_ID_4

BT_AVRCP_OP_ID_5

BT_AVRCP_OP_ID_6

BT_AVRCP_OP_ID_7

BT_AVRCP_OP_ID_8

BT_AVRCP_OP_ID_9

BT_AVRCP_OP_ID_DOT

BT_AVRCP_OP_ID_ENTER

BT_AVRCP_OP_ID_CLEAR

BT_AVRCP_OP_ID_CHANNEL_UP

BT_AVRCP_OP_ID_CHANNEL_DOWN

BT_AVRCP_OP_ID_PREVIOUS_CHANNEL

BT_AVRCP_OP_ID_SOUND_SELECT

BT_AVRCP_OP_ID_INPUT_SELECT

BT_AVRCP_OP_ID_DISPLAY_INFORMATION

BT_AVRCP_OP_ID_HELP

BT_AVRCP_OP_ID_PAGE_UP

BT_AVRCP_OP_ID_PAGE_DOWN

BT_AVRCP_OP_ID_POWER

BT_AVRCP_OP_ID_VOLUME_UP

BT_AVRCP_OP_ID_VOLUME_DOWN

BT_AVRCP_OP_ID_MUTE

BT_AVRCP_OP_ID_PLAY

BT_AVRCP_OP_ID_STOP

 ${\tt BT_AVRCP_OP_ID_PAUSE}$

BT_AVRCP_OP_ID_RECORD

BT_AVRCP_OP_ID_REWIND

BT_AVRCP_OP_ID_FAST_FORWARD

BT_AVRCP_OP_ID_EJECT

BT_AVRCP_OP_ID_FORWARD

BT_AVRCP_OP_ID_BACKWARD

BT_AVRCP_OP_ID_ANGLE

BT_AVRCP_OP_ID_SUBPICTURE

BT_AVRCP_OP_ID_F1

BT_AVRCP_OP_ID_F2

BT_AVRCP_OP_ID_F3

BT_AVRCP_OP_ID_F4

BT_AVRCP_OP_ID_F5

BT_AVRCP_OP_ID_VENDOR_UNIQUE

BT_AVRCP_PDU_ID_GET_CAPABILITY

VENDOR DEPENDENT Transfer PDU ID

BT_AVRCP_PDU_ID_LIST_PLAYER_APP_SETTING_ATTR

BT_AVRCP_PDU_ID_LIST_PLAYER_APP_SETTING_VAL

BT_AVRCP_PDU_ID_GET_CUR_PLAYER_APP_SETTING_VAL

BT_AVRCP_PDU_ID_SET_PLAYER_APP_SETTING_VAL

BT_AVRCP_PDU_ID_GET_PLAYER_APP_SETTING_ATTR_TXT

BT_AVRCP_PDU_ID_GET_PLAYER_APP_SETTING_VAL_TXT

BT_AVRCP_PDU_ID_INFORM_DISPLAYABLE_CHAR_SET

BT_AVRCP_PDU_ID_INFORM_BATTERY_STATUS

BT_AVRCP_PDU_ID_GET_ELEMENT_ATTRIBUTE

BT_AVRCP_PDU_ID_GET_PLAY_STATUS

BT_AVRCP_PDU_ID_REGISTER_NOTIFICATION

BT_AVRCP_PDU_ID_REQUEST_CONTINUING_RESPONSE

BT_AVRCP_PDU_ID_ABORT_CONTINUING_RESPONSE

BT_AVRCP_PDU_ID_SET_ABSOLUTE_VOLUME

BT_AVRCP_PDU_ID_SET_ADDRESSED_PLAYER

BT_AVRCP_PDU_ID_SET_BROWSED_PLAYER

BT_AVRCP_PDU_ID_GET_FOLDER_ITEMS

BT_AVRCP_PDU_ID_CHANGE_PATH

BT_AVRCP_PDU_ID_GET_ITEM_ATTRIBUTES

BT_AVRCP_PDU_ID_PLAY_ITEMS

BT_AVRCP_PDU_ID_SEARCH

BT_AVRCP_PDU_ID_ADD_TO_NOW_PLAYING

BT_AVRCP_PDU_ID_GENERAL_REJECT

BT_AVRCP_PDU_ID_GET_TOTAL_NUM_ITEMS

BT_AVRCP_CAP_ID_COMPANY_ID AVRCP Capability.

 ${\tt BT_AVRCP_CAP_ID_EVENTS_SUPPORTED}$

BT_AVRCP_RESPONSE_TYPE_NOT_IMPLEMENTED
AVRCP Message Response Types.

BT_AVRCP_RESPONSE_TYPE_ACCEPTED

BT_AVRCP_RESPONSE_TYPE_REJECTED

BT_AVRCP_RESPONSE_TYPE_INTERIM

BT_AVRCP_RESPONSE_TYPE_STABLE

BT_AVRCP_RESPONSE_TYPE_CHANGED

BT_AVRCP_PACKET_TYPE_SINGLE AVRCP PDU Packet Type.

BT_AVRCP_PACKET_TYPE_START

BT_AVRCP_PACKET_TYPE_CONTINUE

BT_AVRCP_PACKET_TYPE_END

BT_AVRCP_EVENT_PLAYBACK_STATUS_CHANGED AVRCP Events.

BT_AVRCP_EVENT_TRACK_CHANGED

BT_AVRCP_EVENT_TRACK_REACHED_END

BT_AVRCP_EVENT_TRACK_REACHED_START

BT_AVRCP_EVENT_PLAYBACK_POS_CHANGED

BT_AVRCP_EVENT_BATT_STATUS_CHANGED

BT_AVRCP_EVENT_SYSTEM_STATUS_CHANGED

BT_AVRCP_EVENT_PLAYER_APP_SETTING_CHANGED

BT_AVRCP_EVENT_NOW_PLAYING_CONTENT_CHANGED

BT_AVRCP_EVENT_AVAILABLE_PLAYER_CHANGED

BT_AVRCP_EVENT_ADDRESSED_PLAYER_CHANGED

BT_AVRCP_EVENT_UIDS_CHANGED

BT_AVRCP_EVENT_VOLUME_CHANGED

BT_AVRCP_PLAYER_APP_ATTR_ID_EQUALIZER

AVRCP Player Application Setting Attribute ID.

BT_AVRCP_PLAYER_APP_ATTR_ID_REPEAT

BT_AVRCP_PLAYER_APP_ATTR_ID_SHUFFLE

BT_AVRCP_PLAYER_APP_ATTR_ID_SCAN

BT_AVRCP_MEDIA_ATTR_ID_MEDIA_TITLE

AVRCP Metadata Attribute ID.

BT_AVRCP_MEDIA_ATTR_ID_ARTIST_NAME

BT_AVRCP_MEDIA_ATTR_ID_ALBUM_NAME

BT_AVRCP_MEDIA_ATTR_ID_MEDIA_NUMBER

BT_AVRCP_MEDIA_ATTR_ID_TOTAL_MEDIA_NUMBER

BT_AVRCP_MEDIA_ATTR_ID_GENRE

BT_AVRCP_MEDIA_ATTR_ID_PLAYING_TIME

BT_AVRCP_MEDIA_ATTR_ID_DEFAULT_COVER_ART

BT_AVRCP_SYSTEM_STATUS_POWER_ON

AVRCP System Status Code.

BT_AVRCP_SYSTEM_STATUS_POWER_OFF

BT_AVRCP_SYSTEM_STATUS_UNPLUGED

BT_AVRCP_BATTERY_STATUS_NORMAL

AVRCP Battery Status Code.

BT_AVRCP_BATTERY_STATUS_WARNING

BT_AVRCP_BATTERY_STATUS_CRITICAL

BT_AVRCP_BATTERY_STATUS_EXTERNAL

BT_AVRCP_BATTERY_STATUS_FULL

BT_AVRCP_METADATA_ERROR_INVALID_COMMAND
AVRCP Error Status Code.

BT_AVRCP_METADATA_ERROR_INVALID_PARAMETER

BT_AVRCP_METADATA_ERROR_PARAMETER_NOT_FOUND

BT_AVRCP_METADATA_ERROR_INTERNAL

BT_AVRCP_METADATA_ERROR_OPERATION_SUCCESSFUL

BT_AVRCP_METADATA_ERROR_UID_CHANGED

BT_AVRCP_COMMAND_TYPE_CONTROL
AVRCP Message Command Types.

BT_AVRCP_COMMAND_TYPE_STATUS

BT_AVRCP_COMMAND_TYPE_NOTIFY

BT_AVRCP_SCOPE_MEDIA_PLAYER_LIST AVRCP Scopes.

BT_AVRCP_SCOPE_VIRTUAL_FILESYSTEM

BT_AVRCP_SCOPE_SEARCH

BT_AVRCP_SCOPE_NOW_PLAYING

BT_AVRCP_BOW_ERROR_INVALID_DIRECTION
AVRCP Browsing Error Status Code.

BT_AVRCP_BOW_ERROR_NOT_A_DIRECTORY

BT_AVRCP_BOW_ERROR_DOES_NOT_EXIST

BT_AVRCP_BOW_ERROR_INVALID_SCOPE

BT_AVRCP_BOW_ERROR_RANGE_OUT_OF_BOUNDS

BT_AVRCP_BOW_ERROR_DIRECTORY_NOT_HANDLED

BT_AVRCP_BOW_ERROR_MEDIA_IN_USE

BT_AVRCP_BOW_ERROR_NOW_PLAYING_LIST_FULL

BT_AVRCP_BOW_ERROR_SEARCH_NOT_SUPPORTED

BT_AVRCP_BOW_ERROR_SEARCH_IN_PROGRESS

BT_AVRCP_BOW_ERROR_INVALID_PLAYER_ID

BT_AVRCP_BOW_ERROR_PLAYER_NOT_BROWSABLE

BT_AVRCP_BOW_ERROR_PLAYER_NOT_ADDRESSED

BT_AVRCP_BOW_ERROR_NO_VALID_SEARCH_RESULTS

BT_AVRCP_BOW_ERROR_NO_AVAILABLE_PLAYERS

BT_AVRCP_BOW_ERROR_ADDR_PLAYER_CHANGED

BT_AVRCP_ITEM_TYPER_MEDIA_PLAYER
Browsable Item types

BT_AVRCP_ITEM_TYPER_FOLDER

BT_AVRCP_ITEM_TYPER_MEDIA

BT_AVRCP_CA_SUCCESS_RSP

AVRCP Cover Art OBEX Response Codes

BT_AVRCP_CA_CONTINUE_RSP

BT_AVRCP_CA_BAD_REQ_RSP

BT_AVRCP_CA_NOT_IMPLEMENTED_RSP

BT_AVRCP_CA_UNAUTH_RSP

BT_AVRCP_CA_PRECOND_FAILED_RSP

BT_AVRCP_CA_NOT_FOUND_RSP

```
BT_AVRCP_CA_NOT_ACCEPTABLE_RSP
```

BT_AVRCP_CA_NO_SERVICE_RSP

BT_AVRCP_CA_FORBIDDEN_RSP

BT_AVRCP_CA_SERVER_ERROR

Functions

int bt_avrcp_register_callback(struct bt avrcp cb *cb)

register callbacks to enable avrcp and monitor avrcp states.

Parameters

• **cb** – The callback structure.

Returns 0 in case of success and error code in case of error.

int bt_avrcp_control_connect(struct bt_conn *conn)

Create the AVRCP control 12cap connection.

The sender will be notified by the registered callback (control_connected).

Parameters

• **conn** – connection object.

Returns 0 in case of success and error code in case of error.

int bt_avrcp_control_disconnect(struct bt_conn *conn)

Release the AVRCP control 12cap connection.

The sender will be notified by the registered callback (control_disconnected).

Parameters

• **conn** – connection object.

Returns 0 in case of success and error code in case of error.

struct bt_avrcp_header

#include <avrcp.h> avrcp message header

Public Members

uint8 t ctype_response

profile identifier (it is omitted) command type or response code

uint8_t subunit_id

subunit id

```
uint8_t subunit_type
         subunit type
    uint8_t op_code
         operation code
struct bt_avrcp_unit_info
    #include <avrcp.h> unit info
struct bt_avrcp_subunit_info
    #include <avrcp.h> subunit info
struct bt_avrcp_pass_through
    #include <avrcp.h> pass through message
     Public Members
    uint8_t op_id
         operation id
    uint8_t state_flag
         state flag
    uint8_t op_data_len
         operation data length
    uint8_t op_data[0]
         operation data
struct bt_avrcp_register_ntfy
    #include <avrcp.h> register notification
    Public Members
    uint8 t event_id
         event id
     uint32_t playback_interval
         Playback interval
struct bt_avrcp_player_app_setting_attr_ids
    #include <avrcp.h> player application setting attribute IDs
```

218

```
uint8_t num_of_attr
         number of attributes
    uint8_t attr_ids[0]
         attribute IDs
struct bt_avrcp_player_attr_value
    #include <avrcp.h> attribute value
struct bt_avrcp_player_app_attr_values
    #include <avrcp.h> player application values
     Public Members
     uint8_t num_of_attr
         number of attributes
     struct bt_avrcp_player_attr_value attr_vals[0]
         attribute value
struct bt_avrcp_get_player_app_setting_value_text
     #include <avrcp.h> get player application setting values text
     Public Members
    uint8_t num_of_value
         number of attributes
    uint8_t value_ids[0]
         attribute IDs
struct bt_avrcp_inform_displayable_char_set
     #include <avrcp.h> inform displayable character set
struct bt_avrcp_get_element_attrs
    #include <avrcp.h> get element attributes
```

```
uint8_t identifier[8]
PLAYING (0x0)

struct bt_avrcp_add_to_now_playing
#include <avrcp.h> AddToNowPlaying.

struct bt_avrcp_play_item
#include <avrcp.h> PlayItem.

struct bt_avrcp_company_id
#include <avrcp.h> company id

Public Members

uint8_t company_id0
    company id

struct bt_avrcp_capability_company_id
#include <avrcp.h> capability id

Public Members
```

```
uint8_t capability_id
    capability id

uint8_t capability_count
    capability count

struct bt_avrcp_company_id company_ids[0]
    capability IDs
```

struct bt_avrcp_capability_events_supported

#include <avrcp.h> capability event supports

```
uint8_t capability_id
         capability id
     uint8_t capability_count
         capability count
     uint8_t event_ids[0]
         events supported
struct bt_avrcp_player_app_setting_values
     #include <avrcp.h> player application setting attribute IDs
     Public Members
     uint8_t num_of_value
         number of attributes
     uint8_t value_ids[0]
         attribute IDs
struct bt_avrcp_player_attr_value_text
     #include <avrcp.h> attribute/value text
struct bt_avrcp_player_get_txt_rsp
     #include <avrcp.h> get text response
struct bt_avrcp_element_attr
     #include <avrcp.h> element attribute
struct bt_avrcp_player_get_element_attr_rsp
     #include <avrcp.h> get element attribute response
struct bt_avrcp_play_status_rsp
     #include <avrcp.h> play status response
struct bt_avrcp_event_rsp
     #include <avrcp.h> event response data format
struct bt_avrcp_vendor
```

#include <avrcp.h> vendor dependent message

```
uint8_t company_id0
         company id
    uint8_t pdu_id
         pdu id
     uint8_t packet_type
         packet type
     uint8_t reserved
         reserved
     uint16_t parameter_len
         parameter length
struct bt_avrcp_control_msg
    #include <avrcp.h> avrcp control message
struct bt_avrcp_browsing_header
     #include <avrcp.h> browsing message header
     Public Members
    uint8_t pdu_id
         profile identifier (it is omitted) pdu id
     uint16_t parameter_len
         parameter length
struct bt_avrcp_get_folder_items_cmd
    #include <avrcp.h> get folder items player list
     Public Members
    uint32_t attr_list[0]
         Appendix E in AVRCP spec every attribute id is 4 bytes.
struct bt_avrcp_set_browsed_player_cmd
    #include <avrcp.h> set browsed player
struct bt_avrcp_change_path_cmd
    #include <avrcp.h> change path
```

struct bt_avrcp_get_item_attrs_cmd

#include <avrcp.h> get item attributes

Public Members

uint32_t attr_list[0]

Appendix E in AVRCP spec every attribute id is 4 bytes.

struct bt_avrcp_search_cmd

#include <avrcp.h> search

struct bt_avrcp_get_total_num_of_items_cmd

#include <avrcp.h> get total number of items

struct bt_avrcp_browsing_cmd

#include <avrcp.h> avrcp browsing command

struct bt_avrcp_player_item

#include <avrcp.h> player item

struct bt_avrcp_folder_item

#include <avrcp.h> folder item

struct bt_avrcp_attr_val_entry

#include <avrcp.h> media item attribute

struct bt_avrcp_media_item

#include <avrcp.h> media item

struct bt_avrcp_item

#include <avrcp.h> avrcp item

struct bt_avrcp_get_folder_items_rsp

#include <avrcp.h> get folder items (response)

struct bt_avrcp_folder_name

#include <avrcp.h> get folder name (response)

struct bt_avrcp_set_browsed_player_rsp

#include <avrcp.h> set browsed player (response)

struct bt_avrcp_change_path_rsp

#include <avrcp.h> change path (response)

struct bt_avrcp_get_item_attrs_rsp

#include <avrcp.h> get item attributes (response)

Public Members

```
struct bt_avrcp_attr_val_entry attrs[0]
```

Appendix E in AVRCP spec every attribute id is 4 bytes.

struct bt_avrcp_search_rsp

#include <avrcp.h> search (response)

struct bt_avrcp_get_total_num_of_items_rsp

#include <avrcp.h> get total number of items (response)

struct bt_avrcp_browsing_rsp

#include <avrcp.h> browsing message (response)

struct bt_avrcp_cb

#include <avrcp.h> The connecting callback.

Public Members

```
void (*control_connected)(struct bt_conn *conn, int err)
```

avrcp control connection has been established.

This callback notifies the application of avrcp control connection.

Param conn connection object.

Param err error code.

void (*control_disconnected)(struct bt_conn *conn, int err)

avrcp control connection has been disconnected.

This callback notifies the application of avrcp control disconnection.

Param conn connection object.

void (*browsing_connected)(struct bt conn *conn, int err)

avrcp browsing connection has been established.

This callback notifies the application of avrcp browsing connection.

Param conn connection object.

Param err error code.

void (*browsing_disconnected)(struct bt_conn *conn, int err)

avrcp browsing connection has been disconnected.

This callback notifies the application of avrcp browsing disconnection.

Param conn connection object.

Param err error code.

```
void (*send_result)(struct bt_conn *conn, int err)
        avrcp send result callback.
        This callback notifies the application that a avrcp command send result.
            Param conn connection object.
            Param err error code.
union __unnamed6__
    Public Members
    struct bt_avrcp_header
    uint8_t tl_pt_cr_ipid
struct __unnamed8__
    Public Members
    uint8_t ipid
        IPID
    uint8_t cr
        command/response
    uint8_t packet_type
        packet type
    uint8_t t1
        transaction label
union __unnamed10__
    Public Members
    uint8 t play_status
        EVENT_PLAYBACK_STATUS_CHANGED
    uint8_t identifier[8]
        EVENT_TRACK_CHANGED
    uint32_t playback_pos
        EVENT_PLAYBACK_POS_CHANGED
```

```
uint8_t battery_status
        EVENT_BATT_STATUS_CHANGED
    uint8_t system_status
        EVENT_SYSTEM_STATUS_CHANGED
    struct bt avrcp event rsp setting_changed
        EVENT_PLAYER_APPLICATION_SETTING_CHANGED
    struct bt_avrcp_event_rsp addressed_player_changed
        EVENT_ADDRESSED_PLAYER_CHANGED
    uint16_t uid_counter
        EVENT UIDS CHANGED
    uint8 t absolute_volume
        EVENT_VOLUME_CHANGED
struct setting_changed
    EVENT_PLAYER_APPLICATION_SETTING_CHANGED
struct addressed_player_changed
    EVENT ADDRESSED PLAYER CHANGED
union __unnamed14__
    Public Members
    uint8_t parameter
        parameters
    struct bt_avrcp_player_app_setting_attr_ids player_attr_ids
    struct bt_avrcp_player_app_attr_values player_attr_values
    struct bt_avrcp_get_player_app_setting_value_text player_value_text
    struct bt_avrcp_inform_displayable_char_set inform_char_set
    struct bt_avrcp_get_element_attrs element_attrs
    struct bt_avrcp_play_item play_item
```

```
struct bt_avrcp_add_to_now_playing add_now_play
     struct bt_avrcp_register_ntfy register_notify
     struct bt_avrcp_capability_company_id comapny_id_rsp
     struct bt_avrcp_capability_events_supported events_suported_rsp
     struct bt_avrcp_player_app_setting_attr_ids attr_ids_rsp
     struct bt_avrcp_player_app_setting_values values_rsp
     struct bt_avrcp_player_app_attr_values attr_values_rsp
     struct bt_avrcp_player_get_txt_rsp get_txt_rsp
     struct bt_avrcp_player_get_element_attr_rsp element_attr_rsp
     struct bt_avrcp_play_status_rsp play_status_rsp
     struct bt_avrcp_event_rsp event_rsp
union __unnamed16__
     Public Members
     struct bt_avrcp_unit_info unit_info
     struct bt_avrcp_subunit_info subunit_info
     struct bt_avrcp_pass_through pass_th
     struct bt_avrcp_vendor vendor
union __unnamed18__
```

```
struct bt_avrcp_browsing_header
    uint8_t tl_pt_cr_ipid
struct __unnamed20__
    Public Members
    uint8_t ipid
        IPID
    uint8_t cr
        command/response
    uint8_t packet_type
        packet type
    uint8_t t1
        transaction label
union __unnamed22__
    Public Members
    struct bt_avrcp_get_folder_items_cmd folder_items
    struct bt_avrcp_set_browsed_player_cmd set_browsed_player
    struct bt_avrcp_change_path_cmd change_path
    struct bt_avrcp_get_item_attrs_cmd get_item_attrs
    struct bt_avrcp_search_cmd search
    struct bt_avrcp_get_total_num_of_items_cmd get_total_num_of_items
union __unnamed24__
```

```
struct bt_avrcp_player_item player_item

struct bt_avrcp_folder_item folder_item

struct bt_avrcp_media_item media_item

union __unnamed26__
```

Public Members

```
struct bt_avrcp_get_folder_items_rsp folder_items

struct bt_avrcp_set_browsed_player_rsp set_browsed_player

struct bt_avrcp_change_path_rsp change_path

struct bt_avrcp_get_item_attrs_rsp get_item_attrs

struct bt_avrcp_search_rsp search

struct bt_avrcp_get_total_num_of_items_rsp get_total_num_of_items
```

1.14 Universal Unique Identifiers (UUIDs)

1.14.1 API Reference

```
group bt_uuid
UUIDs .

Defines

BT_UUID_SIZE_16
Size in octets of a 16-bit UUID

BT_UUID_SIZE_32
Size in octets of a 32-bit UUID
```

BT_UUID_SIZE_128

Size in octets of a 128-bit UUID

BT_UUID_INIT_16(value)

Initialize a 16-bit UUID.

Parameters

• value – 16-bit UUID value in host endianness.

BT_UUID_INIT_32(value)

Initialize a 32-bit UUID.

Parameters

• value – 32-bit UUID value in host endianness.

BT_UUID_INIT_128(value...)

Initialize a 128-bit UUID.

Parameters

• **value** – 128-bit UUID array values in little-endian format. Can be combined with *BT_UUID_128_ENCODE* to initialize a UUID from the readable form of UUIDs.

BT_UUID_DECLARE_16(value)

Helper to declare a 16-bit UUID inline.

Parameters

• value – 16-bit UUID value in host endianness.

Returns Pointer to a generic UUID.

BT_UUID_DECLARE_32 (value)

Helper to declare a 32-bit UUID inline.

Parameters

• value – 32-bit UUID value in host endianness.

Returns Pointer to a generic UUID.

BT_UUID_DECLARE_128(value...)

Helper to declare a 128-bit UUID inline.

Parameters

• **value** – 128-bit UUID array values in little-endian format. Can be combined with *BT_UUID_128_ENCODE* to declare a UUID from the readable form of UUIDs.

Returns Pointer to a generic UUID.

BT_UUID_16(__u)

Helper macro to access the 16-bit UUID from a generic UUID.

BT_UUID_32(u)

Helper macro to access the 32-bit UUID from a generic UUID.

BT_UUID_128(__u)

Helper macro to access the 128-bit UUID from a generic UUID.

BT_UUID_128_ENCODE(w32, w1, w2, w3, w48)

Encode 128 bit UUID into array values in little-endian format.

Helper macro to initialize a 128-bit UUID array value from the readable form of UUIDs, or encode 128-bit UUID values into advertising data Can be combined with BT_UUID_DECLARE_128 to declare a 128-bit UUID.

Example of how to declare the UUID 6E400001-B5A3-F393-E0A9-E50E24DCCA9E

```
BT_UUID_DECLARE_128(
BT_UUID_128_ENCODE(0x6E400001, 0xB5A3, 0xF393, 0xE0A9, 0xE50E24DCCA9E))
```

Example of how to encode the UUID 6E400001-B5A3-F393-E0A9-E50E24DCCA9E into advertising data.

```
BT_DATA_BYTES(BT_DATA_UUID128_ALL,
BT_UUID_128_ENCODE(0x6E400001, 0xB5A3, 0xF393, 0xE0A9, 0xE50E24DCCA9E))
```

Just replace the hyphen by the comma and add 0x prefixes.

Parameters

- w32 First part of the UUID (32 bits)
- w1 Second part of the UUID (16 bits)
- w2 Third part of the UUID (16 bits)
- w3 Fourth part of the UUID (16 bits)
- w48 Fifth part of the UUID (48 bits)

Returns The comma separated values for UUID 128 initializer that may be used directly as an argument for BT_UUID_INIT_128 or BT_UUID_DECLARE_128

BT_UUID_16_ENCODE(w16)

Encode 16-bit UUID into array values in little-endian format.

Helper macro to encode 16-bit UUID values into advertising data.

Example of how to encode the UUID 0x180a into advertising data.

```
BT_DATA_BYTES(BT_DATA_UUID16_ALL, BT_UUID_16_ENCODE(0x180a))
```

Parameters

• **w16** – UUID value (16-bits)

Returns The comma separated values for UUID 16 value that may be used directly as an argument for *BT_DATA_BYTES*.

BT_UUID_32_ENCODE(w32)

Encode 32-bit UUID into array values in little-endian format.

Helper macro to encode 32-bit UUID values into advertising data.

Example of how to encode the UUID 0x180a01af into advertising data.

BT_DATA_BYTES(BT_DATA_UUID32_ALL, BT_UUID_32_ENCODE(0x180a01af))

Parameters

• **w32** – UUID value (32-bits)

Returns The comma separated values for UUID 32 value that may be used directly as an argument for *BT_DATA_BYTES*.

BT_UUID_STR_LEN

Recommended length of user string buffer for Bluetooth UUID.

The recommended length guarantee the output of UUID conversion will not lose valuable information about the UUID being processed. If the length of the UUID is known the string can be shorter.

BT_UUID_GAP_VAL

Generic Access UUID value.

BT_UUID_GAP

Generic Access.

BT_UUID_GATT_VAL

Generic attribute UUID value.

BT_UUID_GATT

Generic Attribute.

BT_UUID_IAS_VAL

Immediate Alert Service UUID value.

BT_UUID_IAS

Immediate Alert Service.

BT_UUID_LLS_VAL

Link Loss Service UUID value.

BT_UUID_LLS

Link Loss Service.

BT_UUID_TPS_VAL

Tx Power Service UUID value.

BT_UUID_TPS

Tx Power Service.

BT_UUID_CTS_VAL

Current Time Service UUID value.

BT_UUID_CTS

Current Time Service.

BT_UUID_RTUS_VAL

Reference Time Update Service UUID value.

BT_UUID_RTUS

Reference Time Update Service.

BT_UUID_NDSTS_VAL

Next DST Change Service UUID value.

BT_UUID_NDSTS

Next DST Change Service.

BT_UUID_GS_VAL

Glucose Service UUID value.

BT_UUID_GS

Glucose Service.

BT_UUID_HTS_VAL

Health Thermometer Service UUID value.

BT_UUID_HTS

Health Thermometer Service.

BT_UUID_DIS_VAL

Device Information Service UUID value.

BT_UUID_DIS

Device Information Service.

BT_UUID_NAS_VAL

Network Availability Service UUID value.

BT_UUID_NAS

Network Availability Service.

BT_UUID_WDS_VAL

Watchdog Service UUID value.

BT_UUID_WDS

Watchdog Service.

BT_UUID_HRS_VAL

Heart Rate Service UUID value.

BT_UUID_HRS

Heart Rate Service.

BT_UUID_PAS_VAL

Phone Alert Service UUID value.

BT_UUID_PAS

Phone Alert Service.

BT_UUID_BAS_VAL

Battery Service UUID value.

BT_UUID_BAS

Battery Service.

BT_UUID_BPS_VAL

Blood Pressure Service UUID value.

BT_UUID_BPS

Blood Pressure Service.

BT_UUID_ANS_VAL

Alert Notification Service UUID value.

BT_UUID_ANS

Alert Notification Service.

BT_UUID_HIDS_VAL

HID Service UUID value.

BT_UUID_HIDS

HID Service.

BT_UUID_SPS_VAL

Scan Parameters Service UUID value.

BT_UUID_SPS

Scan Parameters Service.

BT_UUID_RSCS_VAL

Running Speed and Cadence Service UUID value.

BT_UUID_RSCS

Running Speed and Cadence Service.

BT_UUID_AIOS_VAL

Automation IO Service UUID value.

BT_UUID_AIOS

Automation IO Service.

BT_UUID_CSC_VAL

Cycling Speed and Cadence Service UUID value.

BT_UUID_CSC

Cycling Speed and Cadence Service.

BT_UUID_CPS_VAL

Cyclicg Power Service UUID value.

BT_UUID_CPS

Cycling Power Service.

BT_UUID_LNS_VAL

Location and Navigation Service UUID value.

BT_UUID_LNS

Location and Navigation Service.

BT_UUID_ESS_VAL

Environmental Sensing Service UUID value.

BT_UUID_ESS

Environmental Sensing Service.

BT_UUID_BCS_VAL

Body Composition Service UUID value.

BT_UUID_BCS

Body Composition Service.

BT_UUID_UDS_VAL

User Data Service UUID value.

BT_UUID_UDS

User Data Service.

BT_UUID_WSS_VAL

Weight Scale Service UUID value.

BT_UUID_WSS

Weight Scale Service.

BT_UUID_BMS_VAL

Bond Management Service UUID value.

BT_UUID_BMS

Bond Management Service.

BT_UUID_CGMS_VAL

Continuous Glucose Monitoring Service UUID value.

BT_UUID_CGMS

Continuous Glucose Monitoring Service.

BT_UUID_IPSS_VAL

IP Support Service UUID value.

BT_UUID_IPSS

IP Support Service.

BT_UUID_IPS_VAL

Indoor Positioning Service UUID value.

BT_UUID_IPS

Indoor Positioning Service.

BT_UUID_POS_VAL

Pulse Oximeter Service UUID value.

BT_UUID_POS

Pulse Oximeter Service.

BT_UUID_HPS_VAL

HTTP Proxy Service UUID value.

BT_UUID_HPS

HTTP Proxy Service.

BT_UUID_TDS_VAL

Transport Discovery Service UUID value.

BT_UUID_TDS

Transport Discovery Service.

BT_UUID_OTS_VAL

Object Transfer Service UUID value.

BT_UUID_OTS

Object Transfer Service.

BT_UUID_FMS_VAL

Fitness Machine Service UUID value.

BT_UUID_FMS

Fitness Machine Service.

BT_UUID_MESH_PROV_VAL

Mesh Provisioning Service UUID value.

BT_UUID_MESH_PROV

Mesh Provisioning Service.

BT_UUID_MESH_PROXY_VAL

Mesh Proxy Service UUID value.

BT_UUID_MESH_PROXY

Mesh Proxy Service.

BT_UUID_MESH_PROXY_SOLICITATION_VAL

Proxy Solicitation UUID value.

BT_UUID_RCSRV_VAL

Reconnection Configuration Service UUID value.

BT_UUID_RCSRV

Reconnection Configuration Service.

BT_UUID_IDS_VAL

Insulin Delivery Service UUID value.

BT_UUID_IDS

Insulin Delivery Service.

BT_UUID_BSS_VAL

Binary Sensor Service UUID value.

BT_UUID_BSS

Binary Sensor Service.

BT_UUID_ECS_VAL

Emergency Configuration Service UUID value.

BT_UUID_ECS

Energency Configuration Service.

BT_UUID_ACLS_VAL

Authorization Control Service UUID value.

BT_UUID_ACLS

Authorization Control Service.

BT_UUID_PAMS_VAL

Physical Activity Monitor Service UUID value.

BT_UUID_PAMS

Physical Activity Monitor Service.

BT_UUID_AICS_VAL

Audio Input Control Service UUID value.

BT_UUID_AICS

Audio Input Control Service.

BT_UUID_VCS_VAL

Volume Control Service UUID value.

BT_UUID_VCS

Volume Control Service.

BT_UUID_VOCS_VAL

Volume Offset Control Service UUID value.

BT_UUID_VOCS

Volume Offset Control Service.

BT_UUID_CSIS_VAL

Coordinated Set Identification Service UUID value.

BT_UUID_CSIS

Coordinated Set Identification Service.

BT_UUID_DTS_VAL

Device Time Service UUID value.

BT_UUID_DTS

Device Time Service.

BT_UUID_MCS_VAL

Media Control Service UUID value.

BT_UUID_MCS

Media Control Service.

BT_UUID_GMCS_VAL

Generic Media Control Service UUID value.

BT_UUID_GMCS

Generic Media Control Service.

BT_UUID_CTES_VAL

Constant Tone Extension Service UUID value.

BT_UUID_CTES

Constant Tone Extension Service.

BT_UUID_TBS_VAL

Telephone Bearer Service UUID value.

BT_UUID_TBS

Telephone Bearer Service.

BT_UUID_GTBS_VAL

Generic Telephone Bearer Service UUID value.

BT_UUID_GTBS

Generic Telephone Bearer Service.

BT_UUID_MICS_VAL

Microphone Control Service UUID value.

BT_UUID_MICS

Microphone Control Service.

BT_UUID_ASCS_VAL

Audio Stream Control Service UUID value.

BT_UUID_ASCS

Audio Stream Control Service.

BT_UUID_BASS_VAL

Broadcast Audio Scan Service UUID value.

BT_UUID_BASS

Broadcast Audio Scan Service.

BT_UUID_PACS_VAL

Published Audio Capabilities Service UUID value.

BT_UUID_PACS

Published Audio Capabilities Service.

BT_UUID_BASIC_AUDIO_VAL

Basic Audio Announcement Service UUID value.

BT_UUID_BASIC_AUDIO

Basic Audio Announcement Service.

BT_UUID_BROADCAST_AUDIO_VAL

Broadcast Audio Announcement Service UUID value.

BT_UUID_BROADCAST_AUDIO

Broadcast Audio Announcement Service.

BT_UUID_CAS_VAL

Common Audio Service UUID value.

BT_UUID_CAS

Common Audio Service.

BT_UUID_HAS_VAL

Hearing Access Service UUID value.

BT_UUID_HAS

Hearing Access Service.

BT_UUID_TMAS_VAL

Telephony and Media Audio Service UUID value.

BT_UUID_TMAS

Telephony and Media Audio Service.

BT_UUID_PBA_VAL

Public Broadcast Announcement Service UUID value.

BT_UUID_PBA

Public Broadcast Announcement Service.

BT_UUID_GATT_PRIMARY_VAL

GATT Primary Service UUID value.

BT_UUID_GATT_PRIMARY

GATT Primary Service.

BT_UUID_GATT_SECONDARY_VAL

GATT Secondary Service UUID value.

BT_UUID_GATT_SECONDARY

GATT Secondary Service.

BT_UUID_GATT_INCLUDE_VAL

GATT Include Service UUID value.

BT_UUID_GATT_INCLUDE

GATT Include Service.

BT_UUID_GATT_CHRC_VAL

GATT Characteristic UUID value.

BT_UUID_GATT_CHRC

GATT Characteristic.

BT_UUID_GATT_CEP_VAL

GATT Characteristic Extended Properties UUID value.

BT_UUID_GATT_CEP

GATT Characteristic Extended Properties.

BT_UUID_GATT_CUD_VAL

GATT Characteristic User Description UUID value.

BT_UUID_GATT_CUD

GATT Characteristic User Description.

BT_UUID_GATT_CCC_VAL

GATT Client Characteristic Configuration UUID value.

BT_UUID_GATT_CCC

GATT Client Characteristic Configuration.

BT_UUID_GATT_SCC_VAL

GATT Server Characteristic Configuration UUID value.

BT_UUID_GATT_SCC

GATT Server Characteristic Configuration.

BT_UUID_GATT_CPF_VAL

GATT Characteristic Presentation Format UUID value.

BT_UUID_GATT_CPF

GATT Characteristic Presentation Format.

BT_UUID_GATT_CAF_VAL

GATT Characteristic Aggregated Format UUID value.

BT_UUID_GATT_CAF

GATT Characteristic Aggregated Format.

BT_UUID_VALID_RANGE_VAL

Valid Range Descriptor UUID value.

BT_UUID_VALID_RANGE

Valid Range Descriptor.

BT_UUID_HIDS_EXT_REPORT_VAL

HID External Report Descriptor UUID value.

BT_UUID_HIDS_EXT_REPORT

HID External Report Descriptor.

BT_UUID_HIDS_REPORT_REF_VAL

HID Report Reference Descriptor UUID value.

BT_UUID_HIDS_REPORT_REF

HID Report Reference Descriptor.

BT_UUID_VAL_TRIGGER_SETTING_VAL

Value Trigger Setting Descriptor UUID value.

BT_UUID_VAL_TRIGGER_SETTING

Value Trigger Setting Descriptor.

BT_UUID_ES_CONFIGURATION_VAL

Environmental Sensing Configuration Descriptor UUID value.

BT_UUID_ES_CONFIGURATION

Environmental Sensing Configuration Descriptor.

BT_UUID_ES_MEASUREMENT_VAL

Environmental Sensing Measurement Descriptor UUID value.

BT_UUID_ES_MEASUREMENT

Environmental Sensing Measurement Descriptor.

BT_UUID_ES_TRIGGER_SETTING_VAL

Environmental Sensing Trigger Setting Descriptor UUID value.

BT_UUID_ES_TRIGGER_SETTING

Environmental Sensing Trigger Setting Descriptor.

BT_UUID_TM_TRIGGER_SETTING_VAL

Time Trigger Setting Descriptor UUID value.

BT_UUID_TM_TRIGGER_SETTING

Time Trigger Setting Descriptor.

BT_UUID_GAP_DEVICE_NAME_VAL

GAP Characteristic Device Name UUID value.

BT_UUID_GAP_DEVICE_NAME

GAP Characteristic Device Name.

BT_UUID_GAP_APPEARANCE_VAL

GAP Characteristic Appearance UUID value.

BT_UUID_GAP_APPEARANCE

GAP Characteristic Appearance.

BT_UUID_GAP_PPF_VAL

GAP Characteristic Peripheal Privacy Flag UUID value.

BT_UUID_GAP_PPF

GAP Characteristic Peripheal Privacy Flag.

BT_UUID_GAP_RA_VAL

GAP Characteristic Reconnection Address UUID value.

BT_UUID_GAP_RA

GAP Characteristic Reconnection Address.

BT_UUID_GAP_PPCP_VAL

GAP Characteristic Peripheral Preferred Connection Parameters UUID value.

BT_UUID_GAP_PPCP

GAP Characteristic Peripheral Preferred Connection Parameters.

BT_UUID_GATT_SC_VAL

GATT Characteristic Service Changed UUID value.

BT_UUID_GATT_SC

GATT Characteristic Service Changed.

BT_UUID_ALERT_LEVEL_VAL

GATT Characteristic Alert Level UUID value.

BT_UUID_ALERT_LEVEL

GATT Characteristic Alert Level.

BT_UUID_TPS_TX_POWER_LEVEL_VAL

TPS Characteristic Tx Power Level UUID value.

BT_UUID_TPS_TX_POWER_LEVEL

TPS Characteristic Tx Power Level.

BT_UUID_GATT_DT_VAL

GATT Characteristic Date Time UUID value.

BT_UUID_GATT_DT

GATT Characteristic Date Time.

BT_UUID_GATT_DW_VAL

GATT Characteristic Day of Week UUID value.

BT_UUID_GATT_DW

GATT Characteristic Day of Week.

BT_UUID_GATT_DDT_VAL

GATT Characteristic Day Date Time UUID value.

BT_UUID_GATT_DDT

GATT Characteristic Day Date Time.

BT_UUID_GATT_ET256_VAL

GATT Characteristic Exact Time 256 UUID value.

BT_UUID_GATT_ET256

GATT Characteristic Exact Time 256.

BT_UUID_GATT_DST_VAL

GATT Characteristic DST Offset UUID value.

BT_UUID_GATT_DST

GATT Characteristic DST Offset.

BT_UUID_GATT_TZ_VAL

GATT Characteristic Time Zone UUID value.

BT_UUID_GATT_TZ

GATT Characteristic Time Zone.

BT_UUID_GATT_LTI_VAL

GATT Characteristic Local Time Information UUID value.

BT_UUID_GATT_LTI

GATT Characteristic Local Time Information.

BT_UUID_GATT_TDST_VAL

GATT Characteristic Time with DST UUID value.

BT_UUID_GATT_TDST

GATT Characteristic Time with DST.

BT_UUID_GATT_TA_VAL

GATT Characteristic Time Accuracy UUID value.

BT_UUID_GATT_TA

GATT Characteristic Time Accuracy.

BT_UUID_GATT_TS_VAL

GATT Characteristic Time Source UUID value.

BT_UUID_GATT_TS

GATT Characteristic Time Source.

BT_UUID_GATT_RTI_VAL

GATT Characteristic Reference Time Information UUID value.

BT_UUID_GATT_RTI

GATT Characteristic Reference Time Information.

BT_UUID_GATT_TUCP_VAL

GATT Characteristic Time Update Control Point UUID value.

BT_UUID_GATT_TUCP

GATT Characteristic Time Update Control Point.

BT_UUID_GATT_TUS_VAL

GATT Characteristic Time Update State UUID value.

BT_UUID_GATT_TUS

GATT Characteristic Time Update State.

BT_UUID_GATT_GM_VAL

GATT Characteristic Glucose Measurement UUID value.

BT_UUID_GATT_GM

GATT Characteristic Glucose Measurement.

BT_UUID_BAS_BATTERY_LEVEL_VAL

BAS Characteristic Battery Level UUID value.

BT_UUID_BAS_BATTERY_LEVEL

BAS Characteristic Battery Level.

BT_UUID_BAS_BATTERY_POWER_STATE_VAL

BAS Characteristic Battery Power State UUID value.

BT_UUID_BAS_BATTERY_POWER_STATE

BAS Characteristic Battery Power State.

BT_UUID_BAS_BATTERY_LEVEL_STATE_VAL

BAS Characteristic Battery Level StateUUID value.

BT_UUID_BAS_BATTERY_LEVEL_STATE

BAS Characteristic Battery Level State.

BT_UUID_HTS_MEASUREMENT_VAL

HTS Characteristic Temperature Measurement UUID value.

BT_UUID_HTS_MEASUREMENT

HTS Characteristic Temperature Measurement Value.

BT_UUID_HTS_TEMP_TYP_VAL

HTS Characteristic Temperature Type UUID value.

BT_UUID_HTS_TEMP_TYP

HTS Characteristic Temperature Type.

BT_UUID_HTS_TEMP_INT_VAL

HTS Characteristic Intermediate Temperature UUID value.

BT_UUID_HTS_TEMP_INT

HTS Characteristic Intermediate Temperature.

BT_UUID_HTS_TEMP_C_VAL

HTS Characteristic Temperature Celsius UUID value.

BT_UUID_HTS_TEMP_C

HTS Characteristic Temperature Celsius.

BT_UUID_HTS_TEMP_F_VAL

HTS Characteristic Temperature Fahrenheit UUID value.

BT_UUID_HTS_TEMP_F

HTS Characteristic Temperature Fahrenheit.

BT_UUID_HTS_INTERVAL_VAL

HTS Characteristic Measurement Interval UUID value.

BT_UUID_HTS_INTERVAL

HTS Characteristic Measurement Interval.

BT_UUID_HIDS_BOOT_KB_IN_REPORT_VAL

HID Characteristic Boot Keyboard Input Report UUID value.

BT_UUID_HIDS_BOOT_KB_IN_REPORT

HID Characteristic Boot Keyboard Input Report.

BT_UUID_DIS_SYSTEM_ID_VAL

DIS Characteristic System ID UUID value.

BT_UUID_DIS_SYSTEM_ID

DIS Characteristic System ID.

BT_UUID_DIS_MODEL_NUMBER_VAL

DIS Characteristic Model Number String UUID value.

BT_UUID_DIS_MODEL_NUMBER

DIS Characteristic Model Number String.

BT_UUID_DIS_SERIAL_NUMBER_VAL

DIS Characteristic Serial Number String UUID value.

BT_UUID_DIS_SERIAL_NUMBER

DIS Characteristic Serial Number String.

BT_UUID_DIS_FIRMWARE_REVISION_VAL

DIS Characteristic Firmware Revision String UUID value.

BT_UUID_DIS_FIRMWARE_REVISION

DIS Characteristic Firmware Revision String.

BT_UUID_DIS_HARDWARE_REVISION_VAL

DIS Characteristic Hardware Revision String UUID value.

BT_UUID_DIS_HARDWARE_REVISION

DIS Characteristic Hardware Revision String.

BT_UUID_DIS_SOFTWARE_REVISION_VAL

DIS Characteristic Software Revision String UUID value.

BT_UUID_DIS_SOFTWARE_REVISION

DIS Characteristic Software Revision String.

BT_UUID_DIS_MANUFACTURER_NAME_VAL

DIS Characteristic Manufacturer Name String UUID Value.

BT_UUID_DIS_MANUFACTURER_NAME

DIS Characteristic Manufacturer Name String.

BT_UUID_GATT_IEEE_RCDL_VAL

GATT Characteristic IEEE Regulatory Certification Data List UUID Value.

BT_UUID_GATT_IEEE_RCDL

GATT Characteristic IEEE Regulatory Certification Data List.

BT_UUID_CTS_CURRENT_TIME_VAL

CTS Characteristic Current Time UUID value.

BT_UUID_CTS_CURRENT_TIME

CTS Characteristic Current Time.

BT_UUID_MAGN_DECLINATION_VAL

Magnetic Declination Characteristic UUID value.

BT_UUID_MAGN_DECLINATION

Magnetic Declination Characteristic.

BT_UUID_GATT_LLAT_VAL

GATT Characteristic Legacy Latitude UUID Value.

BT_UUID_GATT_LLAT

GATT Characteristic Legacy Latitude.

BT_UUID_GATT_LLON_VAL

GATT Characteristic Legacy Longitude UUID Value.

BT_UUID_GATT_LLON

GATT Characteristic Legacy Longitude.

BT_UUID_GATT_POS_2D_VAL

GATT Characteristic Position 2D UUID Value.

BT_UUID_GATT_POS_2D

GATT Characteristic Position 2D.

BT_UUID_GATT_POS_3D_VAL

GATT Characteristic Position 3D UUID Value.

BT_UUID_GATT_POS_3D

GATT Characteristic Position 3D.

BT_UUID_GATT_SR_VAL

GATT Characteristic Scan Refresh UUID Value.

BT_UUID_GATT_SR

GATT Characteristic Scan Refresh.

BT_UUID_HIDS_BOOT_KB_OUT_REPORT_VAL

HID Boot Keyboard Output Report Characteristic UUID value.

BT_UUID_HIDS_BOOT_KB_OUT_REPORT

HID Boot Keyboard Output Report Characteristic.

BT_UUID_HIDS_BOOT_MOUSE_IN_REPORT_VAL

HID Boot Mouse Input Report Characteristic UUID value.

BT_UUID_HIDS_BOOT_MOUSE_IN_REPORT

HID Boot Mouse Input Report Characteristic.

BT_UUID_GATT_GMC_VAL

GATT Characteristic Glucose Measurement Context UUID Value.

BT_UUID_GATT_GMC

GATT Characteristic Glucose Measurement Context.

BT_UUID_GATT_BPM_VAL

GATT Characteristic Blood Pressure Measurement UUID Value.

BT_UUID_GATT_BPM

GATT Characteristic Blood Pressure Measurement.

BT_UUID_GATT_ICP_VAL

GATT Characteristic Intermediate Cuff Pressure UUID Value.

BT_UUID_GATT_ICP

GATT Characteristic Intermediate Cuff Pressure.

BT_UUID_HRS_MEASUREMENT_VAL

HRS Characteristic Measurement Interval UUID value.

BT_UUID_HRS_MEASUREMENT

HRS Characteristic Measurement Interval.

BT_UUID_HRS_BODY_SENSOR_VAL

HRS Characteristic Body Sensor Location.

BT_UUID_HRS_BODY_SENSOR

HRS Characteristic Control Point.

BT_UUID_HRS_CONTROL_POINT_VAL

HRS Characteristic Control Point UUID value.

BT_UUID_HRS_CONTROL_POINT

HRS Characteristic Control Point.

BT_UUID_GATT_REM_VAL

GATT Characteristic Removable UUID Value.

BT_UUID_GATT_REM

GATT Characteristic Removable.

BT_UUID_GATT_SRVREQ_VAL

GATT Characteristic Service Required UUID Value.

BT_UUID_GATT_SRVREQ

GATT Characteristic Service Required.

BT_UUID_GATT_SC_TEMP_C_VAL

GATT Characteristic Scientific Temperature in Celsius UUID Value.

BT_UUID_GATT_SC_TEMP_C

GATT Characteristic Scientific Temperature in Celsius.

BT_UUID_GATT_STRING_VAL

GATT Characteristic String UUID Value.

BT_UUID_GATT_STRING

GATT Characteristic String.

BT_UUID_GATT_NETA_VAL

GATT Characteristic Network Availability UUID Value.

BT_UUID_GATT_NETA

GATT Characteristic Network Availability.

BT_UUID_GATT_ALRTS_VAL

GATT Characteristic Alert Status UUID Value.

BT_UUID_GATT_ALRTS

GATT Characteristic Alert Status.

BT_UUID_GATT_RCP_VAL

GATT Characteristic Ringer Control Point UUID Value.

BT_UUID_GATT_RCP

GATT Characteristic Ringer Control Point.

BT_UUID_GATT_RS_VAL

GATT Characteristic Ringer Setting UUID Value.

BT_UUID_GATT_RS

GATT Characteristic Ringer Setting.

BT_UUID_GATT_ALRTCID_MASK_VAL

GATT Characteristic Alert Category ID Bit Mask UUID Value.

BT_UUID_GATT_ALRTCID_MASK

GATT Characteristic Alert Category ID Bit Mask.

BT_UUID_GATT_ALRTCID_VAL

GATT Characteristic Alert Category ID UUID Value.

BT_UUID_GATT_ALRTCID

GATT Characteristic Alert Category ID.

BT_UUID_GATT_ALRTNCP_VAL

GATT Characteristic Alert Notification Control Point Value.

BT_UUID_GATT_ALRTNCP

GATT Characteristic Alert Notification Control Point.

BT_UUID_GATT_UALRTS_VAL

GATT Characteristic Unread Alert Status UUID Value.

BT_UUID_GATT_UALRTS

GATT Characteristic Unread Alert Status.

BT_UUID_GATT_NALRT_VAL

GATT Characteristic New Alert UUID Value.

BT_UUID_GATT_NALRT

GATT Characteristic New Alert.

BT_UUID_GATT_SNALRTC_VAL

GATT Characteristic Supported New Alert Category UUID Value.

BT_UUID_GATT_SNALRTC

GATT Characteristic Supported New Alert Category.

BT_UUID_GATT_SUALRTC_VAL

GATT Characteristic Supported Unread Alert Category UUID Value.

BT_UUID_GATT_SUALRTC

GATT Characteristic Supported Unread Alert Category.

BT_UUID_GATT_BPF_VAL

GATT Characteristic Blood Pressure Feature UUID Value.

BT_UUID_GATT_BPF

GATT Characteristic Blood Pressure Feature.

BT_UUID_HIDS_INFO_VAL

HID Information Characteristic UUID value.

BT_UUID_HIDS_INFO

HID Information Characteristic.

BT_UUID_HIDS_REPORT_MAP_VAL

HID Report Map Characteristic UUID value.

BT_UUID_HIDS_REPORT_MAP

HID Report Map Characteristic.

BT_UUID_HIDS_CTRL_POINT_VAL

HID Control Point Characteristic UUID value.

BT_UUID_HIDS_CTRL_POINT

HID Control Point Characteristic.

BT_UUID_HIDS_REPORT_VAL

HID Report Characteristic UUID value.

BT_UUID_HIDS_REPORT

HID Report Characteristic.

BT_UUID_HIDS_PROTOCOL_MODE_VAL

HID Protocol Mode Characteristic UUID value.

BT_UUID_HIDS_PROTOCOL_MODE

HID Protocol Mode Characteristic.

BT_UUID_GATT_SIW_VAL

GATT Characteristic Scan Interval Windows UUID Value.

BT_UUID_GATT_SIW

GATT Characteristic Scan Interval Windows.

BT_UUID_DIS_PNP_ID_VAL

DIS Characteristic PnP ID UUID value.

BT_UUID_DIS_PNP_ID

DIS Characteristic PnP ID.

BT_UUID_GATT_GF_VAL

GATT Characteristic Glucose Feature UUID Value.

BT_UUID_GATT_GF

GATT Characteristic Glucose Feature.

BT_UUID_RECORD_ACCESS_CONTROL_POINT_VAL

Record Access Control Point Characteristic value.

BT_UUID_RECORD_ACCESS_CONTROL_POINT

Record Access Control Point.

BT_UUID_RSC_MEASUREMENT_VAL

RSC Measurement Characteristic UUID value.

BT_UUID_RSC_MEASUREMENT

RSC Measurement Characteristic.

BT_UUID_RSC_FEATURE_VAL

RSC Feature Characteristic UUID value.

BT_UUID_RSC_FEATURE

RSC Feature Characteristic.

BT_UUID_SC_CONTROL_POINT_VAL

SC Control Point Characteristic UUID value.

BT_UUID_SC_CONTROL_POINT

SC Control Point Characteristic.

BT_UUID_GATT_DI_VAL

GATT Characteristic Digital Input UUID Value.

BT_UUID_GATT_DI

GATT Characteristic Digital Input.

BT_UUID_GATT_DO_VAL

GATT Characteristic Digital Output UUID Value.

BT_UUID_GATT_DO

GATT Characteristic Digital Output.

BT_UUID_GATT_AI_VAL

GATT Characteristic Analog Input UUID Value.

BT_UUID_GATT_AI

GATT Characteristic Analog Input.

BT_UUID_GATT_AO_VAL

GATT Characteristic Analog Output UUID Value.

BT_UUID_GATT_AO

GATT Characteristic Analog Output.

BT_UUID_GATT_AGGR_VAL

GATT Characteristic Aggregate UUID Value.

BT_UUID_GATT_AGGR

GATT Characteristic Aggregate.

BT_UUID_CSC_MEASUREMENT_VAL

CSC Measurement Characteristic UUID value.

BT_UUID_CSC_MEASUREMENT

CSC Measurement Characteristic.

BT_UUID_CSC_FEATURE_VAL

CSC Feature Characteristic UUID value.

BT_UUID_CSC_FEATURE

CSC Feature Characteristic.

BT_UUID_SENSOR_LOCATION_VAL

Sensor Location Characteristic UUID value.

BT_UUID_SENSOR_LOCATION

Sensor Location Characteristic.

BT_UUID_GATT_PLX_SCM_VAL

GATT Characteristic PLX Spot-Check Measurement UUID Value.

BT_UUID_GATT_PLX_SCM

GATT Characteristic PLX Spot-Check Measurement.

BT_UUID_GATT_PLX_CM_VAL

GATT Characteristic PLX Continuous Measurement UUID Value.

BT_UUID_GATT_PLX_CM

GATT Characteristic PLX Continuous Measurement.

BT_UUID_GATT_PLX_F_VAL

GATT Characteristic PLX Features UUID Value.

BT_UUID_GATT_PLX_F

GATT Characteristic PLX Features.

BT_UUID_GATT_POPE_VAL

GATT Characteristic Pulse Oximetry Pulastile Event UUID Value.

BT_UUID_GATT_POPE

GATT Characteristic Pulse Oximetry Pulsatile Event.

BT_UUID_GATT_POCP_VAL

GATT Characteristic Pulse Oximetry Control Point UUID Value.

BT_UUID_GATT_POCP

GATT Characteristic Pulse Oximetry Control Point.

BT_UUID_GATT_CPS_CPM_VAL

GATT Characteristic Cycling Power Measurement UUID Value.

BT_UUID_GATT_CPS_CPM

GATT Characteristic Cycling Power Measurement.

BT_UUID_GATT_CPS_CPV_VAL

GATT Characteristic Cycling Power Vector UUID Value.

BT_UUID_GATT_CPS_CPV

GATT Characteristic Cycling Power Vector.

BT_UUID_GATT_CPS_CPF_VAL

GATT Characteristic Cycling Power Feature UUID Value.

BT_UUID_GATT_CPS_CPF

GATT Characteristic Cycling Power Feature.

BT_UUID_GATT_CPS_CPCP_VAL

GATT Characteristic Cycling Power Control Point UUID Value.

BT_UUID_GATT_CPS_CPCP

GATT Characteristic Cycling Power Control Point.

BT_UUID_GATT_LOC_SPD_VAL

GATT Characteristic Location and Speed UUID Value.

BT_UUID_GATT_LOC_SPD

GATT Characteristic Location and Speed.

BT_UUID_GATT_NAV_VAL

GATT Characteristic Navigation UUID Value.

BT_UUID_GATT_NAV

GATT Characteristic Navigation.

BT_UUID_GATT_PQ_VAL

GATT Characteristic Position Quality UUID Value.

BT_UUID_GATT_PQ

GATT Characteristic Position Quality.

BT_UUID_GATT_LNF_VAL

GATT Characteristic LN Feature UUID Value.

BT_UUID_GATT_LNF

GATT Characteristic LN Feature.

BT_UUID_GATT_LNCP_VAL

GATT Characteristic LN Control Point UUID Value.

BT_UUID_GATT_LNCP

GATT Characteristic LN Control Point.

BT_UUID_ELEVATION_VAL

Elevation Characteristic UUID value.

BT_UUID_ELEVATION

Elevation Characteristic.

BT_UUID_PRESSURE_VAL

Pressure Characteristic UUID value.

BT_UUID_PRESSURE

Pressure Characteristic.

BT_UUID_TEMPERATURE_VAL

Temperature Characteristic UUID value.

BT_UUID_TEMPERATURE

Temperature Characteristic.

BT_UUID_HUMIDITY_VAL

Humidity Characteristic UUID value.

BT_UUID_HUMIDITY

Humidity Characteristic.

BT_UUID_TRUE_WIND_SPEED_VAL

True Wind Speed Characteristic UUID value.

BT_UUID_TRUE_WIND_SPEED

True Wind Speed Characteristic.

BT_UUID_TRUE_WIND_DIR_VAL

True Wind Direction Characteristic UUID value.

BT_UUID_TRUE_WIND_DIR

True Wind Direction Characteristic.

BT_UUID_APPARENT_WIND_SPEED_VAL

Apparent Wind Speed Characteristic UUID value.

BT_UUID_APPARENT_WIND_SPEED

Apparent Wind Speed Characteristic.

BT_UUID_APPARENT_WIND_DIR_VAL

Apparent Wind Direction Characteristic UUID value.

BT_UUID_APPARENT_WIND_DIR

Apparent Wind Direction Characteristic.

BT_UUID_GUST_FACTOR_VAL

Gust Factor Characteristic UUID value.

BT_UUID_GUST_FACTOR

Gust Factor Characteristic.

BT_UUID_POLLEN_CONCENTRATION_VAL

Pollen Concentration Characteristic UUID value.

BT_UUID_POLLEN_CONCENTRATION

Pollen Concentration Characteristic.

BT_UUID_UV_INDEX_VAL

UV Index Characteristic UUID value.

BT_UUID_UV_INDEX

UV Index Characteristic.

BT_UUID_IRRADIANCE_VAL

Irradiance Characteristic UUID value.

BT_UUID_IRRADIANCE

Irradiance Characteristic.

BT_UUID_RAINFALL_VAL

Rainfall Characteristic UUID value.

BT_UUID_RAINFALL

Rainfall Characteristic.

BT_UUID_WIND_CHILL_VAL

Wind Chill Characteristic UUID value.

BT_UUID_WIND_CHILL

Wind Chill Characteristic.

BT_UUID_HEAT_INDEX_VAL

Heat Index Characteristic UUID value.

BT_UUID_HEAT_INDEX

Heat Index Characteristic.

BT_UUID_DEW_POINT_VAL

Dew Point Characteristic UUID value.

BT_UUID_DEW_POINT

Dew Point Characteristic.

BT_UUID_GATT_TREND_VAL

GATT Characteristic Trend UUID Value.

BT_UUID_GATT_TREND

GATT Characteristic Trend.

BT_UUID_DESC_VALUE_CHANGED_VAL

Descriptor Value Changed Characteristic UUID value.

BT_UUID_DESC_VALUE_CHANGED

Descriptor Value Changed Characteristic.

BT_UUID_GATT_AEHRLL_VAL

GATT Characteristic Aerobic Heart Rate Low Limit UUID Value.

BT_UUID_GATT_AEHRLL

GATT Characteristic Aerobic Heart Rate Lower Limit.

BT_UUID_GATT_AETHR_VAL

GATT Characteristic Aerobic Threshold UUID Value.

BT_UUID_GATT_AETHR

GATT Characteristic Aerobic Threshold.

BT_UUID_GATT_AGE_VAL

GATT Characteristic Age UUID Value.

BT_UUID_GATT_AGE

GATT Characteristic Age.

BT_UUID_GATT_ANHRLL_VAL

GATT Characteristic Anaerobic Heart Rate Lower Limit UUID Value.

BT_UUID_GATT_ANHRLL

GATT Characteristic Anaerobic Heart Rate Lower Limit.

BT_UUID_GATT_ANHRUL_VAL

GATT Characteristic Anaerobic Heart Rate Upper Limit UUID Value.

BT_UUID_GATT_ANHRUL

GATT Characteristic Anaerobic Heart Rate Upper Limit.

BT_UUID_GATT_ANTHR_VAL

GATT Characteristic Anaerobic Threshold UUID Value.

BT_UUID_GATT_ANTHR

GATT Characteristic Anaerobic Threshold.

BT_UUID_GATT_AEHRUL_VAL

GATT Characteristic Aerobic Heart Rate Upper Limit UUID Value.

BT_UUID_GATT_AEHRUL

GATT Characteristic Aerobic Heart Rate Upper Limit.

BT_UUID_GATT_DATE_BIRTH_VAL

GATT Characteristic Date of Birth UUID Value.

BT_UUID_GATT_DATE_BIRTH

GATT Characteristic Date of Birth.

BT_UUID_GATT_DATE_THRASS_VAL

GATT Characteristic Date of Threshold Assessment UUID Value.

BT_UUID_GATT_DATE_THRASS

GATT Characteristic Date of Threshold Assessment.

BT_UUID_GATT_EMAIL_VAL

GATT Characteristic Email Address UUID Value.

BT_UUID_GATT_EMAIL

GATT Characteristic Email Address.

BT_UUID_GATT_FBHRLL_VAL

GATT Characteristic Fat Burn Heart Rate Lower Limit UUID Value.

BT_UUID_GATT_FBHRLL

GATT Characteristic Fat Burn Heart Rate Lower Limit.

BT_UUID_GATT_FBHRUL_VAL

GATT Characteristic Fat Burn Heart Rate Upper Limit UUID Value.

BT_UUID_GATT_FBHRUL

GATT Characteristic Fat Burn Heart Rate Upper Limit.

BT_UUID_GATT_FIRST_NAME_VAL

GATT Characteristic First Name UUID Value.

BT_UUID_GATT_FIRST_NAME

GATT Characteristic First Name.

BT_UUID_GATT_5ZHRL_VAL

GATT Characteristic Five Zone Heart Rate Limits UUID Value.

BT_UUID_GATT_5ZHRL

GATT Characteristic Five Zone Heart Rate Limits.

BT_UUID_GATT_GENDER_VAL

GATT Characteristic Gender UUID Value.

BT_UUID_GATT_GENDER

GATT Characteristic Gender.

BT_UUID_GATT_HR_MAX_VAL

GATT Characteristic Heart Rate Max UUID Value.

BT_UUID_GATT_HR_MAX

GATT Characteristic Heart Rate Max.

BT_UUID_GATT_HEIGHT_VAL

GATT Characteristic Height UUID Value.

BT_UUID_GATT_HEIGHT

GATT Characteristic Height.

BT_UUID_GATT_HC_VAL

GATT Characteristic Hip Circumference UUID Value.

BT_UUID_GATT_HC

GATT Characteristic Hip Circumference.

BT_UUID_GATT_LAST_NAME_VAL

GATT Characteristic Last Name UUID Value.

BT_UUID_GATT_LAST_NAME

GATT Characteristic Last Name.

BT_UUID_GATT_MRHR_VAL

GATT Characteristic Maximum Recommended Heart Rate> UUID Value.

BT_UUID_GATT_MRHR

GATT Characteristic Maximum Recommended Heart Rate.

BT_UUID_GATT_RHR_VAL

GATT Characteristic Resting Heart Rate UUID Value.

BT_UUID_GATT_RHR

GATT Characteristic Resting Heart Rate.

BT_UUID_GATT_AEANTHR_VAL

GATT Characteristic Sport Type for Aerobic and Anaerobic Thresholds UUID Value.

BT_UUID_GATT_AEANTHR

GATT Characteristic Sport Type for Aerobic and Anaerobic Threshold.

BT_UUID_GATT_3ZHRL_VAL

GATT Characteristic Three Zone Heart Rate Limits UUID Value.

BT_UUID_GATT_3ZHRL

GATT Characteristic Three Zone Heart Rate Limits.

BT_UUID_GATT_2ZHRL_VAL

GATT Characteristic Two Zone Heart Rate Limits UUID Value.

BT_UUID_GATT_2ZHRL

GATT Characteristic Two Zone Heart Rate Limits.

BT_UUID_GATT_VO2_MAX_VAL

GATT Characteristic VO2 Max UUID Value.

BT_UUID_GATT_VO2_MAX

GATT Characteristic VO2 Max.

BT_UUID_GATT_WC_VAL

GATT Characteristic Waist Circumference UUID Value.

BT_UUID_GATT_WC

GATT Characteristic Waist Circumference.

BT_UUID_GATT_WEIGHT_VAL

GATT Characteristic Weight UUID Value.

BT_UUID_GATT_WEIGHT

GATT Characteristic Weight.

BT_UUID_GATT_DBCHINC_VAL

GATT Characteristic Database Change Increment UUID Value.

BT_UUID_GATT_DBCHINC

GATT Characteristic Database Change Increment.

BT_UUID_GATT_USRIDX_VAL

GATT Characteristic User Index UUID Value.

BT_UUID_GATT_USRIDX

GATT Characteristic User Index.

BT_UUID_GATT_BCF_VAL

GATT Characteristic Body Composition Feature UUID Value.

BT_UUID_GATT_BCF

GATT Characteristic Body Composition Feature.

BT_UUID_GATT_BCM_VAL

GATT Characteristic Body Composition Measurement UUID Value.

BT_UUID_GATT_BCM

GATT Characteristic Body Composition Measurement.

BT_UUID_GATT_WM_VAL

GATT Characteristic Weight Measurement UUID Value.

BT_UUID_GATT_WM

GATT Characteristic Weight Measurement.

BT_UUID_GATT_WSF_VAL

GATT Characteristic Weight Scale Feature UUID Value.

BT_UUID_GATT_WSF

GATT Characteristic Weight Scale Feature.

BT_UUID_GATT_USRCP_VAL

GATT Characteristic User Control Point UUID Value.

BT_UUID_GATT_USRCP

GATT Characteristic User Control Point.

BT_UUID_MAGN_FLUX_DENSITY_2D_VAL

Magnetic Flux Density - 2D Characteristic UUID value.

BT_UUID_MAGN_FLUX_DENSITY_2D

Magnetic Flux Density - 2D Characteristic.

BT_UUID_MAGN_FLUX_DENSITY_3D_VAL

Magnetic Flux Density - 3D Characteristic UUID value.

BT_UUID_MAGN_FLUX_DENSITY_3D

Magnetic Flux Density - 3D Characteristic.

BT_UUID_GATT_LANG_VAL

GATT Characteristic Language UUID Value.

BT_UUID_GATT_LANG

GATT Characteristic Language.

BT_UUID_BAR_PRESSURE_TREND_VAL

Barometric Pressure Trend Characteristic UUID value.

BT_UUID_BAR_PRESSURE_TREND

Barometric Pressure Trend Characteristic.

BT_UUID_BMS_CONTROL_POINT_VAL

Bond Management Control Point UUID value.

BT_UUID_BMS_CONTROL_POINT

Bond Management Control Point.

BT_UUID_BMS_FEATURE_VAL

Bond Management Feature UUID value.

BT_UUID_BMS_FEATURE

Bond Management Feature.

BT_UUID_CENTRAL_ADDR_RES_VAL

Central Address Resolution Characteristic UUID value.

BT_UUID_CENTRAL_ADDR_RES

Central Address Resolution Characteristic.

BT_UUID_CGM_MEASUREMENT_VAL

CGM Measurement Characteristic value.

BT_UUID_CGM_MEASUREMENT

CGM Measurement Characteristic.

BT_UUID_CGM_FEATURE_VAL

CGM Feature Characteristic value.

BT_UUID_CGM_FEATURE

CGM Feature Characteristic.

BT_UUID_CGM_STATUS_VAL

CGM Status Characteristic value.

BT_UUID_CGM_STATUS

CGM Status Characteristic.

BT_UUID_CGM_SESSION_START_TIME_VAL

CGM Session Start Time Characteristic value.

BT_UUID_CGM_SESSION_START_TIME

CGM Session Start Time.

BT_UUID_CGM_SESSION_RUN_TIME_VAL

CGM Session Run Time Characteristic value.

BT_UUID_CGM_SESSION_RUN_TIME

CGM Session Run Time.

BT_UUID_CGM_SPECIFIC_OPS_CONTROL_POINT_VAL

CGM Specific Ops Control Point Characteristic value.

BT_UUID_CGM_SPECIFIC_OPS_CONTROL_POINT

CGM Specific Ops Control Point.

BT_UUID_GATT_IPC_VAL

GATT Characteristic Indoor Positioning Configuration UUID Value.

BT_UUID_GATT_IPC

GATT Characteristic Indoor Positioning Configuration.

BT_UUID_GATT_LAT_VAL

GATT Characteristic Latitude UUID Value.

BT_UUID_GATT_LAT

GATT Characteristic Latitude.

BT_UUID_GATT_LON_VAL

GATT Characteristic Longitude UUID Value.

BT_UUID_GATT_LON

GATT Characteristic Longitude.

BT_UUID_GATT_LNCOORD_VAL

GATT Characteristic Local North Coordinate UUID Value.

BT_UUID_GATT_LNCOORD

GATT Characteristic Local North Coordinate.

BT_UUID_GATT_LECOORD_VAL

GATT Characteristic Local East Coordinate UUID Value.

BT_UUID_GATT_LECOORD

GATT Characteristic Local East Coordinate.

BT_UUID_GATT_FN_VAL

GATT Characteristic Floor Number UUID Value.

BT_UUID_GATT_FN

GATT Characteristic Floor Number.

BT_UUID_GATT_ALT_VAL

GATT Characteristic Altitude UUID Value.

BT_UUID_GATT_ALT

GATT Characteristic Altitude.

BT_UUID_GATT_UNCERTAINTY_VAL

GATT Characteristic Uncertainty UUID Value.

BT_UUID_GATT_UNCERTAINTY

GATT Characteristic Uncertainty.

BT_UUID_GATT_LOC_NAME_VAL

GATT Characteristic Location Name UUID Value.

BT_UUID_GATT_LOC_NAME

GATT Characteristic Location Name.

BT_UUID_URI_VAL

URI UUID value.

BT_UUID_URI

URI.

BT_UUID_HTTP_HEADERS_VAL

HTTP Headers UUID value.

BT_UUID_HTTP_HEADERS

HTTP Headers.

BT_UUID_HTTP_STATUS_CODE_VAL

HTTP Status Code UUID value.

BT_UUID_HTTP_STATUS_CODE

HTTP Status Code.

BT_UUID_HTTP_ENTITY_BODY_VAL

HTTP Entity Body UUID value.

BT_UUID_HTTP_ENTITY_BODY

HTTP Entity Body.

BT_UUID_HTTP_CONTROL_POINT_VAL

HTTP Control Point UUID value.

BT_UUID_HTTP_CONTROL_POINT

HTTP Control Point.

BT_UUID_HTTPS_SECURITY_VAL

HTTPS Security UUID value.

BT_UUID_HTTPS_SECURITY

HTTPS Security.

BT_UUID_GATT_TDS_CP_VAL

GATT Characteristic TDS Control Point UUID Value.

BT_UUID_GATT_TDS_CP

GATT Characteristic TDS Control Point.

BT_UUID_OTS_FEATURE_VAL

OTS Feature Characteristic UUID value.

BT_UUID_OTS_FEATURE

OTS Feature Characteristic.

BT_UUID_OTS_NAME_VAL

OTS Object Name Characteristic UUID value.

BT_UUID_OTS_NAME

OTS Object Name Characteristic.

BT_UUID_OTS_TYPE_VAL

OTS Object Type Characteristic UUID value.

BT_UUID_OTS_TYPE

OTS Object Type Characteristic.

BT_UUID_OTS_SIZE_VAL

OTS Object Size Characteristic UUID value.

BT_UUID_OTS_SIZE

OTS Object Size Characteristic.

BT_UUID_OTS_FIRST_CREATED_VAL

OTS Object First-Created Characteristic UUID value.

BT_UUID_OTS_FIRST_CREATED

OTS Object First-Created Characteristic.

BT_UUID_OTS_LAST_MODIFIED_VAL

OTS Object Last-Modified Characteristic UUI value.

BT_UUID_OTS_LAST_MODIFIED

OTS Object Last-Modified Characteristic.

BT_UUID_OTS_ID_VAL

OTS Object ID Characteristic UUID value.

BT_UUID_OTS_ID

OTS Object ID Characteristic.

BT_UUID_OTS_PROPERTIES_VAL

OTS Object Properties Characteristic UUID value.

BT_UUID_OTS_PROPERTIES

OTS Object Properties Characteristic.

BT_UUID_OTS_ACTION_CP_VAL

OTS Object Action Control Point Characteristic UUID value.

BT_UUID_OTS_ACTION_CP

OTS Object Action Control Point Characteristic.

BT_UUID_OTS_LIST_CP_VAL

OTS Object List Control Point Characteristic UUID value.

BT_UUID_OTS_LIST_CP

OTS Object List Control Point Characteristic.

BT_UUID_OTS_LIST_FILTER_VAL

OTS Object List Filter Characteristic UUID value.

BT_UUID_OTS_LIST_FILTER

OTS Object List Filter Characteristic.

BT_UUID_OTS_CHANGED_VAL

OTS Object Changed Characteristic UUID value.

BT_UUID_OTS_CHANGED

OTS Object Changed Characteristic.

BT_UUID_GATT_RPAO_VAL

GATT Characteristic Resolvable Private Address Only UUID Value.

BT_UUID_GATT_RPAO

GATT Characteristic Resolvable Private Address Only.

BT_UUID_OTS_TYPE_UNSPECIFIED_VAL

OTS Unspecified Object Type UUID value.

BT_UUID_OTS_TYPE_UNSPECIFIED

OTS Unspecified Object Type.

BT_UUID_OTS_DIRECTORY_LISTING_VAL

OTS Directory Listing UUID value.

BT_UUID_OTS_DIRECTORY_LISTING

OTS Directory Listing.

BT_UUID_GATT_FMF_VAL

GATT Characteristic Fitness Machine Feature UUID Value.

BT_UUID_GATT_FMF

GATT Characteristic Fitness Machine Feature.

BT_UUID_GATT_TD_VAL

GATT Characteristic Treadmill Data UUID Value.

BT_UUID_GATT_TD

GATT Characteristic Treadmill Data.

BT_UUID_GATT_CTD_VAL

GATT Characteristic Cross Trainer Data UUID Value.

BT_UUID_GATT_CTD

GATT Characteristic Cross Trainer Data.

BT_UUID_GATT_STPCD_VAL

GATT Characteristic Step Climber Data UUID Value.

BT_UUID_GATT_STPCD

GATT Characteristic Step Climber Data.

BT_UUID_GATT_STRCD_VAL

GATT Characteristic Stair Climber Data UUID Value.

BT_UUID_GATT_STRCD

GATT Characteristic Stair Climber Data.

BT_UUID_GATT_RD_VAL

GATT Characteristic Rower Data UUID Value.

BT_UUID_GATT_RD

GATT Characteristic Rower Data.

BT_UUID_GATT_IBD_VAL

GATT Characteristic Indoor Bike Data UUID Value.

BT_UUID_GATT_IBD

GATT Characteristic Indoor Bike Data.

BT_UUID_GATT_TRSTAT_VAL

GATT Characteristic Training Status UUID Value.

BT_UUID_GATT_TRSTAT

GATT Characteristic Training Status.

BT_UUID_GATT_SSR_VAL

GATT Characteristic Supported Speed Range UUID Value.

BT_UUID_GATT_SSR

GATT Characteristic Supported Speed Range.

BT_UUID_GATT_SIR_VAL

GATT Characteristic Supported Inclination Range UUID Value.

BT_UUID_GATT_SIR

GATT Characteristic Supported Inclination Range.

BT_UUID_GATT_SRLR_VAL

GATT Characteristic Supported Resistance Level Range UUID Value.

BT_UUID_GATT_SRLR

GATT Characteristic Supported Resistance Level Range.

BT_UUID_GATT_SHRR_VAL

GATT Characteristic Supported Heart Rate Range UUID Value.

BT_UUID_GATT_SHRR

GATT Characteristic Supported Heart Rate Range.

BT_UUID_GATT_SPR_VAL

GATT Characteristic Supported Power Range UUID Value.

BT_UUID_GATT_SPR

GATT Characteristic Supported Power Range.

BT_UUID_GATT_FMCP_VAL

GATT Characteristic Fitness Machine Control Point UUID Value.

BT_UUID_GATT_FMCP

GATT Characteristic Fitness Machine Control Point.

BT_UUID_GATT_FMS_VAL

GATT Characteristic Fitness Machine Status UUID Value.

BT_UUID_GATT_FMS

GATT Characteristic Fitness Machine Status.

BT_UUID_MESH_PROV_DATA_IN_VAL

Mesh Provisioning Data In UUID value.

BT_UUID_MESH_PROV_DATA_IN

Mesh Provisioning Data In.

BT_UUID_MESH_PROV_DATA_OUT_VAL

Mesh Provisioning Data Out UUID value.

BT_UUID_MESH_PROV_DATA_OUT

Mesh Provisioning Data Out.

BT_UUID_MESH_PROXY_DATA_IN_VAL

Mesh Proxy Data In UUID value.

BT_UUID_MESH_PROXY_DATA_IN

Mesh Proxy Data In.

BT_UUID_MESH_PROXY_DATA_OUT_VAL

Mesh Proxy Data Out UUID value.

BT_UUID_MESH_PROXY_DATA_OUT

Mesh Proxy Data Out.

BT_UUID_GATT_NNN_VAL

GATT Characteristic New Number Needed UUID Value.

BT_UUID_GATT_NNN

GATT Characteristic New Number Needed.

BT_UUID_GATT_AC_VAL

GATT Characteristic Average Current UUID Value.

BT_UUID_GATT_AC

GATT Characteristic Average Current.

BT_UUID_GATT_AV_VAL

GATT Characteristic Average Voltage UUID Value.

BT_UUID_GATT_AV

GATT Characteristic Average Voltage.

BT_UUID_GATT_BOOLEAN_VAL

GATT Characteristic Boolean UUID Value.

BT_UUID_GATT_BOOLEAN

GATT Characteristic Boolean.

BT_UUID_GATT_CRDFP_VAL

GATT Characteristic Chromatic Distance From Planckian UUID Value.

BT_UUID_GATT_CRDFP

GATT Characteristic Chromatic Distance From Planckian.

BT_UUID_GATT_CRCOORDS_VAL

GATT Characteristic Chromaticity Coordinates UUID Value.

BT_UUID_GATT_CRCOORDS

GATT Characteristic Chromaticity Coordinates.

BT_UUID_GATT_CRCCT_VAL

GATT Characteristic Chromaticity In CCT And Duv Values UUID Value.

BT_UUID_GATT_CRCCT

GATT Characteristic Chromaticity In CCT And Duv Values.

BT_UUID_GATT_CRT_VAL

GATT Characteristic Chromaticity Tolerance UUID Value.

BT_UUID_GATT_CRT

GATT Characteristic Chromaticity Tolerance.

BT_UUID_GATT_CIEIDX_VAL

GATT Characteristic CIE 13.3-1995 Color Rendering Index UUID Value.

BT_UUID_GATT_CIEIDX

GATT Characteristic CIE 13.3-1995 Color Rendering Index.

BT_UUID_GATT_COEFFICIENT_VAL

GATT Characteristic Coefficient UUID Value.

BT_UUID_GATT_COEFFICIENT

GATT Characteristic Coefficient.

BT_UUID_GATT_CCTEMP_VAL

GATT Characteristic Correlated Color Temperature UUID Value.

BT_UUID_GATT_CCTEMP

GATT Characteristic Correlated Color Temperature.

BT_UUID_GATT_COUNT16_VAL

GATT Characteristic Count 16 UUID Value.

BT_UUID_GATT_COUNT16

GATT Characteristic Count 16.

BT_UUID_GATT_COUNT24_VAL

GATT Characteristic Count 24 UUID Value.

BT_UUID_GATT_COUNT24

GATT Characteristic Count 24.

BT_UUID_GATT_CNTRCODE_VAL

GATT Characteristic Country Code UUID Value.

BT_UUID_GATT_CNTRCODE

GATT Characteristic Country Code.

BT_UUID_GATT_DATEUTC_VAL

GATT Characteristic Date UTC UUID Value.

BT_UUID_GATT_DATEUTC

GATT Characteristic Date UTC.

BT_UUID_GATT_EC_VAL

GATT Characteristic Electric Current UUID Value.

BT_UUID_GATT_EC

GATT Characteristic Electric Current.

BT_UUID_GATT_ECR_VAL

GATT Characteristic Electric Current Range UUID Value.

BT_UUID_GATT_ECR

GATT Characteristic Electric Current Range.

BT_UUID_GATT_ECSPEC_VAL

GATT Characteristic Electric Current Specification UUID Value.

BT_UUID_GATT_ECSPEC

GATT Characteristic Electric Current Specification.

BT_UUID_GATT_ECSTAT_VAL

GATT Characteristic Electric Current Statistics UUID Value.

BT_UUID_GATT_ECSTAT

GATT Characteristic Electric Current Statistics.

BT_UUID_GATT_ENERGY_VAL

GATT Characteristic Energy UUID Value.

BT_UUID_GATT_ENERGY

GATT Characteristic Energy.

BT_UUID_GATT_EPOD_VAL

GATT Characteristic Energy In A Period Of Day UUID Value.

BT_UUID_GATT_EPOD

GATT Characteristic Energy In A Period Of Day.

BT_UUID_GATT_EVTSTAT_VAL

GATT Characteristic Event Statistics UUID Value.

BT_UUID_GATT_EVTSTAT

GATT Characteristic Event Statistics.

BT_UUID_GATT_FSTR16_VAL

GATT Characteristic Fixed String 16 UUID Value.

BT_UUID_GATT_FSTR16

GATT Characteristic Fixed String 16.

BT_UUID_GATT_FSTR24_VAL

GATT Characteristic Fixed String 24 UUID Value.

BT_UUID_GATT_FSTR24

GATT Characteristic Fixed String 24.

BT_UUID_GATT_FSTR36_VAL

GATT Characteristic Fixed String 36 UUID Value.

BT_UUID_GATT_FSTR36

GATT Characteristic Fixed String 36.

BT_UUID_GATT_FSTR8_VAL

GATT Characteristic Fixed String 8 UUID Value.

BT_UUID_GATT_FSTR8

GATT Characteristic Fixed String 8.

BT_UUID_GATT_GENLVL_VAL

GATT Characteristic Generic Level UUID Value.

BT_UUID_GATT_GENLVL

GATT Characteristic Generic Level.

BT_UUID_GATT_GTIN_VAL

GATT Characteristic Global Trade Item Number UUID Value.

BT_UUID_GATT_GTIN

GATT Characteristic Global Trade Item Number.

BT_UUID_GATT_ILLUM_VAL

GATT Characteristic Illuminance UUID Value.

BT_UUID_GATT_ILLUM

GATT Characteristic Illuminance.

BT_UUID_GATT_LUMEFF_VAL

GATT Characteristic Luminous Efficacy UUID Value.

BT_UUID_GATT_LUMEFF

GATT Characteristic Luminous Efficacy.

BT_UUID_GATT_LUMNRG_VAL

GATT Characteristic Luminous Energy UUID Value.

BT_UUID_GATT_LUMNRG

GATT Characteristic Luminous Energy.

BT_UUID_GATT_LUMEXP_VAL

GATT Characteristic Luminous Exposure UUID Value.

BT_UUID_GATT_LUMEXP

GATT Characteristic Luminous Exposure.

BT_UUID_GATT_LUMFLX_VAL

GATT Characteristic Luminous Flux UUID Value.

BT_UUID_GATT_LUMFLX

GATT Characteristic Luminous Flux.

BT_UUID_GATT_LUMFLXR_VAL

GATT Characteristic Luminous Flux Range UUID Value.

BT_UUID_GATT_LUMFLXR

GATT Characteristic Luminous Flux Range.

BT_UUID_GATT_LUMINT_VAL

GATT Characteristic Luminous Intensity UUID Value.

BT_UUID_GATT_LUMINT

GATT Characteristic Luminous Intensity.

BT_UUID_GATT_MASSFLOW_VAL

GATT Characteristic Mass Flow UUID Value.

BT_UUID_GATT_MASSFLOW

GATT Characteristic Mass Flow.

BT_UUID_GATT_PERLGHT_VAL

GATT Characteristic Perceived Lightness UUID Value.

BT_UUID_GATT_PERLGHT

GATT Characteristic Perceived Lightness.

BT_UUID_GATT_PER8_VAL

GATT Characteristic Percentage 8 UUID Value.

BT_UUID_GATT_PER8

GATT Characteristic Percentage 8.

BT_UUID_GATT_PWR_VAL

GATT Characteristic Power UUID Value.

BT_UUID_GATT_PWR

GATT Characteristic Power.

BT_UUID_GATT_PWRSPEC_VAL

GATT Characteristic Power Specification UUID Value.

BT_UUID_GATT_PWRSPEC

GATT Characteristic Power Specification.

BT_UUID_GATT_RRICR_VAL

GATT Characteristic Relative Runtime In A Current Range UUID Value.

BT_UUID_GATT_RRICR

GATT Characteristic Relative Runtime In A Current Range.

BT_UUID_GATT_RRIGLR_VAL

GATT Characteristic Relative Runtime In A Generic Level Range UUID Value.

BT_UUID_GATT_RRIGLR

GATT Characteristic Relative Runtime In A Generic Level Range.

BT_UUID_GATT_RVIVR_VAL

GATT Characteristic Relative Value In A Voltage Range UUID Value.

BT_UUID_GATT_RVIVR

GATT Characteristic Relative Value In A Voltage Range.

BT_UUID_GATT_RVIIR_VAL

GATT Characteristic Relative Value In A Illuminance Range UUID Value.

BT_UUID_GATT_RVIIR

GATT Characteristic Relative Value In A Illuminance Range.

BT_UUID_GATT_RVIPOD_VAL

GATT Characteristic Relative Value In A Period Of Day UUID Value.

BT_UUID_GATT_RVIPOD

GATT Characteristic Relative Value In A Period Of Day.

BT_UUID_GATT_RVITR_VAL

GATT Characteristic Relative Value In A Temperature Range UUID Value.

BT_UUID_GATT_RVITR

GATT Characteristic Relative Value In A Temperature Range.

BT_UUID_GATT_TEMP8_VAL

GATT Characteristic Temperature 8 UUID Value.

BT_UUID_GATT_TEMP8

GATT Characteristic Temperature 8.

BT_UUID_GATT_TEMP8_IPOD_VAL

GATT Characteristic Temperature 8 In A Period Of Day UUID Value.

BT_UUID_GATT_TEMP8_IPOD

GATT Characteristic Temperature 8 In A Period Of Day.

BT_UUID_GATT_TEMP8_STAT_VAL

GATT Characteristic Temperature 8 Statistics UUID Value.

BT_UUID_GATT_TEMP8_STAT

GATT Characteristic Temperature 8 Statistics.

BT_UUID_GATT_TEMP_RNG_VAL

GATT Characteristic Temperature Range UUID Value.

BT_UUID_GATT_TEMP_RNG

GATT Characteristic Temperature Range.

BT_UUID_GATT_TEMP_STAT_VAL

GATT Characteristic Temperature Statistics UUID Value.

BT_UUID_GATT_TEMP_STAT

GATT Characteristic Temperature Statistics.

BT_UUID_GATT_TIM_DC8_VAL

GATT Characteristic Time Decihour 8 UUID Value.

BT_UUID_GATT_TIM_DC8

GATT Characteristic Time Decihour 8.

BT_UUID_GATT_TIM_EXP8_VAL

GATT Characteristic Time Exponential 8 UUID Value.

BT_UUID_GATT_TIM_EXP8

GATT Characteristic Time Exponential 8.

BT_UUID_GATT_TIM_H24_VAL

GATT Characteristic Time Hour 24 UUID Value.

BT_UUID_GATT_TIM_H24

GATT Characteristic Time Hour 24.

BT_UUID_GATT_TIM_MS24_VAL

GATT Characteristic Time Millisecond 24 UUID Value.

BT_UUID_GATT_TIM_MS24

GATT Characteristic Time Millisecond 24.

BT_UUID_GATT_TIM_S16_VAL

GATT Characteristic Time Second 16 UUID Value.

BT_UUID_GATT_TIM_S16

GATT Characteristic Time Second 16.

BT_UUID_GATT_TIM_S8_VAL

GATT Characteristic Time Second 8 UUID Value.

BT_UUID_GATT_TIM_S8

GATT Characteristic Time Second 8.

BT_UUID_GATT_V_VAL

GATT Characteristic Voltage UUID Value.

BT_UUID_GATT_V

GATT Characteristic Voltage.

BT_UUID_GATT_V_SPEC_VAL

GATT Characteristic Voltage Specification UUID Value.

BT_UUID_GATT_V_SPEC

GATT Characteristic Voltage Specification.

BT_UUID_GATT_V_STAT_VAL

GATT Characteristic Voltage Statistics UUID Value.

BT_UUID_GATT_V_STAT

GATT Characteristic Voltage Statistics.

BT_UUID_GATT_VOLF_VAL

GATT Characteristic Volume Flow UUID Value.

BT_UUID_GATT_VOLF

280

GATT Characteristic Volume Flow.

Chapter 1. Bluetooth

BT_UUID_GATT_CRCOORD_VAL

GATT Characteristic Chromaticity Coordinate (not Coordinates) UUID Value.

BT_UUID_GATT_CRCOORD

GATT Characteristic Chromaticity Coordinate (not Coordinates)

BT_UUID_GATT_RCF_VAL

GATT Characteristic RC Feature UUID Value.

BT_UUID_GATT_RCF

GATT Characteristic RC Feature.

BT_UUID_GATT_RCSET_VAL

GATT Characteristic RC Settings UUID Value.

BT_UUID_GATT_RCSET

GATT Characteristic RC Settings.

BT_UUID_GATT_RCCP_VAL

GATT Characteristic Reconnection Configuration Control Point UUID Value.

BT_UUID_GATT_RCCP

GATT Characteristic Reconnection Configurationn Control Point.

BT_UUID_GATT_IDD_SC_VAL

GATT Characteristic IDD Status Changed UUID Value.

BT_UUID_GATT_IDD_SC

GATT Characteristic IDD Status Changed.

BT_UUID_GATT_IDD_S_VAL

GATT Characteristic IDD Status UUID Value.

BT_UUID_GATT_IDD_S

GATT Characteristic IDD Status.

BT_UUID_GATT_IDD_AS_VAL

GATT Characteristic IDD Announciation Status UUID Value.

BT_UUID_GATT_IDD_AS

GATT Characteristic IDD Announciation Status.

BT_UUID_GATT_IDD_F_VAL

GATT Characteristic IDD Features UUID Value.

BT_UUID_GATT_IDD_F

GATT Characteristic IDD Features.

BT_UUID_GATT_IDD_SRCP_VAL

GATT Characteristic IDD Status Reader Control Point UUID Value.

BT_UUID_GATT_IDD_SRCP

GATT Characteristic IDD Status Reader Control Point.

BT_UUID_GATT_IDD_CCP_VAL

GATT Characteristic IDD Command Control Point UUID Value.

BT_UUID_GATT_IDD_CCP

GATT Characteristic IDD Command Control Point.

BT_UUID_GATT_IDD_CD_VAL

GATT Characteristic IDD Command Data UUID Value.

BT_UUID_GATT_IDD_CD

GATT Characteristic IDD Command Data.

BT_UUID_GATT_IDD_RACP_VAL

GATT Characteristic IDD Record Access Control Point UUID Value.

BT_UUID_GATT_IDD_RACP

GATT Characteristic IDD Record Access Control Point.

BT_UUID_GATT_IDD_HD_VAL

GATT Characteristic IDD History Data UUID Value.

BT_UUID_GATT_IDD_HD

GATT Characteristic IDD History Data.

BT_UUID_GATT_CLIENT_FEATURES_VAL

GATT Characteristic Client Supported Features UUID value.

BT_UUID_GATT_CLIENT_FEATURES

GATT Characteristic Client Supported Features.

BT_UUID_GATT_DB_HASH_VAL

GATT Characteristic Database Hash UUID value.

BT_UUID_GATT_DB_HASH

GATT Characteristic Database Hash.

BT_UUID_GATT_BSS_CP_VAL

GATT Characteristic BSS Control Point UUID Value.

BT_UUID_GATT_BSS_CP

GATT Characteristic BSS Control Point.

BT_UUID_GATT_BSS_R_VAL

GATT Characteristic BSS Response UUID Value.

BT_UUID_GATT_BSS_R

GATT Characteristic BSS Response.

BT_UUID_GATT_EMG_ID_VAL

GATT Characteristic Emergency ID UUID Value.

BT_UUID_GATT_EMG_ID

GATT Characteristic Emergency ID.

BT_UUID_GATT_EMG_TXT_VAL

GATT Characteristic Emergency Text UUID Value.

BT_UUID_GATT_EMG_TXT

GATT Characteristic Emergency Text.

BT_UUID_GATT_ACS_S_VAL

GATT Characteristic ACS Status UUID Value.

BT_UUID_GATT_ACS_S

GATT Characteristic ACS Status.

BT_UUID_GATT_ACS_DI_VAL

GATT Characteristic ACS Data In UUID Value.

BT_UUID_GATT_ACS_DI

GATT Characteristic ACS Data In.

BT_UUID_GATT_ACS_DON_VAL

GATT Characteristic ACS Data Out Notify UUID Value.

BT_UUID_GATT_ACS_DON

GATT Characteristic ACS Data Out Notify.

BT_UUID_GATT_ACS_DOI_VAL

GATT Characteristic ACS Data Out Indicate UUID Value.

BT_UUID_GATT_ACS_DOI

GATT Characteristic ACS Data Out Indicate.

BT_UUID_GATT_ACS_CP_VAL

GATT Characteristic ACS Control Point UUID Value.

BT_UUID_GATT_ACS_CP

GATT Characteristic ACS Control Point.

BT_UUID_GATT_EBPM_VAL

GATT Characteristic Enhanced Blood Pressure Measurement UUID Value.

BT_UUID_GATT_EBPM

GATT Characteristic Enhanced Blood Pressure Measurement.

BT_UUID_GATT_EICP_VAL

GATT Characteristic Enhanced Intermediate Cuff Pressure UUID Value.

BT_UUID_GATT_EICP

GATT Characteristic Enhanced Intermediate Cuff Pressure.

BT_UUID_GATT_BPR_VAL

GATT Characteristic Blood Pressure Record UUID Value.

BT_UUID_GATT_BPR

GATT Characteristic Blood Pressure Record.

BT_UUID_GATT_RU_VAL

GATT Characteristic Registered User UUID Value.

BT_UUID_GATT_RU

GATT Characteristic Registered User.

BT_UUID_GATT_BR_EDR_HD_VAL

GATT Characteristic BR-EDR Handover Data UUID Value.

BT_UUID_GATT_BR_EDR_HD

GATT Characteristic BR-EDR Handover Data.

BT_UUID_GATT_BT_SIG_D_VAL

GATT Characteristic Bluetooth SIG Data UUID Value.

BT_UUID_GATT_BT_SIG_D

GATT Characteristic Bluetooth SIG Data.

BT_UUID_GATT_SERVER_FEATURES_VAL

GATT Characteristic Server Supported Features UUID value.

BT_UUID_GATT_SERVER_FEATURES

GATT Characteristic Server Supported Features.

BT_UUID_GATT_PHY_AMF_VAL

GATT Characteristic Physical Activity Monitor Features UUID Value.

BT_UUID_GATT_PHY_AMF

GATT Characteristic Physical Activity Monitor Features.

BT_UUID_GATT_GEN_AID_VAL

GATT Characteristic General Activity Instantaneous Data UUID Value.

BT_UUID_GATT_GEN_AID

GATT Characteristic General Activity Instantaneous Data.

BT_UUID_GATT_GEN_ASD_VAL

GATT Characteristic General Activity Summary Data UUID Value.

BT_UUID_GATT_GEN_ASD

GATT Characteristic General Activity Summary Data.

BT_UUID_GATT_CR_AID_VAL

GATT Characteristic CardioRespiratory Activity Instantaneous Data UUID Value.

BT_UUID_GATT_CR_AID

GATT Characteristic CardioRespiratory Activity Instantaneous Data.

BT_UUID_GATT_CR_ASD_VAL

GATT Characteristic CardioRespiratory Activity Summary Data UUID Value.

BT_UUID_GATT_CR_ASD

GATT Characteristic CardioRespiratory Activity Summary Data.

BT_UUID_GATT_SC_ASD_VAL

GATT Characteristic Step Counter Activity Summary Data UUID Value.

BT_UUID_GATT_SC_ASD

GATT Characteristic Step Counter Activity Summary Data.

BT_UUID_GATT_SLP_AID_VAL

GATT Characteristic Sleep Activity Instantaneous Data UUID Value.

BT_UUID_GATT_SLP_AID

GATT Characteristic Sleep Activity Instantaneous Data.

BT_UUID_GATT_SLP_ASD_VAL

GATT Characteristic Sleep Actiity Summary Data UUID Value.

BT_UUID_GATT_SLP_ASD

GATT Characteristic Sleep Activity Summary Data.

BT_UUID_GATT_PHY_AMCP_VAL

GATT Characteristic Physical Activity Monitor Control Point UUID Value.

BT_UUID_GATT_PHY_AMCP

GATT Characteristic Physical Activity Monitor Control Point.

BT_UUID_GATT_ACS_VAL

GATT Characteristic Activity Current Session UUID Value.

BT_UUID_GATT_ACS

GATT Characteristic Activity Current Session.

BT_UUID_GATT_PHY_ASDESC_VAL

GATT Characteristic Physical Activity Session Descriptor UUID Value.

BT_UUID_GATT_PHY_ASDESC

GATT Characteristic Physical Activity Session Descriptor.

BT_UUID_GATT_PREF_U_VAL

GATT Characteristic Preffered Units UUID Value.

BT_UUID_GATT_PREF_U

GATT Characteristic Preffered Units.

BT_UUID_GATT_HRES_H_VAL

GATT Characteristic High Resolution Height UUID Value.

BT_UUID_GATT_HRES_H

GATT Characteristic High Resolution Height.

BT_UUID_GATT_MID_NAME_VAL

GATT Characteristic Middle Name UUID Value.

BT_UUID_GATT_MID_NAME

GATT Characteristic Middle Name.

BT_UUID_GATT_STRDLEN_VAL

GATT Characteristic Stride Length UUID Value.

BT_UUID_GATT_STRDLEN

GATT Characteristic Stride Length.

BT_UUID_GATT_HANDEDNESS_VAL

GATT Characteristic Handedness UUID Value.

BT_UUID_GATT_HANDEDNESS

GATT Characteristic Handedness.

BT_UUID_GATT_DEVICE_WP_VAL

GATT Characteristic Device Wearing Position UUID Value.

BT_UUID_GATT_DEVICE_WP

GATT Characteristic Device Wearing Position.

BT_UUID_GATT_4ZHRL_VAL

GATT Characteristic Four Zone Heart Rate Limit UUID Value.

BT_UUID_GATT_4ZHRL

GATT Characteristic Four Zone Heart Rate Limit.

BT_UUID_GATT_HIET_VAL

GATT Characteristic High Intensity Exercise Threshold UUID Value.

BT_UUID_GATT_HIET

GATT Characteristic High Intensity Exercise Threshold.

BT_UUID_GATT_AG_VAL

GATT Characteristic Activity Goal UUID Value.

BT_UUID_GATT_AG

GATT Characteristic Activity Goal.

BT_UUID_GATT_SIN_VAL

GATT Characteristic Sedentary Interval Notification UUID Value.

BT_UUID_GATT_SIN

GATT Characteristic Sedentary Interval Notification.

BT_UUID_GATT_CI_VAL

GATT Characteristic Caloric Intake UUID Value.

BT_UUID_GATT_CI

GATT Characteristic Caloric Intake.

BT_UUID_GATT_TMAPR_VAL

GATT Characteristic TMAP Role UUID Value.

BT_UUID_GATT_TMAPR

GATT Characteristic TMAP Role.

BT_UUID_AICS_STATE_VAL

Audio Input Control Service State value.

BT_UUID_AICS_STATE

Audio Input Control Service State.

BT_UUID_AICS_GAIN_SETTINGS_VAL

Audio Input Control Service Gain Settings Properties value.

BT_UUID_AICS_GAIN_SETTINGS

Audio Input Control Service Gain Settings Properties.

BT_UUID_AICS_INPUT_TYPE_VAL

Audio Input Control Service Input Type value.

BT_UUID_AICS_INPUT_TYPE

Audio Input Control Service Input Type.

BT_UUID_AICS_INPUT_STATUS_VAL

Audio Input Control Service Input Status value.

BT_UUID_AICS_INPUT_STATUS

Audio Input Control Service Input Status.

BT_UUID_AICS_CONTROL_VAL

Audio Input Control Service Control Point value.

BT_UUID_AICS_CONTROL

Audio Input Control Service Control Point.

BT_UUID_AICS_DESCRIPTION_VAL

Audio Input Control Service Input Description value.

BT_UUID_AICS_DESCRIPTION

Audio Input Control Service Input Description.

BT_UUID_VCS_STATE_VAL

Volume Control Setting value.

BT_UUID_VCS_STATE

Volume Control Setting.

BT_UUID_VCS_CONTROL_VAL

Volume Control Control point value.

BT_UUID_VCS_CONTROL

Volume Control Control point.

BT_UUID_VCS_FLAGS_VAL

Volume Control Flags value.

BT_UUID_VCS_FLAGS

Volume Control Flags.

BT_UUID_VOCS_STATE_VAL

Volume Offset State value.

BT_UUID_VOCS_STATE

Volume Offset State.

BT_UUID_VOCS_LOCATION_VAL

Audio Location value.

BT_UUID_VOCS_LOCATION

Audio Location.

BT_UUID_VOCS_CONTROL_VAL

Volume Offset Control Point value.

BT_UUID_VOCS_CONTROL

Volume Offset Control Point.

BT_UUID_VOCS_DESCRIPTION_VAL

Volume Offset Audio Output Description value.

BT_UUID_VOCS_DESCRIPTION

Volume Offset Audio Output Description.

BT_UUID_CSIS_SET_SIRK_VAL

Set Identity Resolving Key value.

BT_UUID_CSIS_SET_SIRK

Set Identity Resolving Key.

BT_UUID_CSIS_SET_SIZE_VAL

Set size value.

BT_UUID_CSIS_SET_SIZE

Set size.

BT_UUID_CSIS_SET_LOCK_VAL

Set lock value.

BT_UUID_CSIS_SET_LOCK

Set lock.

BT_UUID_CSIS_RANK_VAL

Rank value.

BT_UUID_CSIS_RANK

Rank.

BT_UUID_GATT_EDKM_VAL

GATT Characteristic Encrypted Data Key Material UUID Value.

BT_UUID_GATT_EDKM

GATT Characteristic Encrypted Data Key Material.

BT_UUID_GATT_AE32_VAL

GATT Characteristic Apparent Energy 32 UUID Value.

BT_UUID_GATT_AE32

GATT Characteristic Apparent Energy 32.

BT_UUID_GATT_AP_VAL

GATT Characteristic Apparent Power UUID Value.

BT_UUID_GATT_AP

GATT Characteristic Apparent Power.

BT_UUID_GATT_CO2CONC_VAL

GATT Characteristic CO2 Concentration UUID Value.

BT_UUID_GATT_CO2CONC

GATT Characteristic CO2 Concentration.

BT_UUID_GATT_COS_VAL

GATT Characteristic Cosine of the Angle UUID Value.

BT_UUID_GATT_COS

GATT Characteristic Cosine of the Angle.

BT_UUID_GATT_DEVTF_VAL

GATT Characteristic Device Time Feature UUID Value.

BT_UUID_GATT_DEVTF

GATT Characteristic Device Time Feature.

BT_UUID_GATT_DEVTP_VAL

GATT Characteristic Device Time Parameters UUID Value.

BT_UUID_GATT_DEVTP

GATT Characteristic Device Time Parameters.

BT_UUID_GATT_DEVT_VAL

GATT Characteristic Device Time UUID Value.

BT_UUID_GATT_DEVT

GATT Characteristic String.

BT_UUID_GATT_DEVTCP_VAL

GATT Characteristic Device Time Control Point UUID Value.

BT_UUID_GATT_DEVTCP

GATT Characteristic Device Time Control Point.

BT_UUID_GATT_TCLD_VAL

GATT Characteristic Time Change Log Data UUID Value.

BT_UUID_GATT_TCLD

GATT Characteristic Time Change Log Data.

BT_UUID_MCS_PLAYER_NAME_VAL

Media player name value.

BT_UUID_MCS_PLAYER_NAME

Media player name.

BT_UUID_MCS_ICON_OBJ_ID_VAL

Media Icon Object ID value.

BT_UUID_MCS_ICON_OBJ_ID

Media Icon Object ID.

BT_UUID_MCS_ICON_URL_VAL

Media Icon URL value.

BT_UUID_MCS_ICON_URL

Media Icon URL.

BT_UUID_MCS_TRACK_CHANGED_VAL

Track Changed value.

BT_UUID_MCS_TRACK_CHANGED

Track Changed.

BT_UUID_MCS_TRACK_TITLE_VAL

Track Title value.

BT_UUID_MCS_TRACK_TITLE

Track Title.

BT_UUID_MCS_TRACK_DURATION_VAL

Track Duration value.

BT_UUID_MCS_TRACK_DURATION

Track Duration.

BT_UUID_MCS_TRACK_POSITION_VAL

Track Position value.

BT_UUID_MCS_TRACK_POSITION

Track Position.

BT_UUID_MCS_PLAYBACK_SPEED_VAL

Playback Speed value.

BT_UUID_MCS_PLAYBACK_SPEED

Playback Speed.

BT_UUID_MCS_SEEKING_SPEED_VAL

Seeking Speed value.

BT_UUID_MCS_SEEKING_SPEED

Seeking Speed.

BT_UUID_MCS_TRACK_SEGMENTS_OBJ_ID_VAL

Track Segments Object ID value.

BT_UUID_MCS_TRACK_SEGMENTS_OBJ_ID

Track Segments Object ID.

BT_UUID_MCS_CURRENT_TRACK_OBJ_ID_VAL

Current Track Object ID value.

BT_UUID_MCS_CURRENT_TRACK_OBJ_ID

Current Track Object ID.

BT_UUID_MCS_NEXT_TRACK_OBJ_ID_VAL

Next Track Object ID value.

BT_UUID_MCS_NEXT_TRACK_OBJ_ID

Next Track Object ID.

BT_UUID_MCS_PARENT_GROUP_OBJ_ID_VAL

Parent Group Object ID value.

BT_UUID_MCS_PARENT_GROUP_OBJ_ID

Parent Group Object ID.

BT_UUID_MCS_CURRENT_GROUP_OBJ_ID_VAL

Group Object ID value.

BT_UUID_MCS_CURRENT_GROUP_OBJ_ID

Group Object ID.

BT_UUID_MCS_PLAYING_ORDER_VAL

Playing Order value.

BT_UUID_MCS_PLAYING_ORDER

Playing Order.

BT_UUID_MCS_PLAYING_ORDERS_VAL

Playing Orders supported value.

BT_UUID_MCS_PLAYING_ORDERS

Playing Orders supported.

BT_UUID_MCS_MEDIA_STATE_VAL

Media State value.

BT_UUID_MCS_MEDIA_STATE

Media State.

BT_UUID_MCS_MEDIA_CONTROL_POINT_VAL

Media Control Point value.

BT_UUID_MCS_MEDIA_CONTROL_POINT

Media Control Point.

BT_UUID_MCS_MEDIA_CONTROL_OPCODES_VAL

Media control opcodes supported value.

BT_UUID_MCS_MEDIA_CONTROL_OPCODES

Media control opcodes supported.

BT_UUID_MCS_SEARCH_RESULTS_OBJ_ID_VAL

Search result object ID value.

BT_UUID_MCS_SEARCH_RESULTS_OBJ_ID

Search result object ID.

BT_UUID_MCS_SEARCH_CONTROL_POINT_VAL

Search control point value.

BT_UUID_MCS_SEARCH_CONTROL_POINT

Search control point.

BT_UUID_GATT_E32_VAL

GATT Characteristic Energy 32 UUID Value.

BT_UUID_GATT_E32

GATT Characteristic Energy 32.

BT_UUID_OTS_TYPE_MPL_ICON_VAL

Media Player Icon Object Type value.

BT_UUID_OTS_TYPE_MPL_ICON

Media Player Icon Object Type.

BT_UUID_OTS_TYPE_TRACK_SEGMENT_VAL

Track Segments Object Type value.

BT_UUID_OTS_TYPE_TRACK_SEGMENT

Track Segments Object Type.

BT_UUID_OTS_TYPE_TRACK_VAL

Track Object Type value.

BT_UUID_OTS_TYPE_TRACK

Track Object Type.

BT_UUID_OTS_TYPE_GROUP_VAL

Group Object Type value.

BT_UUID_OTS_TYPE_GROUP

Group Object Type.

BT_UUID_GATT_CTEE_VAL

GATT Characteristic Constant Tone Extension Enable UUID Value.

BT_UUID_GATT_CTEE

GATT Characteristic Constant Tone Extension Enable.

BT_UUID_GATT_ACTEML_VAL

GATT Characteristic Advertising Constant Tone Extension Minimum Length UUID Value.

BT_UUID_GATT_ACTEML

GATT Characteristic Advertising Constant Tone Extension Minimum Length.

BT_UUID_GATT_ACTEMTC_VAL

GATT Characteristic Advertising Constant Tone Extension Minimum Transmit Count UUID Value.

BT_UUID_GATT_ACTEMTC

GATT Characteristic Advertising Constant Tone Extension Minimum Transmit Count.

BT_UUID_GATT_ACTETD_VAL

GATT Characteristic Advertising Constant Tone Extension Transmit Duration UUID Value.

BT_UUID_GATT_ACTETD

GATT Characteristic Advertising Constant Tone Extension Transmit Duration.

BT_UUID_GATT_ACTEI_VAL

GATT Characteristic Advertising Constant Tone Extension Interval UUID Value.

BT_UUID_GATT_ACTEI

GATT Characteristic Advertising Constant Tone Extension Interval.

BT_UUID_GATT_ACTEP_VAL

GATT Characteristic Advertising Constant Tone Extension PHY UUID Value.

BT_UUID_GATT_ACTEP

GATT Characteristic Advertising Constant Tone Extension PHY.

BT_UUID_TBS_PROVIDER_NAME_VAL

Bearer Provider Name value.

BT_UUID_TBS_PROVIDER_NAME

Bearer Provider Name.

BT_UUID_TBS_UCI_VAL

Bearer UCI value.

BT_UUID_TBS_UCI

Bearer UCI.

BT_UUID_TBS_TECHNOLOGY_VAL

Bearer Technology value.

BT_UUID_TBS_TECHNOLOGY

Bearer Technology.

BT_UUID_TBS_URI_LIST_VAL

Bearer URI Prefixes Supported List value.

BT_UUID_TBS_URI_LIST

Bearer URI Prefixes Supported List.

BT_UUID_TBS_SIGNAL_STRENGTH_VAL

Bearer Signal Strength value.

BT_UUID_TBS_SIGNAL_STRENGTH

Bearer Signal Strength.

BT_UUID_TBS_SIGNAL_INTERVAL_VAL

Bearer Signal Strength Reporting Interval value.

BT_UUID_TBS_SIGNAL_INTERVAL

Bearer Signal Strength Reporting Interval.

BT_UUID_TBS_LIST_CURRENT_CALLS_VAL

Bearer List Current Calls value.

BT_UUID_TBS_LIST_CURRENT_CALLS

Bearer List Current Calls.

BT_UUID_CCID_VAL

Content Control ID value.

BT_UUID_CCID

Content Control ID.

BT_UUID_TBS_STATUS_FLAGS_VAL

Status flags value.

BT_UUID_TBS_STATUS_FLAGS

Status flags.

BT_UUID_TBS_INCOMING_URI_VAL

Incoming Call Target Caller ID value.

BT_UUID_TBS_INCOMING_URI

Incoming Call Target Caller ID.

BT_UUID_TBS_CALL_STATE_VAL

Call State value.

BT_UUID_TBS_CALL_STATE

Call State.

BT_UUID_TBS_CALL_CONTROL_POINT_VAL

Call Control Point value.

BT_UUID_TBS_CALL_CONTROL_POINT

Call Control Point.

BT_UUID_TBS_OPTIONAL_OPCODES_VAL

Optional Opcodes value.

BT_UUID_TBS_OPTIONAL_OPCODES

Optional Opcodes.

BT_UUID_TBS_TERMINATE_REASON_VAL

Terminate reason value.

BT_UUID_TBS_TERMINATE_REASON_VAL

BT_UUID_TBS_TERMINATE_REASON

Terminate reason.

BT_UUID_TBS_TERMINATE_REASON

BT_UUID_TBS_INCOMING_CALL_VAL

Incoming Call value.

BT_UUID_TBS_INCOMING_CALL

Incoming Call.

BT_UUID_TBS_FRIENDLY_NAME_VAL

Incoming Call Friendly name value.

BT_UUID_TBS_FRIENDLY_NAME

Incoming Call Friendly name.

BT_UUID_MICS_MUTE_VAL

Microphone Control Service Mute value.

BT_UUID_MICS_MUTE

Microphone Control Service Mute.

BT_UUID_ASCS_ASE_SNK_VAL

Audio Stream Endpoint Sink Characteristic value.

BT_UUID_ASCS_ASE_SNK

Audio Stream Endpoint Sink Characteristic.

BT_UUID_ASCS_ASE_SRC_VAL

Audio Stream Endpoint Source Characteristic value.

BT_UUID_ASCS_ASE_SRC

Audio Stream Endpoint Source Characteristic.

BT_UUID_ASCS_ASE_CP_VAL

Audio Stream Endpoint Control Point Characteristic value.

BT_UUID_ASCS_ASE_CP

Audio Stream Endpoint Control Point Characteristic.

BT_UUID_BASS_CONTROL_POINT_VAL

Broadcast Audio Scan Service Scan State value.

BT_UUID_BASS_CONTROL_POINT

Broadcast Audio Scan Service Scan State.

BT_UUID_BASS_RECV_STATE_VAL

Broadcast Audio Scan Service Receive State value.

BT_UUID_BASS_RECV_STATE

Broadcast Audio Scan Service Receive State.

BT_UUID_PACS_SNK_VAL

Sink PAC Characteristic value.

BT_UUID_PACS_SNK

Sink PAC Characteristic.

BT_UUID_PACS_SNK_LOC_VAL

Sink PAC Locations Characteristic value.

BT_UUID_PACS_SNK_LOC

Sink PAC Locations Characteristic.

BT_UUID_PACS_SRC_VAL

Source PAC Characteristic value.

BT_UUID_PACS_SRC

Source PAC Characteristic.

BT_UUID_PACS_SRC_LOC_VAL

Source PAC Locations Characteristic value.

BT_UUID_PACS_SRC_LOC

Source PAC Locations Characteristic.

BT_UUID_PACS_AVAILABLE_CONTEXT_VAL

Available Audio Contexts Characteristic value.

BT_UUID_PACS_AVAILABLE_CONTEXT

Available Audio Contexts Characteristic.

BT_UUID_PACS_SUPPORTED_CONTEXT_VAL

Supported Audio Context Characteristic value.

BT_UUID_PACS_SUPPORTED_CONTEXT

Supported Audio Context Characteristic.

BT_UUID_GATT_NH4CONC_VAL

GATT Characteristic Ammonia Concentration UUID Value.

BT_UUID_GATT_NH4CONC

GATT Characteristic Ammonia Concentration.

BT_UUID_GATT_COCONC_VAL

GATT Characteristic Carbon Monoxide Concentration UUID Value.

BT_UUID_GATT_COCONC

GATT Characteristic Carbon Monoxide Concentration.

BT_UUID_GATT_CH4CONC_VAL

GATT Characteristic Methane Concentration UUID Value.

BT_UUID_GATT_CH4CONC

GATT Characteristic Methane Concentration.

BT_UUID_GATT_NO2CONC_VAL

GATT Characteristic Nitrogen Dioxide Concentration UUID Value.

BT_UUID_GATT_NO2CONC

GATT Characteristic Nitrogen Dioxide Concentration.

BT_UUID_GATT_NONCH4CONC_VAL

GATT Characteristic Non-Methane Volatile Organic Compounds Concentration UUID Value.

BT_UUID_GATT_NONCH4CONC

GATT Characteristic Non-Methane Volatile Organic Compounds Concentration.

BT_UUID_GATT_O3CONC_VAL

GATT Characteristic Ozone Concentration UUID Value.

BT_UUID_GATT_O3CONC

GATT Characteristic Ozone Concentration.

BT_UUID_GATT_PM1CONC_VAL

GATT Characteristic Particulate Matter - PM1 Concentration UUID Value.

BT_UUID_GATT_PM1CONC

GATT Characteristic Particulate Matter - PM1 Concentration.

BT_UUID_GATT_PM25CONC_VAL

GATT Characteristic Particulate Matter - PM2.5 Concentration UUID Value.

BT_UUID_GATT_PM25CONC

GATT Characteristic Particulate Matter - PM2.5 Concentration.

BT_UUID_GATT_PM10CONC_VAL

GATT Characteristic Particulate Matter - PM10 Concentration UUID Value.

BT_UUID_GATT_PM10CONC

GATT Characteristic Particulate Matter - PM10 Concentration.

BT_UUID_GATT_SO2CONC_VAL

GATT Characteristic Sulfur Dioxide Concentration UUID Value.

BT_UUID_GATT_SO2CONC

GATT Characteristic Sulfur Dioxide Concentration.

BT_UUID_GATT_SF6CONC_VAL

GATT Characteristic Sulfur Hexafluoride Concentration UUID Value.

BT_UUID_GATT_SF6CONC

GATT Characteristic Sulfur Hexafluoride Concentration.

BT_UUID_HAS_HEARING_AID_FEATURES_VAL

Hearing Aid Features Characteristic value.

BT_UUID_HAS_HEARING_AID_FEATURES

Hearing Aid Features Characteristic.

BT_UUID_HAS_PRESET_CONTROL_POINT_VAL

Hearing Aid Preset Control Point Characteristic value.

BT_UUID_HAS_PRESET_CONTROL_POINT

Hearing Aid Preset Control Point Characteristic.

BT_UUID_HAS_ACTIVE_PRESET_INDEX_VAL

Active Preset Index Characteristic value.

BT_UUID_HAS_ACTIVE_PRESET_INDEX

Active Preset Index Characteristic.

BT_UUID_GATT_FSTR64_VAL

GATT Characteristic Fixed String 64 UUID Value.

BT_UUID_GATT_FSTR64

GATT Characteristic Fixed String 64.

BT_UUID_GATT_HITEMP_VAL

GATT Characteristic High Temperature UUID Value.

BT_UUID_GATT_HITEMP

GATT Characteristic High Temperature.

BT_UUID_GATT_HV_VAL

GATT Characteristic High Voltage UUID Value.

BT_UUID_GATT_HV

GATT Characteristic High Voltage.

BT_UUID_GATT_LD_VAL

GATT Characteristic Light Distribution UUID Value.

BT_UUID_GATT_LD

GATT Characteristic Light Distribution.

BT_UUID_GATT_LO_VAL

GATT Characteristic Light Output UUID Value.

BT_UUID_GATT_LO

GATT Characteristic Light Output.

BT_UUID_GATT_LST_VAL

GATT Characteristic Light Source Type UUID Value.

BT_UUID_GATT_LST

GATT Characteristic Light Source Type.

BT_UUID_GATT_NOISE_VAL

GATT Characteristic Noise UUID Value.

BT_UUID_GATT_NOISE

GATT Characteristic Noise.

BT_UUID_GATT_RRCCTP_VAL

GATT Characteristic Relative Runtime in a Correlated Color Temperature Range UUID Value.

BT_UUID_GATT_RRCCTR

GATT Characteristic Relative Runtime in a Correlated Color Temperature Range.

BT_UUID_GATT_TIM_S32_VAL

GATT Characteristic Time Second 32 UUID Value.

BT_UUID_GATT_TIM_S32

GATT Characteristic Time Second 32.

BT_UUID_GATT_VOCCONC_VAL

GATT Characteristic VOC Concentration UUID Value.

BT_UUID_GATT_VOCCONC

GATT Characteristic VOC Concentration.

BT_UUID_GATT_VF_VAL

GATT Characteristic Voltage Frequency UUID Value.

BT_UUID_GATT_VF

GATT Characteristic Voltage Frequency.

BT_UUID_BAS_BATTERY_CRIT_STATUS_VAL

BAS Characteristic Battery Critical Status UUID Value.

BT_UUID_BAS_BATTERY_CRIT_STATUS

BAS Characteristic Battery Critical Status.

BT_UUID_BAS_BATTERY_HEALTH_STATUS_VAL

BAS Characteristic Battery Health Status UUID Value.

BT_UUID_BAS_BATTERY_HEALTH_STATUS

BAS Characteristic Battery Health Status.

BT_UUID_BAS_BATTERY_HEALTH_INF_VAL

BAS Characteristic Battery Health Information UUID Value.

BT_UUID_BAS_BATTERY_HEALTH_INF

BAS Characteristic Battery Health Information.

BT_UUID_BAS_BATTERY_INF_VAL

BAS Characteristic Battery Information UUID Value.

BT_UUID_BAS_BATTERY_INF

BAS Characteristic Battery Information.

BT_UUID_BAS_BATTERY_LEVEL_STATUS_VAL

BAS Characteristic Battery Level Status UUID Value.

BT_UUID_BAS_BATTERY_LEVEL_STATUS

BAS Characteristic Battery Level Status.

BT_UUID_BAS_BATTERY_TIME_STATUS_VAL

BAS Characteristic Battery Time Status UUID Value.

BT_UUID_BAS_BATTERY_TIME_STATUS

BAS Characteristic Battery Time Status.

BT_UUID_GATT_ESD_VAL

GATT Characteristic Estimated Service Date UUID Value.

BT_UUID_GATT_ESD

GATT Characteristic Estimated Service Date.

BT_UUID_BAS_BATTERY_ENERGY_STATUS_VAL

BAS Characteristic Battery Energy Status UUID Value.

BT_UUID_BAS_BATTERY_ENERGY_STATUS

BAS Characteristic Battery Energy Status.

BT_UUID_GATT_SL_VAL

GATT Characteristic LE GATT Security Levels UUID Value.

BT_UUID_GATT_SL

GATT Characteristic LE GATT Security Levels.

BT_UUID_RTUS_TIME_UPDATE_STATE_VAL

RTUS Characteristic Time Update State UUID value.

BT_UUID_RTUS_TIME_UPDATE_STATE

RTUS Characteristic Time Update State.

BT_UUID_RTUS_CONTROL_POINT_VAL

RTUS Characteristic Time Update COntrol Point UUID value.

BT_UUID_RTUS_CONTROL_POINT

RTUS Characteristic Time Update COntrol Point.

BT_UUID_CTS_LOCAL_TIME_INFORMATION_VAL

CTS Characteristic Local Time Information UUID value.

BT_UUID_CTS_LOCAL_TIME_INFORMATION

CTS Characteristic Local Time Information.

BT_UUID_CTS_REFERENCE_TIME_INFORMATION_VAL

CTS Characteristic Reference Time Information UUID value.

BT_UUID_CTS_REFERENCE_TIME_INFORMATION

CTS Characteristic Reference Time Information.

BT_UUID_NDTS_VAL

Next DST Change UUID value.

BT_UUID_NDTS

Next DST Change.

BT_UUID_NDTS_TIME_WITH_DTS_VAL

NDTS Time with DST UUID value.

BT_UUID_NDTS_TIME_WITH_DTS

Time with DST.

BT_UUID_GMAS_VAL

Gaming Service UUID value.

BT_UUID_GMAS

Common Audio Service.

BT_UUID_GMAP_ROLE_VAL

Gaming Audio Profile Role UUID value.

BT_UUID_GMAP_ROLE

Gaming Audio Profile Role.

BT_UUID_GMAP_UGG_FEAT_VAL

Gaming Audio Profile Unicast Game Gateway Features UUID value.

BT_UUID_GMAP_UGG_FEAT

Gaming Audio Profile Unicast Game Gateway Features.

BT_UUID_GMAP_UGT_FEAT_VAL

Gaming Audio Profile Unicast Game Terminal Features UUID value.

BT_UUID_GMAP_UGT_FEAT

Gaming Audio Profile Unicast Game Terminal Features.

BT_UUID_GMAP_BGS_FEAT_VAL

Gaming Audio Profile Broadcast Game Sender Features UUID value.

BT_UUID_GMAP_BGS_FEAT

Gaming Audio Profile Broadcast Game Sender Features.

BT_UUID_GMAP_BGR_FEAT_VAL

Gaming Audio Profile Broadcast Game Receiver Features UUID value.

BT_UUID_GMAP_BGR_FEAT

Gaming Audio Profile Broadcast Game Receiver Features.

BT_UUID_SDP_VAL
BT_UUID_SDP
BT_UUID_UDP_VAL
BT_UUID_UDP
BT_UUID_RFCOMM_VAL
BT_UUID_RFCOMM
BT_UUID_TCP_VAL
BT_UUID_TCP
BT_UUID_TCS_BIN_VAL
BT_UUID_TCS_BIN
BT_UUID_TCS_AT_VAL
BT_UUID_TCS_AT
BT_UUID_ATT_VAL
BT_UUID_ATT
BT_UUID_OBEX_VAL
BT_UUID_OBEX
BT_UUID_IP_VAL
BT_UUID_IP
BT_UUID_FTP_VAL
BT_UUID_FTP
BT_UUID_HTTP_VAL

BT_UUID_HTTP
BT_UUID_WSP_VAL
BT_UUID_WSP
BT_UUID_BNEP_VAL
BT_UUID_BNEP
BT_UUID_UPNP_VAL
BT_UUID_UPNP
BT_UUID_HIDP_VAL
BT_UUID_HIDP
BT_UUID_HCRP_CTRL_VAL
BT_UUID_HCRP_CTRL
BT_UUID_HCRP_DATA_VAL
BT_UUID_HCRP_DATA
BT_UUID_HCRP_NOTE_VAL
BT_UUID_HCRP_NOTE
BT_UUID_AVCTP_VAL
BT_UUID_AVCTP
BT_UUID_AVDTP_VAL
BT_UUID_AVDTP
BT_UUID_CMTP_VAL
BT_UUID_CMTP

```
BT_UUID_UDI_VAL

BT_UUID_UDI

BT_UUID_MCAP_CTRL_VAL

BT_UUID_MCAP_CTRL

BT_UUID_MCAP_DATA_VAL

BT_UUID_MCAP_DATA

BT_UUID_L2CAP_VAL

BT_UUID_L2CAP
```

Enums

```
Bluetooth UUID types.

Values:

enumerator BT_UUID_TYPE_16

UUID type 16-bit.

enumerator BT_UUID_TYPE_32

UUID type 32-bit.

enumerator BT_UUID_TYPE_128

UUID type 128-bit.
```

Functions

```
int bt_uuid_cmp(const struct bt_uuid *u1, const struct bt_uuid *u2)
```

Compare Bluetooth UUIDs.

Compares 2 Bluetooth UUIDs, if the types are different both UUIDs are first converted to 128 bits format before comparing.

Parameters

- **u1** First Bluetooth UUID to compare
- u2 Second Bluetooth UUID to compare

Returns negative value if u1 < u2, 0 if u1 == u2, else positive

bool **bt_uuid_create**(struct *bt_uuid* *uuid, const uint8_t *data, uint8_t data_len)

Create a bt_uuid from a little-endian data buffer.

Create a *bt_uuid* from a little-endian data buffer. The data_len parameter is used to determine whether the UUID is in 16, 32 or 128 bit format (length 2, 4 or 16). Note: 32 bit format is not allowed over the air.

Parameters

- **uuid** Pointer to the *bt_uuid* variable
- data pointer to UUID stored in little-endian data buffer
- data_len length of the UUID in the data buffer

Returns true if the data was valid and the UUID was successfully created.

```
void bt_uuid_to_str(const struct bt_uuid *uuid, char *str, size_t len)
```

Convert Bluetooth UUID to string.

Converts Bluetooth UUID to string. UUID can be in any format, 16-bit, 32-bit or 128-bit.

Parameters

- uuid Bluetooth UUID
- **str** pointer where to put converted string
- len length of str

struct bt_uuid

#include <uuid.h> This is a 'tentative' type and should be used as a pointer only.

struct bt_uuid_16

#include <uuid.h>

Public Members

struct bt uuid uuid

UUID generic type.

uint 16_t val

UUID value, 16-bit in host endianness.

struct bt_uuid_32

#include <uuid.h>

Public Members

```
struct bt_uuid uuid

UUID generic type.

uint32_t val

UUID value, 32-bit in host endianness.

struct bt_uuid_128

#include <uuid.h>

Public Members

struct bt_uuid uuid

UUID generic type.

uint8_t val[16]

UUID value, 128-bit in little-endian format.
```

1.15 services

1.15.1 HTTP Proxy Service (HPS)

1.15.1.1 API Reference

```
group bt_hps
```

HTTP Proxy Service (HPS).

[Experimental] Users should note that the APIs can change as a part of ongoing development.

Defines

MAX_URI_LEN

MAX_HEADERS_LEN

MAX_BODY_LEN

Typedefs


```
typedef uint8_t hps_data_status_t
typedef uint8_t hps_http_command_t
typedef uint8_t hps_state_t
typedef uint8_t hps_flags_t
```

Enums

```
Values:
enumerator HPS_HEADERS_RECEIVED
enumerator HPS_HEADERS_TRUNCATED
enumerator HPS_BODY_RECEIVED
enumerator HPS_BODY_TRUNCATED
Values:
enumerator HTTP_GET_REQ
enumerator HTTP_HEAD_REQ
enumerator HTTP_POST_REQ
enumerator HTTP_PUT_REQ
enumerator HTTP_DELETE_REQ
enumerator HTTPS_GET_REQ
enumerator HTTPS_HEAD_REQ
```

enumerator HTTPS_POST_REQ

1.15. services 311



Functions

```
ssize_t write_http_headers(struct bt_conn *conn, const struct bt_gatt_attr *attr, const void *buf, uint16_t
                               len, uint16_t offset, uint8_t flags)
     HTTP Headers GATT write callback.
     If called with conn == NULL, it is a local write.
         Returns Number of bytes written.
ssize_t write_http_entity_body(struct bt_conn *conn, const struct bt_gatt_attr *attr, const void *buf,
                                    uint16_t len, uint16_t offset, uint8_t flags)
     HTTP Entity Body GATT write callback.
     If called with conn == NULL, it is a local write.
          Returns Number of bytes written.
int bt_hps_init(osa_msgq_handle_t queue)
     HTTP Proxy Server initialization.
         Returns Zero in case of success and error code in case of error.
void bt_hps_set_status_code(uint16_t http_status)
     Sets Status Code after HTTP request was fulfilled.
int bt_hps_notify(void)
     Notify HTTP Status after Request was fulfilled.
     This will send a GATT notification to the subscriber.
         Returns Zero in case of success and error code in case of error.
struct hps_status_t
     #include <hps.h>
```

1.15.2 Health Thermometer Service (HTS)

1.15.2.1 API Reference

struct hps_config_t

#include <hps.h>

group bt_hts

Health Thermometer Service (HTS).

[Experimental] Users should note that the APIs can change as a part of ongoing development.

1.15. services 313

Defines

```
hts_unit_celsius_c
hts_unit_fahrenheit_c
hts_include_temp_type
```

Enums

```
enumerator hts_no_temp_type
enumerator hts_armpit
enumerator hts_body
enumerator hts_ear
enumerator hts_finger
enumerator hts_gastroInt
enumerator hts_mouth
enumerator hts_rectum
enumerator hts_toe
enumerator hts_tympanum
```

Functions

```
void bt_hts_indicate(void)
```

Notify indicate a temperature measurement.

This will send a GATT indication to all current subscribers. Awaits an indication response from peer.

Parameters

• none. -

Returns Zero in case of success and error code in case of error.

struct temp_measurement

#include <hts.h>

1.15.3 Internet Protocol Support Profile (IPSP)

1.15.3.1 API Reference

group bt_ipsp

Internet Protocol Support Profile (IPSP).

Defines

USER_DATA_MIN

Typedefs

typedef int (*ipsp_rx_cb_t)(struct net_buf *buf)

Functions

```
int ipsp_init(ipsp_rx_cb_t pf_rx_cb)
```

Initialize the service.

This will setup the data receive callback.

Parameters

• **pf_rx_cb** – Pointer to the callback used for receiving data.

Returns Zero in case of success and error code in case of error.

```
int ipsp_connect(struct bt_conn *conn)
```

Start a connection to an IPSP Node using this connection.

This will try to connect to the Node present.

Parameters

• conn – Pointer to the connection to be used.

Returns Zero in case of success and error code in case of error.

int ipsp_send(struct net_buf *buf)

Send data to the peer IPSP Node/Router.

Parameters

• conn – Pointer to the buffer containing data.

Returns Zero in case of success and error code in case of error.

1.15. services 315

```
int ipsp_listen(void)
Setup an IPSP Server.
```

Returns Zero in case of success and error code in case of error.

1.15.4 Proximity Reporter (PXR)

1.15.4.1 API Reference

```
group bt_pxr
Proximity Reporter (PXR) .

Typedefs

typedef void (*alert_ui_cb)(uint8_t param)
```

Enums

```
Values:
enumerator NO_ALERT
enumerator MILD_ALERT
enumerator HIGH_ALERT
```

If called with conn == NULL, it is a local write.

Functions

```
ssize_t write_ias_alert_level(struct bt_conn *conn, const struct bt_gatt_attr *attr, const void *buf, uint16_t len, uint16_t offset, uint8_t flags)

IAS Alert Level GATT write callback.

If called with conn == NULL, it is a local write.

Returns Number of bytes written.

ssize_t read_lls_alert_level(struct bt_conn *conn, const struct bt_gatt_attr *attr, void *buf, uint16_t len, uint16_t offset)

IAS Alert Level GATT read callback.

Returns Number of bytes read.

ssize_t write_lls_alert_level(struct bt_conn *conn, const struct bt_gatt_attr *attr, const void *buf, uint16_t len, uint16_t offset, uint8_t flags)

LLS Alert Level GATT write callback.
```

Returns Number of bytes written.

ssize_t read_tps_power_level(struct bt_conn *conn, const struct bt_gatt_attr *attr, void *buf, uint16_t len, uint16_t offset)

TPS Power Level GATT read callback.

Returns Number of bytes read.

ssize_t read_tps_power_level_desc(struct bt_conn *conn, const struct bt_gatt_attr *attr, void *buf, uint16 t len, uint16 t offset)

TPS Power Level Descriptor GATT read callback.

Returns Number of bytes read.

uint8_t pxr_lls_get_alert_level(void)

Read LLS Alert Level locally.

Returns Number of bytes written.

uint8_t pxr_ias_get_alert_level(void)

Read IAS Alert Level locally.

Returns Number of bytes written.

int8_t pxr_tps_get_power_level(void)

Read TPS Power Level locally.

Returns Number of bytes written.

void pxr_tps_set_power_level(int8_t power_level)

Write TPS Power Level locally.

Returns Number of bytes written.

int pxr_init(alert_ui_cb cb)

Initialize PXR Service.

Returns Success or error.

int pxr_deinit(void)

Deinitialize PXR Service.

Returns Success or error.

1.15. services 317

INDEX

Symbols	_hfp_ag_call_status_t.hfp_ag_call_call_outgoing		
_BT_GATT_ATTRS_ARRAY_DEFINE (C macro), 120	(C enumerator), 150		
_BT_GATT_SERVICE_ARRAY_ITEM (C macro), 120	_hfp_ag_cind_t (C struct), 159		
_bt_gatt_ccc (C struct), 132	_hfp_ag_get_config(C struct), 159		
_bt_gatt_ccc.cfg (C var), 133	٨		
_bt_gatt_ccc.cfg_changed (C var), 133	A		
_bt_gatt_ccc.cfg_match(Cvar), 133	alert_ui_cb (<i>C type</i>), 316		
_bt_gatt_ccc.cfg_write(Cvar), 133	D		
_bt_gatt_ccc.value(<i>C var</i>), 133	В		
_bt_security(<i>C enum</i>), 6	bt_a2dp_codec_id(Cenum), 199		
_bt_security.BT_SECURITY_FORCE_PAIR (<i>C enu-merator</i>), 7	<pre>bt_a2dp_codec_id.BT_A2DP_ATRAC (C enumerator), 199</pre>		
_bt_security.BT_SECURITY_L0 (C enumerator), 6	<pre>bt_a2dp_codec_id.BT_A2DP_MPEG1 (C enumerator),</pre>		
_bt_security.BT_SECURITY_L1(C enumerator), 6	199		
_bt_security.BT_SECURITY_L2 (C enumerator), 6	<pre>bt_a2dp_codec_id.BT_A2DP_MPEG2 (C enumerator),</pre>		
_bt_security.BT_SECURITY_L3 (<i>C enumerator</i>), 6	199		
_bt_security.BT_SECURITY_L4 (C enumerator), 7	bt_a2dp_codec_id.BT_A2DP_SBC(Cenumerator), 199		
_bt_spp_callback (<i>C struct</i>), 207	bt_a2dp_codec_id.BT_A2DP_VENDOR(C enumerator),		
_hf_multiparty_call_option_t (C enum), 150	199		
_hf_multiparty_call_option_t.hf_multiparty_call_t_optdpncofdeve_ie (C struct), 202			
(C enumerator), 150	bt_a2dp_codec_ie.codec_ie(C var), 203		
_hf_multiparty_call_option_t.hf_multiparty_ca	lldt_opzdoncooer_ie.len (C var), 203		
(C enumerator), 150	bt_a2dp_configure (<i>C function</i>), 201		
_hf_multiparty_call_option_t.hf_multiparty_ca	ldt_opzdonconfigure_endpoint (C function), 201		
(C enumerator), 150	bt_a2dp_connect (C function), 200		
_hf_multiparty_call_option_t.hf_multiparty_ca	ldt_opzdoncohreet_cb (C struct), 204		
(C enumerator), 150	bt_a2dp_connect_cb.connected(C var), 204		
_hf_multiparty_call_option_t.hf_multiparty_ca	lbt_opidoncomect_cb.disconnected(Cvar), 204		
(C enumerator), 150	bt_a2dp_control_cb(C struct), 203		
_hf_volume_type_t (<i>C enum</i>), 149	bt_a2dp_control_cb.configured(C var), 204		
_hf_volume_type_t.hf_volume_type_mic (C enu-	bt_a2dp_control_cb.deconfigured(C var), 204		
merator), 149	bt_a2dp_control_cb.sink_streamer_data (C var),		
_hf_volume_type_t.hf_volume_type_speaker (C	204		
enumerator), 149	bt_a2dp_control_cb.start_play (C var), 204		
_hf_waiting_call_state_t (<i>C struct</i>), 160	bt_a2dp_control_cb.stop_play(Cvar), 204		
_hfp_ag_call_status_t (C enum), 149	bt_a2dp_deconfigure (C function), 202		
_hfp_ag_call_status_t.hfp_ag_call_call_active			
(C enumerator), 150	bt_a2dp_discover_peer_endpoint_cb_t (C type),		
_hfp_ag_call_status_t.hfp_ag_call_call_end	199		
(C enumerator), 150	bt_a2dp_discover_peer_endpoints (C function),		
_hfp_ag_call_status_t.hfp_ag_call_call_incomi			
(C enumerator), 150	bt_a2dp_endpoint (C struct), 204		
	- · · · · · · · · · · · · · · · · · · ·		

bt_a2dp_endpoint.capabilities (C var), 205 bt_a2dp_endpoint.codec_buffer (C var), 205 bt_a2dp_endpoint.codec_buffer_nocached (C var), 205 bt_a2dp_endpoint.codec_id (C var), 205 bt_a2dp_endpoint.config (C var), 205 bt_a2dp_endpoint.config (C var), 205 bt_a2dp_endpoint.info (C var), 205 bt_a2dp_endpoint.info (C var), 205 bt_a2dp_endpoint_config (C struct), 203 bt_a2dp_endpoint_config.media_config (C var), 203 bt_a2dp_endpoint_configure_result (C struct), 203 bt_a2dp_endpoint_configure_result.a2dp (C var), 203 bt_a2dp_endpoint_configure_result.config (C var), 203 bt_a2dp_endpoint_configure_result.config (C var), 203 bt_a2dp_endpoint_configure_result.config (C var), 203 bt_a2dp_endpoint_configure_result.configure_result.configure_result.configure_result.configure_result.configure_result.configure_result.a2dp_endpoint_configure_result.err (C var), 203	bt_addr_cmp (C function), 77 bt_addr_copy (C function), 78 bt_addr_eq (C function), 77 bt_addr_from_str (C function), 79 BT_ADDR_IS_NRPA (C macro), 77 BT_ADDR_IS_RPA (C macro), 77 BT_ADDR_IS_STATIC (C macro), 77 BT_ADDR_LE_ANONYMOUS (C macro), 76 BT_ADDR_LE_ANY (C macro), 77 bt_addr_le_any (C var), 80 bt_addr_le_cmp (C function), 78 bt_addr_le_create_nrpa (C function), 78 bt_addr_le_create_static (C function), 78 bt_addr_le_create_static (C function), 78 bt_addr_le_is_identity (C function), 79 bt_addr_le_is_identity (C function), 79 bt_addr_le_is_rpa (C function), 78 BT_ADDR_LE_NONE (C macro), 77 bt_addr_le_none (C var), 80
203	BT_ADDR_LE_PUBLIC (C macro), 76
BT_A2DP_ENDPOINT_INIT (C macro), 198	BT_ADDR_LE_PUBLIC_ID (C macro), 76
BT_A2DP_EP_CONTENT_PROTECTION_INIT (C macro), 197	BT_ADDR_LE_RANDOM (C macro), 76 BT_ADDR_LE_RANDOM_ID (C macro), 76
BT_A2DP_EP_DELAY_REPORTING_INIT (C macro), 197	BT_ADDR_LE_SIZE (C macro), 76
BT_A2DP_EP_HEADER_COMPRESSION_INIT (C macro),	BT_ADDR_LE_STR_LEN (C macro), 77
198	bt_addr_le_t (C struct), 80
BT_A2DP_EP_MULTIPLEXING_INIT (C macro), 198	bt_addr_le_to_str(C function), 79
BT_A2DP_EP_RECOVERY_SERVICE_INIT (C macro), 197	BT_ADDR_LE_UNRESOLVED (C macro), 76
${\tt BT_A2DP_EP_REPORTING_SERVICE_INIT} \ \ (C \ \ macro),$	BT_ADDR_NONE (C macro), 77
197	$bt_addr_none(C var), 80$
BT_A2DP_MPEG_1_2_IE_LENGTH (C macro), 197	BT_ADDR_SET_NRPA (C macro), 77
BT_A2DP_MPEG_2_4_IE_LENGTH (C macro), 197	BT_ADDR_SET_RPA (C macro), 77
bt_a2dp_reconfigure (C function), 202	BT_ADDR_SET_STATIC (C macro), 77
bt_a2dp_register_connect_callback (<i>C function</i>),	BT_ADDR_SIZE (C macro), 76
201 bt_a2dp_register_endpoint(C function), 200	BT_ADDR_STR_LEN (C macro), 77 bt_addr_t (C struct), 80
BT_A2DP_SBC_IE_LENGTH (C macro), 197	bt_addr_to_str (C function), 79
BT_A2DP_SBC_SINK_ENDPOINT (C macro), 198	BT_APPEARANCE_AIRCRAFT_LARGE_PASSENGER (C
BT_A2DP_SBC_SOURCE_ENDPOINT (C macro), 198	<i>macro</i>), 101
BT_A2DP_SINK_ENDPOINT_INIT (C macro), 198	BT_APPEARANCE_AIRCRAFT_LIGHT (C macro), 100
BT_A2DP_SINK_SBC_CODEC_BUFFER_NOCACHED_SIZE (C macro), 197	BT_APPEARANCE_AIRCRAFT_MICROLIGHT (C macro), 100
BT_A2DP_SINK_SBC_CODEC_BUFFER_SIZE (C macro), 197	$\begin{array}{cccccccccccccccccccccccccccccccccccc$
BT_A2DP_SOURCE_ENDPOINT_INIT (C macro), 198	BT_APPEARANCE_APPLIANCE_CLOTHES_IRON (C
BT_A2DP_SOURCE_SBC_CODEC_BUFFER_NOCACHED_SIZE	•
(C macro), 197	BT_APPEARANCE_APPLIANCE_CLOTHES_STEAMER (C
BT_A2DP_SOURCE_SBC_CODEC_BUFFER_SIZE (C	macro), 100
macro), 197	BT_APPEARANCE_APPLIANCE_COFFEE_MAKER (C
bt_a2dp_start (C function), 202	<i>macro</i>), 99
bt_a2dp_stop (C function), 202	BT_APPEARANCE_APPLIANCE_CURLING_IRON (C
BT_ADDR_ANY (C macro), 76	macro), 100
bt_addr_any (C var), 80	BT_APPEARANCE_APPLIANCE_DRYER (C macro), 99

320 Index

DT ADDEADANCE ADDITANCE EDECTED (C	DT ADDEADANCE AN FOULDMENT TIMED (C) 101
BT_APPEARANCE_APPLIANCE_FREEZER (C macro), 99 BT_APPEARANCE_APPLIANCE_HAIR_DRYER (C macro),	BT_APPEARANCE_AV_EQUIPMENT_TUNER (C macro), 101 BT_APPEARANCE_AV_EQUIPMENT_TURNTABLE (C
100	macro), 101
- 0 0	
BT_APPEARANCE_APPLIANCE_MICROWAVE (C macro), 99	BT_APPEARANCE_BLOOD_PRESSURE_ARM (C macro), 86
BT_APPEARANCE_APPLIANCE_OVEN (C macro), 99	BT_APPEARANCE_BLOOD_PRESSURE_WRIST (C macro),
BT_APPEARANCE_APPLIANCE_REFRIGERATOR (C	86
macro), 99	BT_APPEARANCE_COMPUTER_ALL_IN_ONE (C macro), 84
BT_APPEARANCE_APPLIANCE_RICE_COOKER (C macro),	BT_APPEARANCE_COMPUTER_BLADE_SERVER (C macro),
100	84
BT_APPEARANCE_APPLIANCE_ROBOTIC_VACUUM_CLEANE	
(C macro), 100	84
BT_APPEARANCE_APPLIANCE_TOASTER (C macro), 99	BT_APPEARANCE_COMPUTER_DESKTOP_WORKSTATION
BT_APPEARANCE_APPLIANCE_VACUUM_CLEANER (C	(C macro), 84
macro), 100	BT_APPEARANCE_COMPUTER_DETACHABLE (C macro), 84
BT_APPEARANCE_APPLIANCE_WASHING_MACHINE (C	${\tt BT_APPEARANCE_COMPUTER_DOCKING_STATION} \qquad (C$
macro), 99	<i>macro</i>), 84
BT_APPEARANCE_AUDIO_SINK_BOOKSHELF_SPEAKER	BT_APPEARANCE_COMPUTER_HANDHELD_PCPDA (C
(C macro), 97	<i>macro</i>), 84
BT_APPEARANCE_AUDIO_SINK_SOUNDBAR (C macro), 97	${\tt BT_APPEARANCE_COMPUTER_IOT_GATEWAY} \ (C \ macro),$
BT_APPEARANCE_AUDIO_SINK_SPEAKERPHONE (C	85
macro), 97	BT_APPEARANCE_COMPUTER_LAPTOP (C macro), 84
BT_APPEARANCE_AUDIO_SINK_STANDALONE_SPEAKER	BT_APPEARANCE_COMPUTER_MINI_PC (C macro), 85
(C macro), 97	${\tt BT_APPEARANCE_COMPUTER_PALMSIZE_PCPDA} \qquad (C$
BT_APPEARANCE_AUDIO_SINK_STANDMOUNTED_SPEAKER	macro), 84
(C macro), 97	BT_APPEARANCE_COMPUTER_SERVER_CLASS (C macro),
BT_APPEARANCE_AUDIO_SOURCE_ALARM (C macro), 97	84
BT_APPEARANCE_AUDIO_SOURCE_AUDITORIUM (C	BT_APPEARANCE_COMPUTER_STICK_PC (C macro), 85
<i>macro</i>), 98	BT_APPEARANCE_COMPUTER_TABLET (C macro), 84
BT_APPEARANCE_AUDIO_SOURCE_BELL (C macro), 97	${\tt BT_APPEARANCE_COMPUTER_WEARABLE_COMPUTER} (C$
BT_APPEARANCE_AUDIO_SOURCE_BROADCASTING_DEVIC	EE macro), 84
(C macro), 97	BT_APPEARANCE_CONTINUOUS_GLUCOSE_MONITOR (C
BT_APPEARANCE_AUDIO_SOURCE_BROADCASTING_ROOM	<i>macro</i>), 103
(C macro), 98	BT_APPEARANCE_CONTROL_ACCESS_DOOR (C macro), 94
BT_APPEARANCE_AUDIO_SOURCE_HORN (C macro), 97	BT_APPEARANCE_CONTROL_ACCESS_LOCK (C macro), 94
BT_APPEARANCE_AUDIO_SOURCE_KIOSK (C macro), 98	BT_APPEARANCE_CONTROL_BATTERY_SWITCH (C
BT_APPEARANCE_AUDIO_SOURCE_MICROPHONE (C	macro), 88
<i>macro</i>), 97	BT_APPEARANCE_CONTROL_BUTTON (C macro), 88
	BT_APPEARANCE_CONTROL_DOOR_LOCK (C macro), 94
macro), 98	BT_APPEARANCE_CONTROL_DOUBLE_SWITCH (C macro),
BT_APPEARANCE_AV_EQUIPMENT_AMPLIFIER (C	88
macro), 101	BT_APPEARANCE_CONTROL_ELEVATOR (C macro), 94
BT_APPEARANCE_AV_EQUIPMENT_BLURAY_PLAYER (C	BT_APPEARANCE_CONTROL_EMERGENCY_EXIT_DOOR (C
macro), 101	macro), 94
BT_APPEARANCE_AV_EQUIPMENT_CD_PLAYER (C	BT_APPEARANCE_CONTROL_ENERGY_HARVESTING_SWITCH
macro), 101	(C macro), 88
BT_APPEARANCE_AV_EQUIPMENT_DVD_PLAYER (C	BT_APPEARANCE_CONTROL_ENTRANCE_GATE (C macro),
macro), 101	94
BT_APPEARANCE_AV_EQUIPMENT_OPTICAL_DISC_PLAYE	
(C macro), 101	BT_APPEARANCE_CONTROL_LOCKER (C macro), 95
BT_APPEARANCE_AV_EQUIPMENT_RADIO (C macro), 101	BT_APPEARANCE_CONTROL_MULTI_SWITCH (C macro),
	88
BT_APPEARANCE_AV_EQUIPMENT_RECEIVER (C macro), 101	
	BT_APPEARANCE_CONTROL_PUSH_BUTTON (C macro), 88
BT_APPEARANCE_AV_EQUIPMENT_SET_TOP_BOX (C	BT_APPEARANCE_CONTROL_ROTARY_SWITCH (C macro),
<i>macro</i>), 101	88

Index 321

BT_APPEARANCE_CONTROL_SINGLE_SWITCH (C macro),	BT_APPEARANCE_GENERIC_HEARING_AID (C macro),
88	102
BT_APPEARANCE_CONTROL_SLIDER (C macro), 88	BT_APPEARANCE_GENERIC_HEART_RATE (C macro), 86
BT_APPEARANCE_CONTROL_SWITCH (C macro), 87	BT_APPEARANCE_GENERIC_HEATING (C macro), 93
BT_APPEARANCE_CONTROL_TOUCH_PANEL (C macro), 88	BT_APPEARANCE_GENERIC_HID (C macro), 86
BT_APPEARANCE_CONTROL_TRIPLE_SWITCH (C macro),	BT_APPEARANCE_GENERIC_HUMIDIFIER (C macro), 93
88	BT_APPEARANCE_GENERIC_HVAC (C macro), 92
BT_APPEARANCE_CONTROL_WINDOW (C macro), 94	$BT_APPEARANCE_GENERIC_INSULIN_PUMP$ (C macro),
BT_APPEARANCE_CYCLING_CADENCE (C macro), 87	103
BT_APPEARANCE_CYCLING_COMPUTER (C macro), 87	BT_APPEARANCE_GENERIC_KEYRING (C macro), 85
BT_APPEARANCE_CYCLING_POWER (C macro), 87	$BT_APPEARANCE_GENERIC_LIGHT_FIXTURES$ (C
BT_APPEARANCE_CYCLING_SPEED (C macro), 87	<i>macro</i>), 90
BT_APPEARANCE_CYCLING_SPEED_CADENCE (C macro),	BT_APPEARANCE_GENERIC_LIGHT_SOURCE (C macro),
87	96
BT_APPEARANCE_DISPLAY_EQUIPMENT_MONITOR (C	BT_APPEARANCE_GENERIC_MEDIA_PLAYER (C macro),
<i>macro</i>), 101	85
BT_APPEARANCE_DISPLAY_EQUIPMENT_PROJECTOR (C	${\tt BT_APPEARANCE_GENERIC_MEDICATION_DELIVERY}\ (C$
<i>macro</i>), 102	<i>macro</i>), 103
BT_APPEARANCE_DISPLAY_EQUIPMENT_TELEVISION	BT_APPEARANCE_GENERIC_MOTORIZED_DEVICE (C
(C macro), 101	macro), 95
BT_APPEARANCE_FAN_AXIAL (C macro), 92	${\tt BT_APPEARANCE_GENERIC_MOTORIZED_VEHICLE} \hspace{0.5cm} (C$
BT_APPEARANCE_FAN_CEILING (C macro), 92	macro), 98
BT_APPEARANCE_FAN_DESK (C macro), 92	${\tt BT_APPEARANCE_GENERIC_NETWORK_DEVICE} \qquad \qquad (C$
BT_APPEARANCE_FAN_EXHAUST (C macro), 92	macro), 88
BT_APPEARANCE_FAN_PEDESTAL (C macro), 92	${\tt BT_APPEARANCE_GENERIC_OUTDOOR_SPORTS} \qquad \qquad (C$
BT_APPEARANCE_FAN_WALL (C macro), 92	<i>macro</i>), 103
BT_APPEARANCE_GENERIC_ACCESS_CONTROL (C	BT_APPEARANCE_GENERIC_PERSONAL_MOBILITY_DEVICE
macro), 94	(C macro), 103
$BT_APPEARANCE_GENERIC_AIR_CONDITIONING$ (C	BT_APPEARANCE_GENERIC_PHONE (C macro), 84
macro), 93	BT_APPEARANCE_GENERIC_POWER_DEVICE (C macro),
BT_APPEARANCE_GENERIC_AIRCRAFT (C macro), 100	95
BT_APPEARANCE_GENERIC_AUDIO_SINK (C macro), 97	$BT_APPEARANCE_GENERIC_PULSE_OXIMETER \qquad (C$
BT_APPEARANCE_GENERIC_AUDIO_SOURCE (C macro),	macro), 102
97	BT_APPEARANCE_GENERIC_REMOTE (C macro), 85
$BT_APPEARANCE_GENERIC_AV_EQUIPMENT$ (C macro),	BT_APPEARANCE_GENERIC_SENSOR (C macro), 89
101	BT_APPEARANCE_GENERIC_SIGNAGE (C macro), 102
BT_APPEARANCE_GENERIC_BARCODE_SCANNER (C	BT_APPEARANCE_GENERIC_SPIROMETER (C macro), 103
macro), 85	BT_APPEARANCE_GENERIC_TAG (C macro), 85
	BT_APPEARANCE_GENERIC_THERMOMETER (C macro), 85
macro), 86	BT_APPEARANCE_GENERIC_WALKING (C macro), 87
BT_APPEARANCE_GENERIC_CLOCK (C macro), 85	BT_APPEARANCE_GENERIC_WATCH (C macro), 85
BT_APPEARANCE_GENERIC_COMPUTER (C macro), 84	BT_APPEARANCE_GENERIC_WEARABLE_AUDIO_DEVICE
$BT_APPEARANCE_GENERIC_CONTROL_DEVICE$ (C	(C macro), 100
macro), 87	BT_APPEARANCE_GENERIC_WEIGHT_SCALE (C macro),
BT_APPEARANCE_GENERIC_CYCLING (C macro), 87	102
BT_APPEARANCE_GENERIC_DISPLAY (C macro), 85	BT_APPEARANCE_GENERIC_WINDOW_COVERING (C
$BT_APPEARANCE_GENERIC_DISPLAY_EQUIPMENT$ (C	macro), 96
macro), 101	$BT_APPEARANCE_HEARING_AID_BEHIND_EAR$ (C
$BT_APPEARANCE_GENERIC_DOMESTIC_APPLIANCE$ (C	macro), 102
macro), 99	BT_APPEARANCE_HEARING_AID_COCHLEAR_IMPLANT
BT_APPEARANCE_GENERIC_EYEGLASSES (C macro), 85	(C macro), 102
BT_APPEARANCE_GENERIC_FAN (C macro), 92	BT_APPEARANCE_HEARING_AID_IN_EAR (C macro), 102
BT_APPEARANCE_GENERIC_GAMING (C macro), 102	BT_APPEARANCE_HEART_RATE_BELT (C macro), 86
RT APPEARANCE GENERIC GLUCOSE (C. macro) 87	RT APPEARANCE HEATING AIR CURTAIN (Cmacro) 94

BT_APPEARANCE_HEATING_BOILER (C macro), 94	BT_APPEARANCE_LIGHT_FIXTURES_FLOOD (C macro),
BT_APPEARANCE_HEATING_FAN_HEATER (C macro), 94	91
BT_APPEARANCE_HEATING_HEAT_PUMP (C macro), 94	BT_APPEARANCE_LIGHT_FIXTURES_FLOOR (C macro),
BT_APPEARANCE_HEATING_INFRARED_HEATER (C	90
<i>macro</i>), 94	BT_APPEARANCE_LIGHT_FIXTURES_GARDEN (C macro),
BT_APPEARANCE_HEATING_RADIANT_PANEL_HEATER	91
(C macro), 94	BT_APPEARANCE_LIGHT_FIXTURES_HIGH_BAY (C
BT_APPEARANCE_HEATING_RADIATOR (C macro), 93	macro), 92
BT_APPEARANCE_HID_BARCODE_SCANNER(C macro), 86	BT_APPEARANCE_LIGHT_FIXTURES_IN_GROUND (C
BT_APPEARANCE_HID_CARD_READER (C macro), 86	macro), 91
BT_APPEARANCE_HID_DIGITAL_PEN (C macro), 86	BT_APPEARANCE_LIGHT_FIXTURES_LINEAR (C macro),
BT_APPEARANCE_HID_DIGITIZER_TABLET (C macro),	91
86	BT_APPEARANCE_LIGHT_FIXTURES_LOW_BAY (C
BT_APPEARANCE_HID_GAMEPAD (C macro), 86	macro), 92
BT_APPEARANCE_HID_JOYSTICK (C macro), 86	BT_APPEARANCE_LIGHT_FIXTURES_PATHWAY (C
BT_APPEARANCE_HID_KEYBOARD (C macro), 86	macro), 91
BT_APPEARANCE_HID_MOUSE (C macro), 86	BT_APPEARANCE_LIGHT_FIXTURES_PENDANT (C
BT_APPEARANCE_HID_PRESENTATION_REMOTE (C	<i>macro</i>), 91
macro), 87	BT_APPEARANCE_LIGHT_FIXTURES_POLE_TOP (C
BT_APPEARANCE_HID_TOUCHPAD (C macro), 87	<i>macro</i>), 91
BT_APPEARANCE_HOME_VIDEO_GAME_CONSOLE (C	BT_APPEARANCE_LIGHT_FIXTURES_SHELVES (C
macro), 102	<i>macro</i>), 91
BT_APPEARANCE_HVAC_AIR_CURTAIN (C macro), 93	BT_APPEARANCE_LIGHT_FIXTURES_STREET (C macro),
BT_APPEARANCE_HVAC_BOILER (C macro), 93	91
BT_APPEARANCE_HVAC_DEHUMIDIFIER (C macro), 93	BT_APPEARANCE_LIGHT_FIXTURES_TROFFER (C
BT_APPEARANCE_HVAC_FAN_HEATER (C macro), 93	macro), 91
BT_APPEARANCE_HVAC_HEAT_PUMP (C macro), 93	BT_APPEARANCE_LIGHT_FIXTURES_UNDERWATER (C
BT_APPEARANCE_HVAC_HEATER (C macro), 93	macro), 91
BT_APPEARANCE_HVAC_HUMIDIFIER (C macro), 93	BT_APPEARANCE_LIGHT_FIXTURES_WALL (C macro), 90
BT_APPEARANCE_HVAC_INFRARED_HEATER (C macro),	BT_APPEARANCE_LIGHT_SOURCE_FLUORESCENT_LAMP
93	(C macro), 96
BT_APPEARANCE_HVAC_RADIANT_PANEL_HEATER (C	BT_APPEARANCE_LIGHT_SOURCE_HID_LAMP (C macro),
macro), 93	96
BT_APPEARANCE_HVAC_RADIATOR (C macro), 93	BT_APPEARANCE_LIGHT_SOURCE_INCANDESCENT_BULB
BT_APPEARANCE_HVAC_THERMOSTAT (C macro), 93	(C macro), 96
BT_APPEARANCE_INSULIN_PEN (C macro), 103	BT_APPEARANCE_LIGHT_SOURCE_LED_ARRAY (C
BT_APPEARANCE_INSULIN_PUMP_DURABLE (C macro),	macro), 96
103	BT_APPEARANCE_LIGHT_SOURCE_LED_LAMP (C macro),
BT_APPEARANCE_INSULIN_PUMP_PATCH(C macro), 103	96
BT_APPEARANCE_LIGHT_FIXTURES_BAY (C macro), 92	BT_APPEARANCE_LIGHT_SOURCE_LOW_VOLTAGE_HALOGEN
BT_APPEARANCE_LIGHT_FIXTURES_BOLLARD_WITH (C	(C macro), 96
<i>macro</i>), 91	BT_APPEARANCE_LIGHT_SOURCE_MULTICOLOR_LED_ARRAY
BT_APPEARANCE_LIGHT_FIXTURES_BULB (C macro), 92	(C macro), 96
BT_APPEARANCE_LIGHT_FIXTURES_CABINET (C	BT_APPEARANCE_LIGHT_SOURCE_OLED (C macro), 96
macro), 91	BT_APPEARANCE_MOBILITY_POWERED_WHEELCHAIR (C
BT_APPEARANCE_LIGHT_FIXTURES_CEILING (C	<i>macro</i>), 103
macro), 90	BT_APPEARANCE_MOBILITY_SCOOTER (C macro), 103
BT_APPEARANCE_LIGHT_FIXTURES_CONTROLLER (C	BT_APPEARANCE_MOTORIZED_AWNING (C macro), 95
macro), 92	BT_APPEARANCE_MOTORIZED_BLINDS_OR_SHADES (C
BT_APPEARANCE_LIGHT_FIXTURES_DESK (C macro), 91	macro), 95
BT_APPEARANCE_LIGHT_FIXTURES_DESK(C macro), 91 BT_APPEARANCE_LIGHT_FIXTURES_DRIVER (C macro),	BT_APPEARANCE_MOTORIZED_CURTAINS (C macro), 95
92	BT_APPEARANCE_MOTORIZED_GATE (C macro), 95
BT_APPEARANCE_LIGHT_FIXTURES_EMERGENCY_EXIT	BT_APPEARANCE_MOTORIZED_SCREEN (C macro), 95
(C macro), 92	BT_APPEARANCE_MULTISENSOR (C macro), 90
(C macro), 72	DI_III I DIMINCE_HOLI IOLNOON (C macro), 70

```
BT_APPEARANCE_NETWORK_ACCESS_POINT (C macro), 89
                                                BT_APPEARANCE_SENSOR_VEHICLE_TIRE_PRESSURE
BT_APPEARANCE_NETWORK_MESH_DEVICE (C macro), 88
                                                        (C macro), 90
BT_APPEARANCE_NETWORK_MESH_PROXY (C macro), 88
                                                BT_APPEARANCE_SENSOR_WALL_MOUNTED (C macro), 90
BT_APPEARANCE_OUTDOOR_SPORTS_LOCATION
                                                BT_APPEARANCE_SENSOR_WIND (C macro), 90
       macro), 103
                                                BT_APPEARANCE_SIGNAGE_DIGITAL (C macro), 102
BT_APPEARANCE_OUTDOOR_SPORTS_LOCATION_AND_NAV BT_APPEARANCE_SIGNAGE_ELECTRONIC_LABEL
                                                                                            (C
        (C macro), 103
                                                        macro), 102
BT_APPEARANCE_OUTDOOR_SPORTS_LOCATION_POD (C BT_APPEARANCE_SMARTWATCH (C macro), 85
                                                BT_APPEARANCE_SPIROMETER_HANDHELD (C macro),
        macro), 103
BT_APPEARANCE_OUTDOOR_SPORTS_LOCATION_POD_AND_NAV
                                                BT_APPEARANCE_SPORTS_WATCH (C macro), 85
        (C macro), 104
BT_APPEARANCE_PORTABLE_HANDHELD_CONSOLE
                                               BT_APPEARANCE_SPOT_LIGHT (C macro), 91
       macro), 102
                                                BT_APPEARANCE_THERMOMETER_EAR (C macro), 86
BT_APPEARANCE_POWER_CHARGE_CASE (C macro), 96
                                                BT_APPEARANCE_UNKNOWN (C macro), 84
BT\_APPEARANCE\_POWER\_FLUORESCENT\_LAMP\_GEAR (C
                                                BT_APPEARANCE_VEHICLE_AGRICULTURAL (C macro),
        macro), 95
BT_APPEARANCE_POWER_HID_LAMP_GEAR (C macro), 95
                                                BT_APPEARANCE_VEHICLE_BUS (C macro), 99
                                                BT_APPEARANCE_VEHICLE_CAMPER_OR_CARAVAN
BT_APPEARANCE_POWER_LED_DRIVER (C macro), 95
                                                                                            (C
BT_APPEARANCE_POWER_OUTLET (C macro), 95
                                                        macro), 99
BT_APPEARANCE_POWER_PLUG (C macro), 95
                                                BT_APPEARANCE_VEHICLE_CAR (C macro), 98
BT_APPEARANCE_POWER_POWER_BANK (C macro), 96
                                                BT_APPEARANCE_VEHICLE_LARGE_GOODS (C macro), 98
BT_APPEARANCE_POWER_STRIP (C macro), 95
                                                BT_APPEARANCE_VEHICLE_LIGHT (C macro), 98
BT_APPEARANCE_POWER_SUPPLY (C macro), 95
                                                BT APPEARANCE VEHICLE MINIBUS (C macro), 98
BT_APPEARANCE_PULSE_OXIMETER_FINGERTIP
                                            (C BT_APPEARANCE_VEHICLE_MOPED (C macro), 98
       macro), 102
                                                BT_APPEARANCE_VEHICLE_MOTORBIKE (C macro), 98
BT_APPEARANCE_PULSE_OXIMETER_WRIST (C macro),
                                                BT_APPEARANCE_VEHICLE_QUAD_BIKE (C macro), 98
                                                BT_APPEARANCE_VEHICLE_RECREATIONAL (C macro),
BT_APPEARANCE_SENSOR_AIR_QUALITY (C macro), 89
                                                BT_APPEARANCE_VEHICLE_SCOOTER (C macro), 98
BT_APPEARANCE_SENSOR_AMBIENT_LIGHT (C macro),
                                                BT_APPEARANCE_VEHICLE_THREE_WHEELED (C macro),
BT_APPEARANCE_SENSOR_CARBON_DIOXIDE (C macro),
                                                BT_APPEARANCE_VEHICLE_TROLLEY (C macro), 99
BT_APPEARANCE_SENSOR_CARBON_MONOXIDE
                                               BT_APPEARANCE_VEHICLE_TWO_WHEELED (C macro), 98
                                                BT_APPEARANCE_WALKING_IN_SHOE (C macro), 87
        macro), 89
BT_APPEARANCE_SENSOR_CEILING_MOUNTED
                                            (C BT_APPEARANCE_WALKING_ON_HIP (C macro), 87
       macro), 90
                                                BT_APPEARANCE_WALKING_ON_SHOE (C macro), 87
BT_APPEARANCE_SENSOR_COLOR_LIGHT (C macro), 89
                                                BT_APPEARANCE_WEARABLE_AUDIO_DEVICE_EARBUD
BT_APPEARANCE_SENSOR_CONTACT (C macro), 89
                                                        (C macro), 100
                                                BT_APPEARANCE_WEARABLE_AUDIO_DEVICE_HEADPHONES
BT_APPEARANCE_SENSOR_ENERGY (C macro), 89
BT_APPEARANCE_SENSOR_ENERGY_METER (C macro), 90
                                                        (C macro), 100
BT_APPEARANCE_SENSOR_FIRE (C macro), 90
                                                BT_APPEARANCE_WEARABLE_AUDIO_DEVICE_HEADSET
BT_APPEARANCE_SENSOR_FLAME_DETECTOR (C macro),
                                                        (C macro), 100
                                                BT_APPEARANCE_WEARABLE_AUDIO_DEVICE_NECK_BAND
BT_APPEARANCE_SENSOR_FLUSH_MOUNTED (C macro),
                                                        (C macro), 100
                                                BT_APPEARANCE_WINDOW_AWNING (C macro), 96
BT_APPEARANCE_SENSOR_HUMIDITY (C macro), 89
                                                BT_APPEARANCE_WINDOW_BLINDS (C macro), 96
BT_APPEARANCE_SENSOR_LEAK (C macro), 89
                                                BT_APPEARANCE_WINDOW_CURTAIN (C macro), 97
                                                BT_APPEARANCE_WINDOW_EXTERIOR_SCREEN
BT_APPEARANCE_SENSOR_MOTION (C macro), 89
                                                                                            (C
BT_APPEARANCE_SENSOR_MULTI (C macro), 90
                                                        macro), 97
BT_APPEARANCE_SENSOR_OCCUPANCY (C macro), 89
                                                BT_APPEARANCE_WINDOW_EXTERIOR_SHUTTER
                                                                                            (C
BT_APPEARANCE_SENSOR_PROXIMITY (C macro), 90
                                                        macro), 97
BT_APPEARANCE_SENSOR_RAIN (C macro), 89
                                                BT_APPEARANCE_WINDOW_SHADES (C macro), 96
BT_APPEARANCE_SENSOR_SMOKE (C macro), 89
                                                bt_avrcp_add_to_now_playing (C struct), 220
```

```
bt_avrcp_attr_val_entry (C struct), 223
                                                 bt_avrcp_browsing_header.__unnamed18__._unnamed20__
BT_AVRCP_BATTERY_STATUS_CRITICAL (C macro), 214
                                                         (C struct), 228
BT_AVRCP_BATTERY_STATUS_EXTERNAL (C macro), 214
                                                 bt_avrcp_browsing_header.__unnamed18__._unnamed20__.cr
BT_AVRCP_BATTERY_STATUS_FULL (C macro), 214
                                                         (C var), 228
                                                 bt_avrcp_browsing_header.__unnamed18__._unnamed20__.ipid
BT_AVRCP_BATTERY_STATUS_NORMAL (C macro), 214
BT_AVRCP_BATTERY_STATUS_WARNING (C macro), 214
                                                         (C var), 228
BT_AVRCP_BOW_ERROR_ADDR_PLAYER_CHANGED
                                             (C bt_avrcp_browsing_header.__unnamed18__._unnamed20__.packe
                                                         (C \ var), 228
        macro), 216
BT_AVRCP_BOW_ERROR_DIRECTORY_NOT_HANDLED (C bt_avrcp_browsing_header.__unnamed18__._unnamed20__.tl
                                                         (C \ var), 228
        macro), 215
BT_AVRCP_BOW_ERROR_DOES_NOT_EXIST (C macro),
                                                 bt_avrcp_browsing_header.__unnamed18__.tl_pt_cr_ipid
        215
                                                         (C var), 228
                                             (C \ bt\_avrcp\_browsing\_header.parameter\_len
BT_AVRCP_BOW_ERROR_INVALID_DIRECTION
                                                                                              (C
                                                         var), 222
        macro), 215
BT_AVRCP_BOW_ERROR_INVALID_PLAYER_ID
                                             (C bt_avrcp_browsing_header.pdu_id(Cvar), 222
        macro), 216
                                                 bt_avrcp_browsing_rsp (C struct), 224
BT_AVRCP_BOW_ERROR_INVALID_SCOPE (C macro), 215
                                                 bt_avrcp_browsing_rsp.__unnamed26__ (C union),
BT_AVRCP_BOW_ERROR_MEDIA_IN_USE (C macro), 215
                                                         229
BT_AVRCP_BOW_ERROR_NO_AVAILABLE_PLAYERS
                                            (C bt_avrcp_browsing_rsp.__unnamed26__.change_path
        macro), 216
                                                         (C var), 229
BT_AVRCP_BOW_ERROR_NO_VALID_SEARCH_RESULTS
                                                 bt_avrcp_browsing_rsp.__unnamed26__.folder_items
        (C macro), 216
                                                         (C \ var), 229
BT_AVRCP_BOW_ERROR_NOT_A_DIRECTORY (C macro), bt_avrcp_browsing_rsp.__unnamed26__.get_item_attrs
                                                         (C \ var), 229
BT_AVRCP_BOW_ERROR_NOW_PLAYING_LIST_FULL (C bt_avrcp_browsing_rsp.__unnamed26__.get_total_num_of_items
        macro), 216
                                                         (C var), 229
                                             (C \ bt\_avrcp\_browsing\_rsp.\_\_unnamed26\_\_.search
BT_AVRCP_BOW_ERROR_PLAYER_NOT_ADDRESSED
                                                         (C var), 229
        macro), 216
BT_AVRCP_BOW_ERROR_PLAYER_NOT_BROWSABLE
                                            (C bt_avrcp_browsing_rsp.__unnamed26__.set_browsed_player
        macro), 216
                                                         (C var), 229
BT_AVRCP_BOW_ERROR_RANGE_OUT_OF_BOUNDS
                                             (C BT_AVRCP_CA_BAD_REQ_RSP (C macro), 216
        macro), 215
                                                 BT_AVRCP_CA_CONTINUE_RSP (C macro), 216
BT_AVRCP_BOW_ERROR_SEARCH_IN_PROGRESS
                                             (C BT_AVRCP_CA_FORBIDDEN_RSP (C macro), 217
                                                 BT_AVRCP_CA_NO_SERVICE_RSP (C macro), 217
        macro), 216
                                            (C BT_AVRCP_CA_NOT_ACCEPTABLE_RSP (C macro), 216
BT_AVRCP_BOW_ERROR_SEARCH_NOT_SUPPORTED
        macro), 216
                                                 BT_AVRCP_CA_NOT_FOUND_RSP (C macro), 216
bt_avrcp_browsing_cmd (C struct), 223
                                                 BT_AVRCP_CA_NOT_IMPLEMENTED_RSP (C macro), 216
bt_avrcp_browsing_cmd.__unnamed22__ (C union), BT_AVRCP_CA_PRECOND_FAILED_RSP (C macro), 216
                                                 BT_AVRCP_CA_SERVER_ERROR (C macro), 217
bt_avrcp_browsing_cmd.__unnamed22__.change_patBtT_AVRCP_CA_SUCCESS_RSP(C macro), 216
        (C var), 228
                                                 BT_AVRCP_CA_UNAUTH_RSP (C macro), 216
bt_avrcp_browsing_cmd.__unnamed22__.folder_iteMts_AVRCP_CAP_ID_COMPANY_ID(C macro), 212
                                                 BT_AVRCP_CAP_ID_EVENTS_SUPPORTED (C macro), 212
        (C var), 228
\verb|bt_avrcp_browsing_cmd.__unnamed22_.get_item_a \verb|attt_ras| vrcp_capability_company_id| (C \textit{struct}), 220 \\
                                                 bt_avrcp_capability_company_id.capability_count
        (C \ var), 228
bt_avrcp_browsing_cmd.__unnamed22__.get_total_num_of_icems, 220
                                                 bt_avrcp_capability_company_id.capability_id
        (C var), 228
bt_avrcp_browsing_cmd.__unnamed22__.search
                                                         (C var), 220
        (C \ var), 228
                                                 bt_avrcp_capability_company_id.company_ids
bt_avrcp_browsing_cmd.__unnamed22__.set_browsed_player(C var), 220
        (C \ var), 228
                                                 bt_avrcp_capability_events_supported
                                                                                              (C
bt_avrcp_browsing_header (C struct), 222
                                                         struct), 220
bt_avrcp_browsing_header.__unnamed18__
                                            (C bt_avrcp_capability_events_supported.capability_count
        union), 227
                                                         (C var), 221
```

```
bt_avrcp_capability_events_supported.capabilityt_iavrcp_event_rsp.__unnamed10__.battery_status
        (C var), 221
                                                         (C \ var), 225
bt_avrcp_capability_events_supported.event_idsbt_avrcp_event_rsp.__unnamed10__.identifier
        (C var), 221
                                                         (C var), 225
                                                 bt_avrcp_event_rsp.__unnamed10__.play_status
bt_avrcp_cb (C struct), 224
bt_avrcp_cb.browsing_connected (C var), 224
                                                         (C var), 225
bt_avrcp_cb.browsing_disconnected(C var), 224
                                                 bt_avrcp_event_rsp.__unnamed10__.playback_pos
bt_avrcp_cb.control_connected (C var), 224
                                                         (C \ var), 225
bt_avrcp_cb.control_disconnected(C var), 224
                                                 bt_avrcp_event_rsp.__unnamed10__.setting_changed
bt_avrcp_cb.send_result(Cvar), 224
                                                         (C struct), 226
bt_avrcp_change_path_cmd (C struct), 222
                                                 bt_avrcp_event_rsp.__unnamed10__.setting_changed
                                                         (C var), 226
bt_avrcp_change_path_rsp (C struct), 223
BT_AVRCP_COMMAND_TYPE_CONTROL (C macro), 215
                                                 bt_avrcp_event_rsp.__unnamed10__.system_status
BT_AVRCP_COMMAND_TYPE_NOTIFY (C macro), 215
                                                         (C var), 226
BT_AVRCP_COMMAND_TYPE_STATUS (C macro), 215
                                                 bt_avrcp_event_rsp.__unnamed10__.uid_counter
bt_avrcp_company_id(C struct), 220
                                                         (C \ var), 226
bt_avrcp_company_id.company_id0 (C var), 220
                                                 BT_AVRCP_EVENT_SYSTEM_STATUS_CHANGED
                                                                                              (C
bt_avrcp_control_connect (C function), 217
                                                         macro), 213
bt_avrcp_control_disconnect (C function), 217
                                                 BT_AVRCP_EVENT_TRACK_CHANGED (C macro), 213
                                                 BT_AVRCP_EVENT_TRACK_REACHED_END (C macro), 213
bt_avrcp_control_msg (C struct), 222
bt_avrcp_control_msg.__unnamed16__ (C union),
                                                 BT_AVRCP_EVENT_TRACK_REACHED_START (C macro),
                                                 BT_AVRCP_EVENT_UIDS_CHANGED (C macro), 213
bt_avrcp_control_msg.__unnamed16__.pass_th
                                                 BT_AVRCP_EVENT_VOLUME_CHANGED (C macro), 213
        (C \ var), 227
bt_avrcp_control_msg.__unnamed16__.subunit_inflot_avrcp_folder_item (C struct), 223
        (C var), 227
                                                 bt_avrcp_folder_name (C struct), 223
                                                 bt_avrcp_get_element_attrs (C struct), 219
bt_avrcp_control_msg.__unnamed16__.unit_info
                                                 bt_avrcp_get_element_attrs.identifier (C var),
        (C \ var), 227
bt_avrcp_control_msg.__unnamed16__.vendor (C
                                                         220
                                                 bt_avrcp_get_folder_items_cmd (C struct), 222
        var), 227
BT_AVRCP_COVER_ART_PSM (C macro), 208
                                                 bt_avrcp_get_folder_items_cmd.attr_list
bt_avrcp_element_attr(C struct), 221
                                                         var), 222
BT_AVRCP_EVENT_ADDRESSED_PLAYER_CHANGED
                                             (C bt_avrcp_get_folder_items_rsp(C struct), 223
                                                 bt_avrcp_get_item_attrs_cmd (C struct), 222
        macro), 213
BT_AVRCP_EVENT_AVAILABLE_PLAYER_CHANGED
                                             (C bt_avrcp_get_item_attrs_cmd.attr_list(C var),
        macro), 213
BT_AVRCP_EVENT_BATT_STATUS_CHANGED (C macro), bt_avrcp_get_item_attrs_rsp(C struct), 223
                                                 bt_avrcp_get_item_attrs_rsp.attrs (C var), 224
BT_AVRCP_EVENT_NOW_PLAYING_CONTENT_CHANGED
                                                 bt_avrcp_get_player_app_setting_value_text
        (C macro), 213
                                                         (C struct), 219
BT_AVRCP_EVENT_PLAYBACK_POS_CHANGED (C macro), bt_avrcp_get_player_app_setting_value_text.num_of_value
        213
                                                         (C var), 219
BT_AVRCP_EVENT_PLAYBACK_STATUS_CHANGED
                                             (C
                                                bt_avrcp_get_player_app_setting_value_text.value_ids
        macro), 213
                                                         (C var), 219
BT\_AVRCP\_EVENT\_PLAYER\_APP\_SETTING\_CHANGED (C bt_avrcp_get_total_num_of_items_cmd (C struct),
        macro), 213
                                                         223
bt_avrcp_event_rsp (C struct), 221
                                                 bt_avrcp_get_total_num_of_items_rsp (C struct),
bt_avrcp_event_rsp.__unnamed10__(Cunion), 225
                                                         224
bt_avrcp_event_rsp.__unnamed10__.absolute_volumme_avrcp_header (C struct), 217
                                                 bt_avrcp_header.__unnamed6__(Cunion), 225
        (C \ var), 226
\verb|bt_avrcp_event_rsp._unnamed10_.addressed_playeravchap.gleedader._unnamed6_.._unnamed8_.(C)
                                                         struct), 225
        (C struct), 226
bt_avrcp_event_rsp.__unnamed10__.addressed_playeravchapqdeedder.__unnamed6__.__unnamed8__.cr
                                                         (C var), 225
        (C \ var), 226
```

```
bt_avrcp_header._unnamed6__.unnamed8__.ipidBT_AVRCP_OP_ID_2 (C macro), 209
        (C var), 225
                                                 BT_AVRCP_OP_ID_3 (C macro), 209
bt_avrcp_header.__unnamed6__._unnamed8__.packReT_AVRCP_OP_ID_4 (C macro), 209
        (C var), 225
                                                 BT_AVRCP_OP_ID_5 (C macro), 209
bt_avrcp_header.__unnamed6__._unnamed8__.tl
                                                 BT_AVRCP_OP_ID_6 (C macro), 209
        (C var), 225
                                                 BT_AVRCP_OP_ID_7 (C macro), 209
bt_avrcp_header.__unnamed6__.tl_pt_cr_ipid
                                                 BT AVRCP OP ID 8 (C macro), 209
                                                 BT_AVRCP_OP_ID_9 (C macro), 209
        (C var), 225
bt_avrcp_header.ctype_response (C var), 217
                                                 BT_AVRCP_OP_ID_ANGLE (C macro), 211
bt_avrcp_header.op_code(Cvar), 218
                                                 BT_AVRCP_OP_ID_BACKWARD (C macro), 211
bt_avrcp_header.subunit_id(C var), 217
                                                 BT_AVRCP_OP_ID_CHANNEL_DOWN (C macro), 210
bt_avrcp_header.subunit_type (C var), 217
                                                 BT_AVRCP_OP_ID_CHANNEL_UP (C macro), 210
bt_avrcp_inform_displayable_char_set
                                             (C BT_AVRCP_OP_ID_CLEAR (C macro), 210
                                                 BT_AVRCP_OP_ID_CONTENTS_MENU (C macro), 209
        struct), 219
bt_avrcp_item(C struct), 223
                                                 BT_AVRCP_OP_ID_DISPLAY_INFORMATION (C macro),
bt_avrcp_item.__unnamed24__(Cunion), 228
                                                         210
bt_avrcp_item.__unnamed24__.folder_item
                                             (C BT_AVRCP_OP_ID_DOT (C macro), 209
                                                 BT_AVRCP_OP_ID_DOWN (C macro), 208
        var), 229
bt_avrcp_item.__unnamed24__.media_item
                                             (C BT_AVRCP_OP_ID_EJECT (C macro), 211
                                                 BT_AVRCP_OP_ID_ENTER (C macro), 210
        var), 229
bt_avrcp_item.__unnamed24__.player_item
                                             (C BT_AVRCP_OP_ID_EXIT (C macro), 209
        var), 229
                                                 BT_AVRCP_OP_ID_F1 (C macro), 211
                                                 BT_AVRCP_OP_ID_F2 (C macro), 211
BT_AVRCP_ITEM_TYPER_FOLDER (C macro), 216
BT_AVRCP_ITEM_TYPER_MEDIA (C macro), 216
                                                 BT AVRCP OP ID F3 (C macro), 211
BT_AVRCP_ITEM_TYPER_MEDIA_PLAYER (C macro), 216
                                                 BT_AVRCP_OP_ID_F4 (C macro), 211
BT_AVRCP_MEDIA_ATTR_ID_ALBUM_NAME (C macro),
                                                 BT_AVRCP_OP_ID_F5 (C macro), 211
        214
                                                 BT_AVRCP_OP_ID_FAST_FORWARD (C macro), 210
BT_AVRCP_MEDIA_ATTR_ID_ARTIST_NAME (C macro),
                                                 BT_AVRCP_OP_ID_FAVORITE_MENU (C macro), 209
                                                 BT_AVRCP_OP_ID_FORWARD (C macro), 211
        214
BT_AVRCP_MEDIA_ATTR_ID_DEFAULT_COVER_ART (C BT_AVRCP_OP_ID_HELP (C macro), 210
        macro), 214
                                                 BT_AVRCP_OP_ID_INPUT_SELECT (C macro), 210
BT_AVRCP_MEDIA_ATTR_ID_GENRE (C macro), 214
                                                 BT_AVRCP_OP_ID_LEFT (C macro), 208
BT_AVRCP_MEDIA_ATTR_ID_MEDIA_NUMBER (C macro),
                                                 BT_AVRCP_OP_ID_LEFT_DOWN (C macro), 209
                                                 BT_AVRCP_OP_ID_LEFT_UP (C macro), 209
        214
                                                 BT_AVRCP_OP_ID_MUTE (C macro), 210
BT_AVRCP_MEDIA_ATTR_ID_MEDIA_TITLE (C macro),
                                                 BT_AVRCP_OP_ID_PAGE_DOWN (C macro), 210
        214
BT_AVRCP_MEDIA_ATTR_ID_PLAYING_TIME (C macro),
                                                 BT_AVRCP_OP_ID_PAGE_UP (C macro), 210
                                                 BT_AVRCP_OP_ID_PAUSE (C macro), 210
BT_AVRCP_MEDIA_ATTR_ID_TOTAL_MEDIA_NUMBER (C
                                                 BT_AVRCP_OP_ID_PLAY (C macro), 210
                                                 BT_AVRCP_OP_ID_POWER (C macro), 210
        macro), 214
bt_avrcp_media_item (C struct), 223
                                                 BT_AVRCP_OP_ID_PREVIOUS_CHANNEL (C macro), 210
                                                 BT_AVRCP_OP_ID_RECORD (C macro), 210
BT_AVRCP_METADATA_ERROR_INTERNAL (C macro), 215
BT_AVRCP_METADATA_ERROR_INVALID_COMMAND
                                                 BT_AVRCP_OP_ID_REWIND (C macro), 210
                                                 BT_AVRCP_OP_ID_RIGHT (C macro), 209
        macro), 215
BT_AVRCP_METADATA\_ERROR_INVALID\_PARAMETER (C
                                                 BT_AVRCP_OP_ID_RIGHT_DOWN (C macro), 209
                                                 BT_AVRCP_OP_ID_RIGHT_UP (C macro), 209
        macro), 215
BT_AVRCP_METADATA_ERROR_OPERATION_SUCCESSFUL
                                                 BT_AVRCP_OP_ID_ROOT_MENU (C macro), 209
        (C macro), 215
                                                 BT_AVRCP_OP_ID_SELECT (C macro), 208
BT_AVRCP_METADATA_ERROR_PARAMETER_NOT_FOUND
                                                 BT_AVRCP_OP_ID_SETUP_MENU (C macro), 209
                                                 BT_AVRCP_OP_ID_SOUND_SELECT (C macro), 210
        (C macro), 215
BT_AVRCP_METADATA_ERROR_UID_CHANGED (C macro),
                                                 BT_AVRCP_OP_ID_STOP (C macro), 210
                                                 BT_AVRCP_OP_ID_SUBPICTURE (C macro), 211
        215
BT_AVRCP_OP_ID_0 (C macro), 209
                                                 BT_AVRCP_OP_ID_UP (C macro), 208
BT_AVRCP_OP_ID_1 (C macro), 209
                                                 BT_AVRCP_OP_ID_VENDOR_UNIQUE (C macro), 211
```

```
BT_AVRCP_OP_ID_VOLUME_DOWN (C macro), 210
                                                 BT_AVRCP_PDU_ID_SET_BROWSED_PLAYER (C macro),
BT_AVRCP_OP_ID_VOLUME_UP (C macro), 210
                                                         212
BT_AVRCP_OPCODE_PASS_THROUGH (C macro), 208
                                                 BT_AVRCP_PDU_ID_SET_PLAYER_APP_SETTING_VAL
BT_AVRCP_OPCODE_SUBUNIT_INFO (C macro), 208
                                                         (C macro), 211
BT_AVRCP_OPCODE_UNIT_INFO (C macro), 208
                                                 bt_avrcp_play_item (C struct), 220
BT_AVRCP_OPCODE_VENDOR_DEPENDENT (C macro), 208
                                                 bt_avrcp_play_status_rsp (C struct), 221
BT_AVRCP_PACKET_TYPE_CONTINUE (C macro), 213
                                                 BT_AVRCP_PLAYER_APP_ATTR_ID_EQUALIZER
                                                                                              (C
BT_AVRCP_PACKET_TYPE_END (C macro), 213
                                                         macro), 214
BT_AVRCP_PACKET_TYPE_SINGLE (C macro), 213
                                                 BT_AVRCP_PLAYER_APP_ATTR_ID_REPEAT (C macro),
BT_AVRCP_PACKET_TYPE_START (C macro), 213
                                                         214
bt_avrcp_pass_through (C struct), 218
                                                 BT_AVRCP_PLAYER_APP_ATTR_ID_SCAN (C macro), 214
bt_avrcp_pass_through.op_data(C var), 218
                                                 BT_AVRCP_PLAYER_APP_ATTR_ID_SHUFFLE (C macro),
bt_avrcp_pass_through.op_data_len(C var), 218
                                                         214
bt_avrcp_pass_through.op_id(Cvar), 218
                                                 bt_avrcp_player_app_attr_values (C struct), 219
bt_avrcp_pass_through.state_flag(Cvar), 218
                                                 bt\_avrcp\_player\_app\_attr\_values.attr\_vals (C
{\tt BT\_AVRCP\_PDU\_ID\_ABORT\_CONTINUING\_RESPONSE}~(C
                                                         var), 219
                                                 bt_avrcp_player_app_attr_values.num_of_attr
        macro), 212
BT_AVRCP_PDU_ID_ADD_TO_NOW_PLAYING (C macro),
                                                         (C var), 219
        212
                                                 bt_avrcp_player_app_setting_attr_ids
                                                                                              (C
BT_AVRCP_PDU_ID_CHANGE_PATH (C macro), 212
                                                         struct), 218
BT_AVRCP_PDU_ID_GENERAL_REJECT (C macro), 212
                                                 bt_avrcp_player_app_setting_attr_ids.attr_ids
BT_AVRCP_PDU_ID_GET_CAPABILITY (C macro), 211
                                                         (C var), 219
BT_AVRCP_PDU_ID_GET_CUR_PLAYER_APP_SETTING_VALbt_avrcp_player_app_setting_attr_ids.num_of_attr
        (C macro), 211
                                                         (C var), 219
BT_AVRCP_PDU_ID_GET_ELEMENT_ATTRIBUTE
                                             (C bt_avrcp_player_app_setting_values (C struct),
        macro), 211
BT_AVRCP_PDU_ID_GET_FOLDER_ITEMS (C macro), 212
                                                 bt_avrcp_player_app_setting_values.num_of_value
BT_AVRCP_PDU_ID_GET_ITEM_ATTRIBUTES (C macro),
                                                         (C \ var), 221
        212
                                                 bt_avrcp_player_app_setting_values.value_ids
BT_AVRCP_PDU_ID_GET_PLAY_STATUS (C macro), 212
                                                         (C \ var), 221
BT_AVRCP_PDU_ID_GET_PLAYER_APP_SETTING_ATTR_TXTt_avrcp_player_attr_value (C struct), 219
        (C macro), 211
                                                 bt_avrcp_player_attr_value_text (C struct), 221
BT_AVRCP_PDU_ID_GET_PLAYER_APP_SETTING_VAL_TXTbt_avrcp_player_get_element_attr_rsp
                                                                                              (C
                                                         struct), 221
        (C macro), 211
                                                 bt_avrcp_player_get_txt_rsp (C struct), 221
BT_AVRCP_PDU_ID_GET_TOTAL_NUM_ITEMS (C macro),
        212
                                                 bt_avrcp_player_item (C struct), 223
BT_AVRCP_PDU_ID_INFORM_BATTERY_STATUS
                                             (C bt_avrcp_register_callback (C function), 217
        macro), 211
                                                 bt_avrcp_register_ntfy (C struct), 218
BT_AVRCP_PDU_ID_INFORM_DISPLAYABLE_CHAR_SET
                                                 bt_avrcp_register_ntfy.event_id(Cvar), 218
                                                 \verb|bt_avrcp_register_ntfy.playback_interval| (C
        (C macro), 211
BT_AVRCP_PDU_ID_LIST_PLAYER_APP_SETTING_ATTR
                                                         var), 218
        (C macro), 211
                                                 BT_AVRCP_RESPONSE_TYPE_ACCEPTED (C macro), 212
BT_AVRCP_PDU_ID_LIST_PLAYER_APP_SETTING_VAL
                                                 BT_AVRCP_RESPONSE_TYPE_CHANGED (C macro), 213
        (C macro), 211
                                                 BT_AVRCP_RESPONSE_TYPE_INTERIM (C macro), 213
BT_AVRCP_PDU_ID_PLAY_ITEMS (C macro), 212
                                                 BT_AVRCP_RESPONSE_TYPE_NOT_IMPLEMENTED
                                                                                              (C
                                             (C
BT_AVRCP_PDU_ID_REGISTER_NOTIFICATION
                                                         macro), 212
                                                 BT_AVRCP_RESPONSE_TYPE_REJECTED (C macro), 212
        macro), 212
BT_AVRCP_PDU_ID_REQUEST_CONTINUING_RESPONSE
                                                 BT_AVRCP_RESPONSE_TYPE_STABLE (C macro), 213
        (C macro), 212
                                                 BT_AVRCP_SCOPE_MEDIA_PLAYER_LIST (C macro), 215
BT_AVRCP_PDU_ID_SEARCH (C macro), 212
                                                 BT_AVRCP_SCOPE_NOW_PLAYING (C macro), 215
BT_AVRCP_PDU_ID_SET_ABSOLUTE_VOLUME (C macro),
                                                 BT_AVRCP_SCOPE_SEARCH (C macro), 215
                                                 BT_AVRCP_SCOPE_VIRTUAL_FILESYSTEM (C macro),
        212
BT_AVRCP_PDU_ID_SET_ADDRESSED_PLAYER
                                             (C
        macro), 212
                                                 bt_avrcp_search_cmd (C struct), 223
```

```
bt_avrcp_search_rsp (C struct), 224
                                                  bt_bond_info.addr (C var), 75
bt_avrcp_set_browsed_player_cmd (C struct), 222
                                                  BT_BR_CONN_PARAM (C macro), 5
                                                  bt_br_conn_param (C struct), 32
bt_avrcp_set_browsed_player_rsp (C struct), 223
bt_avrcp_subunit_info(C struct), 218
                                                  BT_BR_CONN_PARAM_DEFAULT (C macro), 5
BT_AVRCP_SUBUNIT_TYPE_PANEL (C macro), 208
                                                  BT_BR_CONN_PARAM_INIT (C macro), 4
BT_AVRCP_SUBUNIT_TYPE_UNIT (C macro), 208
                                                  bt_br_discovery_cb_t (C type), 40
BT_AVRCP_SYSTEM_STATUS_POWER_OFF (C macro), 214
                                                  bt_br_discovery_param(C struct), 74
BT_AVRCP_SYSTEM_STATUS_POWER_ON (C macro), 214
                                                  bt_br_discovery_param.length(C var), 75
BT_AVRCP_SYSTEM_STATUS_UNPLUGED (C macro), 214
                                                  bt_br_discovery_param.limited(C var), 75
                                                  bt_br_discovery_result (C struct), 74
bt_avrcp_unit_info (C struct), 218
bt_avrcp_vendor (C struct), 221
                                                  bt_br_discovery_result._priv(C var), 74
bt_avrcp_vendor.__unnamed14__(Cunion), 226
                                                  bt_br_discovery_result.addr (C var), 74
bt_avrcp_vendor.__unnamed14__.add_now_play
                                                  bt_br_discovery_result.cod(C var), 74
                                                  bt_br_discovery_result.eir(C var), 74
        (C \ var), 226
bt_avrcp_vendor.__unnamed14__.attr_ids_rsp
                                                  bt_br_discovery_result.rssi(C var),74
        (C \ var), 227
                                                  bt_br_discovery_start (C function), 61
bt_avrcp_vendor.__unnamed14__.attr_values_rsp bt_br_discovery_stop (C function), 61
        (C var), 227
                                                  bt_br_oob (C struct), 75
bt_avrcp_vendor.__unnamed14__.comapny_id_rsp bt_br_oob.addr(Cvar),75
        (C \ var), 227
                                                  bt_br_oob_get_local (C function), 61
bt_avrcp_vendor.__unnamed14__.element_attr_rspbt_br_set_connectable (C function), 61
        (C \ var), 227
                                                  bt_br_set_discoverable (C function), 61
bt_avrcp_vendor.__unnamed14__.element_attrs
                                                  BT_BUF_ACL_RX_SIZE (C macro), 34
                                                  BT_BUF_ACL_SIZE (C macro), 33
        (C var), 226
bt_avrcp_vendor.__unnamed14__.event_rsp
                                             (C BT_BUF_CMD_SIZE (C macro), 33
        var), 227
                                                  BT_BUF_CMD_TX_SIZE (C macro), 34
bt_avrcp_vendor.__unnamed14__.events_suported_brspbuf_data(C struct), 36
                                                  BT_BUF_EVT_RX_SIZE (C macro), 34
        (C \ var), 227
bt_avrcp_vendor.__unnamed14__.get_txt_rsp (C BT_BUF_EVT_SIZE (C macro), 33
        var), 227
                                                  bt_buf_get_evt (C function), 35
bt_avrcp_vendor.__unnamed14__.inform_char_set bt_buf_get_rx (C function), 35
        (C var), 226
                                                  bt_buf_get_tx (C function), 35
bt_avrcp_vendor.__unnamed14__.parameter
                                             (C bt_buf_get_type (C function), 36
                                                  BT_BUF_ISO_RX_COUNT (C macro), 34
        var), 226
bt_avrcp_vendor.__unnamed14__.play_item
                                              (C BT_BUF_ISO_RX_SIZE (C macro), 34
                                                  BT_BUF_ISO_SIZE (C macro), 34
        var), 226
bt_avrcp_vendor.__unnamed14__.play_status_rsp BT_BUF_RESERVE (C macro), 33
        (C var), 227
                                                  BT_BUF_RX_COUNT (C macro), 34
bt_avrcp_vendor.__unnamed14__.player_attr_ids BT_BUF_RX_SIZE (C macro), 34
                                                  bt_buf_set_type (C function), 35
        (C \ var), 226
bt_avrcp_vendor.__unnamed14__.player_attr_valueE_BUF_SIZE (C macro), 33
        (C \ var), 226
                                                  bt_buf_type (C enum), 34
bt_avrcp_vendor.__unnamed14__.player_value_textt_buf_type.BT_BUF_ACL_IN(Cenumerator), 34
                                                  bt_buf_type.BT_BUF_ACL_OUT (C enumerator), 34
        (C var), 226
bt_avrcp_vendor.__unnamed14__.register_notify bt_buf_type.BT_BUF_CMD (Cenumerator), 34
                                                  bt_buf_type.BT_BUF_EVT (C enumerator), 34
        (C \ var), 227
bt_avrcp_vendor.__unnamed14__.values_rsp (C bt_buf_type.BT_BUF_H4 (C enumerator), 35
                                                  bt_buf_type.BT_BUF_ISO_IN (C enumerator), 34
        var), 227
bt_avrcp_vendor.company_id0 (C var), 222
                                                  bt_buf_type.BT_BUF_ISO_OUT (C enumerator), 34
                                                  BT_COMP_ID_LF (C macro), 80
bt_avrcp_vendor.packet_type (C var), 222
bt_avrcp_vendor.parameter_len (C var), 222
                                                  bt_configure_data_path(Cfunction), 62
bt_avrcp_vendor.pdu_id(Cvar), 222
                                                  bt_conn_auth_cancel (C function), 19
bt_avrcp_vendor.reserved(Cvar), 222
                                                  bt_conn_auth_cb (C struct), 29
bt_bond_info (C struct), 75
                                                  bt_conn_auth_cb.cancel (C var), 31
```

```
bt_conn_auth_cb.oob_data_request(C var), 30
                                                 bt_conn_disconnect(C function), 12
bt_conn_auth_cb.pairing_accept (C var), 29
                                                 bt_conn_enc_key_size (C function), 15
                                                 bt_conn_foreach (C function), 9
bt_conn_auth_cb.pairing_confirm(C var), 31
bt_conn_auth_cb.passkey_confirm(C var), 30
                                                 bt_conn_get_dst (C function), 10
bt_conn_auth_cb.passkey_display (C var), 30
                                                 bt_conn_get_dst_br (C function), 10
bt_conn_auth_cb.passkey_entry (C var), 30
                                                 bt_conn_get_info (C function), 10
bt_conn_auth_cb.pincode_entry (C var), 31
                                                 bt_conn_get_remote_info (C function), 10
bt_conn_auth_cb_overlay (C function), 18
                                                 bt_conn_get_security (C function), 15
bt_conn_auth_cb_register (C function), 17
                                                 bt_conn_index (C function), 10
bt_conn_auth_info_cb (C struct), 31
                                                 bt_conn_info(C struct), 22
bt_conn_auth_info_cb.bond_deleted(C var), 32
                                                 bt_conn_info.__unnamed37__(Cunion), 32
                                                 bt_conn_info.__unnamed37__.br(Cvar), 32
bt_conn_auth_info_cb.node (C var), 32
bt_conn_auth_info_cb.pairing_complete (C var),
                                                 bt_conn_info._unnamed37_.le(Cvar), 32
        32
                                                 bt_conn_info.id(C var), 23
bt_conn_auth_info_cb.pairing_failed(C var), 32
                                                 bt_conn_info.role(C var), 23
bt_conn_auth_info_cb_register (C function), 18
                                                 bt_conn_info.security(C var), 23
bt_conn_auth_info_cb_unregister (C function), 18
                                                 bt_conn_info.state(C var), 23
bt_conn_auth_keypress (C enum), 7
                                                 bt_conn_info.type (C var), 23
bt_conn_auth_keypress.BT_CONN_AUTH_KEYPRESS_CLEAREDNN_INTERVAL_TO_MS (C macro), 4
                                                 BT_CONN_INTERVAL_TO_US (C macro), 4
        (Cenumerator), 8
bt_conn_auth_keypress.BT_CONN_AUTH_KEYPRESS_DIGHT_COMMTEREDcreate (C function), 13
        (C enumerator), 7
                                                 bt_conn_le_create_auto (C function), 14
bt_conn_auth_keypress.BT_CONN_AUTH_KEYPRESS_DIBILITCONNASED_CREATE_CONN (C macro), 4
        (C enumerator), 8
                                                 BT_CONN_LE_CREATE_CONN_AUTO (C macro), 4
bt_conn_auth_keypress.BT_CONN_AUTH_KEYPRESS_ENTRYCOOMPLE_TOEDEATE_PARAM (C macro), 4
        (C enumerator), 8
                                                 bt_conn_le_create_param (C struct), 25
bt_conn_auth_keypress.BT_CONN_AUTH_KEYPRESS_ENTRYcoxTiaRTEEDcreate_param.interval (C var), 25
                                                 bt_conn_le_create_param.interval_coded
        (C enumerator), 7
                                                                                               (C
bt_conn_auth_keypress_notify (C function), 18
                                                          var), 25
bt_conn_auth_pairing_confirm (C function), 19
                                                 bt_conn_le_create_param.options(C var), 25
bt_conn_auth_passkey_confirm (C function), 19
                                                 bt_conn_le_create_param.timeout(C var), 25
bt_conn_auth_passkey_entry (C function), 18
                                                 bt_conn_le_create_param.window(Cvar), 25
bt_conn_auth_pincode_entry (C function), 19
                                                 bt_conn_le_create_param.window_coded (C var),
bt_conn_br_info (C struct), 22
bt_conn_br_remote_info(C struct), 23
                                                 BT_CONN_LE_CREATE_PARAM_INIT (C macro), 4
bt_conn_br_remote_info.features (C var), 23
                                                 bt_conn_le_create_synced (C function), 13
bt_conn_br_remote_info.num_pages (C var), 23
                                                 bt_conn_le_create_synced_param (C struct), 25
bt_conn_cb (C struct), 26
                                                 bt_conn_le_create_synced_param.peer(Cvar), 26
bt_conn_cb.connected(C var), 26
                                                 bt_conn_le_create_synced_param.subevent
bt_conn_cb.disconnected(Cvar), 26
                                                          var), 26
bt_conn_cb.identity_resolved (C var), 27
                                                 bt_conn_le_data_len_info (C struct), 21
bt_conn_cb.le_data_len_updated(C var), 28
                                                 bt_conn_le_data_len_info.rx_max_len(Cvar), 21
bt_conn_cb.le_param_reg(C var), 27
                                                 bt_conn_le_data_len_info.rx_max_time (C var),
bt_conn_cb.le_param_updated(Cvar), 27
                                                          21
bt_conn_cb.le_phy_updated(Cvar), 28
                                                 bt_conn_le_data_len_info.tx_max_len(Cvar), 21
                                                 bt_conn_le_data_len_info.tx_max_time (C var),
bt_conn_cb.recycled(Cvar), 26
bt_conn_cb.remote_info_available (C var), 28
bt_conn_cb.security_changed (C var), 27
                                                 BT_CONN_LE_DATA_LEN_PARAM (C macro), 3
BT_CONN_CB_DEFINE (C macro), 4
                                                 bt_conn_le_data_len_param (C struct), 21
bt_conn_cb_register(C function), 15
                                                 bt_conn_le_data_len_param.tx_max_len (C var),
bt_conn_cb_unregister (C function), 15
bt_conn_create_auto_stop (C function), 14
                                                 bt_conn_le_data_len_param.tx_max_time (C var),
bt_conn_create_br (C function), 20
bt_conn_create_sco (C function), 20
                                                 BT_CONN_LE_DATA_LEN_PARAM_INIT (C macro), 3
```

```
bt_conn_le_data_len_update (C function), 12
                                                 bt_conn_lookup_addr_le(Cfunction), 10
bt_conn_le_enhanced_get_tx_power_level
                                             (C bt_conn_oob_info (C struct), 28
       function), 11
                                                 bt_conn_oob_info.__unnamed42__(Cunion), 33
bt_conn_le_get_remote_tx_power_level (C func-
                                                 bt_conn_oob_info.__unnamed42__.lesc (C struct),
        tion), 11
bt_conn_le_get_tx_power_level (C function), 11
                                                 bt_conn_oob_info.__unnamed42__.lesc(Cvar), 33
bt_conn_le_info (C struct), 21
                                                 bt_conn_oob_info.__unnamed42__.lesc.oob_config
bt_conn_le_info.dst(C var), 22
                                                          (C var), 33
                                                 bt_conn_oob_info.PhonyNameDueToError.BT_CONN_OOB_LE_LEGACY
bt_conn_le_info.interval(C var), 22
bt_conn_le_info.latency (C var), 22
                                                         (C enumerator), 28
                                                 bt_conn_oob_info.PhonyNameDueToError.BT_CONN_OOB_LE_SC
bt_conn_le_info.local(C var), 22
bt_conn_le_info.remote(C var), 22
                                                         (C enumerator), 28
                                                 bt_conn_oob_info.type(C var), 29
bt_conn_le_info.src(C var), 22
bt_conn_le_info.timeout(C var), 22
                                                 bt_conn_pairing_feat (C struct), 29
bt_conn_le_param_update (C function), 12
                                                 bt_conn_pairing_feat.auth_req(Cvar), 29
bt_conn_le_phy_info (C struct), 20
                                                 bt_conn_pairing_feat.init_key_dist(C var), 29
bt_conn_le_phy_info.rx_phy(C var), 20
                                                 bt_conn_pairing_feat.io_capability(C var), 29
BT_CONN_LE_PHY_PARAM (C macro), 3
                                                 bt_conn_pairing_feat.max_enc_key_size (C var),
bt_conn_le_phy_param (C struct), 20
                                                 bt_conn_pairing_feat.oob_data_flag(C var), 29
bt_conn_le_phy_param.pref_rx_phy (C var), 21
bt_conn_le_phy_param.pref_tx_phy(C var), 21
                                                 bt_conn_pairing_feat.resp_key_dist(C var), 29
BT_CONN_LE_PHY_PARAM_1M (C macro), 3
                                                 bt_conn_ref(C function), 9
BT_CONN_LE_PHY_PARAM_2M (C macro), 3
                                                 bt_conn_remote_info(C struct), 23
BT_CONN_LE_PHY_PARAM_ALL (C macro), 3
                                                 bt_conn_remote_info.__unnamed39__(Cunion), 32
BT_CONN_LE_PHY_PARAM_CODED (C macro), 3
                                                 bt_conn_remote_info.__unnamed39__.br (C var),
BT_CONN_LE_PHY_PARAM_INIT (C macro), 3
bt_conn_le_phy_update (C function), 12
                                                 bt_conn_remote_info.__unnamed39__.le (C var),
bt_conn_le_remote_info(C struct), 23
bt_conn_le_remote_info.features (C var), 23
                                                 bt_conn_remote_info.manufacturer (C var), 24
                                                 bt_conn_remote_info.subversion(C var), 24
bt_conn_le_set_tx_power_report_enable (C func-
        tion), 11
                                                 bt_conn_remote_info.type (C var), 24
bt_conn_le_tx_power (C struct), 24
                                                 bt_conn_remote_info.version(C var), 24
bt_conn_le_tx_power.current_level (C var), 24
                                                 BT_CONN_ROLE_MASTER (C macro), 4
bt_conn_le_tx_power.max_level(C var), 24
                                                 BT_CONN_ROLE_SLAVE (C macro), 4
                                                 bt_conn_set_bondable (C function), 16
bt_conn_le_tx_power.phy (C var), 24
bt_conn_le_tx_power_phy (C enum), 7
                                                 bt_conn_set_security (C function), 14
bt_conn_le_tx_power_phy.BT_CONN_LE_TX_POWER_PHYt_1&fonn_state (C enum), 6
        (C enumerator), 7
                                                 bt_conn_state.BT_CONN_STATE_CONNECTED (C enu-
bt_conn_le_tx_power_phy.BT_CONN_LE_TX_POWER_PHY_2M
                                                         merator), 6
                                                                                              (C
        (C enumerator), 7
                                                 bt_conn_state.BT_CONN_STATE_CONNECTING
bt_conn_le_tx_power_phy.BT_CONN_LE_TX_POWER_PHY_CODED_enator), 6
        (C enumerator), 7
                                                 bt_conn_state.BT_CONN_STATE_DISCONNECTED
bt_conn_le_tx_power_phy.BT_CONN_LE_TX_POWER_PHY_CODED_e&@merator), 6
                                                 \verb|bt_conn_state.BT_CONN_STATE_DISCONNECTING|| (C
        (C enumerator), 7
bt_conn_le_tx_power_phy.BT_CONN_LE_TX_POWER_PHY_NONE enumerator), 6
        (C enumerator), 7
                                                 bt_conn_type (C enum), 5
bt_conn_le_tx_power_report (C struct), 24
                                                 bt_conn_type.BT_CONN_TYPE_ALL (C enumerator), 6
bt_conn_le_tx_power_report.delta(C var), 25
                                                 bt_conn_type.BT_CONN_TYPE_BR (C enumerator), 5
bt_conn_le_tx_power_report.phy (C var), 24
                                                 bt_conn_type.BT_CONN_TYPE_ISO (C enumerator), 6
bt_conn_le_tx_power_report.reason(C var), 24
                                                 bt_conn_type.BT_CONN_TYPE_LE(C enumerator), 5
bt_conn_le_tx_power_report.tx_power_level (C
                                                 bt_conn_type.BT_CONN_TYPE_SCO (C enumerator), 5
                                                 bt_conn_unref(C function), 9
bt_conn_le_tx_power_report.tx_power_level_flagBT_DATA(C macro), 36
        (C var), 25
                                                 bt_data (C struct), 65
```

BT_DATA_3D_INFO (C macro), 83	BT_GAP_ADV_FAST_INT_MIN_1 (C macro), 104
BT_DATA_ADV_INT (C macro), 82	BT_GAP_ADV_FAST_INT_MIN_2 (C macro), 104
BT_DATA_ADV_INT_LONG (C macro), 83	$BT_GAP_ADV_HIGH_DUTY_CYCLE_MAX_TIMEOUT$ (C
BT_DATA_BIG_INFO (C macro), 83	<i>macro</i>), 105
BT_DATA_BROADCAST_CODE (C macro), 83	BT_GAP_ADV_MAX_ADV_DATA_LEN (C macro), 105
BT_DATA_BROADCAST_NAME (C macro), 83	BT_GAP_ADV_MAX_EXT_ADV_DATA_LEN (C macro), 105
BT_DATA_BYTES (C macro), 37	BT_GAP_ADV_SLOW_INT_MAX (C macro), 104
BT_DATA_CHANNEL_MAP_UPDATE_IND (C macro), 82	BT_GAP_ADV_SLOW_INT_MIN (C macro), 104
BT_DATA_CSIS_RSI (C macro), 83	BT_GAP_DATA_LEN_DEFAULT (C macro), 105
BT_DATA_ENCRYPTED_AD_DATA (C macro), 83	BT_GAP_DATA_LEN_MAX (C macro), 105
BT_DATA_FLAGS (C macro), 80	BT_GAP_DATA_TIME_DEFAULT (C macro), 105
BT_DATA_GAP_APPEARANCE (C macro), 81	BT_GAP_DATA_TIME_MAX (C macro), 105
bt_data_get_len (C function), 49	BT_GAP_INIT_CONN_INT_MAX (C macro), 105
BT_DATA_INDOOR_POS (C macro), 82	BT_GAP_INIT_CONN_INT_MIN (C macro), 105
BT_DATA_LE_BT_DEVICE_ADDRESS (C macro), 82	BT_GAP_NO_TIMEOUT (C macro), 105
BT_DATA_LE_ROLE (C macro), 82	BT_GAP_PER_ADV_FAST_INT_MAX_1 (C macro), 104
BT_DATA_LE_SC_CONFIRM_VALUE (C macro), 82	BT_GAP_PER_ADV_FAST_INT_MAX_2 (C macro), 104
BT_DATA_LE_SC_RANDOM_VALUE (C macro), 82	BT_GAP_PER_ADV_FAST_INT_MIN_1 (C macro), 104
BT_DATA_LE_SUPPORTED_FEATURES (C macro), 82	BT_GAP_PER_ADV_FAST_INT_MIN_2 (C macro), 104
BT_DATA_MANUFACTURER_DATA (C macro), 83	BT_GAP_PER_ADV_INTERVAL_TO_MS (C macro), 106
BT_DATA_MESH_BEACON (C macro), 83	BT_GAP_PER_ADV_MAX_INTERVAL (C macro), 106
BT_DATA_MESH_MESSAGE (C macro), 83	BT_GAP_PER_ADV_MAX_SKIP (C macro), 105
BT_DATA_MESH_PROV (C macro), 83	BT_GAP_PER_ADV_MAX_TIMEOUT (C macro), 106
BT_DATA_NAME_COMPLETE (C macro), 81	BT_GAP_PER_ADV_MIN_INTERVAL (C macro), 106
BT_DATA_NAME_SHORTENED (C macro), 81	BT_GAP_PER_ADV_MIN_TIMEOUT (C macro), 106
bt_data_parse (C function), 59	BT_GAP_PER_ADV_SLOW_INT_MAX (C macro), 104
BT_DATA_PERIPHERAL_INT_RANGE (C macro), 81	BT_GAP_PER_ADV_SLOW_INT_MIN (C macro), 104
BT_DATA_PUB_TARGET_ADDR (C macro), 81	BT_GAP_RSSI_INVALID (C macro), 105
BT_DATA_RAND_TARGET_ADDR (C macro), 81	BT_GAP_SCAN_FAST_INTERVAL (C macro), 104
bt_data_serialize (C function), 49	BT_GAP_SCAN_FAST_WINDOW (C macro), 104
BT_DATA_SERIALIZED_SIZE (C macro), 36	BT_GAP_SCAN_SLOW_INTERVAL_1 (C macro), 104
BT_DATA_SIMPLE_PAIRING_HASH (C macro), 82	BT_GAP_SCAN_SLOW_INTERVAL_2 (C macro), 104
BT_DATA_SIMPLE_PAIRING_RAND (C macro), 82	BT_GAP_SCAN_SLOW_WINDOW_1 (C macro), 104
BT_DATA_SM_OOB_FLAGS (C macro), 81	BT_GAP_SCAN_SLOW_WINDOW_2 (C macro), 104
BT_DATA_SM_TK_VALUE (C macro), 81	BT_GAP_SID_INVALID (C macro), 105
BT_DATA_SOLICIT128 (C macro), 81	BT_GAP_SID_MAX (C macro), 105
BT_DATA_SOLICIT16 (C macro), 81	BT_GAP_TX_POWER_INVALID (C macro), 105
BT_DATA_SOLICIT32 (C macro), 82	bt_gatt_attr (<i>C struct</i>), 115
BT_DATA_SVC_DATA128 (C macro), 82	bt_gatt_attr.handle(C var), 116
BT_DATA_SVC_DATA16 (C macro), 81	$bt_gatt_attr.perm(Cvar), 116$
BT_DATA_SVC_DATA32 (C macro), 82	bt_gatt_attr.user_data(<i>C var</i>), 116
BT_DATA_TRANS_DISCOVER_DATA (C macro), 82	bt_gatt_attr.uuid(C var), 116
BT_DATA_TX_POWER (C macro), 81	<pre>bt_gatt_attr.write(C var), 116</pre>
BT_DATA_URI (C macro), 82	bt_gatt_attr_func_t (<i>C type</i>), 123
BT_DATA_UUID128_ALL (C macro), 81	<pre>bt_gatt_attr_get_handle (C function), 125</pre>
BT_DATA_UUID128_SOME (C macro), 81	bt_gatt_attr_next (C function), 125
BT_DATA_UUID16_ALL (C macro), 80	bt_gatt_attr_read (C function), 126
BT_DATA_UUID16_SOME (C macro), 80	bt_gatt_attr_read_ccc (C function), 127
BT_DATA_UUID32_ALL (C macro), 81	bt_gatt_attr_read_cep (C function), 128
BT_DATA_UUID32_SOME (C macro), 80	bt_gatt_attr_read_chrc (C function), 127
bt_enable (C function), 46	bt_gatt_attr_read_cpf (C function), 129
bt_foreach_bond (C function), 62	bt_gatt_attr_read_cud (C function), 128
BT_GAP_ADV_FAST_INT_MAX_1 (C macro), 104	bt_gatt_attr_read_func_t (C type), 113
BT_GAP_ADV_FAST_INT_MAX_2 (C macro), 104	bt_gatt_attr_read_included (C function), 127
·······//	5 = = = = ::::(: ;:::::::::::::::::::::::

```
bt_gatt_attr_read_service (C function), 126
                                                  bt_gatt_cpf.unit(C var), 119
bt_gatt_attr_value_handle (C function), 126
                                                  BT_GATT_CUD (C macro), 122
bt_gatt_attr_write_ccc (C function), 128
                                                  BT_GATT_DESCRIPTOR (C macro), 122
bt_gatt_attr_write_func_t (C type), 113
                                                  bt_gatt_discover (C function), 139
                                                  bt_gatt_discover_func_t (C type), 135
BT_GATT_ATTRIBUTE (C macro), 122
bt_gatt_authorization_cb (C struct), 117
                                                  bt_gatt_discover_params (C struct), 144
bt_gatt_authorization_cb.read_authorize
                                              (C bt_gatt_discover_params.__unnamed59__
                                                                                                (C
                                                          union), 146
        var), 118
bt_gatt_authorization_cb.write_authorize (C bt_gatt_discover_params.__unnamed59__._included
        var), 118
                                                          (C struct), 147
bt_gatt_authorization_cb_register (C function),
                                                  bt_gatt_discover_params.__unnamed59__._included
        123
                                                          (C var), 147
bt_gatt_cancel (C function), 144
                                                  bt_gatt_discover_params.__unnamed59__._included.attr_handl
bt_gatt_cb (C struct), 117
                                                          (C var), 147
bt_gatt_cb.att_mtu_updated(Cvar), 117
                                                  bt_gatt_discover_params.__unnamed59__._included.end_handle
bt_gatt_cb_register (C function), 123
                                                          (C \ var), 147
BT_GATT_CCC (C macro), 121
                                                  bt_gatt_discover_params.__unnamed59__._included.start_hand
bt_gatt_ccc (C struct), 118
                                                          (C var), 147
bt_gatt_ccc.flags (C var), 119
                                                  bt_gatt_discover_params.__unnamed59__.start_handle
bt_gatt_ccc_cfg (C struct), 132
                                                          (C \ var), 147
bt_gatt_ccc_cfg.id(Cvar), 132
                                                  bt_gatt_discover_params.end_handle(C var), 145
bt_gatt_ccc_cfg.peer(Cvar), 132
                                                  bt_gatt_discover_params.func(Cvar), 145
bt_gatt_ccc_cfg.value(Cvar), 132
                                                  bt_gatt_discover_params.type (C var), 145
BT_GATT_CCC_INDICATE (C macro), 113
                                                  bt_gatt_discover_params.uuid(C var), 145
BT_GATT_CCC_INITIALIZER (C macro), 121
                                                  BT_GATT_ERR (C macro), 112
BT_GATT_CCC_MANAGED (C macro), 121
                                                  bt_gatt_exchange_mtu (C function), 139
BT_GATT_CCC_MAX (C macro), 121
                                                  bt_gatt_exchange_params (C struct), 144
BT_GATT_CCC_NOTIFY (C macro), 113
                                                  bt_gatt_exchange_params.func(Cvar), 144
                                                  bt_gatt_find_by_uuid (C function), 125
BT_GATT_CEP (C macro), 121
bt_gatt_cep (C struct), 118
                                                  bt_gatt_foreach_attr (C function), 125
                                                  bt_gatt_foreach_attr_type (C function), 124
bt_gatt_cep.properties (C var), 118
BT_GATT_CEP_RELIABLE_WRITE (C macro), 112
                                                  bt_gatt_get_mtu (C function), 132
BT_GATT_CEP_WRITABLE_AUX (C macro), 112
                                                  bt_gatt_include (C struct), 117
BT_GATT_CHARACTERISTIC (C macro), 121
                                                  bt_gatt_include.end_handle(C var), 117
                                                  bt_gatt_include.start_handle(C var), 117
bt_gatt_chrc (C struct), 118
                                                  bt_gatt_include.uuid(Cvar), 117
bt_gatt_chrc.properties (C var), 118
bt_gatt_chrc.uuid(Cvar), 118
                                                  BT_GATT_INCLUDE_SERVICE (C macro), 120
bt_gatt_chrc.value_handle(C var), 118
                                                  bt_gatt_indicate (C function), 131
BT_GATT_CHRC_AUTH (C macro), 112
                                                  bt_gatt_indicate_func_t (C type), 123
BT_GATT_CHRC_BROADCAST (C macro), 112
                                                  bt_gatt_indicate_params (C struct), 134
BT_GATT_CHRC_EXT_PROP (C macro), 112
                                                  bt_gatt_indicate_params._ref(C var), 134
BT_GATT_CHRC_INDICATE (C macro), 112
                                                  bt_gatt_indicate_params.attr(C var), 134
BT_GATT_CHRC_INIT (C macro), 121
                                                  bt_gatt_indicate_params.data(C var), 134
BT_GATT_CHRC_NOTIFY (C macro), 112
                                                  bt_gatt_indicate_params.destroy(Cvar), 134
BT_GATT_CHRC_READ (C macro), 112
                                                  bt_gatt_indicate_params.func(Cvar), 134
BT_GATT_CHRC_WRITE (C macro), 112
                                                  bt_gatt_indicate_params.len(Cvar), 134
BT_GATT_CHRC_WRITE_WITHOUT_RESP (C macro), 112
                                                  bt_gatt_indicate_params.uuid(Cvar), 134
bt_gatt_complete_func_t (C type), 123
                                                  bt_gatt_indicate_params_destroy_t (C type), 123
BT_GATT_CPF (C macro), 122
                                                  bt_gatt_is_subscribed (C function), 132
bt_gatt_cpf (C struct), 119
                                                  bt_gatt_notify (C function), 130
bt_gatt_cpf.description(C var), 119
                                                  bt_gatt_notify_cb (C function), 129
bt_gatt_cpf.exponent (C var), 119
                                                  bt_gatt_notify_func_t (C type), 136
bt_gatt_cpf.format(C var), 119
                                                  bt_gatt_notify_multiple (C function), 130
bt_gatt_cpf.name_space (C var), 119
                                                  bt_gatt_notify_params (C struct), 133
```

```
bt_gatt_notify_params.attr(C var), 133
                                                 bt_gatt_read_params.__unnamed62__.single (C
                                                         var), 147
bt_gatt_notify_params.data(C var), 133
bt_gatt_notify_params.func(Cvar), 134
                                                 bt_gatt_read_params.__unnamed62__.single.handle
bt_gatt_notify_params.len(C var), 133
                                                         (C \ var), 147
                                                 bt_gatt_read_params.__unnamed62__.single.offset
bt_gatt_notify_params.user_data(C var), 134
                                                         (C var), 147
bt_gatt_notify_params.uuid(Cvar), 133
bt_gatt_notify_uuid(C function), 131
                                                 bt_gatt_read_params._att_mtu(Cvar), 145
                                                 bt_gatt_read_params.func(Cvar), 145
bt_gatt_perm (C enum), 114
bt_gatt_perm.BT_GATT_PERM_NONE (C enumerator),
                                                 bt_gatt_read_params.handle_count (C var), 145
                                                 bt_gatt_resubscribe (C function), 143
bt_gatt_perm.BT_GATT_PERM_PREPARE_WRITE
                                            (C
                                                bt_gatt_scc (C struct), 119
                                                 bt_gatt_scc.flags(C var), 119
        enumerator), 114
bt_gatt_perm.BT_GATT_PERM_READ (C enumerator),
                                                 BT_GATT_SCC_BROADCAST (C macro), 113
                                                 BT_GATT_SECONDARY_SERVICE (C macro), 120
bt_gatt_perm.BT_GATT_PERM_READ_AUTHEN (C enu-
                                                 BT_GATT_SERVICE (C macro), 120
        merator), 114
                                                 bt_gatt_service (C struct), 116
bt_gatt_perm.BT_GATT_PERM_READ_ENCRYPT
                                            (C bt_gatt_service.attr_count(C var), 116
                                                 bt_gatt_service.attrs(Cvar), 116
        enumerator), 114
bt_gatt_perm.BT_GATT_PERM_READ_LESC (C enu-
                                                 BT_GATT_SERVICE_DEFINE (C macro), 120
                                                 BT_GATT_SERVICE_INSTANCE_DEFINE (C macro), 120
        merator), 115
bt_gatt_perm.BT_GATT_PERM_WRITE(C enumerator),
                                                 bt_gatt_service_is_registered (C function), 124
                                                 bt_gatt_service_register (C function), 124
                                             (C bt_gatt_service_static(C struct), 116
bt_gatt_perm.BT_GATT_PERM_WRITE_AUTHEN
        enumerator), 114
                                                 bt_gatt_service_static.attr_count(Cvar), 116
bt_gatt_perm.BT_GATT_PERM_WRITE_ENCRYPT
                                            (C bt_gatt_service_static.attrs(C var), 116
        enumerator), 114
                                                 bt_gatt_service_unregister (C function), 124
bt_gatt_perm.BT_GATT_PERM_WRITE_LESC (C enu-
                                                 bt_gatt_service_val(C struct), 116
        merator), 115
                                                 bt_gatt_service_val.end_handle (C var), 117
BT_GATT_PRIMARY_SERVICE (C macro), 120
                                                 bt_gatt_service_val.uuid(Cvar), 117
bt_gatt_read (C function), 140
                                                 bt_gatt_subscribe (C function), 142
                                                 bt_gatt_subscribe_func_t (C type), 136
bt_gatt_read_func_t (C type), 135
bt_gatt_read_params (C struct), 145
                                                 bt_gatt_subscribe_params (C struct), 146
bt_gatt_read_params.__unnamed62__ (C union),
                                                bt_gatt_subscribe_params.ccc_handle (C var),
bt_gatt_read_params.__unnamed62__.by_uuid (C bt_gatt_subscribe_params.min_security (C var).
        struct), 148
bt_gatt_read_params.__unnamed62__.by_uuid (C bt_gatt_subscribe_params.notify(Cvar), 146
        var), 147
                                                 bt_gatt_subscribe_params.subscribe(C var), 146
bt_gatt_read_params.__unnamed62__.by_uuid.end_bhargddet_subscribe_params.value(C var), 146
                                                 bt_gatt_subscribe_params.value_handle (C var),
        (C \ var), 148
bt_gatt_read_params.__unnamed62__.by_uuid.start_handled46
        (C \ var), 148
                                                 bt_gatt_subscribe_params.write(C var), 146
bt_gatt_read_params.__unnamed62__.by_uuid.uuidbt_gatt_unsubscribe(C function), 143
        (C var), 148
                                                 bt_gatt_write (C function), 141
bt_gatt_read_params.__unnamed62__.multiple
                                                 bt_gatt_write_func_t (C type), 136
                                                 bt_gatt_write_params (C struct), 145
        (C struct), 147
bt_gatt_read_params.__unnamed62__.multiple
                                                 bt_gatt_write_params.data(C var), 145
        (C var), 147
                                                 bt_gatt_write_params.func(C var), 145
bt_gatt_read_params.__unnamed62__.multiple.harlott_egatt_write_params.handle(C var), 145
                                                 bt_gatt_write_params.length(Cvar), 146
        (C var), 148
bt_gatt_read_params.__unnamed62__.multiple.varhitabdætt_write_params.offset(Cvar), 145
        (C var), 148
                                                 bt_gatt_write_without_response (C function), 142
bt_gatt_read_params.__unnamed62__.single (C bt_gatt_write_without_response_cb (C function),
                                                         141
        struct), 147
```

bt_get_appearance (C function), 47	bt_hfp_ag_send_signal_indicator (C function),
bt_get_name (C function), 47	155
bt_hfp_ag_call_status_pl (C function), 154	<pre>bt_hfp_ag_set_cops (C function), 153</pre>
bt_hfp_ag_cb (C struct), 159	bt_hfp_ag_set_inband_ring_tone (C function), 153
bt_hfp_ag_cb.ata_response(C var), 159	bt_hfp_ag_set_phnum_tag(Cfunction), 154
bt_hfp_ag_cb.brva(C var), 160	<pre>bt_hfp_ag_set_volume_control(C function), 153</pre>
bt_hfp_ag_cb.chld(Cvar), 160	bt_hfp_ag_unknown_at_response (C function), 156
bt_hfp_ag_cb.chup_response(C var), 159	bt_hfp_hf_at_cmd (C enum), 150
bt_hfp_ag_cb.codec_negotiate(C var), 160	bt_hfp_hf_at_cmd.BT_HFP_HF_AT_CHUP (C enumer-
bt_hfp_ag_cb.connected(Cvar), 159	ator), 150
bt_hfp_ag_cb.dial(Cvar), 160	<pre>bt_hfp_hf_at_cmd.BT_HFP_HF_ATA (C enumerator),</pre>
bt_hfp_ag_cb.disconnected(C var), 159	150
bt_hfp_ag_cb.hfu_brsf(C var), 159	bt_hfp_hf_cb (C struct), 160
bt_hfp_ag_cb.nrec(Cvar), 160	bt_hfp_hf_cb.battery (C var), 162
bt_hfp_ag_cb.unkown_at (C var), 160	bt_hfp_hf_cb.call(C var), 161
bt_hfp_ag_cb.volume_control(Cvar), 159	bt_hfp_hf_cb.call_held(Cvar), 161
bt_hfp_ag_close_audio (C function), 152	bt_hfp_hf_cb.call_phnum(Cvar), 162
bt_hfp_ag_codec_selector (C function), 156	bt_hfp_hf_cb.call_setup(C var), 161
bt_hfp_ag_connect (C function), 151	bt_hfp_hf_cb.cmd_complete_cb(Cvar), 162
bt_hfp_ag_deinit (C function), 151	bt_hfp_hf_cb.connected(C var), 161
bt_hfp_ag_disconnect (C function), 151	bt_hfp_hf_cb.disconnected(Cvar), 161
bt_hfp_ag_discover (C function), 151	bt_hfp_hf_cb.ring_indication(C var), 162
bt_hfp_ag_discover_callback (<i>C type</i>), 149	bt_hfp_hf_cb.roam (C var), 162
<pre>bt_hfp_ag_get_peer_supp_features (C function),</pre>	bt_hfp_hf_cb.service(Cvar), 161
152	bt_hfp_hf_cb.signal (C var), 161
bt_hfp_ag_handle_btrh (C function), 154	bt_hfp_hf_cb.voicetag_phnum(Cvar), 162
<pre>bt_hfp_ag_handle_indicator_enable (C function),</pre>	bt_hfp_hf_cb.waiting_call (C var), 162
154	bt_hfp_hf_cmd_complete(C struct), 160
bt_hfp_ag_init (C function), 151	bt_hfp_hf_dial (C function), 157
bt_hfp_ag_open_audio (C function), 152	bt_hfp_hf_dial_memory (C function), 157
<pre>bt_hfp_ag_register_cind_features (C function),</pre>	<pre>bt_hfp_hf_disable_call_waiting_notification</pre>
152	(C function), 158
<pre>bt_hfp_ag_register_supp_features (C function),</pre>	bt_hfp_hf_disable_clip_notification (C func-
152	tion), 158
<pre>bt_hfp_ag_send_battery_indicator (C function),</pre>	<pre>bt_hfp_hf_enable_call_waiting_notification</pre>
bt_hfp_ag_send_call_indicator (<i>C function</i>), 155	bt_hfp_hf_enable_clip_notification (C func-
bt_hfp_ag_send_callring (C function), 154	tion), 158
${\tt bt_hfp_ag_send_callsetup_indicator} (C \textit{func-}$	bt_hfp_hf_get_last_voice_tag_number (C func-
tion), 155	tion), 158
bt_hfp_ag_send_ccwa_indicator (<i>C function</i>), 156	bt_hfp_hf_last_dial (C function), 158
<pre>bt_hfp_ag_send_disable_voice_ecnr (C function),</pre>	bt_hfp_hf_multiparty_call_option (C function), 158
$\verb bt_hfp_ag_send_disable_voice_recognition (C$	<pre>bt_hfp_hf_register(C function), 156</pre>
function), 152	bt_hfp_hf_send_cmd (C function), 157
<pre>bt_hfp_ag_send_enable_voice_ecnr (C function),</pre>	<pre>bt_hfp_hf_start_voice_recognition (C function), 157</pre>
	bt_hfp_hf_stop_voice_recognition (<i>C function</i>),
bt_hfp_ag_send_roaming_indicator (<i>C function</i>),	bt_hfp_hf_volume_update (C function), 157
155	bt_hps_init (C function), 313
bt_hfp_ag_send_service_indicator (<i>C function</i>),	bt_hps_notify (C function), 313
155	bt_hps_set_status_code (C function), 313
	ht hts indicate (C function) 314

bt_id_create (C function), 48	bt_l2cap_chan_state.BT_L2CAP_CONNECTED (C
BT_ID_DEFAULT (C macro), 36	enumerator), 166
bt_id_delete(C function), 49	bt_12cap_chan_state.BT_L2CAP_CONNECTING (C
bt_id_get (C function), 48	enumerator), 166
bt_id_reset (C function), 49	bt_l2cap_chan_state.BT_L2CAP_DISCONNECTED (C
bt_is_ready (<i>C function</i>), 47	enumerator), 166
bt_12cap_br_chan (<i>C struct</i>), 171	bt_l2cap_chan_state.BT_L2CAP_DISCONNECTING
bt_12cap_br_chan.chan(<i>C var</i>), 172	(C enumerator), 166
bt_12cap_br_chan.ident (C var), 172	bt_12cap_chan_state_t (C type), 166
bt_12cap_br_chan.pending_rx_mps (C var), 172	bt_12cap_chan_status (C enum), 166
bt_12cap_br_chan.pending_rx_mtu (<i>C var</i>), 172	bt_l2cap_chan_status.BT_L2CAP_NUM_STATUS (C
bt_12cap_br_chan.psm(<i>C var</i>), 172	enumerator), 167
bt_12cap_br_chan.rx (<i>C var</i>), 172	bt_12cap_chan_status.BT_L2CAP_STATUS_ENCRYPT_PENDING
bt_12cap_br_chan.tx(C var), 172	(C enumerator), 167
<pre>bt_12cap_br_endpoint (C struct), 171</pre>	$bt_12cap_chan_status.BT_L2CAP_STATUS_OUT$ (C
<pre>bt_12cap_br_endpoint.cid(C var), 171</pre>	enumerator), 166
<pre>bt_12cap_br_endpoint.credits(C var), 171</pre>	bt_l2cap_chan_status.BT_L2CAP_STATUS_SHUTDOWN
<pre>bt_12cap_br_endpoint.init_credits(C var), 171</pre>	(C enumerator), 166
<pre>bt_l2cap_br_endpoint.mps (C var), 171</pre>	bt_12cap_chan_status_t (C type), 166
<pre>bt_12cap_br_endpoint.mtu(C var), 171</pre>	bt_12cap_ecred_chan_connect (C function), 167
bt_12cap_br_server_register (C function), 167	<pre>bt_l2cap_ecred_chan_reconfigure (C function),</pre>
BT_L2CAP_BUF_SIZE (C macro), 163	168
BT_L2CAP_CFG_OPT_EXT_FLOW_SPEC (C macro), 164	<pre>bt_12cap_ext_flow_spec (C struct), 172</pre>
BT_L2CAP_CFG_OPT_EXT_WIN_SIZE (C macro), 164	BT_L2CAP_FEATURE_EFS_BR_EDR (C macro), 165
BT_L2CAP_CFG_OPT_FCS (C macro), 164	BT_L2CAP_FEATURE_ERTM (C macro), 165
BT_L2CAP_CFG_OPT_FUSH_TIMEOUT (C macro), 164	BT_L2CAP_FEATURE_EXTENDED_WINDOW_SIZE (C
BT_L2CAP_CFG_OPT_MTU (C macro), 164	macro), 165
BT_L2CAP_CFG_OPT_QOS (C macro), 164	BT_L2CAP_FEATURE_FC (C macro), 165
BT_L2CAP_CFG_OPT_RETRANS_FC (C macro), 164	BT_L2CAP_FEATURE_FCS (C macro), 165
bt_12cap_cfg_options (C struct), 172	BT_L2CAP_FEATURE_FIXED_CHANNELS (C macro), 165
bt_12cap_chan (C struct), 169	BT_L2CAP_FEATURE_QOS (C macro), 165
bt_12cap_chan.conn (<i>C var</i>), 170	BT_L2CAP_FEATURE_RTM (C macro), 165
bt_12cap_chan.ops (<i>C var</i>), 170	BT_L2CAP_FEATURE_SM (C macro), 165
bt_12cap_chan_connect (C function), 168	BT_L2CAP_FEATURE_UCD (C macro), 165
bt_12cap_chan_destroy_t (C type), 166	BT_L2CAP_HDR_SIZE (C macro), 163
bt_12cap_chan_disconnect (C function), 168	BT_L2CAP_LE_CHAN (C macro), 164
bt_12cap_chan_give_credits (C function), 169	bt_l2cap_le_chan (C struct), 170
bt_12cap_chan_ops (C struct), 172	bt_12cap_le_chansdu (<i>C var</i>), 171
bt_12cap_chan_ops.alloc_buf (C var), 173	bt_12cap_le_chan.chan (C var), 170
bt_12cap_chan_ops.alloc_seg (C var), 173	bt_12cap_le_chan.pending_rx_mtu (C var), 170
bt_12cap_chan_ops.connected (C var), 173	bt_12cap_le_chan.rx (C var), 170
bt_12cap_chan_ops.disconnected (C var), 173	bt_12cap_le_chan.tx (<i>C var</i>), 170 bt_12cap_le_chan.tx (<i>C var</i>), 171
bt_12cap_chan_ops.encrypt_change (C var), 173	bt_12cap_le_chan.tx_buf(C var), 171 bt_12cap_le_chan.tx_buf(C var), 171
	- ' ' '
bt_12cap_chan_ops.reconfigured (C var), 174	bt_l2cap_le_chan.tx_queue (<i>C var</i>), 171
bt_12cap_chan_ops.recv (C var), 173	bt_l2cap_le_chan.tx_work(C var), 171
bt_12cap_chan_ops.sent (C var), 173	bt_l2cap_le_endpoint (<i>C struct</i>), 170
bt_12cap_chan_ops.status(C var), 174	bt_l2cap_le_endpoint.cid(C var), 170
bt_12cap_chan_recv_complete (<i>C function</i>), 169	bt_l2cap_le_endpoint.credits(C var), 170
bt_12cap_chan_send (<i>C function</i>), 168	bt_l2cap_le_endpoint.init_credits(C var), 170
BT_L2CAP_CHAN_SEND_RESERVE (C macro), 165	bt_l2cap_le_endpoint.mps (C var), 170
bt_12cap_chan_state (<i>C enum</i>), 166	bt_l2cap_le_endpoint.mtu(C var), 170
bt_l2cap_chan_state.BT_L2CAP_CONFIG (C enu-	BT_L2CAP_MODE_BASIC (C macro), 165
merator), 166	BT_L2CAP_MODE_ERTM (C macro), 165
	BT_L2CAP_MODE_FC (C macro), 165

BT_L2CAP_MODE_RTM (C macro), 165	BT_LE_EXT_ADV_CONN_NAME (C macro), 38
BT_L2CAP_MODE_SM (<i>C macro</i>), 165	bt_le_ext_adv_connected_info (C struct), 63
bt_12cap_qos (<i>C struct</i>), 172	bt_le_ext_adv_connected_info.conn (C var), 63
bt_12cap_retrans_fc (C struct), 172	bt_le_ext_adv_create (C function), 51
BT_L2CAP_RX_MTU (C macro), 163	bt_le_ext_adv_delete (C function), 52
BT_L2CAP_SDU_BUF_SIZE (C macro), 164	bt_le_ext_adv_get_index (C function), 52
BT_L2CAP_SDU_CHAN_SEND_RESERVE (C macro), 165	bt_le_ext_adv_get_info (C function), 53
BT_L2CAP_SDU_HDR_SIZE (C macro), 163	bt_le_ext_adv_info (C struct), 67
BT_L2CAP_SDU_RX_MTU (C macro), 164	bt_le_ext_adv_info.addr (C var), 67
BT_L2CAP_SDU_TX_MTU (C macro), 164	bt_le_ext_adv_info.tx_power(C var),67
bt_12cap_server (C struct), 174	BT_LE_EXT_ADV_NCONN (C macro), 38
bt_12cap_server.accept (C var), 174	BT_LE_EXT_ADV_NCONN_IDENTITY (C macro), 38
bt_12cap_server.psm(C var), 174	BT_LE_EXT_ADV_NCONN_NAME (C macro), 38
bt_l2cap_server.sec_level (<i>C var</i>), 174	<pre>bt_le_ext_adv_oob_get_local (C function), 60</pre>
bt_12cap_server_register (C function), 167	BT_LE_EXT_ADV_SCAN_NAME (C macro), 38
BT_L2CAP_TX_MTU (C macro), 163	<pre>bt_le_ext_adv_scanned_info (C struct), 63</pre>
BT_LE_AD_GENERAL (C macro), 83	<pre>bt_le_ext_adv_scanned_info.addr (C var), 63</pre>
BT_LE_AD_LIMITED (C macro), 83	<pre>bt_le_ext_adv_sent_info (C struct), 63</pre>
BT_LE_AD_NO_BREDR (C macro), 83	<pre>bt_le_ext_adv_sent_info.num_sent(C var), 63</pre>
BT_LE_ADV_CONN (C macro), 37	<pre>bt_le_ext_adv_set_data (C function), 51</pre>
BT_LE_ADV_CONN_DIR (C macro), 37	<pre>bt_le_ext_adv_start (C function), 51</pre>
BT_LE_ADV_CONN_DIR_LOW_DUTY (C macro), 37	BT_LE_EXT_ADV_START_DEFAULT (C macro), 38
BT_LE_ADV_CONN_NAME (C macro), 37	BT_LE_EXT_ADV_START_PARAM (C macro), 38
BT_LE_ADV_CONN_NAME_AD (C macro), 37	bt_le_ext_adv_start_param (C struct), 66
BT_LE_ADV_NCONN (C macro), 37	<pre>bt_le_ext_adv_start_param.num_events (C var),</pre>
BT_LE_ADV_NCONN_IDENTITY (C macro), 37	67
BT_LE_ADV_NCONN_NAME (C macro), 37	<pre>bt_le_ext_adv_start_param.timeout(C var), 67</pre>
BT_LE_ADV_PARAM (C macro), 37	BT_LE_EXT_ADV_START_PARAM_INIT (C macro), 38
bt_le_adv_param (<i>C struct</i>), 65	bt_le_ext_adv_stop (<i>C function</i>), 51
bt_le_adv_param.id(C var), 65	bt_le_ext_adv_update_param (C function), 52
bt_le_adv_param.interval_max (C var), 66	bt_le_filter_accept_list_add (<i>C function</i>), 58
bt_le_adv_param.interval_min(C var), 66	bt_le_filter_accept_list_clear (<i>C function</i>), 59
bt_le_adv_param.options (C var), 65	bt_le_filter_accept_list_remove (C function), 58
bt_le_adv_param.peer (C var), 66	bt_le_oob (C struct), 74
bt_le_adv_param.secondary_max_skip (C var), 65	bt_le_oob.addr (<i>C var</i>), 74
bt_le_adv_param.sid (C var), 65	bt_le_oob.le_sc_data (C var), 74
BT_LE_ADV_PARAM_INIT (C macro), 37	
	bt_le_oob_get_local (C function), 60
bt_le_adv_start (C function), 50	bt_le_oob_get_sc_data (C function), 17
bt_le_adv_stop (C function), 50	bt_le_oob_sc_data (C struct), 73
bt_le_adv_update_data (C function), 50	bt_le_oob_sc_data.c(Cvar),74
BT_LE_CONN_PARAM (C macro), 2	bt_le_oob_sc_data.r(Cvar),74
bt_le_conn_param (C struct), 20	bt_le_oob_set_legacy_flag (C function), 16
BT_LE_CONN_PARAM_DEFAULT (C macro), 3	bt_le_oob_set_legacy_tk (C function), 16
BT_LE_CONN_PARAM_INIT (C macro), 2	bt_le_oob_set_sc_data (C function), 16
BT_LE_DATA_LEN_PARAM_DEFAULT (C macro), 3	bt_le_oob_set_sc_flag (C function), 16
BT_LE_DATA_LEN_PARAM_MAX (C macro), 3	bt_le_per_adv_data_request (C struct), 63
bt_le_ext_adv_cb (C struct), 64	<pre>bt_le_per_adv_data_request.count (C var), 64</pre>
bt_le_ext_adv_cb.connected(<i>C var</i>), 65	<pre>bt_le_per_adv_data_request.start(C var), 64</pre>
bt_le_ext_adv_cb.scanned(C var),65	BT_LE_PER_ADV_DEFAULT (C macro), 39
<pre>bt_le_ext_adv_cb.sent (C var), 64</pre>	<pre>bt_le_per_adv_list_add (C function), 57</pre>
BT_LE_EXT_ADV_CODED_NCONN (C macro), 38	<pre>bt_le_per_adv_list_clear (C function), 57</pre>
${\tt BT_LE_EXT_ADV_CODED_NCONN_IDENTITY} \ \ (C \ \ macro),$	<pre>bt_le_per_adv_list_remove (C function), 57</pre>
38	BT_LE_PER_ADV_PARAM (C macro), 39
BT_LE_EXT_ADV_CODED_NCONN_NAME (C macro), 38	bt_le_per_adv_param(C struct),66

```
bt_le_per_adv_param.interval_max(C var), 66
                                                 bt_le_per_adv_sync_info(C struct), 71
bt_le_per_adv_param.interval_min(C var), 66
                                                 bt_le_per_adv_sync_info.addr (C var), 71
bt_le_per_adv_param.options (C var), 66
                                                 bt_le_per_adv_sync_info.interval (C var), 71
BT_LE_PER_ADV_PARAM_INIT (C macro), 38
                                                 bt_le_per_adv_sync_info.phy(Cvar),71
bt_le_per_adv_response_info (C struct), 64
                                                 bt_le_per_adv_sync_info.sid(Cvar),71
bt_le_per_adv_response_info.cte_type (C var),
                                                bt_le_per_adv_sync_lookup_addr (C function), 55
                                                 bt_le_per_adv_sync_lookup_index (C function), 54
bt_le_per_adv_response_info.response_slot (C bt_le_per_adv_sync_param(C struct), 70
        var), 64
                                                 bt_le_per_adv_sync_param.addr(Cvar),70
bt_le_per_adv_response_info.rssi(C var), 64
                                                 bt_le_per_adv_sync_param.options (C var), 70
bt_le_per_adv_response_info.subevent (C var),
                                                 bt_le_per_adv_sync_param.sid(C var), 70
                                                 bt_le_per_adv_sync_param.skip(C var), 70
bt_le_per_adv_response_info.tx_power (C var),
                                                 bt_le_per_adv_sync_param.timeout(C var),71
                                                 bt_le_per_adv_sync_recv_disable (C function), 56
bt_le_per_adv_response_info.tx_status (C var),
                                                 bt_le_per_adv_sync_recv_enable (C function), 55
                                                 bt_le_per_adv_sync_recv_info (C struct), 68
                                                 bt_le_per_adv_sync_recv_info.addr (C var), 69
bt_le_per_adv_response_params (C struct), 75
bt_le_per_adv_response_params.request_event
                                                 bt_le_per_adv_sync_recv_info.cte_type (C var),
        (C var), 76
bt_le_per_adv_response_params.request_subeventbt_le_per_adv_sync_recv_info.rssi (C var), 69
        (C var), 76
                                                 bt_le_per_adv_sync_recv_info.sid(Cvar), 69
bt_le_per_adv_response_params.response_slot
                                                 bt_le_per_adv_sync_recv_info.tx_power (C var),
        (C var), 76
                                                         69
bt_le_per_adv_response_params.response_subeverltt_le_per_adv_sync_state_info (C struct), 69
        (C var), 76
                                                 bt_le_per_adv_sync_state_info.recv_enabled
bt_le_per_adv_set_data (C function), 53
                                                         (C var), 69
bt_le_per_adv_set_info_transfer (C function), 56
                                                 bt_le_per_adv_sync_subevent (C function), 62
bt_le_per_adv_set_param (C function), 53
                                                 bt_le_per_adv_sync_subevent_params (C struct),
bt_le_per_adv_set_response_data (C function), 63
                                                         75
bt_le_per_adv_set_subevent_data (C function), 53
                                                 bt_le_per_adv_sync_subevent_params.num_subevents
bt_le_per_adv_start (C function), 53
                                                         (C var), 75
bt_le_per_adv_stop (C function), 54
                                                 bt_le_per_adv_sync_subevent_params.properties
bt_le_per_adv_subevent_data_params (C struct),
                                                         (C var), 75
                                                 bt_le_per_adv_sync_subevent_params.subevents
bt_le_per_adv_subevent_data_params.data
                                                         (C var), 75
                                                 bt_le_per_adv_sync_synced_info (C struct), 67
        var), 67
bt_le_per_adv_subevent_data_params.response_slbt_bequer_adv_sync_synced_info.addr(Cvar),68
        (C var), 67
                                                 bt_le_per_adv_sync_synced_info.conn(Cvar),68
bt_le_per_adv_subevent_data_params.response_slbmt_bst_apretr_adv_sync_synced_info.interval
        (C var), 67
                                                         var), 68
                                                 bt_le_per_adv_sync_synced_info.phy (C var), 68
bt_le_per_adv_subevent_data_params.subevent
        (C var), 67
                                                 bt_le_per_adv_sync_synced_info.recv_enabled
bt_le_per_adv_sync_cb (C struct), 69
                                                         (C var), 68
bt_le_per_adv_sync_cb.biginfo(C var), 70
                                                 bt_le_per_adv_sync_synced_info.service_data
bt_le_per_adv_sync_cb.cte_report_cb(Cvar),70
                                                         (C var), 68
bt_le_per_adv_sync_cb.recv(C var), 69
                                                 bt_le_per_adv_sync_synced_info.sid(C var), 68
bt_le_per_adv_sync_cb.state_changed(Cvar),70
                                                 bt_le_per_adv_sync_term_info (C struct), 68
bt_le_per_adv_sync_cb.synced (C var), 69
                                                 bt_le_per_adv_sync_term_info.addr (C var), 68
bt_le_per_adv_sync_cb.term(C var), 69
                                                 bt_le_per_adv_sync_term_info.reason(C var), 68
bt_le_per_adv_sync_cb_register (C function), 55
                                                 bt_le_per_adv_sync_term_info.sid(C var), 68
bt_le_per_adv_sync_create (C function), 55
                                                 bt_le_per_adv_sync_transfer (C function), 56
bt_le_per_adv_sync_delete (C function), 55
                                                 bt_le_per_adv_sync_transfer_param (C struct), 71
bt_le_per_adv_sync_get_index (C function), 54
                                                 bt_le_per_adv_sync_transfer_param.options (C
bt_le_per_adv_sync_get_info (C function), 54
                                                         var), 71
```

```
bt_le_per_adv_sync_transfer_param.skip
                                             (C bt_passkey_set (C function), 17
        var), 71
                                                 bt_ready_cb_t (C type), 40
bt_le_per_adv_sync_transfer_param.timeout (C
                                                 bt_rfcomm_create_pdu (C function), 176
                                                 bt_rfcomm_dlc(C struct), 177
bt_le_per_adv_sync_transfer_subscribe (C func-
                                                 bt_rfcomm_dlc_connect (C function), 176
        tion), 56
                                                 bt_rfcomm_dlc_disconnect(C function), 176
bt_le_per_adv_sync_transfer_unsubscribe
                                             (C bt_rfcomm_dlc_ops (C struct), 177
        function), 56
                                                 bt_rfcomm_dlc_ops.connected(C var), 177
BT_LE_SCAN_ACTIVE (C macro), 39
                                                 bt_rfcomm_dlc_ops.disconnected(Cvar), 177
bt_le_scan_cb (C struct), 73
                                                 bt_rfcomm_dlc_ops.recv(Cvar), 177
bt_le_scan_cb.recv(C var), 73
                                                 bt_rfcomm_dlc_ops.sent (C var), 177
                                                 bt_rfcomm_dlc_send(C function), 176
bt_le_scan_cb.timeout (C var), 73
                                                 bt_rfcomm_role(Cenum), 175
bt_le_scan_cb_register (C function), 58
bt_le_scan_cb_t (C type), 40
                                                 bt_rfcomm_role.BT_RFCOMM_ROLE_ACCEPTOR
                                                                                               (C
bt_le_scan_cb_unregister(C function), 58
                                                          enumerator), 175
BT_LE_SCAN_CODED_ACTIVE (C macro), 39
                                                 bt_rfcomm_role.BT_RFCOMM_ROLE_INITIATOR
                                                                                               (C
BT_LE_SCAN_CODED_PASSIVE (C macro), 39
                                                          enumerator), 175
                                                 bt_rfcomm_role_t (C type), 175
BT_LE_SCAN_OPT_FILTER_WHITELIST (C macro), 39
BT_LE_SCAN_PARAM (C macro), 39
                                                 bt_rfcomm_server (C struct), 177
bt_le_scan_param (C struct), 71
                                                 bt_rfcomm_server.accept (C var), 177
bt_le_scan_param.interval(C var), 72
                                                 bt_rfcomm_server.channel(Cvar), 177
bt_le_scan_param.interval_coded(C var),72
                                                 bt_rfcomm_server_register (C function), 176
                                                 BT_SDP_ADVANCED_AUDIO_SVCLASS (C macro), 179
bt_le_scan_param.options(C var),72
bt_le_scan_param.timeout(C var),72
                                                 BT_SDP_ALT16 (C macro), 190
bt_le_scan_param.type(C var),72
                                                 BT_SDP_ALT32 (C macro), 190
bt_le_scan_param.window(C var), 72
                                                 BT_SDP_ALT8 (C macro), 190
bt_le_scan_param.window_coded(Cvar),72
                                                 BT_SDP_ALT_UNSPEC (C macro), 190
BT_LE_SCAN_PARAM_INIT (C macro), 39
                                                 BT_SDP_APPLE_AGENT_SVCLASS (C macro), 183
BT_LE_SCAN_PASSIVE (C macro), 39
                                                 BT_SDP_ARRAY_16 (C macro), 191
                                                 BT_SDP_ARRAY_32 (C macro), 191
bt_le_scan_recv_info (C struct), 72
bt_le_scan_recv_info.addr (C var), 72
                                                 BT_SDP_ARRAY_8 (C macro), 191
bt_le_scan_recv_info.adv_props (C var), 73
                                                 BT_SDP_ATTR_ADD_PROTO_DESC_LIST (C macro), 184
                                                 BT_SDP_ATTR_AUDIO_FEEDBACK_SUPPORT (C macro),
bt_le_scan_recv_info.adv_type (C var), 73
bt_le_scan_recv_info.interval (C var), 73
                                                          185
                                                 BT_SDP_ATTR_BROWSE_GRP_LIST (C macro), 183
bt_le_scan_recv_info.primary_phy (C var), 73
bt_le_scan_recv_info.rssi(C var), 72
                                                 BT_SDP_ATTR_CLNT_EXEC_URL (C macro), 184
bt_le_scan_recv_info.secondary_phy (C var), 73
                                                 BT_SDP_ATTR_DATA_EXCHANGE_SPEC (C macro), 185
bt_le_scan_recv_info.sid(Cvar),72
                                                 BT_SDP_ATTR_DOC_URL (C macro), 184
bt_le_scan_recv_info.tx_power(Cvar),72
                                                 BT_SDP_ATTR_EXTERNAL_NETWORK (C macro), 185
                                                 BT_SDP_ATTR_FAX_CLASS1_SUPPORT (C macro), 185
bt_le_scan_start (C function), 57
bt_le_scan_stop (C function), 58
                                                 BT_SDP_ATTR_FAX_CLASS20_SUPPORT (C macro), 185
                                                 BT_SDP_ATTR_FAX_CLASS2_SUPPORT (C macro), 185
bt_le_set_auto_conn (C function), 14
bt_le_set_chan_map (C function), 59
                                                 BT_SDP_ATTR_GOEP_L2CAP_PSM (C macro), 184
bt_le_set_rpa_timeout (C function), 59
                                                 BT_SDP_ATTR_GROUP_ID (C macro), 184
BT_LE_SUPP_FEAT_16_ENCODE (C macro), 107
                                                 BT_SDP_ATTR_HID_BATTERY_POWER (C macro), 188
BT_LE_SUPP_FEAT_24_ENCODE (C macro), 107
                                                 BT_SDP_ATTR_HID_BOOT_DEVICE (C macro), 188
BT_LE_SUPP_FEAT_32_ENCODE (C macro), 106
                                                 BT_SDP_ATTR_HID_COUNTRY_CODE (C macro), 187
BT_LE_SUPP_FEAT_40_ENCODE (C macro), 106
                                                 BT_SDP_ATTR_HID_DESCRIPTOR_LIST (C macro), 187
BT_LE_SUPP_FEAT_8_ENCODE (C macro), 107
                                                 BT_SDP_ATTR_HID_DEVICE_RELEASE_NUMBER
                                                                                               (C
BT_LE_SUPP_FEAT_VALIDATE (C macro), 108
                                                          macro), 187
bt_le_whitelist_add (C function), 58
                                                 BT_SDP_ATTR_HID_DEVICE_SUBCLASS (C macro), 187
bt_le_whitelist_clear (C function), 59
                                                 BT_SDP_ATTR_HID_LANG_ID_BASE_LIST (C macro),
bt_le_whitelist_rem (C function), 59
                                                          187
BT_PASSKEY_INVALID (C macro), 4
```

BT_SDP_ATTR_HID_NORMALLY_CONNECTABLE (C macro), 188	BT_SDP_ATTR_SUPPORTED_FORMATS_LIST (C macro), 185
BT_SDP_ATTR_HID_PARSER_VERSION (C macro), 187	BT_SDP_ATTR_SUPPORTED_FUNCTIONS (C macro), 186
BT_SDP_ATTR_HID_PROFILE_VERSION (C macro), 188	BT_SDP_ATTR_SUPPORTED_MESSAGE_TYPES (C macro),
BT_SDP_ATTR_HID_RECONNECT_INITIATE (C macro),	186
187	BT_SDP_ATTR_SUPPORTED_REPOSITORIES (C macro),
BT_SDP_ATTR_HID_REMOTE_WAKEUP (C macro), 188	186
BT_SDP_ATTR_HID_SDP_DISABLE (C macro), 187	BT_SDP_ATTR_SVCDB_STATE (C macro), 184
BT_SDP_ATTR_HID_SUPERVISION_TIMEOUT (C macro),	BT_SDP_ATTR_SVCDESC_PRIMARY (C macro), 191
188	BT_SDP_ATTR_SVCINFO_TTL (C macro), 183
BT_SDP_ATTR_HID_VIRTUAL_CABLE (C macro), 187	BT_SDP_ATTR_SVCLASS_ID_LIST (C macro), 183
BT_SDP_ATTR_HOMEPAGE_URL (C macro), 185	BT_SDP_ATTR_SVCNAME_PRIMARY (C macro), 191
BT_SDP_ATTR_ICON_URL (C macro), 184	BT_SDP_ATTR_TOTAL_IMAGING_DATA_CAPACITY (C
BT_SDP_ATTR_IP4_SUBNET (C macro), 186	macro), 186
BT_SDP_ATTR_IP6_SUBNET (C macro), 186	BT_SDP_ATTR_VENDOR_ID (C macro), 187
BT_SDP_ATTR_IP_SUBNET (C macro), 184	BT_SDP_ATTR_VENDOR_ID_SOURCE (C macro), 187
BT_SDP_ATTR_LANG_BASE_ATTR_ID_LIST (C macro),	BT_SDP_ATTR_VERSION (C macro), 187
183	BT_SDP_ATTR_VERSION_NUM_LIST (C macro), 184
BT_SDP_ATTR_MAP_SUPPORTED_FEATURES (C macro),	BT_SDP_ATTR_WAP_GATEWAY (C macro), 185
186	BT_SDP_ATTR_WAP_STACK_TYPE (C macro), 186
BT_SDP_ATTR_MAS_INSTANCE_ID (C macro), 186	bt_sdp_attribute (C struct), 195
BT_SDP_ATTR_MAX_NET_ACCESSRATE (C macro), 186	bt_sdp_attribute.id(C var), 196
BT_SDP_ATTR_MCAP_SUPPORTED_PROCEDURES (C	bt_sdp_attribute.val (C var), 196
macro), 185	BT_SDP_AUDIO_SINK_SVCLASS (C macro), 179
BT_SDP_ATTR_MPMD_SCENARIOS (C macro), 184	BT_SDP_AUDIO_SOURCE_SVCLASS (C macro), 179
BT_SDP_ATTR_MPS_DEPENDENCIES (C macro), 184	BT_SDP_AV_REMOTE_CONTROLLER_SVCLASS (C macro),
BT_SDP_ATTR_MPSD_SCENARIOS (C macro), 184	179
BT_SDP_ATTR_NET_ACCESS_TYPE (C macro), 186	BT_SDP_AV_REMOTE_SVCLASS (C macro), 179
BT_SDP_ATTR_NETWORK (C macro), 185	BT_SDP_AV_REMOTE_TARGET_SVCLASS (C macro), 179
BT_SDP_ATTR_NETWORK (C macro), 185	BT_SDP_AV_SVCLASS (C macro), 181
BT_SDP_ATTR_PBAP_SUPPORTED_FEATURES (C macro),	BT_SDP_BASIC_PRINTING_SVCLASS (C macro), 180
186	BT_SDP_BOOL (C macro), 189
BT_SDP_ATTR_PRIMARY_RECORD (C macro), 187	BT_SDP_BROWSE_GRP_DESC_SVCLASS (C macro), 178
BT_SDP_ATTR_PRODUCT_ID (C macro), 187	BT_SDP_CIP_SVCLASS (C macro), 176
BT_SDP_ATTR_PROFILE_DESC_LIST (C macro), 184	bt_sdp_client_result (<i>C struct</i>), 196
BT_SDP_ATTR_PROTO_DESC_LIST (C macro), 183	bt_sdp_client_result.next_record_hint (C var),
BT_SDP_ATTR_PROVNAME_PRIMARY (C macro), 191	196
BT_SDP_ATTR_RECORD_HANDLE (C macro), 183	bt_sdp_client_result.resp_buf(C var), 196
BT_SDP_ATTR_RECORD_STATE (C macro), 183	bt_sdp_client_result.uuid(C var), 196
BT_SDP_ATTR_REMOTE_AUDIO_VOLUME_CONTROL (C	BT_SDP_CORDLESS_TELEPHONY_SVCLASS (C macro),
macro), 185	178
BT_SDP_ATTR_SECURITY_DESC (C macro), 186	bt_sdp_data_elem (<i>C struct</i>), 195
BT_SDP_ATTR_SERVICE_AVAILABILITY (C macro), 184	bt_sdp_data_elem.data_size (C var), 195
BT_SDP_ATTR_SERVICE_ID (C macro), 183	bt_sdp_data_elem.total_size (C var), 195
BT_SDP_ATTR_SERVICE_VERSION (C macro), 185	bt_sdp_data_elem.type (C var), 195
BT_SDP_ATTR_SPECIFICATION_ID (C macro), 187	BT_SDP_DATA_ELEM_LIST (C macro), 191
BT_SDP_ATTR_SUPPORTED_CAPABILITIES (C macro),	BT_SDP_DATA_NIL (C macro), 188
186	BT_SDP_DIALUP_NET_SVCLASS (C macro), 178
	BT_SDP_DIRECT_PRINTING_SVCLASS (C macro), 179
macro), 185	BT_SDP_DIRECT_PRT_REFOBJS_SVCLASS (C macro),
BT_SDP_ATTR_SUPPORTED_FEATURES (C macro), 186	180
BT_SDP_ATTR_SUPPORTED_FEATURES_LIST (C macro),	bt_sdp_discover (C function), 193
184	bt_sdp_discover_cancel (C function), 194
-	bt_sdp_discover_func_t (C type), 192
	-

```
bt_sdp_discover_params (C struct), 196
                                                  BT_SDP_PBAP_PCE_SVCLASS (C macro), 181
bt_sdp_discover_params.func(Cvar), 197
                                                  BT_SDP_PBAP_PSE_SVCLASS (C macro), 181
                                                  BT_SDP_PBAP_SVCLASS (C macro), 181
bt_sdp_discover_params.pool (C var), 197
bt_sdp_discover_params.uuid(C var), 197
                                                  BT_SDP_PNP_INFO_SVCLASS (C macro), 182
BT_SDP_FAX_SVCLASS (C macro), 179
                                                  BT_SDP_PRIMARY_LANG_BASE (C macro), 191
BT_SDP_GENERIC_ACCESS_SVCLASS (C macro), 183
                                                  BT_SDP_PRINTING_STATUS_SVCLASS (C macro), 180
BT SDP GENERIC ATTRIB SVCLASS (C macro), 183
                                                  bt_sdp_proto (C enum), 193
BT_SDP_GENERIC_AUDIO_SVCLASS (C macro), 182
                                                  bt_sdp_proto.BT_SDP_PROTO_L2CAP (C enumerator),
BT_SDP_GENERIC_FILETRANS_SVCLASS (C macro), 182
BT\_SDP\_GENERIC\_NETWORKING\_SVCLASS (C macro),
                                                  bt\_sdp\_proto.BT\_SDP\_PROTO\_RFCOMM (C enumera-
                                                          tor), 193
BT_SDP_GENERIC_TELEPHONY_SVCLASS (C macro), 182
                                                  BT_SDP_PUBLIC_BROWSE_GROUP (C macro), 178
bt_sdp_get_addl_proto_param(C function), 194
                                                  BT_SDP_RECORD (C macro), 192
bt_sdp_get_features (C function), 195
                                                  bt_sdp_record (C struct), 196
bt_sdp_get_profile_version (C function), 194
                                                  bt_sdp_record.attr_count (C var), 196
bt_sdp_get_proto_param (C function), 194
                                                  bt_sdp_record.attrs(C var), 196
BT_SDP_GN_SVCLASS (C macro), 179
                                                  bt_sdp_record.handle(C var), 196
BT_SDP_GNSS_SERVER_SVCLASS (C macro), 181
                                                  bt_sdp_record.index (C var), 196
BT_SDP_GNSS_SVCLASS (C macro), 181
                                                  bt_sdp_record.next (C var), 196
BT_SDP_HANDSFREE_AGW_SVCLASS (C macro), 180
                                                  BT_SDP_REFERENCE_PRINTING_SVCLASS (C macro),
BT_SDP_HANDSFREE_SVCLASS (C macro), 180
                                                           180
BT_SDP_HCR_PRINT_SVCLASS (C macro), 180
                                                  BT_SDP_REFLECTED_UI_SVCLASS (C macro), 180
BT_SDP_HCR_SCAN_SVCLASS (C macro), 180
                                                  bt_sdp_register_service (C function), 193
BT SDP HCR SVCLASS (C macro), 180
                                                  BT_SDP_SAP_SVCLASS (C macro), 181
BT_SDP_HDP_SINK_SVCLASS (C macro), 183
                                                  BT_SDP_SDP_SERVER_SVCLASS (C macro), 178
BT_SDP_HDP_SOURCE_SVCLASS (C macro), 183
                                                  BT_SDP_SEQ16 (C macro), 190
BT_SDP_HDP_SVCLASS (C macro), 182
                                                  BT_SDP_SEQ32 (C macro), 190
BT_SDP_HEADSET_AGW_SVCLASS (C macro), 179
                                                  BT_SDP_SEQ8 (C macro), 190
BT_SDP_HEADSET_SVCLASS (C macro), 178
                                                  BT_SDP_SEQ_UNSPEC (C macro), 190
BT_SDP_HID_SVCLASS (C macro), 180
                                                  BT_SDP_SERIAL_PORT_SVCLASS (C macro), 178
BT_SDP_IMAGING_ARCHIVE_SVCLASS (C macro), 180
                                                  BT_SDP_SERVER_RECORD_HANDLE (C macro), 191
BT_SDP_IMAGING_REFOBJS_SVCLASS (C macro), 180
                                                  BT_SDP_SERVICE_ID (C macro), 192
BT_SDP_IMAGING_RESPONDER_SVCLASS (C macro), 180
                                                  BT_SDP_SERVICE_NAME (C macro), 192
BT_SDP_IMAGING_SVCLASS (C macro), 180
                                                  BT_SDP_SIZE_DESC_MASK (C macro), 191
BT_SDP_INT128 (C macro), 189
                                                  BT_SDP_SIZE_INDEX_OFFSET (C macro), 191
                                                  BT_SDP_SUPPORTED_FEATURES (C macro), 192
BT_SDP_INT16 (C macro), 189
BT_SDP_INT32 (C macro), 189
                                                  BT_SDP_TEXT_STR16 (C macro), 189
BT_SDP_INT64 (C macro), 189
                                                  BT_SDP_TEXT_STR32 (C macro), 189
                                                  BT_SDP_TEXT_STR8 (C macro), 189
BT_SDP_INT8 (C macro), 189
BT_SDP_INTERCOM_SVCLASS (C macro), 179
                                                  BT_SDP_TEXT_STR_UNSPEC (C macro), 189
BT_SDP_IRMC_SYNC_CMD_SVCLASS (C macro), 178
                                                  BT_SDP_TYPE_DESC_MASK (C macro), 191
BT_SDP_IRMC_SYNC_SVCLASS (C macro), 178
                                                  BT_SDP_TYPE_SIZE (C macro), 191
BT_SDP_LAN_ACCESS_SVCLASS (C macro), 178
                                                  BT_SDP_TYPE_SIZE_VAR (C macro), 191
BT_SDP_LIST (C macro), 191
                                                  BT_SDP_UDI_MT_SVCLASS (C macro), 181
BT_SDP_MAP_MCE_SVCLASS (C macro), 181
                                                  BT_SDP_UDI_TA_SVCLASS (C macro), 181
BT_SDP_MAP_MSE_SVCLASS (C macro), 181
                                                  BT_SDP_UINT128 (C macro), 189
BT_SDP_MAP_SVCLASS (C macro), 181
                                                  BT_SDP_UINT16 (C macro), 188
                                                  BT_SDP_UINT32 (C macro), 188
BT_SDP_MPS_SC_SVCLASS (C macro), 181
                                                  BT_SDP_UINT64 (C macro), 188
BT_SDP_MPS_SVCLASS (C macro), 182
BT_SDP_NAP_SVCLASS (C macro), 179
                                                  BT_SDP_UINT8 (C macro), 188
BT_SDP_NEW_SERVICE (C macro), 191
                                                  BT_SDP_UPNP_IP_SVCLASS (C macro), 182
BT_SDP_OBEX_FILETRANS_SVCLASS (C macro), 178
                                                  BT_SDP_UPNP_L2CAP_SVCLASS (C macro), 182
BT_SDP_OBEX_OBJPUSH_SVCLASS (C macro), 178
                                                  BT_SDP_UPNP_LAP_SVCLASS (C macro), 182
BT_SDP_PANU_SVCLASS (C macro), 179
                                                  BT_SDP_UPNP_PAN_SVCLASS (C macro), 182
```

```
BT_SDP_UPNP_SVCLASS (C macro), 182
                                                  bt_spp_discover (C function), 206
BT_SDP_URL_STR16 (C macro), 190
                                                  bt_spp_discover_callback (C type), 205
BT_SDP_URL_STR32 (C macro), 190
                                                  bt_spp_get_channel (C function), 207
BT_SDP_URL_STR8 (C macro), 190
                                                  bt_spp_get_conn (C function), 207
BT_SDP_URL_STR_UNSPEC (C macro), 190
                                                  bt_spp_get_role (C function), 207
BT_SDP_UUID128 (C macro), 189
                                                  bt_spp_role(Cenum), 206
BT_SDP_UUID16 (C macro), 189
                                                  bt_spp_role.BT_SPP_ROLE_CLIENT (C enumerator),
BT_SDP_UUID32 (C macro), 189
BT_SDP_UUID_UNSPEC (C macro), 189
                                                  bt_spp_role.BT_SPP_ROLE_SERVER (C enumerator),
BT_SDP_VIDEO_CONF_GW_SVCLASS (C macro), 181
                                                          206
BT_SDP_VIDEO_DISTRIBUTION_SVCLASS (C macro),
                                                  bt_spp_role_t (C type), 205
        182
                                                  bt_spp_server_register (C function), 206
BT_SDP_VIDEO_SINK_SVCLASS (C macro), 182
                                                  bt_unpair (C function), 62
                                                  bt_uuid (C struct), 309
BT_SDP_VIDEO_SOURCE_SVCLASS (C macro), 182
BT_SDP_WAP_CLIENT_SVCLASS (C macro), 179
                                                  BT_UUID_128 (C macro), 230
BT_SDP_WAP_SVCLASS (C macro), 179
                                                  bt_uuid_128 (C struct), 310
bt_security_err(Cenum), 8
                                                  bt_uuid_128.uuid (C var), 310
bt_security_err.BT_SECURITY_ERR_AUTH_FAIL (C
                                                 bt_uuid_128.val (C var), 310
        enumerator), 8
                                                  BT_UUID_128_ENCODE (C macro), 230
bt_security_err.BT_SECURITY_ERR_AUTH_REQUIREMEDIT_UUID_16 (C macro), 230
        (C enumerator), 8
                                                  bt_uuid_16 (C struct), 309
bt_security_err.BT_SECURITY_ERR_INVALID_PARAM bt_uuid_16.uuid(C var), 309
                                                  bt_uuid_16.val (C var), 309
        (C enumerator), 9
bt_security_err.BT_SECURITY_ERR_KEY_REJECTED BT_UUID_16_ENCODE (C macro), 231
        (C enumerator), 9
                                                  BT_UUID_32 (C macro), 230
bt_security_err.BT_SECURITY_ERR_OOB_NOT_AVAILABLEquid_32 (C struct), 309
        (C enumerator), 8
                                                  bt_uuid_32.uuid(C var), 310
bt_security_err.BT_SECURITY_ERR_PAIR_NOT_ALLOWDED_uuid_32.val(Cvar), 310
                                                  BT_UUID_32_ENCODE (C macro), 231
        (C enumerator), 9
bt_security_err.BT_SECURITY_ERR_PAIR_NOT_SUPPORTEDUID_ACLS (C macro), 238
                                                  BT_UUID_ACLS_VAL (C macro), 238
        (Cenumerator), 8
bt_security_err.BT_SECURITY_ERR_PIN_OR_KEY_MISENIMOUID_AICS (C macro), 238
                                                  BT_UUID_AICS_CONTROL (C macro), 288
        (C enumerator), 8
bt_security_err.BT_SECURITY_ERR_SUCCESS
                                                  BT_UUID_AICS_CONTROL_VAL (C macro), 288
                                                  BT_UUID_AICS_DESCRIPTION (C macro), 288
        enumerator), 8
bt_security_err.BT_SECURITY_ERR_UNSPECIFIED
                                                  BT_UUID_AICS_DESCRIPTION_VAL (C macro), 288
        (C enumerator), 9
                                                  BT_UUID_AICS_GAIN_SETTINGS (C macro), 288
bt_security_flag(Cenum), 7
                                                  BT_UUID_AICS_GAIN_SETTINGS_VAL (C macro), 288
bt_security_flag.BT_SECURITY_FLAG_00B (C enu-
                                                  BT_UUID_AICS_INPUT_STATUS (C macro), 288
                                                  BT_UUID_AICS_INPUT_STATUS_VAL (C macro), 288
        merator), 7
bt_security_flag.BT_SECURITY_FLAG_SC (C enu-
                                                  BT_UUID_AICS_INPUT_TYPE (C macro), 288
                                                  BT_UUID_AICS_INPUT_TYPE_VAL (C macro), 288
        merator), 7
bt_security_info(C struct), 22
                                                  BT_UUID_AICS_STATE (C macro), 288
bt_security_info.enc_key_size (C var), 22
                                                  BT_UUID_AICS_STATE_VAL (C macro), 288
bt_security_info.flags(C var), 22
                                                  BT_UUID_AICS_VAL (C macro), 238
bt_security_info.level(C var), 22
                                                  BT_UUID_AIOS (C macro), 235
bt_security_t (C type), 5
                                                  BT_UUID_AIOS_VAL (C macro), 235
bt_set_appearance (C function), 47
                                                  BT_UUID_ALERT_LEVEL (C macro), 244
                                                  BT_UUID_ALERT_LEVEL_VAL (C macro), 244
bt_set_bondable (C function), 16
bt_set_name (C function), 47
                                                  BT_UUID_ANS (C macro), 234
bt_spp_callback(C type), 205
                                                  BT_UUID_ANS_VAL (C macro), 234
                                                  BT_UUID_APPARENT_WIND_DIR (C macro), 258
bt_spp_client_connect (C function), 206
                                                  BT_UUID_APPARENT_WIND_DIR_VAL (C macro), 258
bt_spp_data_send (C function), 206
bt_spp_disconnect (C function), 207
                                                  BT_UUID_APPARENT_WIND_SPEED (C macro), 258
```

BT_UUID_APPARENT_WIND_SPEED_VAL (C macro), 258 BT_UUID_ASCS (C macro), 239 BT_UUID_ASCS_ASE_CP (C macro), 298 BT_UUID_ASCS_ASE_CP_VAL (C macro), 298 BT_UUID_ASCS_ASE_SNK (C macro), 298 BT_UUID_ASCS_ASE_SNK_VAL (C macro), 298 BT_UUID_ASCS_ASE_SRC (C macro), 298 BT_UUID_ASCS_ASE_SRC_VAL (C macro), 298 BT_UUID_ASCS_ASE_SRC_VAL (C macro), 298 BT_UUID_ASCS_VAL (C macro), 306 BT_UUID_ATT_(C macro), 306 BT_UUID_ATT_VAL (C macro), 306	BT_UUID_BASS_RECV_STATE (C macro), 298 BT_UUID_BASS_RECV_STATE_VAL (C macro), 298 BT_UUID_BASS_VAL (C macro), 240 BT_UUID_BCS (C macro), 235 BT_UUID_BCS_VAL (C macro), 235 BT_UUID_BMS (C macro), 236 BT_UUID_BMS_CONTROL_POINT (C macro), 265 BT_UUID_BMS_CONTROL_POINT_VAL (C macro), 264 BT_UUID_BMS_FEATURE (C macro), 265 BT_UUID_BMS_FEATURE_VAL (C macro), 265 BT_UUID_BMS_VAL (C macro), 236
BT_UUID_AVCTP (C macro), 307	BT_UUID_BNEP (C macro), 307
BT_UUID_AVCTP_VAL (C macro), 307	BT_UUID_BNEP_VAL (C macro), 307
BT_UUID_AVDTP (C macro), 307	BT_UUID_BPS (C macro), 234
BT_UUID_AVDTP_VAL (C macro), 307	BT_UUID_BPS_VAL (C macro), 234
BT_UUID_BAR_PRESSURE_TREND (C macro), 264	BT_UUID_BROADCAST_AUDIO (C macro), 240
BT_UUID_BAR_PRESSURE_TREND_VAL (C macro), 264	BT_UUID_BROADCAST_AUDIO_VAL (C macro), 240
BT_UUID_BAS (C macro), 234	BT_UUID_BSS (C macro), 237
BT_UUID_BAS_BATTERY_CRIT_STATUS (C macro), 303	BT_UUID_BSS_VAL (C macro), 237
BT_UUID_BAS_BATTERY_CRIT_STATUS_VAL (C macro),	BT_UUID_CAS (C macro), 240
303	BT_UUID_CAS_VAL (C macro), 240
BT_UUID_BAS_BATTERY_ENERGY_STATUS (C macro),	BT_UUID_CCID (C macro), 297
304	BT_UUID_CCID_VAL (C macro), 296
BT_UUID_BAS_BATTERY_ENERGY_STATUS_VAL (C	BT_UUID_CENTRAL_ADDR_RES (C macro), 265
macro), 304	BT_UUID_CENTRAL_ADDR_RES_VAL (C macro), 265
BT_UUID_BAS_BATTERY_HEALTH_INF (C macro), 303	BT_UUID_CGM_FEATURE (C macro), 265
BT_UUID_BAS_BATTERY_HEALTH_INF_VAL (C macro),	BT_UUID_CGM_FEATURE_VAL (C macro), 265
303	BT_UUID_CGM_MEASUREMENT (C macro), 265
BT_UUID_BAS_BATTERY_HEALTH_STATUS (C macro),	BT_UUID_CGM_MEASUREMENT_VAL (C macro), 265
303	BT_UUID_CGM_SESSION_RUN_TIME (C macro), 265
BT_UUID_BAS_BATTERY_HEALTH_STATUS_VAL (C	BT_UUID_CGM_SESSION_RUN_TIME_VAL(C macro), 265
macro), 303	BT_UUID_CGM_SESSION_START_TIME (C macro), 265
BT_UUID_BAS_BATTERY_INF (C macro), 303 BT_UUID_BAS_BATTERY_INF_VAL (C macro), 303	BT_UUID_CGM_SESSION_START_TIME_VAL (C macro), 265
BT_UUID_BAS_BATTERY_LEVEL (C macro), 303 BT_UUID_BAS_BATTERY_LEVEL (C macro), 246	BT_UUID_CGM_SPECIFIC_OPS_CONTROL_POINT (C
BT_UUID_BAS_BATTERY_LEVEL_STATE (C macro), 246	macro), 266
BT_UUID_BAS_BATTERY_LEVEL_STATE_VAL (C macro),	BT_UUID_CGM_SPECIFIC_OPS_CONTROL_POINT_VAL
246	(<i>C macro</i>), 266
BT_UUID_BAS_BATTERY_LEVEL_STATUS (C macro), 303	BT_UUID_CGM_STATUS (C macro), 265
BT_UUID_BAS_BATTERY_LEVEL_STATUS_VAL (C	BT_UUID_CGM_STATUS_VAL (C macro), 265
macro), 303	BT_UUID_CGMS (C macro), 236
BT_UUID_BAS_BATTERY_LEVEL_VAL (C macro), 246	BT_UUID_CGMS_VAL (C macro), 236
BT_UUID_BAS_BATTERY_POWER_STATE (C macro), 246	bt_uuid_cmp (C function), 308
BT_UUID_BAS_BATTERY_POWER_STATE_VAL (C macro),	BT_UUID_CMTP (C macro), 307
246	BT_UUID_CMTP_VAL (C macro), 307
BT_UUID_BAS_BATTERY_TIME_STATUS (C macro), 303	BT_UUID_CPS (C macro), 235
BT_UUID_BAS_BATTERY_TIME_STATUS_VAL (C macro),	BT_UUID_CPS_VAL (C macro), 235
303	bt_uuid_create (C function), 308
BT_UUID_BAS_VAL (C macro), 234	BT_UUID_CSC (C macro), 235
BT_UUID_BASIC_AUDIO (C macro), 240	BT_UUID_CSC_FEATURE (C macro), 255
BT_UUID_BASIC_AUDIO_VAL (C macro), 240	BT_UUID_CSC_FEATURE_VAL (C macro), 255
BT_UUID_BASS (C macro), 240	BT_UUID_CSC_MEASUREMENT (C macro), 255
BT_UUID_BASS_CONTROL_POINT (C macro), 298	BT_UUID_CSC_MEASUREMENT_VAL (C macro), 255
BT_UUID_BASS_CONTROL_POINT_VAL (C macro), 298	BT_UUID_CSC_VAL (C macro), 235
• //	

	_UUID_CSIS (C macro), 238	BT_UUID_DTS_VAL (C macro), 238
	_UUID_CSIS_RANK (C macro), 290	BT_UUID_ECS (C macro), 238
	_UUID_CSIS_RANK_VAL (C macro), 290	BT_UUID_ECS_VAL (C macro), 238
	_UUID_CSIS_SET_LOCK (C macro), 290	BT_UUID_ELEVATION (C macro), 257
BT	_UUID_CSIS_SET_LOCK_VAL (C macro), 290	BT_UUID_ELEVATION_VAL (C macro), 257
BT	_UUID_CSIS_SET_SIRK (C macro), 289	BT_UUID_ES_CONFIGURATION (C macro), 243
BT	_UUID_CSIS_SET_SIRK_VAL (C macro), 289	BT_UUID_ES_CONFIGURATION_VAL (C macro), 242
ВТ	_UUID_CSIS_SET_SIZE (C macro), 290	BT_UUID_ES_MEASUREMENT (C macro), 243
ВТ	_UUID_CSIS_SET_SIZE_VAL (C macro), 290	BT_UUID_ES_MEASUREMENT_VAL (C macro), 243
	_UUID_CSIS_VAL (C macro), 238	BT_UUID_ES_TRIGGER_SETTING (C macro), 243
	UUID_CTES (C macro), 239	BT_UUID_ES_TRIGGER_SETTING_VAL (C macro), 243
	_UUID_CTES_VAL (C macro), 239	BT_UUID_ESS (C macro), 235
	UUID_CTS (C macro), 232	BT_UUID_ESS_VAL (C macro), 235
	_UUID_CTS_CURRENT_TIME (C macro), 248	BT_UUID_FMS (C macro), 237
	_UUID_CTS_CURRENT_TIME_VAL (C macro), 248	BT_UUID_FMS_VAL (C macro), 237
	_UUID_CTS_LOCAL_TIME_INFORMATION (C macro),	BT_UUID_FTP (C macro), 306
ы		BT_UUID_FTP_VAL (C macro), 306
рт	304	
ВІ	_UUID_CTS_LOCAL_TIME_INFORMATION_VAL (C	BT_UUID_GAP (C macro), 232
	<i>macro</i>), 304	BT_UUID_GAP_APPEARANCE (C macro), 243
BI	_UUID_CTS_REFERENCE_TIME_INFORMATION (C	BT_UUID_GAP_APPEARANCE_VAL (C macro), 243
	<i>macro</i>), 304	BT_UUID_GAP_DEVICE_NAME (C macro), 243
BT	_UUID_CTS_REFERENCE_TIME_INFORMATION_VAL	BT_UUID_GAP_DEVICE_NAME_VAL (C macro), 243
	(C macro), 304	BT_UUID_GAP_PPCP (C macro), 244
	_UUID_CTS_VAL (C macro), 232	BT_UUID_GAP_PPCP_VAL (C macro), 244
	_UUID_DECLARE_128 (C macro), 230	BT_UUID_GAP_PPF (C macro), 243
	_UUID_DECLARE_16 (C macro), 230	BT_UUID_GAP_PPF_VAL (C macro), 243
	_UUID_DECLARE_32 (C macro), 230	BT_UUID_GAP_RA (C macro), 243
BT	_UUID_DESC_VALUE_CHANGED (C macro), 259	BT_UUID_GAP_RA_VAL (C macro), 243
BT	_UUID_DESC_VALUE_CHANGED_VAL (C macro), 259	BT_UUID_GAP_VAL (C macro), 232
BT	_UUID_DEW_POINT (C macro), 259	BT_UUID_GATT (C macro), 232
BT	_UUID_DEW_POINT_VAL (C macro), 259	BT_UUID_GATT_2ZHRL (C macro), 263
BT	_UUID_DIS (C macro), 233	BT_UUID_GATT_2ZHRL_VAL (C macro), 262
BT	_UUID_DIS_FIRMWARE_REVISION (C macro), 248	BT_UUID_GATT_3ZHRL (C macro), 262
BT	_UUID_DIS_FIRMWARE_REVISION_VAL (C macro),	BT_UUID_GATT_3ZHRL_VAL (C macro), 262
	248	BT_UUID_GATT_4ZHRL (C macro), 287
BT	_UUID_DIS_HARDWARE_REVISION (C macro), 248	BT_UUID_GATT_4ZHRL_VAL (C macro), 287
BT	_UUID_DIS_HARDWARE_REVISION_VAL (C macro),	BT_UUID_GATT_5ZHRL (C macro), 261
	248	BT_UUID_GATT_5ZHRL_VAL (C macro), 261
ВТ	_UUID_DIS_MANUFACTURER_NAME (C macro), 248	BT_UUID_GATT_AC (C macro), 273
		BT_UUID_GATT_AC_VAL (C macro), 272
	248	BT_UUID_GATT_ACS (C macro), 286
ВТ	_UUID_DIS_MODEL_NUMBER (C macro), 247	BT_UUID_GATT_ACS_CP (C macro), 284
	_UUID_DIS_MODEL_NUMBER_VAL (C macro), 247	BT_UUID_GATT_ACS_CP_VAL (C macro), 284
	_UUID_DIS_PNP_ID (C macro), 253	BT_UUID_GATT_ACS_DI (C macro), 283
	_UUID_DIS_PNP_ID_VAL (C macro), 253	BT_UUID_GATT_ACS_DI_VAL (C macro), 283
	_UUID_DIS_SERIAL_NUMBER (C macro), 248	BT_UUID_GATT_ACS_D0I (C macro), 283
	_UUID_DIS_SERIAL_NUMBER_VAL (C macro), 248	BT_UUID_GATT_ACS_DOI_VAL (C macro), 283
	_UUID_DIS_SOFTWARE_REVISION (C macro), 248	BT_UUID_GATT_ACS_DON (C macro), 283
ВI	_UUID_DIS_SOFTWARE_REVISION_VAL (C macro),	BT_UUID_GATT_ACS_DON_VAL (C macro), 283
	248	BT_UUID_GATT_ACS_S (C macro), 283
	_UUID_DIS_SYSTEM_ID (C macro), 247	BT_UUID_GATT_ACS_S_VAL (C macro), 283
	_UUID_DIS_SYSTEM_ID_VAL (C macro), 247	BT_UUID_GATT_ACS_VAL (C macro), 286
	_UUID_DIS_VAL (C macro), 233	BT_UUID_GATT_ACTEI (C macro), 295
BT	_UUID_DTS (C macro), 239	BT_UUID_GATT_ACTEI_VAL (C macro), 295

	/2 > 2.52
BT_UUID_GATT_ACTEML (C macro), 295	BT_UUID_GATT_BPF (C macro), 252
BT_UUID_GATT_ACTEML_VAL (C macro), 295	BT_UUID_GATT_BPF_VAL (C macro), 252
BT_UUID_GATT_ACTEMTC (C macro), 295	BT_UUID_GATT_BPM (C macro), 250
BT_UUID_GATT_ACTEMTC_VAL (C macro), 295	BT_UUID_GATT_BPM_VAL (C macro), 250
BT_UUID_GATT_ACTEP (C macro), 295	BT_UUID_GATT_BPR (C macro), 284
BT_UUID_GATT_ACTEP_VAL (C macro), 295	BT_UUID_GATT_BPR_VAL (C macro), 284
BT_UUID_GATT_ACTETD (C macro), 295	BT_UUID_GATT_BR_EDR_HD (C macro), 284
BT_UUID_GATT_ACTETD_VAL (C macro), 295	BT_UUID_GATT_BR_EDR_HD_VAL (C macro), 284
BT_UUID_GATT_AE32 (C macro), 290	BT_UUID_GATT_BSS_CP (C macro), 283
BT_UUID_GATT_AE32_VAL (C macro), 290	BT_UUID_GATT_BSS_CP_VAL (C macro), 282
BT_UUID_GATT_AEANTHR (C macro), 262	BT_UUID_GATT_BSS_R (C macro), 283
BT_UUID_GATT_AEANTHR_VAL (C macro), 262	BT_UUID_GATT_BSS_R_VAL (C macro), 283
BT_UUID_GATT_AEHRLL (C macro), 259	BT_UUID_GATT_BT_SIG_D (C macro), 284
BT_UUID_GATT_AEHRLL_VAL (C macro), 259	BT_UUID_GATT_BT_SIG_D_VAL (C macro), 284
BT_UUID_GATT_AEHRUL (C macro), 260	BT_UUID_GATT_CAF (C macro), 242
BT_UUID_GATT_AEHRUL_VAL (C macro), 260	BT_UUID_GATT_CAF_VAL (C macro), 242
BT_UUID_GATT_AETHR (C macro), 260	BT_UUID_GATT_CCC (C macro), 241
BT_UUID_GATT_AETHR_VAL (C macro), 260	BT_UUID_GATT_CCC_VAL (C macro), 241
BT_UUID_GATT_AG (C macro), 287	BT_UUID_GATT_CCTEMP (C macro), 274
BT_UUID_GATT_AG_VAL (C macro), 287	BT_UUID_GATT_CCTEMP_VAL (C macro), 274
BT_UUID_GATT_AGE (C macro), 260	BT_UUID_GATT_CEP (C macro), 241
BT_UUID_GATT_AGE_VAL (C macro), 260	BT_UUID_GATT_CEP_VAL (C macro), 241
BT_UUID_GATT_AGGR (C macro), 255	BT_UUID_GATT_CH4CONC (C macro), 300
BT_UUID_GATT_AGGR_VAL (C macro), 255	BT_UUID_GATT_CH4CONC_VAL (C macro), 300
BT_UUID_GATT_AI (C macro), 254	BT_UUID_GATT_CHRC (C macro), 241
BT_UUID_GATT_AI_VAL (C macro), 254	BT_UUID_GATT_CHRC_VAL (C macro), 241
BT_UUID_GATT_ALRTCID (C macro), 252	BT_UUID_GATT_CHRC_VAL (C macro), 241 BT_UUID_GATT_CI (C macro), 287
BT_UUID_GATT_ALRTCID_MASK (C macro), 251	BT_UUID_GATT_CI_VAL (C macro), 287
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251	BT_UUID_GATT_CIEIDX (C macro), 273
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 267	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC (C macro), 300
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC (C macro), 300 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260 BT_UUID_GATT_ANHRLL_VAL (C macro), 260	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC (C macro), 300 BT_UUID_GATT_COCONC_VAL (C macro), 299
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260 BT_UUID_GATT_ANHRLL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC (C macro), 300 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260 BT_UUID_GATT_ANHRLL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COCONC_VAL (C macro), 274 BT_UUID_GATT_COEFFICIENT (C macro), 274
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COCONC_VAL (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290 BT_UUID_GATT_COUNT16 (C macro), 274 BT_UUID_GATT_COUNT16 (C macro), 274
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260 BT_UUID_GATT_ANHRLL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_AO (C macro), 255 BT_UUID_GATT_AO_VAL (C macro), 254 BT_UUID_GATT_AP (C macro), 290	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290 BT_UUID_GATT_COUNT16 (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL_(C macro), 260 BT_UUID_GATT_ANHRUL_(C macro), 260 BT_UUID_GATT_ANHRUL_(C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 255 BT_UUID_GATT_AO (C macro), 255 BT_UUID_GATT_AO (C macro), 290 BT_UUID_GATT_AP_VAL (C macro), 290	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290 BT_UUID_GATT_COUNT16 (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24_VAL (C macro), 274
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260 BT_UUID_GATT_ANHRLL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_AO (C macro), 255 BT_UUID_GATT_AO (C macro), 254 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AV (C macro), 273	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290 BT_UUID_GATT_COUNT16 (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24_VAL (C macro), 274 BT_UUID_GATT_COUNT24_VAL (C macro), 274 BT_UUID_GATT_COUNT24_VAL (C macro), 274
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_AO (C macro), 255 BT_UUID_GATT_AO (C macro), 255 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AV_VAL (C macro), 273 BT_UUID_GATT_AV_VAL (C macro), 273	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290 BT_UUID_GATT_COUNT16 (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24_VAL (C macro), 274 BT_UUID_GATT_COUNT24_VAL (C macro), 274 BT_UUID_GATT_COFF (C macro), 242 BT_UUID_GATT_CPF_VAL (C macro), 242
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ALT_VAL (C macro), 260 BT_UUID_GATT_ANHRLL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_AO (C macro), 255 BT_UUID_GATT_AO (C macro), 254 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AP_VAL (C macro), 273 BT_UUID_GATT_BCF (C macro), 263	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290 BT_UUID_GATT_COUNT16 (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24_VAL (C macro), 274 BT_UUID_GATT_CPF (C macro), 242 BT_UUID_GATT_CPF_VAL (C macro), 242 BT_UUID_GATT_CPS_CPCP (C macro), 256
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANO_VAL (C macro), 254 BT_UUID_GATT_AO_VAL (C macro), 254 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AP_VAL (C macro), 273 BT_UUID_GATT_BCF (C macro), 263 BT_UUID_GATT_BCF_VAL (C macro), 263	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290 BT_UUID_GATT_COUNT16 (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24_VAL (C macro), 274 BT_UUID_GATT_COPF (C macro), 242 BT_UUID_GATT_CPF_VAL (C macro), 242 BT_UUID_GATT_CPS_CPCP (C macro), 256 BT_UUID_GATT_CPS_CPCP_VAL (C macro), 256
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_AO (C macro), 255 BT_UUID_GATT_AO (C macro), 254 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AV_VAL (C macro), 273 BT_UUID_GATT_BCF (C macro), 263 BT_UUID_GATT_BCF_VAL (C macro), 263 BT_UUID_GATT_BCM (C macro), 263 BT_UUID_GATT_BCM (C macro), 263	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290 BT_UUID_GATT_COUNT16 (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24_VAL (C macro), 274 BT_UUID_GATT_COFF (C macro), 242 BT_UUID_GATT_CPF_VAL (C macro), 242 BT_UUID_GATT_CPS_CPCP (C macro), 256 BT_UUID_GATT_CPS_CPCP_VAL (C macro), 256 BT_UUID_GATT_CPS_CPCP (C macro), 256 BT_UUID_GATT_CPS_CPCP_VAL (C macro), 256
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL_(C macro), 260 BT_UUID_GATT_ANHRLL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_AO (C macro), 255 BT_UUID_GATT_AO (C macro), 255 BT_UUID_GATT_AO (C macro), 254 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AV_VAL (C macro), 273 BT_UUID_GATT_BCF_C (C macro), 263 BT_UUID_GATT_BCF_VAL (C macro), 263 BT_UUID_GATT_BCM_(C macro), 263 BT_UUID_GATT_BCM_VAL (C macro), 263 BT_UUID_GATT_BCM_VAL (C macro), 263	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CLIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290 BT_UUID_GATT_COUNT16 (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COFF (C macro), 242 BT_UUID_GATT_CPF_VAL (C macro), 242 BT_UUID_GATT_CPS_CPCP (C macro), 256 BT_UUID_GATT_CPS_CPCP (C macro), 256 BT_UUID_GATT_CPS_CPF_VAL (C macro), 256
BT_UUID_GATT_ALRTCID_MASK_VAL (C macro), 251 BT_UUID_GATT_ALRTCID_VAL (C macro), 252 BT_UUID_GATT_ALRTNCP (C macro), 252 BT_UUID_GATT_ALRTNCP_VAL (C macro), 252 BT_UUID_GATT_ALRTS (C macro), 251 BT_UUID_GATT_ALRTS_VAL (C macro), 251 BT_UUID_GATT_ALT_VAL (C macro), 267 BT_UUID_GATT_ALT_VAL (C macro), 266 BT_UUID_GATT_ANHRLL (C macro), 260 BT_UUID_GATT_ANHRUL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANHRUL_VAL (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_ANTHR_VAL (C macro), 260 BT_UUID_GATT_AO (C macro), 255 BT_UUID_GATT_AO (C macro), 254 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AP_VAL (C macro), 290 BT_UUID_GATT_AV_VAL (C macro), 273 BT_UUID_GATT_BCF (C macro), 263 BT_UUID_GATT_BCF_VAL (C macro), 263 BT_UUID_GATT_BCM (C macro), 263 BT_UUID_GATT_BCM (C macro), 263	BT_UUID_GATT_CIEIDX (C macro), 273 BT_UUID_GATT_CIEIDX_VAL (C macro), 273 BT_UUID_GATT_CLIENT_FEATURES (C macro), 282 BT_UUID_GATT_CLIENT_FEATURES_VAL (C macro), 282 BT_UUID_GATT_CNTRCODE (C macro), 274 BT_UUID_GATT_CNTRCODE_VAL (C macro), 274 BT_UUID_GATT_CO2CONC (C macro), 290 BT_UUID_GATT_CO2CONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 290 BT_UUID_GATT_COCONC_VAL (C macro), 299 BT_UUID_GATT_COEFFICIENT (C macro), 274 BT_UUID_GATT_COEFFICIENT_VAL (C macro), 274 BT_UUID_GATT_COS (C macro), 291 BT_UUID_GATT_COS_VAL (C macro), 290 BT_UUID_GATT_COUNT16 (C macro), 274 BT_UUID_GATT_COUNT16_VAL (C macro), 274 BT_UUID_GATT_COUNT24 (C macro), 274 BT_UUID_GATT_COUNT24_VAL (C macro), 274 BT_UUID_GATT_COFF (C macro), 242 BT_UUID_GATT_CPF_VAL (C macro), 242 BT_UUID_GATT_CPS_CPCP (C macro), 256 BT_UUID_GATT_CPS_CPCP_VAL (C macro), 256 BT_UUID_GATT_CPS_CPCP (C macro), 256 BT_UUID_GATT_CPS_CPCP_VAL (C macro), 256

BT_UUID_GATT_CPS_CPV (C macro), 256	BT_UUID_GATT_E32 (C macro), 294
BT_UUID_GATT_CPS_CPV_VAL (C macro), 256	BT_UUID_GATT_E32_VAL (C macro), 294
BT_UUID_GATT_CR_AID (C macro), 285	BT_UUID_GATT_EBPM (C macro), 284
BT_UUID_GATT_CR_AID_VAL (C macro), 285	BT_UUID_GATT_EBPM_VAL (C macro), 284
BT_UUID_GATT_CR_ASD (C macro), 285	BT_UUID_GATT_EC (C macro), 274
BT_UUID_GATT_CR_ASD_VAL (C macro), 285	BT_UUID_GATT_EC_VAL (C macro), 274
BT_UUID_GATT_CRCCT (C macro), 273	BT_UUID_GATT_ECR (C macro), 275
BT_UUID_GATT_CRCCT_VAL (C macro), 273	BT_UUID_GATT_ECR_VAL (C macro), 274
BT_UUID_GATT_CRCOORD (C macro), 281	BT_UUID_GATT_ECSPEC (C macro), 275
BT_UUID_GATT_CRCOORD_VAL (C macro), 280	BT_UUID_GATT_ECSPEC_VAL (C macro), 275
BT_UUID_GATT_CRCOORDS (C macro), 273	BT_UUID_GATT_ECSTAT (C macro), 275
BT_UUID_GATT_CRCOORDS_VAL (C macro), 273	BT_UUID_GATT_ECSTAT_VAL (C macro), 275
BT_UUID_GATT_CRDFP (C macro), 273	BT_UUID_GATT_EDKM (C macro), 290
BT_UUID_GATT_CRDFP_VAL (C macro), 273	BT_UUID_GATT_EDKM_VAL (C macro), 290
BT_UUID_GATT_CRT (C macro), 273	BT_UUID_GATT_EICP (C macro), 284
BT_UUID_GATT_CRT_VAL (C macro), 273	BT_UUID_GATT_EICP_VAL (C macro), 284
BT_UUID_GATT_CTD (C macro), 270	BT_UUID_GATT_EMAIL (C macro), 261
BT_UUID_GATT_CTD_VAL (C macro), 270	BT_UUID_GATT_EMAIL_VAL (C macro), 261
BT_UUID_GATT_CTEE (C macro), 295	BT_UUID_GATT_EMG_ID (C macro), 283
BT_UUID_GATT_CTEE_VAL (C macro), 295	BT_UUID_GATT_EMG_ID_VAL (C macro), 283
BT_UUID_GATT_CUD (C macro), 241	BT_UUID_GATT_EMG_TXT (C macro), 283
BT_UUID_GATT_CUD_VAL (C macro), 241	BT_UUID_GATT_EMG_TXT_VAL (C macro), 283
BT_UUID_GATT_DATE_BIRTH (C macro), 260	BT_UUID_GATT_ENERGY (C macro), 275
BT_UUID_GATT_DATE_BIRTH_VAL (C macro), 260	BT_UUID_GATT_ENERGY_VAL (C macro), 275
BT_UUID_GATT_DATE_THRASS (C macro), 261	BT_UUID_GATT_EPOD (C macro), 275
BT_UUID_GATT_DATE_THRASS_VAL (C macro), 260	BT_UUID_GATT_EPOD_VAL (C macro), 275
BT_UUID_GATT_DATEUTC (C macro), 274	BT_UUID_GATT_ESD (C macro), 304
BT_UUID_GATT_DATEUTC_VAL (C macro), 274	BT_UUID_GATT_ESD_VAL (C macro), 303
BT_UUID_GATT_DB_HASH (C macro), 282	BT_UUID_GATT_ET256 (C macro), 303
BT_UUID_GATT_DB_HASH_VAL (C macro), 282	BT_UUID_GATT_ET256_VAL (C macro), 244
BT_UUID_GATT_DBCHINC (C macro), 263	BT_UUID_GATT_EVTSTAT (C macro), 275
BT_UUID_GATT_DBCHINC_VAL (C macro), 263	BT_UUID_GATT_EVTSTAT_VAL (C macro), 275
BT_UUID_GATT_DDT (C macro), 244	BT_UUID_GATT_FBHRLL (C macro), 261
BT_UUID_GATT_DDT_VAL (C macro), 244	BT_UUID_GATT_FBHRLL_VAL (C macro), 261
BT_UUID_GATT_DEVICE_WP (C macro), 287	BT_UUID_GATT_FBHRUL (C macro), 261
BT_UUID_GATT_DEVICE_WP_VAL (C macro), 287	BT_UUID_GATT_FBHRUL_VAL (C macro), 261
BT_UUID_GATT_DEVT (C macro), 291	BT_UUID_GATT_FIRST_NAME (C macro), 261
BT_UUID_GATT_DEVT_VAL (C macro), 291	BT_UUID_GATT_FIRST_NAME_VAL (C macro), 261
BT_UUID_GATT_DEVTCP (C macro), 291	BT_UUID_GATT_FMCP (C macro), 272
BT_UUID_GATT_DEVTCP_VAL (C macro), 291	BT_UUID_GATT_FMCP_VAL (C macro), 272
BT_UUID_GATT_DEVTF (C macro), 291	BT_UUID_GATT_FMF (C macro), 270
BT_UUID_GATT_DEVTF_VAL (C macro), 291	BT_UUID_GATT_FMF_VAL (C macro), 270
BT_UUID_GATT_DEVTP (C macro), 291	BT_UUID_GATT_FMS (C macro), 272
BT_UUID_GATT_DEVTP_VAL (C macro), 291	BT_UUID_GATT_FMS_VAL (C macro), 272
BT_UUID_GATT_DI (C macro), 254	BT_UUID_GATT_FN (C macro), 266
BT_UUID_GATT_DI_VAL (C macro), 254	BT_UUID_GATT_FN_VAL (C macro), 266
BT_UUID_GATT_DO (C macro), 254	BT_UUID_GATT_FSTR16 (C macro), 275
BT_UUID_GATT_DO_VAL (C macro), 254	BT_UUID_GATT_FSTR16_VAL (C macro), 275
BT_UUID_GATT_DST (C macro), 245	BT_UUID_GATT_FSTR24 (C macro), 275
BT_UUID_GATT_DST_VAL (C macro), 245	BT_UUID_GATT_FSTR24_VAL (C macro), 275
BT_UUID_GATT_DT (C macro), 244	BT_UUID_GATT_FSTR36 (C macro), 276
BT_UUID_GATT_DT_VAL (C macro), 244	BT_UUID_GATT_FSTR36_VAL (C macro), 276
BT_UUID_GATT_DW (C macro), 244	BT_UUID_GATT_FSTR64 (C macro), 301
BT_UUID_GATT_DW_VAL (C macro), 244	BT_UUID_GATT_FSTR64_VAL (C macro), 301
	(0

BT_UUID_GATT_FSTR8 (C macro), 276	BT_UUID_GATT_IDD_SRCP (C macro), 282
BT_UUID_GATT_FSTR8_VAL (C macro), 276	BT_UUID_GATT_IDD_SRCP_VAL (C macro), 282
BT_UUID_GATT_GEN_AID (C macro), 285	BT_UUID_GATT_IEEE_RCDL (C macro), 248
BT_UUID_GATT_GEN_AID_VAL (C macro), 285	BT_UUID_GATT_IEEE_RCDL_VAL (C macro), 248
BT_UUID_GATT_GEN_ASD (C macro), 285	BT_UUID_GATT_ILLUM (C macro), 276
BT_UUID_GATT_GEN_ASD_VAL (C macro), 285	BT_UUID_GATT_ILLUM_VAL (C macro), 276
BT_UUID_GATT_GENDER (C macro), 261	BT_UUID_GATT_INCLUDE (C macro), 241
BT_UUID_GATT_GENDER_VAL (C macro), 261	BT_UUID_GATT_INCLUDE_VAL (C macro), 241
BT_UUID_GATT_GENLVL (C macro), 276	BT_UUID_GATT_IPC (C macro), 266
BT_UUID_GATT_GENLVL_VAL (C macro), 276	BT_UUID_GATT_IPC_VAL (C macro), 266
BT_UUID_GATT_GF (C macro), 253	BT_UUID_GATT_LANG (C macro), 264
BT_UUID_GATT_GF_VAL (C macro), 253	BT_UUID_GATT_LANG_VAL (C macro), 264
BT_UUID_GATT_GM (C macro), 246	BT_UUID_GATT_LAST_NAME (C macro), 262
BT_UUID_GATT_GM_VAL (C macro), 246	BT_UUID_GATT_LAST_NAME_VAL (C macro), 262
BT_UUID_GATT_GMC (C macro), 250	BT_UUID_GATT_LAT (C macro), 266
BT_UUID_GATT_GMC_VAL (C macro), 250	BT_UUID_GATT_LAT_VAL (C macro), 266
BT_UUID_GATT_GTIN (C macro), 276	BT_UUID_GATT_LD (C macro), 302
BT_UUID_GATT_GTIN_VAL (C macro), 276	BT_UUID_GATT_LD_VAL (C macro), 302
BT_UUID_GATT_HANDEDNESS (C macro), 287	BT_UUID_GATT_LECOORD (C macro), 266
BT_UUID_GATT_HANDEDNESS_VAL (C macro), 287	BT_UUID_GATT_LECOORD_VAL (C macro), 266
BT_UUID_GATT_HC (C macro), 262	BT_UUID_GATT_LLAT (C macro), 249
BT_UUID_GATT_HC_VAL (C macro), 262	BT_UUID_GATT_LLAT_VAL (C macro), 249
BT_UUID_GATT_HEIGHT (C macro), 262	BT_UUID_GATT_LLON (C macro), 249
BT_UUID_GATT_HEIGHT_VAL (C macro), 262	BT_UUID_GATT_LLON_VAL (C macro), 249
BT_UUID_GATT_HIET (C macro), 287	BT_UUID_GATT_LNCOORD (C macro), 266
BT_UUID_GATT_HIET_VAL (C macro), 287	BT_UUID_GATT_LNCOORD_VAL (C macro), 266
BT_UUID_GATT_HITEMP (C macro), 301	BT_UUID_GATT_LNCP (C macro), 257
BT_UUID_GATT_HITEMP_VAL (C macro), 301	BT_UUID_GATT_LNCP_VAL (C macro), 257
BT_UUID_GATT_HR_MAX (C macro), 261	BT_UUID_GATT_LNF (C macro), 257
BT_UUID_GATT_HR_MAX_VAL (C macro), 261	BT_UUID_GATT_LNF_VAL (C macro), 257
BT_UUID_GATT_HRES_H (C macro), 286	BT_UUID_GATT_LO (C macro), 302
BT_UUID_GATT_HRES_H_VAL (C macro), 286	BT_UUID_GATT_LO_VAL (C macro), 302
BT_UUID_GATT_HV (C macro), 302	BT_UUID_GATT_LOC_NAME (C macro), 267
BT_UUID_GATT_HV_VAL (C macro), 301	BT_UUID_GATT_LOC_NAME_VAL (C macro), 267
BT_UUID_GATT_IBD (C macro), 271	BT_UUID_GATT_LOC_SPD (C macro), 256
BT_UUID_GATT_IBD_VAL (C macro), 271	BT_UUID_GATT_LOC_SPD_VAL (C macro), 256
BT_UUID_GATT_ICP (C macro), 250	BT_UUID_GATT_LON (C macro), 266
BT_UUID_GATT_ICP_VAL (C macro), 250	BT_UUID_GATT_LON_VAL (C macro), 266
	BT_UUID_GATT_LST (C macro), 302
BT_UUID_GATT_IDD_AS (C macro), 281	
BT_UUID_GATT_IDD_AS_VAL (C macro), 281	BT_UUID_GATT_LST_VAL (C macro), 302
BT_UUID_GATT_IDD_CCP (C macro), 282	BT_UUID_GATT_LTI (C macro), 245
BT_UUID_GATT_IDD_CCP_VAL (C macro), 282	BT_UUID_GATT_LTI_VAL (C macro), 245
BT_UUID_GATT_IDD_CD (C macro), 282	BT_UUID_GATT_LUMEFF (C macro), 276
BT_UUID_GATT_IDD_CD_VAL (C macro), 282	BT_UUID_GATT_LUMEFF_VAL (C macro), 276
BT_UUID_GATT_IDD_F (C macro), 281	BT_UUID_GATT_LUMEXP (C macro), 277
BT_UUID_GATT_IDD_F_VAL (C macro), 281	BT_UUID_GATT_LUMEXP_VAL (C macro), 276
BT_UUID_GATT_IDD_HD (C macro), 282	BT_UUID_GATT_LUMFLX (C macro), 277
BT_UUID_GATT_IDD_HD_VAL (C macro), 282	BT_UUID_GATT_LUMFLX_VAL (C macro), 277
BT_UUID_GATT_IDD_RACP (C macro), 282	BT_UUID_GATT_LUMFLXR (C macro), 277
BT_UUID_GATT_IDD_RACP_VAL (C macro), 282	BT_UUID_GATT_LUMFLXR_VAL (C macro), 277
BT_UUID_GATT_IDD_S (C macro), 281	BT_UUID_GATT_LUMINT (C macro), 277
BT_UUID_GATT_IDD_S_VAL (C macro), 281	BT_UUID_GATT_LUMINT_VAL (C macro), 277
BT_UUID_GATT_IDD_SC (C macro), 281	BT_UUID_GATT_LUMNRG (C macro), 276
BT_UUID_GATT_IDD_SC_VAL (C macro), 281	BT_UUID_GATT_LUMNRG_VAL (C macro), 276

BT_UUID_GATT_MASSFLOW (C macro), 277	BT_UUID_GATT_PQ (C macro), 257
BT_UUID_GATT_MASSFLOW_VAL (C macro), 277	BT_UUID_GATT_PQ_VAL (C macro), 257
BT_UUID_GATT_MID_NAME (C macro), 286	BT_UUID_GATT_PREF_U (C macro), 286
BT_UUID_GATT_MID_NAME_VAL (C macro), 286	BT_UUID_GATT_PREF_U_VAL (C macro), 286
BT_UUID_GATT_MRHR (C macro), 262	BT_UUID_GATT_PRIMARY (C macro), 241
BT_UUID_GATT_MRHR_VAL (C macro), 262	BT_UUID_GATT_PRIMARY_VAL (C macro), 241
BT_UUID_GATT_NALRT (C macro), 252	BT_UUID_GATT_PWR (C macro), 277
BT_UUID_GATT_NALRT_VAL (C macro), 252	BT_UUID_GATT_PWR_VAL (C macro), 277
BT_UUID_GATT_NAV (C macro), 257	BT_UUID_GATT_PWRSPEC (C macro), 278
BT_UUID_GATT_NAV_VAL (C macro), 256	BT_UUID_GATT_PWRSPEC_VAL (C macro), 278
BT_UUID_GATT_NETA (C macro), 251	BT_UUID_GATT_RCCP (C macro), 281
BT_UUID_GATT_NETA_VAL (C macro), 251	BT_UUID_GATT_RCCP_VAL (C macro), 281
BT_UUID_GATT_NH4CONC (C macro), 299	BT_UUID_GATT_RCF (C macro), 281
BT_UUID_GATT_NH4CONC_VAL (C macro), 299	BT_UUID_GATT_RCF_VAL (C macro), 281
BT_UUID_GATT_NNN (C macro), 272	BT_UUID_GATT_RCP (C macro), 251
BT_UUID_GATT_NNN_VAL (C macro), 272	BT_UUID_GATT_RCP_VAL (C macro), 251
BT_UUID_GATT_NO2CONC (C macro), 300	BT_UUID_GATT_RCSET (C macro), 281
BT_UUID_GATT_NO2CONC_VAL (C macro), 300	BT_UUID_GATT_RCSET_VAL (C macro), 281
BT_UUID_GATT_NOISE (C macro), 302	BT_UUID_GATT_RD (C macro), 271
BT_UUID_GATT_NOISE_VAL (C macro), 302	BT_UUID_GATT_RD_VAL (C macro), 270
BT_UUID_GATT_NONCH4CONC (C macro), 300	BT_UUID_GATT_REM (C macro), 250
BT_UUID_GATT_NONCH4CONC_VAL (C macro), 300	BT_UUID_GATT_REM_VAL (C macro), 250
BT_UUID_GATT_03CONC (C macro), 300	BT_UUID_GATT_RHR (C macro), 262
BT_UUID_GATT_03CONC_VAL (C macro), 300	BT_UUID_GATT_RHR_VAL (C macro), 262
BT_UUID_GATT_PER8 (C macro), 277	BT_UUID_GATT_RPAO (C macro), 269
BT_UUID_GATT_PER8_VAL (C macro), 277	BT_UUID_GATT_RPAO_VAL (C macro), 269
BT_UUID_GATT_PERLGHT (C macro), 277	BT_UUID_GATT_RRCCTP_VAL (C macro), 302
BT_UUID_GATT_PERLGHT_VAL (C macro), 277	BT_UUID_GATT_RRCCTR (C macro), 302
BT_UUID_GATT_PHY_AMCP (C macro), 286	BT_UUID_GATT_RRICR (C macro), 278
BT_UUID_GATT_PHY_AMCP_VAL (C macro), 286	BT_UUID_GATT_RRICR_VAL (C macro), 278
BT_UUID_GATT_PHY_AMF (C macro), 285	BT_UUID_GATT_RRIGLR (C macro), 278
BT_UUID_GATT_PHY_AMF_VAL (C macro), 285	BT_UUID_GATT_RRIGLR_VAL (C macro), 278
BT_UUID_GATT_PHY_ASDESC (C macro), 286	BT_UUID_GATT_RS (C macro), 251
BT_UUID_GATT_PHY_ASDESC_VAL (C macro), 286	BT_UUID_GATT_RS_VAL (C macro), 251
BT_UUID_GATT_PLX_CM (C macro), 255	BT_UUID_GATT_RTI (C macro), 245
BT_UUID_GATT_PLX_CM (C macro), 255 BT_UUID_GATT_PLX_CM_VAL (C macro), 255	BT_UUID_GATT_RTI_VAL (C macro), 245
BT_UUID_GATT_PLX_F (C macro), 255	BT_UUID_GATT_RU (C macro), 243 BT_UUID_GATT_RU (C macro), 284
BT_UUID_GATT_PLX_F_VAL (C macro), 255	BT_UUID_GATT_RU_VAL (C macro), 284
BT_UUID_GATT_PLX_SCM (C macro), 255	BT_UUID_GATT_RVIIR (C macro), 278
BT_UUID_GATT_PLX_SCM_VAL (C macro), 255	BT_UUID_GATT_RVIIR_VAL (C macro), 278
BT_UUID_GATT_PM10CONC (C macro), 300	BT_UUID_GATT_RVIPOD (C macro), 278
BT_UUID_GATT_PM10CONC_VAL (C macro), 300	BT_UUID_GATT_RVIPOD_VAL (C macro), 278
BT_UUID_GATT_PM1CONC (C macro), 300	BT_UUID_GATT_RVITR (C macro), 278
BT_UUID_GATT_PM1CONC_VAL (C macro), 300	BT_UUID_GATT_RVITR_VAL (C macro), 278
BT_UUID_GATT_PM25CONC (C macro), 300	BT_UUID_GATT_RVIVR (C macro), 278
BT_UUID_GATT_PM25CONC_VAL (C macro), 300	BT_UUID_GATT_RVIVR_VAL (C macro), 278
BT_UUID_GATT_POCP (C macro), 256	BT_UUID_GATT_SC (C macro), 244
BT_UUID_GATT_POCP_VAL (C macro), 256	BT_UUID_GATT_SC_ASD (C macro), 285
BT_UUID_GATT_POPE (C macro), 256	BT_UUID_GATT_SC_ASD_VAL (C macro), 285
BT_UUID_GATT_POPE_VAL (C macro), 256	BT_UUID_GATT_SC_TEMP_C (C macro), 251
BT_UUID_GATT_POS_2D (C macro), 249	BT_UUID_GATT_SC_TEMP_C_VAL (C macro), 251
BT_UUID_GATT_POS_2D_VAL (C macro), 249	BT_UUID_GATT_SC_VAL (C macro), 244
BT_UUID_GATT_POS_3D (C macro), 249	BT_UUID_GATT_SCC (C macro), 242
BT_UUID_GATT_POS_3D_VAL (C macro), 249	BT_UUID_GATT_SCC_VAL (C macro), 242

BT_UUID_GATT_SECONDARY (C macro), 241	BT_UUID_GATT_TEMP8 (C macro), 279
BT_UUID_GATT_SECONDARY_VAL (C macro), 241	BT_UUID_GATT_TEMP8_IPOD (C macro), 279
BT_UUID_GATT_SERVER_FEATURES (C macro), 285	BT_UUID_GATT_TEMP8_IPOD_VAL (C macro), 279
BT_UUID_GATT_SERVER_FEATURES_VAL (C macro), 284	BT_UUID_GATT_TEMP8_STAT (C macro), 279
BT_UUID_GATT_SF6CONC (C macro), 301	BT_UUID_GATT_TEMP8_STAT_VAL (C macro), 279
BT_UUID_GATT_SF6CONC_VAL (C macro), 301	BT_UUID_GATT_TEMP8_VAL (C macro), 278
BT_UUID_GATT_SHRR (C macro), 271	BT_UUID_GATT_TEMP_RNG (C macro), 279
BT_UUID_GATT_SHRR_VAL (C macro), 271	BT_UUID_GATT_TEMP_RNG_VAL (C macro), 279
BT_UUID_GATT_SIN (C macro), 287	BT_UUID_GATT_TEMP_STAT (C macro), 279
BT_UUID_GATT_SIN_VAL (C macro), 287	BT_UUID_GATT_TEMP_STAT_VAL (C macro), 279
BT_UUID_GATT_SIR (C macro), 271	BT_UUID_GATT_TIM_DC8 (C macro), 279
BT_UUID_GATT_SIR_VAL (C macro), 271	BT_UUID_GATT_TIM_DC8_VAL (C macro), 279
BT_UUID_GATT_SIW (C macro), 253	BT_UUID_GATT_TIM_EXP8 (C macro), 279
BT_UUID_GATT_SIW_VAL (C macro), 253	BT_UUID_GATT_TIM_EXP8_VAL (C macro), 279
BT_UUID_GATT_SL (C macro), 304	BT_UUID_GATT_TIM_H24 (C macro), 279
BT_UUID_GATT_SL_VAL (C macro), 304	BT_UUID_GATT_TIM_H24_VAL (C macro), 279
BT_UUID_GATT_SLP_AID (C macro), 285	BT_UUID_GATT_TIM_MS24 (C macro), 280
BT_UUID_GATT_SLP_AID_VAL (C macro), 285	BT_UUID_GATT_TIM_MS24_VAL (C macro), 280
BT_UUID_GATT_SLP_ASD (C macro), 286	BT_UUID_GATT_TIM_S16 (C macro), 280
BT_UUID_GATT_SLP_ASD_VAL (C macro), 286	BT_UUID_GATT_TIM_S16_VAL (C macro), 280
BT_UUID_GATT_SNALRTC (C macro), 252	BT_UUID_GATT_TIM_S32 (C macro), 302
BT_UUID_GATT_SNALRTC_VAL (C macro), 252	BT_UUID_GATT_TIM_S32_VAL (C macro), 302
BT_UUID_GATT_SO2CONC (C macro), 301	BT_UUID_GATT_TIM_S8 (C macro), 280
BT_UUID_GATT_SO2CONC_VAL (C macro), 301	BT_UUID_GATT_TIM_S8_VAL (C macro), 280
BT_UUID_GATT_SPR (C macro), 271	BT_UUID_GATT_TMAPR (C macro), 288
BT_UUID_GATT_SPR_VAL (C macro), 271	BT_UUID_GATT_TMAPR_VAL (C macro), 288
BT_UUID_GATT_SR (C macro), 249	BT_UUID_GATT_TREND (C macro), 259
BT_UUID_GATT_SR_VAL (C macro), 249	BT_UUID_GATT_TREND_VAL (C macro), 259
BT_UUID_GATT_SRLR (C macro), 271	BT_UUID_GATT_TRSTAT (C macro), 271
BT_UUID_GATT_SRLR_VAL (C macro), 271	BT_UUID_GATT_TRSTAT_VAL (C macro), 271
BT_UUID_GATT_SRVREQ (C macro), 251	BT_UUID_GATT_TS (C macro), 245
BT_UUID_GATT_SRVREQ_VAL (C macro), 250	BT_UUID_GATT_TS_VAL (C macro), 245
BT_UUID_GATT_SSR (C macro), 271	BT_UUID_GATT_TUCP (C macro), 246
BT_UUID_GATT_SSR_VAL (C macro), 271	BT_UUID_GATT_TUCP_VAL (C macro), 246
BT_UUID_GATT_STPCD (C macro), 270	BT_UUID_GATT_TUS (C macro), 246
BT_UUID_GATT_STPCD_VAL (C macro), 270	BT_UUID_GATT_TUS_VAL (C macro), 246
BT_UUID_GATT_STRCD (C macro), 270	BT_UUID_GATT_TZ (C macro), 245
BT_UUID_GATT_STRCD_VAL (C macro), 270	BT_UUID_GATT_TZ_VAL (C macro), 245
BT_UUID_GATT_STRDLEN (C macro), 287	BT_UUID_GATT_UALRTS (C macro), 252
BT_UUID_GATT_STRDLEN_VAL (C macro), 286	BT_UUID_GATT_UALRTS_VAL (C macro), 252
BT_UUID_GATT_STRING (C macro), 251	BT_UUID_GATT_UNCERTAINTY (C macro), 267
BT_UUID_GATT_STRING_VAL (C macro), 251	BT_UUID_GATT_UNCERTAINTY_VAL (C macro), 267
BT_UUID_GATT_SUALRTC (C macro), 252	BT_UUID_GATT_USRCP (C macro), 264
BT_UUID_GATT_SUALRTC_VAL (C macro), 252	BT_UUID_GATT_USRCP_VAL (C macro), 264
BT_UUID_GATT_TA (C macro), 245	BT_UUID_GATT_USRIDX (C macro), 263
BT_UUID_GATT_TA_VAL (C macro), 245	BT_UUID_GATT_USRIDX_VAL (C macro), 263
BT_UUID_GATT_TCLD (C macro), 291	BT_UUID_GATT_V (C macro), 280
BT_UUID_GATT_TCLD_VAL (C macro), 291	BT_UUID_GATT_V_SPEC (C macro), 280
BT_UUID_GATT_TD (C macro), 270	BT_UUID_GATT_V_SPEC_VAL (C macro), 280
BT_UUID_GATT_TD_VAL (C macro), 270	BT_UUID_GATT_V_STAT (C macro), 280
BT_UUID_GATT_TDS_CP (C macro), 268	BT_UUID_GATT_V_STAT_VAL (C macro), 280
BT_UUID_GATT_TDS_CP_VAL (C macro), 268	BT_UUID_GATT_V_VAL (C macro), 280
BT_UUID_GATT_TDST (C macro), 245	BT_UUID_GATT_VAL (C macro), 232
BT_UUID_GATT_TDST_VAL (C macro), 245	BT_UUID_GATT_VF (C macro), 303
======================================	(C //mc/o), 505

DE INITE CAME UP MAI (C) 202	DE HILLD HIDD (C) 207
BT_UUID_GATT_VF_VAL (C macro), 303	BT_UUID_HIDP (C macro), 307
BT_UUID_GATT_V02_MAX (C macro), 263	BT_UUID_HIDP_VAL (C macro), 307
BT_UUID_GATT_VO2_MAX_VAL (C macro), 263	BT_UUID_HIDS (C macro), 234
BT_UUID_GATT_VOCCONC (C macro), 302	BT_UUID_HIDS_BOOT_KB_IN_REPORT (C macro), 247
BT_UUID_GATT_VOCCONC_VAL (C macro), 302	BT_UUID_HIDS_BOOT_KB_IN_REPORT_VAL (C macro),
BT_UUID_GATT_VOLF (C macro), 280	247
BT_UUID_GATT_VOLF_VAL (C macro), 280	BT_UUID_HIDS_BOOT_KB_OUT_REPORT (C macro), 249
BT_UUID_GATT_WC (C macro), 263	BT_UUID_HIDS_BOOT_KB_OUT_REPORT_VAL (C macro),
BT_UUID_GATT_WC_VAL (C macro), 263	249
BT_UUID_GATT_WEIGHT (C macro), 263	BT_UUID_HIDS_BOOT_MOUSE_IN_REPORT (C macro),
BT_UUID_GATT_WEIGHT_VAL (C macro), 263	249
BT_UUID_GATT_WM (C macro), 264	${\tt BT_UUID_HIDS_BOOT_MOUSE_IN_REPORT_VAL} \qquad (C$
BT_UUID_GATT_WM_VAL (C macro), 264	macro), 249
BT_UUID_GATT_WSF (C macro), 264	BT_UUID_HIDS_CTRL_POINT (C macro), 253
BT_UUID_GATT_WSF_VAL (C macro), 264	BT_UUID_HIDS_CTRL_POINT_VAL (C macro), 253
BT_UUID_GMAP_BGR_FEAT (C macro), 305	BT_UUID_HIDS_EXT_REPORT (C macro), 242
BT_UUID_GMAP_BGR_FEAT_VAL (C macro), 305	BT_UUID_HIDS_EXT_REPORT_VAL (C macro), 242
BT_UUID_GMAP_BGS_FEAT (C macro), 305	BT_UUID_HIDS_INFO (C macro), 253
BT_UUID_GMAP_BGS_FEAT_VAL (C macro), 305	BT_UUID_HIDS_INFO_VAL (C macro), 252
BT_UUID_GMAP_ROLE (C macro), 305	BT_UUID_HIDS_PROTOCOL_MODE (C macro), 253
BT_UUID_GMAP_ROLE_VAL (C macro), 305	BT_UUID_HIDS_PROTOCOL_MODE_VAL (C macro), 253
BT_UUID_GMAP_UGG_FEAT (C macro), 305	BT_UUID_HIDS_REPORT (C macro), 253
BT_UUID_GMAP_UGG_FEAT_VAL (C macro), 305	BT_UUID_HIDS_REPORT_MAP (C macro), 253
BT_UUID_GMAP_UGT_FEAT (C macro), 305	BT_UUID_HIDS_REPORT_MAP_VAL (C macro), 253
BT_UUID_GMAP_UGT_FEAT_VAL (C macro), 305	BT_UUID_HIDS_REPORT_REF (C macro), 242
BT_UUID_GMAS (C macro), 305	BT_UUID_HIDS_REPORT_REF_VAL (C macro), 242
BT_UUID_GMAS_VAL (C macro), 305	BT_UUID_HIDS_REPORT_VAL (C macro), 253
BT_UUID_GMCS (C macro), 239	BT_UUID_HIDS_VAL (C macro), 234
BT_UUID_GMCS_VAL (C macro), 239	BT_UUID_HPS (C macro), 236
BT_UUID_GS (C macro), 233	BT_UUID_HPS_VAL (C macro), 236
BT_UUID_GS_VAL (C macro), 233	BT_UUID_HRS (C macro), 234
BT_UUID_GTBS (C macro), 239	BT_UUID_HRS_BODY_SENSOR (C macro), 250
BT_UUID_GTBS_VAL (C macro), 239	BT_UUID_HRS_BODY_SENSOR_VAL (C macro), 250
	· · · · · · · · · · · · · · · · · · ·
BT_UUID_GUST_FACTOR (C macro), 258	BT_UUID_HRS_CONTROL_POINT (C macro), 250
BT_UUID_GUST_FACTOR_VAL (C macro), 258	BT_UUID_HRS_CONTROL_POINT_VAL (C macro), 250
BT_UUID_HAS (C macro), 240	BT_UUID_HRS_MEASUREMENT (C macro), 250
BT_UUID_HAS_ACTIVE_PRESET_INDEX (C macro), 301	BT_UUID_HRS_MEASUREMENT_VAL (C macro), 250
BT_UUID_HAS_ACTIVE_PRESET_INDEX_VAL (C macro),	BT_UUID_HRS_VAL (C macro), 233
301	BT_UUID_HTS (C macro), 233
BT_UUID_HAS_HEARING_AID_FEATURES (C macro), 301	BT_UUID_HTS_INTERVAL (C macro), 247
BT_UUID_HAS_HEARING_AID_FEATURES_VAL (C	BT_UUID_HTS_INTERVAL_VAL (C macro), 247
macro), 301	BT_UUID_HTS_MEASUREMENT (C macro), 246
BT_UUID_HAS_PRESET_CONTROL_POINT (C macro), 301	BT_UUID_HTS_MEASUREMENT_VAL (C macro), 246
$BT_UUID_HAS_PRESET_CONTROL_POINT_VAL$ (C	BT_UUID_HTS_TEMP_C (C macro), 247
<i>macro</i>), 301	BT_UUID_HTS_TEMP_C_VAL (C macro), 247
BT_UUID_HAS_VAL (C macro), 240	BT_UUID_HTS_TEMP_F (C macro), 247
BT_UUID_HCRP_CTRL (C macro), 307	BT_UUID_HTS_TEMP_F_VAL (C macro), 247
BT_UUID_HCRP_CTRL_VAL (C macro), 307	BT_UUID_HTS_TEMP_INT (C macro), 247
BT_UUID_HCRP_DATA (C macro), 307	BT_UUID_HTS_TEMP_INT_VAL (C macro), 247
BT_UUID_HCRP_DATA_VAL (C macro), 307	BT_UUID_HTS_TEMP_TYP (C macro), 247
BT_UUID_HCRP_NOTE (C macro), 307	BT_UUID_HTS_TEMP_TYP_VAL (C macro), 246
BT_UUID_HCRP_NOTE_VAL (C macro), 307	BT_UUID_HTS_VAL (C macro), 233
BT_UUID_HEAT_INDEX (C macro), 259	BT_UUID_HTTP (C macro), 306
BT_UUID_HEAT_INDEX_VAL (C macro), 259	BT_UUID_HTTP_CONTROL_POINT (C macro), 267
(//	

BT_UUID_HTTP_CONTROL_POINT_VAL (C macro), 267	BT_UUID_MCS_MEDIA_CONTROL_OPCODES (C macro),
BT_UUID_HTTP_ENTITY_BODY (C macro), 267	294
BT_UUID_HTTP_ENTITY_BODY_VAL (C macro), 267	BT_UUID_MCS_MEDIA_CONTROL_OPCODES_VAL (C
BT_UUID_HTTP_HEADERS (C macro), 267 BT_UUID_HTTP_HEADERS_VAL (C macro), 267	macro), 294
BT_UUID_HTTP_STATUS_CODE (C macro), 267	BT_UUID_MCS_MEDIA_CONTROL_POINT (C macro), 294 BT_UUID_MCS_MEDIA_CONTROL_POINT_VAL (C macro),
BT_UUID_HTTP_STATUS_CODE_VAL (C macro), 267	BI_UUID_MCS_MEDIA_CONTROL_POINI_VAL (C macro), 294
BT_UUID_HTTP_VAL (C macro), 306	BT_UUID_MCS_MEDIA_STATE (C macro), 293
BT_UUID_HTTPS_SECURITY (C macro), 268	BT_UUID_MCS_MEDIA_STATE_VAL (C macro), 293
BT_UUID_HTTPS_SECURITY_VAL (C macro), 268	BT_UUID_MCS_NEXT_TRACK_OBJ_ID (C macro), 293
BT_UUID_HUMIDITY (C macro), 257	BT_UUID_MCS_NEXT_TRACK_OBJ_ID_VAL (C macro),
BT_UUID_HUMIDITY_VAL (C macro), 257	293
BT_UUID_IAS (C macro), 232	BT_UUID_MCS_PARENT_GROUP_OBJ_ID (C macro), 293
BT_UUID_IAS_VAL (C macro), 232	BT_UUID_MCS_PARENT_GROUP_OBJ_ID_VAL (C macro),
BT_UUID_IDS (C macro), 237	293
BT_UUID_IDS_VAL (C macro), 237	BT_UUID_MCS_PLAYBACK_SPEED (C macro), 292
BT_UUID_INIT_128 (<i>C macro</i>), 230	BT_UUID_MCS_PLAYBACK_SPEED_VAL (C macro), 292
BT_UUID_INIT_16 (<i>C macro</i>), 229	BT_UUID_MCS_PLAYER_NAME (C macro), 291
BT_UUID_INIT_32 (<i>C macro</i>), 230	BT_UUID_MCS_PLAYER_NAME_VAL (C macro), 291
BT_UUID_IP (C macro), 306	BT_UUID_MCS_PLAYING_ORDER (C macro), 293
BT_UUID_IP_VAL (C macro), 306	BT_UUID_MCS_PLAYING_ORDER_VAL (C macro), 293
BT_UUID_IPS (C macro), 236	BT_UUID_MCS_PLAYING_ORDERS (C macro), 293
BT_UUID_IPS_VAL (C macro), 236	BT_UUID_MCS_PLAYING_ORDERS_VAL (C macro), 293
BT_UUID_IPSS (C macro), 236	BT_UUID_MCS_SEARCH_CONTROL_POINT (C macro), 294
BT_UUID_IPSS_VAL (C macro), 236	BT_UUID_MCS_SEARCH_CONTROL_POINT_VAL (C
BT_UUID_IRRADIANCE (C macro), 259	<i>macro</i>), 294
BT_UUID_IRRADIANCE_VAL (C macro), 258	BT_UUID_MCS_SEARCH_RESULTS_OBJ_ID (C macro),
BT_UUID_L2CAP (C macro), 308	294
BT_UUID_L2CAP_VAL (C macro), 308	BT_UUID_MCS_SEARCH_RESULTS_OBJ_ID_VAL (C
BT_UUID_LLS (C macro), 232	<i>macro</i>), 294
BT_UUID_LLS_VAL (C macro), 232	BT_UUID_MCS_SEEKING_SPEED (C macro), 292
BT_UUID_LNS (C macro), 235	BT_UUID_MCS_SEEKING_SPEED_VAL (C macro), 292
BT_UUID_LNS_VAL (C macro), 235	BT_UUID_MCS_TRACK_CHANGED (C macro), 292
BT_UUID_MAGN_DECLINATION (C macro), 249	BT_UUID_MCS_TRACK_CHANGED_VAL (C macro), 292
BT_UUID_MAGN_DECLINATION_VAL (C macro), 248	BT_UUID_MCS_TRACK_DURATION (C macro), 292
BT_UUID_MAGN_FLUX_DENSITY_2D (C macro), 264	BT_UUID_MCS_TRACK_DURATION_VAL (C macro), 292
BT_UUID_MAGN_FLUX_DENSITY_2D_VAL(C macro), 264	BT_UUID_MCS_TRACK_POSITION (C macro), 292
BT_UUID_MAGN_FLUX_DENSITY_3D (C macro), 264	BT_UUID_MCS_TRACK_POSITION_VAL (C macro), 292
BT_UUID_MAGN_FLUX_DENSITY_3D_VAL (C macro), 264	BT_UUID_MCS_TRACK_SEGMENTS_OBJ_ID (C macro),
BT_UUID_MCAP_CTRL (C macro), 308	293
BT_UUID_MCAP_CTRL_VAL (C macro), 308	BT_UUID_MCS_TRACK_SEGMENTS_OBJ_ID_VAL (C
BT_UUID_MCAP_DATA (C macro), 308	macro), 292
BT_UUID_MCAP_DATA_VAL (C macro), 308	BT_UUID_MCS_TRACK_TITLE (C macro), 292
BT_UUID_MCS (C macro), 239	BT_UUID_MCS_TRACK_TITLE_VAL (C macro), 292
BT_UUID_MCS_CURRENT_GROUP_OBJ_ID (C macro), 293	BT_UUID_MCS_VAL (C macro), 239
BT_UUID_MCS_CURRENT_GROUP_OBJ_ID_VAL (C	BT_UUID_MESH_PROV (C macro), 237
macro), 293	BT_UUID_MESH_PROV_DATA_IN (C macro), 272
BT_UUID_MCS_CURRENT_TRACK_OBJ_ID (C macro), 293	BT_UUID_MESH_PROV_DATA_IN_VAL (C macro), 272
BT_UUID_MCS_CURRENT_TRACK_OBJ_ID_VAL (C	BT_UUID_MESH_PROV_DATA_OUT (C macro), 272
macro), 293	BT_UUID_MESH_PROV_DATA_OUT_VAL (C macro), 272
BT_UUID_MCS_ICON_OBJ_ID (C macro), 291	
BT_UUID_MCS_ICON_OBJ_ID_VAL (C macro), 291	BT_UUID_MESH_PROV_VAL (C macro), 237
DI_UUID_HES_IEUN_UDS_ID_VIIE (@ maero), 291	BT_UUID_MESH_PROV_VAL (C macro), 237 BT_UUID_MESH_PROXY (C macro), 237
BT_UUID_MCS_ICON_URL (C macro), 292	
	BT_UUID_MESH_PROXY (C macro), 237

```
BT_UUID_MESH_PROXY_DATA_OUT (C macro), 272
                                                  BT_UUID_OTS_TYPE_TRACK_VAL (C macro), 294
BT_UUID_MESH_PROXY_DATA_OUT_VAL (C macro), 272
                                                  BT_UUID_OTS_TYPE_UNSPECIFIED (C macro), 270
BT_UUID_MESH_PROXY_SOLICITATION_VAL (C macro),
                                                  BT_UUID_OTS_TYPE_UNSPECIFIED_VAL (C macro), 270
                                                  BT_UUID_OTS_TYPE_VAL (C macro), 268
BT_UUID_MESH_PROXY_VAL (C macro), 237
                                                  BT_UUID_OTS_VAL (C macro), 237
BT_UUID_MICS (C macro), 239
                                                  BT_UUID_PACS (C macro), 240
BT UUID MICS MUTE (C macro), 298
                                                  BT UUID PACS AVAILABLE CONTEXT (C macro), 299
BT_UUID_MICS_MUTE_VAL (C macro), 298
                                                  BT_UUID_PACS_AVAILABLE_CONTEXT_VAL (C macro),
BT_UUID_MICS_VAL (C macro), 239
                                                          299
BT_UUID_NAS (C macro), 233
                                                  BT_UUID_PACS_SNK (C macro), 299
BT_UUID_NAS_VAL (C macro), 233
                                                  BT_UUID_PACS_SNK_LOC (C macro), 299
BT_UUID_NDSTS (C macro), 233
                                                  BT_UUID_PACS_SNK_LOC_VAL (C macro), 299
BT_UUID_NDSTS_VAL (C macro), 233
                                                  BT_UUID_PACS_SNK_VAL (C macro), 299
BT_UUID_NDTS (C macro), 304
                                                  BT_UUID_PACS_SRC (C macro), 299
BT_UUID_NDTS_TIME_WITH_DTS (C macro), 305
                                                  BT_UUID_PACS_SRC_LOC (C macro), 299
BT_UUID_NDTS_TIME_WITH_DTS_VAL (C macro), 305
                                                  BT_UUID_PACS_SRC_LOC_VAL (C macro), 299
BT_UUID_NDTS_VAL (C macro), 304
                                                  BT_UUID_PACS_SRC_VAL (C macro), 299
                                                  BT_UUID_PACS_SUPPORTED_CONTEXT (C macro), 299
BT_UUID_OBEX (C macro), 306
BT_UUID_OBEX_VAL (C macro), 306
                                                  BT_UUID_PACS_SUPPORTED_CONTEXT_VAL (C macro),
BT_UUID_OTS (C macro), 237
BT_UUID_OTS_ACTION_CP (C macro), 269
                                                  BT_UUID_PACS_VAL (C macro), 240
BT_UUID_OTS_ACTION_CP_VAL (C macro), 269
                                                  BT_UUID_PAMS (C macro), 238
BT_UUID_OTS_CHANGED (C macro), 269
                                                  BT_UUID_PAMS_VAL (C macro), 238
BT UUID OTS CHANGED VAL (C macro), 269
                                                  BT UUID PAS (C macro), 234
BT_UUID_OTS_DIRECTORY_LISTING (C macro), 270
                                                  BT_UUID_PAS_VAL (C macro), 234
BT_UUID_OTS_DIRECTORY_LISTING_VAL (C macro),
                                                  BT UUID PBA (C macro), 241
                                                  BT_UUID_PBA_VAL (C macro), 240
BT_UUID_OTS_FEATURE (C macro), 268
                                                  BT_UUID_POLLEN_CONCENTRATION (C macro), 258
BT_UUID_OTS_FEATURE_VAL (C macro), 268
                                                  BT_UUID_POLLEN_CONCENTRATION_VAL (C macro), 258
BT_UUID_OTS_FIRST_CREATED (C macro), 268
                                                  BT_UUID_POS (C macro), 236
BT_UUID_OTS_FIRST_CREATED_VAL (C macro), 268
                                                  BT_UUID_POS_VAL (C macro), 236
                                                  BT_UUID_PRESSURE (C macro), 257
BT_UUID_OTS_ID (C macro), 269
BT_UUID_OTS_ID_VAL (C macro), 269
                                                  BT_UUID_PRESSURE_VAL (C macro), 257
BT_UUID_OTS_LAST_MODIFIED (C macro), 269
                                                  BT_UUID_RAINFALL (C macro), 259
BT_UUID_OTS_LAST_MODIFIED_VAL (C macro), 268
                                                  BT_UUID_RAINFALL_VAL (C macro), 259
BT_UUID_OTS_LIST_CP (C macro), 269
                                                  BT_UUID_RCSRV (C macro), 237
BT_UUID_OTS_LIST_CP_VAL (C macro), 269
                                                  BT_UUID_RCSRV_VAL (C macro), 237
BT_UUID_OTS_LIST_FILTER (C macro), 269
                                                  BT_UUID_RECORD_ACCESS_CONTROL_POINT (C macro),
BT_UUID_OTS_LIST_FILTER_VAL (C macro), 269
BT_UUID_OTS_NAME (C macro), 268
                                                  BT_UUID_RECORD_ACCESS_CONTROL_POINT_VAL
                                                                                                (C
BT_UUID_OTS_NAME_VAL (C macro), 268
                                                          macro), 254
BT_UUID_OTS_PROPERTIES (C macro), 269
                                                  BT_UUID_RFCOMM (C macro), 306
BT_UUID_OTS_PROPERTIES_VAL (C macro), 269
                                                  BT_UUID_RFCOMM_VAL (C macro), 306
BT_UUID_OTS_SIZE (C macro), 268
                                                  BT_UUID_RSC_FEATURE (C macro), 254
BT_UUID_OTS_SIZE_VAL (C macro), 268
                                                  BT_UUID_RSC_FEATURE_VAL (C macro), 254
BT_UUID_OTS_TYPE (C macro), 268
                                                  BT_UUID_RSC_MEASUREMENT (C macro), 254
BT_UUID_OTS_TYPE_GROUP (C macro), 295
                                                  BT_UUID_RSC_MEASUREMENT_VAL (C macro), 254
                                                  BT_UUID_RSCS (C macro), 234
BT_UUID_OTS_TYPE_GROUP_VAL (C macro), 295
BT_UUID_OTS_TYPE_MPL_ICON (C macro), 294
                                                  BT_UUID_RSCS_VAL (C macro), 234
BT_UUID_OTS_TYPE_MPL_ICON_VAL (C macro), 294
                                                  BT_UUID_RTUS (C macro), 233
                                                  BT_UUID_RTUS_CONTROL_POINT (C macro), 304
BT_UUID_OTS_TYPE_TRACK (C macro), 295
BT_UUID_OTS_TYPE_TRACK_SEGMENT (C macro), 294
                                                  BT_UUID_RTUS_CONTROL_POINT_VAL (C macro), 304
BT_UUID_OTS_TYPE_TRACK_SEGMENT_VAL (C macro),
                                                  BT_UUID_RTUS_TIME_UPDATE_STATE (C macro), 304
        294
```

DT HILLD DTHE TIME HODATE STATE WAL (C magne)	DT HILLD TOS DIN MAI (C magro) 206
BT_UUID_RTUS_TIME_UPDATE_STATE_VAL (C macro),	BT_UUID_TCS_BIN_VAL (C macro), 306
304	BT_UUID_TDS (C macro), 236
BT_UUID_RTUS_VAL (C macro), 233	BT_UUID_TDS_VAL (C macro), 236
BT_UUID_SC_CONTROL_POINT (C macro), 254	BT_UUID_TEMPERATURE (C macro), 257
BT_UUID_SC_CONTROL_POINT_VAL (C macro), 254	BT_UUID_TEMPERATURE_VAL (C macro), 257
BT_UUID_SDP (C macro), 306	BT_UUID_TM_TRIGGER_SETTING (C macro), 243
BT_UUID_SDP_VAL (C macro), 305	BT_UUID_TM_TRIGGER_SETTING_VAL (C macro), 243
BT_UUID_SENSOR_LOCATION (C macro), 255	BT_UUID_TMAS (C macro), 240
BT_UUID_SENSOR_LOCATION_VAL (C macro), 255	BT_UUID_TMAS_VAL (C macro), 240
BT_UUID_SIZE_128 (C macro), 229	bt_uuid_to_str(C function), 309
BT_UUID_SIZE_16 (C macro), 229	BT_UUID_TPS (C macro), 232
BT_UUID_SIZE_32 (C macro), 229	BT_UUID_TPS_TX_POWER_LEVEL (C macro), 244
BT_UUID_SPS (C macro), 234	BT_UUID_TPS_TX_POWER_LEVEL_VAL (C macro), 244
BT_UUID_SPS_VAL (C macro), 234	BT_UUID_TPS_VAL (C macro), 232
BT_UUID_STR_LEN (C macro), 232	BT_UUID_TRUE_WIND_DIR (C macro), 258
BT_UUID_TBS (C macro), 239	BT_UUID_TRUE_WIND_DIR_VAL (C macro), 258
BT_UUID_TBS_CALL_CONTROL_POINT (C macro), 297	BT_UUID_TRUE_WIND_SPEED (C macro), 258
BT_UUID_TBS_CALL_CONTROL_POINT_VAL (C macro),	BT_UUID_TRUE_WIND_SPEED_VAL (C macro), 258
297	BT_UUID_UDI (C macro), 308
BT_UUID_TBS_CALL_STATE (C macro), 297	BT_UUID_UDI_VAL (C macro), 307
BT_UUID_TBS_CALL_STATE_VAL (C macro), 297	BT_UUID_UDP (C macro), 306
BT_UUID_TBS_FRIENDLY_NAME (C macro), 298	BT_UUID_UDP_VAL (C macro), 306
BT_UUID_TBS_FRIENDLY_NAME_VAL (C macro), 298	BT_UUID_UDS (C macro), 235
BT_UUID_TBS_INCOMING_CALL (C macro), 298	BT_UUID_UDS_VAL (C macro), 235
BT_UUID_TBS_INCOMING_CALL_VAL (C macro), 297	BT_UUID_UPNP (C macro), 307
BT_UUID_TBS_INCOMING_URI (C macro), 297	BT_UUID_UPNP_VAL (C macro), 307
BT_UUID_TBS_INCOMING_URI_VAL (C macro), 297	BT_UUID_URI (C macro), 267
BT_UUID_TBS_LIST_CURRENT_CALLS (C macro), 296 BT_UUID_TBS_LIST_CURRENT_CALLS (C macro)	BT_UUID_URI_VAL (C macro), 267
BT_UUID_TBS_LIST_CURRENT_CALLS_VAL (C macro),	BT_UUID_UV_INDEX (C macro), 258
296	BT_UUID_UV_INDEX_VAL (C macro), 258
BT_UUID_TBS_OPTIONAL_OPCODES (C macro), 297	BT_UUID_VAL_TRIGGER_SETTING (C macro), 242
BT_UUID_TBS_OPTIONAL_OPCODES_VAL (C macro), 297	BT_UUID_VAL_TRIGGER_SETTING_VAL (C macro), 242
BT_UUID_TBS_PROVIDER_NAME (C macro), 296	BT_UUID_VALID_RANGE (C macro), 242
BT_UUID_TBS_PROVIDER_NAME_VAL (C macro), 296	BT_UUID_VALID_RANGE_VAL (C macro), 242
BT_UUID_TBS_SIGNAL_INTERVAL (C macro), 296	BT_UUID_VCS (C macro), 238
BT_UUID_TBS_SIGNAL_INTERVAL_VAL (C macro), 296	BT_UUID_VCS_CONTROL (C macro), 289
BT_UUID_TBS_SIGNAL_STRENGTH (C macro), 296	BT_UUID_VCS_CONTROL_VAL (C macro), 289
BT_UUID_TBS_SIGNAL_STRENGTH_VAL (C macro), 296	BT_UUID_VCS_FLAGS (C macro), 289
BT_UUID_TBS_STATUS_FLAGS (C macro), 297	BT_UUID_VCS_FLAGS_VAL (C macro), 289
BT_UUID_TBS_STATUS_FLAGS_VAL (C macro), 297	BT_UUID_VCS_STATE (C macro), 289
BT_UUID_TBS_TECHNOLOGY (C macro), 296	BT_UUID_VCS_STATE_VAL (C macro), 288
BT_UUID_TBS_TECHNOLOGY_VAL (C macro), 296	BT_UUID_VCS_VAL (C macro), 238
BT_UUID_TBS_TERMINATE_REASON (C macro), 297	BT_UUID_VOCS (C macro), 238
BT_UUID_TBS_TERMINATE_REASON_VAL(C macro), 297	BT_UUID_VOCS_CONTROL (C macro), 289
BT_UUID_TBS_UCI (C macro), 296	BT_UUID_VOCS_CONTROL_VAL (C macro), 289
BT_UUID_TBS_UCI_VAL (C macro), 296	BT_UUID_VOCS_DESCRIPTION (C macro), 289
BT_UUID_TBS_URI_LIST (C macro), 296	BT_UUID_VOCS_DESCRIPTION_VAL (C macro), 289
BT_UUID_TBS_URI_LIST_VAL (C macro), 296	BT_UUID_VOCS_LOCATION (C macro), 289
BT_UUID_TBS_VAL (C macro), 239	BT_UUID_VOCS_LOCATION_VAL (C macro), 289
BT_UUID_TCP (C macro), 306	BT_UUID_VOCS_STATE (C macro), 289
BT_UUID_TCP_VAL (C macro), 306	BT_UUID_VOCS_STATE_VAL (C macro), 289
BT_UUID_TCS_AT (C macro), 306	BT_UUID_VOCS_VAL (C macro), 289
BT_UUID_TCS_AT_VAL (C macro), 306	BT_UUID_WDS (C macro), 233
	BT_UUID_WDS_VAL (C macro), 233
BT_UUID_TCS_BIN (C macro), 306	DI_UUID_WDS_VAL (C MACIO), 255

BT_UUID_WIND_CHILL (C macro), 259 BT_UUID_WIND_CHILL_VAL (C macro), 259 BT_UUID_WSP (C macro), 307 BT_UUID_WSP_VAL (C macro), 307	MEDIA_TYPE (C enum), 199 MEDIA_TYPE.BT_A2DP_AUDIO (C enumerator), 199 MEDIA_TYPE.BT_A2DP_MULTIMEDIA (C enumerator), 200
BT_UUID_WSS (C macro), 236	MEDIA_TYPE.BT_A2DP_VIDEO (C enumerator), 199
BT_UUID_WSS_VAL (C macro), 235	P
D	
discover_cb_t (C struct), 208	PhonyNameDueToError.BODY_SET(<i>Cenumerator</i>), 312 PhonyNameDueToError.BT_A2DP_DISCOVER_ENDPOINT_CONTINUE
Н	(C enumerator), 200 PhonyNameDueToError.BT_A2DP_DISCOVER_ENDPOINT_STOP
hf_multiparty_call_option_t(C type), 149 hf_volume_type_t(C type), 149	$(\textit{C enumerator}), 200 \\ \texttt{PhonyNameDueToError.BT_CONN_LE_OPT_CODED} (\textit{C}$
hf_waiting_call_state_t (C type), 149	enumerator), 8
hfp_ag_call_setup_status_t (C enum), 150	${\tt PhonyNameDueToError.BT_CONN_LE_OPT_NO_1M} (C$
hfp_ag_call_setup_status_t.HFP_AG_CALL_SETUP_ (C enumerator), 150	STATUS_INTERMETATOR), 8 PhonyNameDueToError.BT_CONN_LE_OPT_NONE (C
hfp_ag_call_setup_status_t.HFP_AG_CALL_SETUP_	STATUS INCOMENCION), 8
(C enumerator), 150	PhonyNameDueToError.BT_CONN_LE_PHY_OPT_CODED_S2
hfp_ag_call_setup_status_t.HFP_AG_CALL_SETUP_ (C enumerator), 150	STATUS_OUFGOING_NAUERTING PhonyNameDueToError.BT_CONN_LE_PHY_OPT_CODED_S8
hfp_ag_call_setup_status_t.HFP_AG_CALL_SETUP_	
(C enumerator), 150	PhonyNameDueToError.BT_CONN_LE_PHY_OPT_NONE
hfp_ag_call_status_t (C type), 149	(C enumerator), 5
hfp_ag_cind_t (C type), 149	PhonyNameDueToError.BT_CONN_ROLE_CENTRAL (C
hfp_ag_get_config (C type), 149	enumerator), 6
HFP_HF_CMD_CME_ERROR (C macro), 149	PhonyNameDueToError.BT_CONN_ROLE_PERIPHERAL
HFP_HF_CMD_ERROR (C macro), 148	(C enumerator), 6
HFP_HF_CMD_OK (C macro), 148	PhonyNameDueToError.BT_GAP_ADV_PROP_CONNECTABLE
HFP_HF_CMD_UNKNOWN_ERROR (C macro), 149	(C enumerator), 109
HFP_HF_DIGIT_ARRAY_SIZE (C macro), 148	PhonyNameDueToError.BT_GAP_ADV_PROP_DIRECTED
HFP_HF_MAX_OPERATOR_NAME_LEN (C macro), 148	(C enumerator), 109
hps_config_t(C struct), 313	PhonyNameDueToError.BT_GAP_ADV_PROP_EXT_ADV
hps_data_status_t (<i>C type</i>), 311	(C enumerator), 109
hps_flags_t (C type), 311	PhonyNameDueToError.BT_GAP_ADV_PROP_SCAN_RESPONSE
hps_http_command_t(Ctype), 311	(C enumerator), 109
hps_state_t (<i>C type</i>), 311	PhonyNameDueToError.BT_GAP_ADV_PROP_SCANNABLE
hps_status_t (<i>C struct</i>), 313	(C enumerator), 109
hts_include_temp_type(<i>C macro</i>), 314	PhonyNameDueToError.BT_GAP_ADV_TYPE_ADV_DIRECT_IND
hts_unit_celsius_c(<i>C macro</i>), 314	(C enumerator), 108
hts_unit_fahrenheit_c (<i>C macro</i>), 314	PhonyNameDueToError.BT_GAP_ADV_TYPE_ADV_IND
I	(C enumerator), 108 PhonyNameDueToError.BT_GAP_ADV_TYPE_ADV_NONCONN_IND
<pre>ipsp_connect (C function), 315</pre>	(C enumerator), 108
<pre>ipsp_init (C function), 315</pre>	PhonyNameDueToError.BT_GAP_ADV_TYPE_ADV_SCAN_IND
<pre>ipsp_listen (C function), 315</pre>	(C enumerator), 108
ipsp_rx_cb_t (<i>C type</i>), 315	PhonyNameDueToError.BT_GAP_ADV_TYPE_EXT_ADV
ipsp_send (C function), 315	(C enumerator), 109 PhonyNameDueToError.BT_GAP_ADV_TYPE_SCAN_RSP
M	(C enumerator), 109
MAX_BODY_LEN (C macro), 310	PhonyNameDueToError.BT_GAP_CTE_AOA (C enumer-
MAX_HEADERS_LEN (C macro), 310	ator), 109
MAX_URI_LEN (C macro), 310	PhonyNameDueToError.BT_GAP_CTE_AOD_1US (C enumerator), 109

```
PhonyNameDueToError.BT_GAP_CTE_AOD_2US
                                               PhonyNameDueToError.BT_GATT_SUBSCRIBE_FLAG_WRITE_PENDING
        enumerator), 109
                                                         (C enumerator), 138
PhonyNameDueToError.BT_GAP_CTE_NONE (C enu-
                                                PhonyNameDueToError.BT_GATT_SUBSCRIBE_NUM_FLAGS
                                                        (C enumerator), 139
       merator), 109
                                                PhonyNameDueToError.BT_GATT_WRITE_FLAG_CMD
PhonyNameDueToError.BT_GAP_LE_PHY_1M (C enu-
       merator), 108
                                                        (C enumerator), 115
PhonyNameDueToError.BT_GAP_LE_PHY_2M (C enu-
                                                PhonyNameDueToError.BT_GATT_WRITE_FLAG_EXECUTE
                                                         (C enumerator), 115
       merator), 108
PhonyNameDueToError.BT_GAP_LE_PHY_CODED
                                            (C
                                                PhonyNameDueToError.BT_GATT_WRITE_FLAG_PREPARE
        enumerator), 108
                                                        (C enumerator), 115
PhonyNameDueToError.BT_GAP_LE_PHY_NONE
                                            (C
                                                PhonyNameDueToError.BT_LE_ADV_OPT_ANONYMOUS
        enumerator), 108
                                                        (C enumerator), 43
                                                PhonyNameDueToError.BT_LE_ADV_OPT_CODED
                                                                                             (C
PhonyNameDueToError.BT_GAP_SCA_0_20 (C enu-
       merator), 110
                                                        enumerator), 43
PhonyNameDueToError.BT_GAP_SCA_101_150
                                            (C
                                                PhonyNameDueToError.BT_LE_ADV_OPT_CONNECTABLE
        enumerator), 110
                                                         (C enumerator), 40
PhonyNameDueToError.BT_GAP_SCA_151_250
                                                PhonyNameDueToError.BT_LE_ADV_OPT_DIR_ADDR_RPA
                                            (C
       enumerator), 110
                                                        (C enumerator), 42
PhonyNameDueToError.BT_GAP_SCA_21_30 (C enu-
                                                PhonyNameDueToError.BT_LE_ADV_OPT_DIR_MODE_LOW_DUTY
       merator), 110
                                                         (C enumerator), 41
PhonyNameDueToError.BT_GAP_SCA_251_500
                                            (C
                                                PhonyNameDueToError.BT_LE_ADV_OPT_DISABLE_CHAN_37
        enumerator), 110
                                                        (C enumerator), 43
                                                PhonyNameDueToError.BT_LE_ADV_OPT_DISABLE_CHAN_38
PhonyNameDueToError.BT_GAP_SCA_31_50 (C enu-
        merator), 110
                                                         (C enumerator), 43
PhonyNameDueToError.BT_GAP_SCA_51_75 (C enu-
                                                PhonyNameDueToError.BT_LE_ADV_OPT_DISABLE_CHAN_39
       merator), 110
                                                        (C enumerator), 43
PhonyNameDueToError.BT_GAP_SCA_76_100 (C enu-
                                                PhonyNameDueToError.BT_LE_ADV_OPT_EXT_ADV (C
        merator), 110
                                                         enumerator), 42
PhonyNameDueToError.BT_GAP_SCA_UNKNOWN
                                                PhonyNameDueToError.BT_LE_ADV_OPT_FILTER_CONN
                                            (C
        enumerator), 110
                                                         (C enumerator), 42
PhonyNameDueToError.BT_GATT_DISCOVER_ATTRIBUTEPhonyNameDueToError.BT_LE_ADV_OPT_FILTER_SCAN_REQ
        (C enumerator), 137
                                                         (C enumerator), 42
PhonyNameDueToError.BT_GATT_DISCOVER_CHARACTERHSdiffyOnameDueToError.BT_LE_ADV_OPT_FORCE_NAME_IN_AD
        (C enumerator), 137
                                                        (C enumerator), 43
PhonyNameDueToError.BT_GATT_DISCOVER_DESCRIPTORhonyNameDueToError.BT_LE_ADV_OPT_NO_2M
                                                                                             (C
        (C enumerator), 137
                                                        enumerator), 42
PhonyNameDueToError.BT_GATT_DISCOVER_INCLUDE PhonyNameDueToError.BT_LE_ADV_OPT_NONE
                                                                                             (C
        (C enumerator), 137
                                                         enumerator), 40
PhonyNameDueToError.BT_GATT_DISCOVER_PRIMARY PhonyNameDueToError.BT_LE_ADV_OPT_NOTIFY_SCAN_REQ
        (C enumerator), 137
                                                         (C enumerator), 42
PhonyNameDueToError.BT_GATT_DISCOVER_SECONDARYPhonyNameDueToError.BT_LE_ADV_OPT_ONE_TIME
        (C enumerator), 137
                                                         (C enumerator), 41
PhonyNameDueToError.BT_GATT_DISCOVER_STD_CHAR_PRESSONNAMEDueToError.BT_LE_ADV_OPT_SCANNABLE
                                                         (C enumerator), 42
        (C enumerator), 137
PhonyNameDueToError.BT_GATT_ITER_CONTINUE (C PhonyNameDueToError.BT_LE_ADV_OPT_USE_IDENTITY
        enumerator), 123
                                                         (C enumerator), 41
PhonyNameDueToError.BT_GATT_ITER_STOP (C enu- PhonyNameDueToError.BT_LE_ADV_OPT_USE_NAME
       merator), 123
                                                         (C enumerator), 41
PhonyNameDueToError.BT_GATT_SUBSCRIBE_FLAG_NO_RREGSWENameDueToError.BT_LE_ADV_OPT_USE_NRPA
        (C enumerator), 138
                                                         (C enumerator), 43
PhonyNameDueToError.BT_GATT_SUBSCRIBE_FLAG_SENMhonyNameDueToError.BT_LE_ADV_OPT_USE_TX_POWER
        (C enumerator), 138
                                                        (C enumerator), 43
PhonyNameDueToError.BT_GATT_SUBSCRIBE_FLAG_VOLDATOM.PNameDueToError.BT_LE_PER_ADV_OPT_INCLUDE_ADI
        (C enumerator), 138
                                                         (C enumerator), 44
```

```
PhonyNameDueToError.BT_LE_PER_ADV_OPT_NONE
                                                    PhonyNameDueToError.BT_RFCOMM_CHAN_HSP_HS (C
                                                             enumerator), 175
        (C enumerator), 44
PhonyNameDueToError.BT_LE_PER_ADV_OPT_USE_TX_PRIMBRyNameDueToError.BT_RFCOMM_CHAN_SPP
        (C enumerator), 44
                                                             enumerator), 175
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_OPT_DONFIL6FYNCapAeDaueToError.BT_SDP_DISCOVER_UUID_CONTINUE
        (C enumerator), 45
                                                             (C enumerator), 193
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_OPT_DONFILGYYNCapAeDDueTUSError.BT_SDP_DISCOVER_UUID_STOP
        (C enumerator), 45
                                                             (C enumerator), 193
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_OPT_DONPhonyNameDueTibError.BT_UUID_TYPE_128 (C enu-
        (C enumerator), 45
                                                            merator), 308
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_OPT_FILPHEROLDMETEOError.BT_UUID_TYPE_16 (C enu-
        (C enumerator), 44
                                                             merator), 308
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_OPT_NONEhonyNameDueToError.BT_UUID_TYPE_32 (C enu-
                                                            merator), 308
        (C enumerator), 44
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_OPT_REPRINCITYING AT SAURS EDSTATE (C enumerator),
        (C enumerator), 44
                                                             312
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_OPT_SYNChONNINGIGEDISHTGIENFEADERS_SET (C enumerator),
        (C enumerator), 45
                                                             312
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_OPT_USEPIREMY_MADN@DUESTOError.HIGH_ALERT (C enumerator),
        (C enumerator), 44
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_TRANSFEROOPINATION TO BE BODY_RECEIVED (C enu-
        (C enumerator), 45
                                                            merator), 311
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_TRANSFEROMPINAMONDUETOError.HPS_BODY_TRUNCATED
                                                                                                   (C
        (C enumerator), 45
                                                             enumerator), 311
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_TRANSFERO ONLYINAMIA PROPERTY CONFIGURED PROPERTY CONFIGURED
        (C enumerator), 45
                                                            (C enumerator), 312
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_TRANSFERIONFIN_SYNEWIGHTO_FACE.HPS_ERR_INVALID_REQUEST
                                                             (C enumerator), 312
        (C enumerator), 45
(C enumerator), 45
                                                             (C enumerator), 312
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_TRANSFERMONYNAMANUADOJAODOJ2LISPS_HEADERS_RECEIVED (C
        (C enumerator), 45
                                                             enumerator), 311
PhonyNameDueToError.BT_LE_PER_ADV_SYNC_TRANSFEROOPINGNIAMONONGFECOTE.HPS_HEADERS_TRUNCATED (C
        (C enumerator), 45
                                                            enumerator), 311
PhonyNameDueToError.BT_LE_SCAN_OPT_CODED (C PhonyNameDueToError.hts_armpit (C enumerator),
        enumerator), 46
                                                             314
PhonyNameDueToError.BT_LE_SCAN_OPT_FILTER_ACCEPTION.StimeDueToError.hts_body(Cenumerator), 314
        (C enumerator), 46
                                                    PhonyNameDueToError.hts_ear(Cenumerator), 314
PhonyNameDueToError.BT_LE_SCAN_OPT_FILTER_DUPLEMCONTYNameDueToError.hts_finger (C enumerator),
        (C enumerator), 46
                                                             314
PhonyNameDueToError.BT_LE_SCAN_OPT_NO_1M (C PhonyNameDueToError.hts_gastroInt (C enumera-
        enumerator), 46
                                                            tor), 314
PhonyNameDueToError.BT_LE_SCAN_OPT_NONE
                                                   PhonyNameDueToError.hts_mouth (C enumerator),
                                               (C
        enumerator), 46
                                                            314
PhonyNameDueToError.BT_LE_SCAN_TYPE_ACTIVE
                                                    {\tt PhonyNameDueToError.hts\_no\_temp\_type} \ \ ({\tt Cenu-temp\_type} \ \ \ ({\tt Cenu-temp\_type} \ \ \ ({\tt Cenu-temp\_type} \ \ \ \ ({\tt Cenu-temp\_type} \ \ \ \ \ ({\tt Cenu-temp\_type} \ \ \ \ \ \ \ \ \ \ )
        (C enumerator), 46
                                                            merator), 314
                                                    PhonyNameDueToError.hts_rectum (C enumerator),
PhonyNameDueToError.BT_LE_SCAN_TYPE_PASSIVE
        (C enumerator), 46
PhonyNameDueToError.BT_RFCOMM_CHAN_HFP_AG (C
                                                    PhonyNameDueToError.hts_toe (C enumerator), 314
        enumerator), 175
                                                    PhonyNameDueToError.hts_tympanum (C enumera-
                                                            tor), 314
{\tt PhonyNameDueToError.BT\_RFCOMM\_CHAN\_HFP\_HF} \ \ (C
                                                    PhonyNameDueToError.HTTP_DELETE_REQ (C enu-
        enumerator), 175
PhonyNameDueToError.BT_RFCOMM_CHAN_HSP_AG (C
                                                            merator), 311
```

enumerator), 175

PhonyNameDueToError.HTTP_GET_REQ (C enumera-

```
write_ias_alert_level (C function), 316
        tor), 311
PhonyNameDueToError.HTTP_HEAD_REQ (C enumera- write_lls_alert_level (C function), 316
{\tt PhonyNameDueToError.HTTP\_POST\_REQ}~(C~enumera-
        tor), 311
PhonyNameDueToError.HTTP_PUT_REQ (C enumera-
        tor), 311
PhonyNameDueToError.HTTP_REQ_CANCEL (C enu-
        merator), 312
PhonyNameDueToError.HTTPS_CERTIFICATE_INVALID
        (C enumerator), 312
PhonyNameDueToError.HTTPS_CERTIFICATE_VALID
        (C enumerator), 312
PhonyNameDueToError.HTTPS_DELETE_REQ (C enu-
        merator), 312
{\tt PhonyNameDueToError.HTTPS\_GET\_REQ}\ (C\ enumera-
        tor), 311
PhonyNameDueToError.HTTPS_HEAD_REQ (C enumer-
        ator), 311
PhonyNameDueToError.HTTPS_POST_REQ (C enumer-
        ator), 311
PhonyNameDueToError.HTTPS_PUT_REQ (C enumera-
        tor), 311
PhonyNameDueToError.IDLE_STATE (C enumerator),
        312
PhonyNameDueToError.MILD_ALERT (C enumerator),
        316
PhonyNameDueToError.NO_ALERT (Cenumerator), 316
PhonyNameDueToError.URI_SET (C enumerator), 312
pxr_deinit (C function), 317
pxr_ias_get_alert_level (C function), 317
pxr_init (C function), 317
pxr_lls_get_alert_level (C function), 317
pxr_tps_get_power_level (C function), 317
pxr_tps_set_power_level (C function), 317
R
read_lls_alert_level (C function), 316
read_tps_power_level (C function), 317
read_tps_power_level_desc (C function), 317
ROLE_TYPE (C enum), 200
ROLE_TYPE.BT_A2DP_SINK (C enumerator), 200
ROLE_TYPE.BT_A2DP_SOURCE (C enumerator), 200
Т
temp_measurement (C struct), 314
U
USER_DATA_MIN (C macro), 315
W
write_http_entity_body (C function), 313
write_http_headers (C function), 313
```

How To Reach Us

Home Page:

nxp.com

Web Support:

nxp.com/support

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: nxp.com/SalesTermsandConditions.

Right to make changes - NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Security — Customer understands that all NXP products may be subject to unidentified or documented vulnerabilities. Customer is responsible for the design and operation of its applications and products throughout their lifecycles to reduce the effect of these vulnerabilities on customer's applications and products. Customer's responsibility also extends to other open and/or proprietary technologies supported by NXP products for use in customer's applications. NXP accepts no liability for any vulnerability. Customer should regularly check security updates from NXP and follow up appropriately. Customer shall select products with security features that best meet rules, regulations, and standards of the intended application and make the ultimate design decisions regarding its products and is solely responsible for compliance with all legal, regulatory, and security related requirements concerning its products, regardless of any information or support that may be provided by NXP. NXP has a Product Security Incident Response Team (PSIRT) (reachable at PSIRT@nxp.com) that manages the investigation, reporting, and solution release to security vulnerabilities of NXP products.

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX,EMBRACE, GREENCHIP, HITAG, ICODE, JCOP, LIFE, VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, AltiVec, CodeWarrior, ColdFire, ColdFire+, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorlQ, QorlQ Qonverge, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, Tower, TurboLink, EdgeScale, EdgeLock, elQ, and Immersive3D are trademarks of NXP B.V. All other product or service names are the property of their respective owners. AMBA, Arm, Arm7, Arm7TDMI, Arm9, Arm11, Artisan, big.LITTLE, Cordio, CoreLink, CoreSight, Cortex, DesignStart, DynamlQ, Jazelle, Keil, Mali, Mbed, Mbed Enabled, NEON, POP, RealView, SecurCore, Socrates, Thumb, TrustZone, ULINK, ULINK2, ULINK-PLUS, ULINKpro, µVision, Versatile are trademarks or registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. The related technology may be protected by any or all of patents, copyrights, designs and trade secrets. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.



© NXP B.V. 2021.

All rights reserved.

For more information, please visit: http://www.nxp.com
For sales office addresses, please send an email to: salesaddresses@nxp.com

Date of release: 12 July 2022
Document identifier: EFBTPALAPIRM