## **MLIB User's Guide**

ARM® Cortex® M0+

Document Number: CM0MLIBUG

Rev. 4, 05/2020



#### **Contents**

Sec	tion number Title	P	age
	Chapter Library		
1.1	Introduction		7
1.2	Library integration into project (MCUXpresso IDE)		9
1.3	Library integration into project (Kinetis Design Studio)		. 18
1.4	Library integration into project (Keil µVision)		26
1.5	Library integration into project (IAR Embedded Workbench)		34
	Chapter Algorithms in		
2.1	MLIB_Abs		43
2.2	MLIB_AbsSat		44
2.3	MLIB_Add		45
2.4	MLIB_AddSat		47
2.5	MLIB_Add4		48
2.6	MLIB_Add4Sat		49
2.7	MLIB_Clb		51
2.8	MLIB_Conv		. 52
2.9	MLIB_Div		53
2.10	MLIB_DivSat		55
2.11	MLIB_Div1Q		57
2.12	MLIB_Div1QSat		59
2.13	MLIB_Log2		61
2.14	MLIB_Mac		62
2.15	MLIB_MacSat		64
2.16	MLIB_MacRnd		65
2.17	MLIB_MacRndSat		67
2.18	MLIB_Mac4		68
2.19	MLIB_Mac4Sat		70

Sec	tion number Title	Page
2.20	MLIB_Mac4Rnd	71
2.21	MLIB_Mac4RndSat	73
2.22	MLIB_Mnac	74
2.23	MLIB_MnacSat	76
2.24	MLIB_MnacRnd	77
2.25	MLIB_MnacRndSat	79
2.26	MLIB_Msu	80
2.27	MLIB_MsuSat	82
2.28	MLIB_MsuRnd	83
2.29	MLIB_MsuRndSat	85
2.30	MLIB_Msu4	86
2.31	MLIB_Msu4Sat	88
2.32	MLIB_Msu4Rnd	89
2.33	MLIB_Msu4RndSat	91
2.34	MLIB_Mul	
2.35	MLIB_MulSat	94
2.36	MLIB_MulNeg	95
2.37	MLIB_MulNegSat	97
2.38	MLIB_MulRnd	98
2.39	MLIB_MulRndSat	100
2.40	MLIB_MulNegRnd	
2.41	MLIB_MulNegRndSat	
2.42	MLIB_Neg	
2.43	MLIB_NegSat	
2.44	MLIB_Rcp	
2.45	MLIB_Rcp1Q	
2.46	MLIB_Rnd	
2.47	MLIB_RndSat	
2.48	MLIB_Sat	112

Section number	Title	Page
2.49 MLIB_Sh1L		114
2.50 MLIB_Sh1LSat		115
2.51 MLIB_Sh1R		116
2.52 MLIB_ShL		117
2.53 MLIB_ShLSat		118
2.54 MLIB_ShR		120
2.55 MLIB_ShLBi		121
2.56 MLIB_ShLBiSat		122
2.57 MLIB_ShRBi		
2.58 MLIB_ShRBiSat		
2.59 MLIB_Sign		126
2.60 MLIB_Sub		128
2.61 MLIB_SubSat		129
2.62 MLIB_Sub4		130
2.63 MLIB_Sub4Sat		132

# Chapter 1 Library

#### 1.1 Introduction

#### 1.1.1 Overview

This user's guide describes the Math Library (MLIB) for the family of ARM Cortex M0+core-based microcontrollers. This library contains optimized functions.

## 1.1.2 Data types

MLIB supports several data types: (un)signed integer, fractional, and accumulator. The integer data types are useful for general-purpose computation; they are familiar to the MPU and MCU programmers. The fractional data types enable powerful numeric and digital-signal-processing algorithms to be implemented. The accumulator data type is a combination of both; that means it has the integer and fractional portions.

The following list shows the integer types defined in the libraries:

- Unsigned 16-bit integer —<0; 65535> with the minimum resolution of 1
- Signed 16-bit integer —<-32768; 32767> with the minimum resolution of 1
- Unsigned 32-bit integer —<0; 4294967295> with the minimum resolution of 1
- Signed 32-bit integer —<-2147483648; 2147483647> with the minimum resolution of 1

The following list shows the fractional types defined in the libraries:

- Fixed-point 16-bit fractional —<-1;  $1 2^{-15}$ > with the minimum resolution of  $2^{-15}$
- Fixed-point 32-bit fractional —<-1; 1 2<sup>-31</sup>> with the minimum resolution of 2<sup>-31</sup>

The following list shows the accumulator types defined in the libraries:

#### Introduction

- Fixed-point 16-bit accumulator —<-256.0; 256.0  $2^{-7}$ > with the minimum resolution of  $2^{-7}$
- Fixed-point 32-bit accumulator —<-65536.0;  $65536.0 2^{-15}$ > with the minimum resolution of  $2^{-15}$

#### 1.1.3 API definition

MLIB uses the types mentioned in the previous section. To enable simple usage of the algorithms, their names use set prefixes and postfixes to distinguish the functions' versions. See the following example:

```
f32Result = MLIB Mac F32lss(f32Accum, f16Mult1, f16Mult2);
```

where the function is compiled from four parts:

- MLIB—this is the library prefix
- Mac—the function name—Multiply-Accumulate
- F32—the function output type
- lss—the types of the function inputs; if all the inputs have the same type as the output, the inputs are not marked

The input and output types are described in the following table:

Туре	Output	Input
frac16_t	F16	S
frac32_t	F32	I
acc32_t	A32	а

Table 1-1. Input/output types

## 1.1.4 Supported compilers

MLIB for the ARM Cortex M0+ core is written in C language or assembly language with C-callable interface depending on the specific function. The library is built and tested using the following compilers:

- Kinetis Design Studio
- MCUXpresso IDE
- IAR Embedded Workbench
- Keil µVision

For the MCUXpresso IDE, the library is delivered in the *mlib.a* file.

For the Kinetis Design Studio, the library is delivered in the *mlib.a* file.

For the IAR Embedded Workbench, the library is delivered in the *mlib.a* file.

For the Keil µVision, the library is delivered in the *mlib.lib* file.

The interfaces to the algorithms included in this library are combined into a single public interface include file, *mlib.h*. This is done to lower the number of files required to be included in your application.

## 1.1.5 Library configuration

MLIB for the ARM Cortex M0+ core is written in C language or assembly language with C-callable interface depending on the specific function. Some functions from this library are inline type, which are compiled together with project using this library. The optimization level for inline function is usually defined by the specific compiler setting. It can cause an issue especially when high optimization level is set. Therefore the optimization level for all inline assembly written functions is defined by compiler pragmas using macros. The configuration header file RTCESL\_cfg.h is located in: specific library folder\MLIB\Include. The optimization level can be changed by modifying the macro value for specific compiler. In case of any change the library functionality is not guaranteed.

Similarly as optimization level the Memory-mapped divide and square root module support can be disable or enable if it has not been done by defined symbol RTCESL\_MMDVSQ\_ON or RTCESL\_MMDVSQ\_OFF in project setting described in Memory-mapped divide and square root support cheaper for specific compiler.

#### 1.1.6 Special issues

- 1. The equations describing the algorithms are symbolic. If there is positive 1, the number is the closest number to 1 that the resolution of the used fractional type allows. If there are maximum or minimum values mentioned, check the range allowed by the type of the particular function version.
- 2. The library functions that round the result (the API contains Rnd) round to nearest (half up).

## 1.2 Library integration into project (MCUXpresso IDE)

#### Library integration into project (MCUXpresso IDE)

This section provides a step-by-step guide on how to quickly and easily include MLIB into any MCUXpresso SDK example or demo application projects using MCUXpresso IDE. This example uses the default installation path (C:\NXP\RTCESL\CM0\_RTCESL\_4.5\_MCUX). If you have a different installation path, use that path instead.

## 1.2.1 Memory-mapped divide and square root support

Some Kinetis platforms contain a peripheral module dedicated for division and square root. This section shows how to turn the memory-mapped divide and square root (MMDVSQ) support on and off.

- 1. In the MCUXpresso SDK project name node or in the left-hand part, click Properties or select Project > Properties from the menu. A project properties dialog appears.
- 2. Expand the C/C++ Build node and select Settings. See Figure 1-1.
- 3. In the right-hand part, under the MCU C Compiler node, click the Preprocessor node. See Figure 1-1.




Figure 1-1. Defined symbols

4. In the right-hand part of the dialog, click the Add... icon located next to the Defined symbols (-D) title.

- 5. In the dialog that appears (see Figure 1-2), type the following:
  - RTCESL\_MMDVSQ\_ON—to turn the hardware division and square root support on
  - RTCESL\_MMDVSQ\_OFF—to turn the hardware division and square root support off

If neither of these two defines is defined, the hardware division and square root support is turned off by default.




Figure 1-2. Symbol definition

- 6. Click OK in the dialog.
- 7. Click OK in the main dialog.

See the device reference manual to verify whether the device contains the MMDVSQ module.

## 1.2.2 Library path variable

To make the library integration easier, create a variable that holds the information about the library path.

- 1. Right-click the MCUXpresso SDK project name node in the left-hand part and click Properties, or select Project > Properties from the menu. A project properties dialog appears.
- 2. Expand the Resource node and click Linked Resources. See Figure 1-3.

#### Library integration into project (MCUXpresso IDE)




Figure 1-3. Project properties

- 3. Click the New... button in the right-hand side.
- 4. In the dialog that appears (see Figure 1-4), type this variable name into the Name box: RTCESL\_LOC.
- 5. Select the library parent folder by clicking Folder..., or just type the following path into the Location box: C:\NXP\RTCESL\CM0\_RTCESL\_4.5\_MCUX. Click OK.




Figure 1-4. New variable

- 6. Create such variable for the environment. Expand the C/C++ Build node and click Environment.
- 7. Click the Add... button in the right-hand side.
- 8. In the dialog that appears (see Figure 1-5), type this variable name into the Name box: RTCESL\_LOC.
- 9. Type the library parent folder path into the Value box: C:\NXP\RTCESL \CM0\_RTCESL\_4.5\_MCUX.
- 10. Tick the Add to all configurations box to use this variable in all configurations. See Figure 1-5.
- 11. Click OK.
- 12. In the previous dialog, click OK.

#### Library integration into project (MCUXpresso IDE)




Figure 1-5. Environment variable

#### 1.2.3 Library folder addition

To use the library, add it into the Project tree dialog.

- 1. Right-click the MCUXpresso SDK project name node in the left-hand part and click New > Folder, or select File > New > Folder from the menu. A dialog appears.
- 2. Click Advanced to show the advanced options.
- 3. To link the library source, select the Link to alternate location (Linked Folder) option.
- 4. Click Variables..., select the RTCESL\_LOC variable in the dialog, click OK, and/or type the variable name into the box. See Figure 1-6.

MLIB User's Guide, Rev. 4, 05/2020

NXP Semiconductors

5. Click Finish, and the library folder is linked in the project. See Figure 1-7.




Figure 1-6. Folder link




Figure 1-7. Projects libraries paths

## 1.2.4 Library path setup

- 1. Right-click the MCUXpresso SDK project name node in the left-hand part and click Properties, or select Project > Properties from the menu. The project properties dialog appears.
- 2. Expand the C/C++ General node, and click Paths and Symbols.
- 3. In the right-hand dialog, select the Library Paths tab. See Figure 1-9.
- 4. Click the Add... button on the right, and a dialog appears.
- 5. Look for the RTCESL\_LOC variable by clicking Variables..., and then finish the path in the box by adding the following (see Figure 1-8): \${RTCESL\_LOC}\MLIB.
- 6. Click OK, you will see the path added into the list. See Figure 1-9.

#### Library integration into project (MCUXpresso IDE)




Figure 1-8. Library path inclusion




Figure 1-9. Library paths

- 7. After adding the library path, add the library file. Click the Libraries tab. See Figure 1-11.
- 8. Click the Add... button on the right, and a dialog appears.
- 9. Type the following into the File text box (see Figure 1-10): :mlib.a
- 10. Click OK, and you will see the library added in the list. See Figure 1-11.




Figure 1-10. Library file inclusion




Figure 1-11. Libraries

- 11. In the right-hand dialog, select the Includes tab, and click GNU C in the Languages list. See Figure 1-13.
- 12. Click the Add... button on the right, and a dialog appears. See Figure 1-12.
- 13. Look for the RTCESL\_LOC variable by clicking Variables..., and then finish the path in the box to be: \${RTCESL\_LOC}\MLIB\Include
- 14. Click OK, and you will see the path added in the list. See Figure 1-13. Click OK.




Figure 1-12. Library include path addition

Library integration into project (Kinetis Design Studio)




Figure 1-13. Compiler setting

Type the #include syntax into the code where you want to call the library functions. In the left-hand dialog, open the required .c file. After the file opens, include the following line into the #include section:

```
#include "mlib.h"
```

When you click the Build icon (hammer), the project is compiled without errors.

## 1.3 Library integration into project (Kinetis Design Studio)

This section provides a step-by-step guide on how to quickly and easily include MLIB into an empty project or any MCUXpresso SDK example or demo application projects using Kinetis Design Studio. This example uses the default installation path (C:\NXP\RTCESL\CM0\_RTCESL\_4.5\_KDS). If you have a different installation path, use that path instead. If you want to use an existing MCUXpresso SDK project (for example the hello\_world project) see Memory-mapped divide and square root support. If not, continue with the next section.

## 1.3.1 Memory-mapped divide and square root support

Some Kinetis platforms contain a peripheral module dedicated for division and square root. This section shows how to turn the memory-mapped divide and square root (MMDVSQ) support on and off.

- 1. Right-click the MyProject01 or MCUXpresso SDK project name node or in the left-hand part and click Properties, or select Project > Properties from the menu. A project properties dialog appears.
- 2. Expand the C/C++ Build node and select Settings. See Figure 1-14.
- 3. In the right-hand part, under the Cross ARM C compiler node, click the Preprocessor node. See Figure 1-14.




Figure 1-14. Defined symbols

- 4. In the right-hand part of the dialog, click the Add... icon located next to the Defined symbols (-D) title.
- 5. In the dialog that appears (see Figure 1-15), type the following:
  - RTCESL\_MMDVSQ\_ON—to turn the hardware division and square root support on
  - RTCESL\_MMDVSQ\_OFF—to turn the hardware division and square root support off

If neither of these two defines is defined, the hardware division and square root support is turned off by default.

Library integration into project (Kinetis Design Studio)




Figure 1-15. Symbol definition

- 6. Click OK in the dialog.
- 7. Click OK in the main dialog.

See the device reference manual to verify whether the device contains the MMDVSQ module.

## 1.3.2 Library path variable

To make the library integration easier, create a variable that will hold the information about the library path.

- 1. Right-click the MyProject01 or MCUXpresso SDK project name node in the left-hand part and click Properties, or select Project > Properties from the menu. A project properties dialog appears.
- 2. Expand the Resource node and click Linked Resources. See Figure 1-16.




Figure 1-16. Project properties

- 3. Click the New... button in the right-hand side.
- 4. In the dialog that appears (see Figure 1-17), type this variable name into the Name box: RTCESL\_LOC.
- 5. Select the library parent folder by clicking Folder..., or just type the following path into the Location box: C:\NXP\RTCESL\CM0\_RTCESL\_4.5\_KDS. Click OK.




Figure 1-17. New variable

MLIB User's Guide, Rev. 4, 05/2020

#### Library integration into project (Kinetis Design Studio)

- 6. Create such variable for the environment. Expand the C/C++ Build node and click Environment.
- 7. Click the Add... button in the right-hand side.
- 8. In the dialog that appears (see Figure 1-18), type this variable name into the Name box: RTCESL\_LOC.
- 9. Type the library parent folder path into the Value box: C:\NXP\RTCESL \CM0\_RTCESL\_4.5\_KDS.
- 10. Tick the Add to all configurations box to use this variable in all configurations. See Figure 1-18.
- 11. Click OK.
- 12. In the previous dialog, click OK.




Figure 1-18. Environment variable

## 1.3.3 Library folder addition

To use the library, add it into the Project tree dialog.

- 1. Right-click the MyProject01 or MCUXpresso SDK project name node in the left-hand part and click New > Folder, or select File > New > Folder from the menu. A dialog appears.
- 2. Click Advanced to show the advanced options.
- 3. To link the library source, select the option Link to alternate location (Linked Folder).
- 4. Click Variables..., select the RTCESL\_LOC variable in the dialog, click OK, and/or type the variable name into the box. See Figure 1-19.

5. Click Finish, and you will see the library folder linked in the project. See Figure 1-20.




Figure 1-19. Folder link




Figure 1-20. Projects libraries paths

#### 1.3.4 Library path setup

- 1. Right-click the MyProject01 or MCUXpresso SDK project name node in the left-hand part and click Properties, or select Project > Properties from the menu. A project properties dialog appears.
- 2. Expand the C/C++ General node, and click Paths and Symbols.
- 3. In the right-hand dialog, select the Library Paths tab. See Figure 1-22.
- 4. Click the Add... button on the right, and a dialog appears.
- 5. Look for the RTCESL\_LOC variable by clicking Variables..., and then finish the path in the box by adding the following (see Figure 1-21): \${RTCESL\_LOC}\MLIB.

#### Library integration into project (Kinetis Design Studio)

6. Click OK, and the path will be visible in the list. See Figure 1-22.




Figure 1-21. Library path inclusion




Figure 1-22. Library paths

- 7. After adding the library path, add the library file. Click the Libraries tab. See Figure 1-24.
- 8. Click the Add... button on the right, and a dialog appears.
- 9. Type the following into the File text box (see Figure 1-23): :mlib.a
- 10. Click OK, and you will see the library added in the list. See Figure 1-24.




Figure 1-23. Library file inclusion




Figure 1-24. Libraries

- 11. In the right-hand dialog, select the Includes tab, and click GNU C in the Languages list. See Figure 1-26.
- 12. Click the Add... button on the right, and a dialog appears. See Figure 1-25.
- 13. Look for the RTCESL\_LOC variable by clicking Variables..., and then finish the path in the box to be: \${RTCESL\_LOC}\MLIB\Include
- 14. Click OK, and you will see the path added in the list. See Figure 1-26. Click OK.




Figure 1-25. Library include path addition




Figure 1-26. Compiler setting

Type the #include syntax into the code. Include the library into the *main.c* file. In the left-hand dialog, open the Sources folder of the project, and double-click the *main.c* file. After the *main.c* file opens up, include the following line in the #include section:

#include "mlib.h"

When you click the Build icon (hammer), the project will be compiled without errors.

## 1.4 Library integration into project (Keil µVision)

This section provides a step-by-step guide on how to quickly and easily include MLIB into an empty project or any MCUXpresso SDK example or demo application projects using Keil µVision. This example uses the default installation path (C:\NXP\RTCESL \CM0\_RTCESL\_4.5\_KEIL). If you have a different installation path, use that path instead. If any MCUXpresso SDK project is intended to use (for example hello\_world project) go to Memory-mapped divide and square root support chapter otherwise read next chapter.

## 1.4.1 NXP pack installation for new project (without MCUXpresso SDK)

This example uses the NXP MKV10Z32xxx7 part, and the default installation path (C: \NXP\RTCESL\CM0\_RTCESL\_4.5\_KEIL) is supposed. If the compiler has never been used to create any NXP MCU-based projects before, check whether the NXP MCU pack for the particular device is installed. Follow these steps:

- 1. Launch Keil μVision.
- 2. In the main menu, go to Project > Manage > Pack Installer....
- 3. In the left-hand dialog (under the Devices tab), expand the All Devices > Freescale (NXP) node.
- 4. Look for a line called "KVxx Series" and click it.
- 5. In the right-hand dialog (under the Packs tab), expand the Device Specific node.
- 6. Look for a node called "Keil::Kinetis\_KVxx\_DFP." If there are the Install or Update options, click the button to install/update the package. See Figure 1-27.
- 7. When installed, the button has the "Up to date" title. Now close the Pack Installer.




Figure 1-27. Pack Installer

## 1.4.2 New project (without MCUXpresso SDK)

To start working on an application, create a new project. If the project already exists and is opened, skip to the next section. Follow these steps to create a new project:

- 1. Launch Keil µVision.
- 2. In the main menu, select Project > New μVision Project..., and the Create New Project dialog appears.
- 3. Navigate to the folder where you want to create the project, for example C: \KeilProjects\MyProject01. Type the name of the project, for example MyProject01. Click Save. See Figure 1-28.




Figure 1-28. Create New Project dialog

- 4. In the next dialog, select the Software Packs in the very first box.
- 5. Type 'kv10' into the Search box, so that the device list is reduced to the KV10 devices.
- 6. Expand the KV10 node.

7. Click the MKV10Z32xxx7 node, and then click OK. See Figure 1-29.




Figure 1-29. Select Device dialog

- 8. In the next dialog, expand the Device node, and tick the box next to the Startup node. See Figure 1-30.
- 9. Expand the CMSIS node, and tick the box next to the CORE node.




Figure 1-30. Manage Run-Time Environment dialog

10. Click OK, and a new project is created. The new project is now visible in the left-hand part of Keil μVision. See Figure 1-31.




Figure 1-31. Project

## 1.4.3 Memory-mapped divide and square root support

Some Kinetis platforms contain a peripheral module dedicated for division and square root. This section shows how to turn the memory-mapped divide and square root (MMDVSQ) support on and off.

- 1. In the main menu, go to Project > Options for Target 'Target1'..., and a dialog appears.
- 2. Select the C/C++ tab. See Figure 1-32.
- 3. In the Include Preprocessor Symbols text box, type the following:
  - RTCESL\_MMDVSQ\_ON—to turn the hardware division and square root support on
  - RTCESL\_MMDVSQ\_OFF—to turn the hardware division and square root support off

If neither of these two defines is defined, the hardware division and square root support is turned off by default.

Library integration into project (Keil µVision)




Figure 1-32. Preprocessor symbols

4. Click OK in the main dialog.

See the device reference manual to verify whether the device contains the MMDVSQ module.

#### 1.4.4 Linking the files into the project

To include the library files in the project, create groups and add them.

- 1. Right-click the Target 1 node in the left-hand part of the Project tree, and select Add Group... from the menu. A new group with the name New Group is added.
- 2. Click the newly created group, and press F2 to rename it to RTCESL.
- 3. Right-click the RTCESL node, and select Add Existing Files to Group 'RTCESL'... from the menu.
- 4. Navigate into the library installation folder C:\NXP\RTCESL \CM0\_RTCESL\_4.5\_KEIL\MLIB\Include, and select the *mlib.h* file. If the file does not appear, set the Files of type filter to Text file. Click Add. See Figure 1-33.




Figure 1-33. Adding .h files dialog

5. Navigate to the parent folder C:\NXP\RTCESL\CM0\_RTCESL\_4.5\_KEIL\MLIB, and select the *mlib.lib* file. If the file does not appear, set the Files of type filter to Library file. Click Add. See Figure 1-34.




Figure 1-34. Adding .lib files dialog

6. Now, all necessary files are in the project tree; see Figure 1-35. Click Close.

MLIB User's Guide, Rev. 4, 05/2020

#### Library integration into project (Keil µVision)



Figure 1-35. Project workspace

#### 1.4.5 Library path setup

The following steps show the inclusion of all dependent modules.

- 1. In the main menu, go to Project > Options for Target 'Target1'..., and a dialog appears.
- 2. Select the C/C++ tab. See Figure 1-36.
- 3. In the Include Paths text box, type the following path (if there are more paths, they must be separated by ';') or add it by clicking the ... button next to the text box:
  - "C:\NXP\RTCESL\CM0\_RTCESL\_4.5\_KEIL\MLIB\Include"
- 4. Click OK.
- 5. Click OK in the main dialog.




Figure 1-36. Library path addition

Type the #include syntax into the code. Include the library into a source file. In the new project, it is necessary to create a source file:

- 1. Right-click the Source Group 1 node, and Add New Item to Group 'Source Group 1'... from the menu.
- 2. Select the C File (.c) option, and type a name of the file into the Name box, for example 'main.c'. See Figure 1-37.

#### Library integration into project (IAR Embedded Workbench)




Figure 1-37. Adding new source file dialog

- 3. Click Add, and a new source file is created and opened up.
- 4. In the opened source file, include the following line into the #include section, and create a main function:

```
#include "mlib.h"
int main(void)
{
   while(1);
}
```

When you click the Build (F7) icon, the project will be compiled without errors.

## 1.5 Library integration into project (IAR Embedded Workbench)

This section provides a step-by-step guide on how to quickly and easily include the MLIB into an empty project or any MCUXpresso SDK example or demo application projects using IAR Embedded Workbench. This example uses the default installation path (C:\NXP\RTCESL\CM0\_RTCESL\_4.5\_IAR). If you have a different installation path, use that path instead. If any MCUXpresso SDK project is intended to use (for example hello\_world project) go to Memory-mapped divide and square root support chapter otherwise read next chapter.

## 1.5.1 New project (without MCUXpresso SDK)

This example uses the NXP MKV10Z32xxx7 part, and the default installation path (C: \NXP\RTCESL\CM0\_RTCESL\_4.5\_IAR) is supposed. To start working on an application, create a new project. If the project already exists and is opened, skip to the next section. Perform these steps to create a new project:

- 1. Launch IAR Embedded Workbench.
- 2. In the main menu, select Project > Create New Project... so that the "Create New Project" dialog appears. See Figure 1-38.




Figure 1-38. Create New Project dialog

- 3. Expand the C node in the tree, and select the "main" node. Click OK.
- 4. Navigate to the folder where you want to create the project, for example, C: \IARProjects\MyProject01. Type the name of the project, for example, MyProject01. Click Save, and a new project is created. The new project is now visible in the left-hand part of IAR Embedded Workbench. See Figure 1-39.

#### Library integration into project (IAR Embedded Workbench)



Figure 1-39. New project

- 5. In the main menu, go to Project > Options..., and a dialog appears.
- 6. In the Target tab, select the Device option, and click the button next to the dialog to select the MCU. In this example, select NXP > KV1x > NXP MKV10Z32xxx7 Click OK. See Figure 1-40.




Figure 1-40. Options dialog

# 1.5.2 Memory-mapped divide and square root support

Some Kinetis platforms contain a peripheral module dedicated to division and square root. This section shows how to turn the memory-mapped divide and square root (MMDVSQ) support on and off.

- 1. In the main menu, go to Project > Options..., and a dialog appears.
- 2. In the left-hand column, select C/C++ Compiler.
- 3. In the right-hand part of the dialog, click the Preprocessor tab (it can be hidden in the right; use the arrow icons for navigation).
- 4. In the text box (at the Defined symbols: (one per line)), type the following (See Figure 1-41):
  - RTCESL\_MMDVSQ\_ON—to turn the hardware division and square root support on
  - RTCESL\_MMDVSQ\_OFF—to turn the hardware division and square root support off

If neither of these two defines is defined, the hardware division and square root support is turned off by default.




Figure 1-41. Defined symbols

5. Click OK in the main dialog.

Library integration into project (IAR Embedded Workbench)

See the device reference manual to verify whether the device contains the MMDVSQ module.

# 1.5.3 Library path variable

To make the library integration easier, create a variable that will hold the information about the library path.

- 1. In the main menu, go to Tools > Configure Custom Argument Variables..., and a dialog appears.
- 2. Click the New Group button, and another dialog appears. In this dialog, type the name of the group PATH, and click OK. See Figure 1-42.




Figure 1-42. New Group

- 3. Click on the newly created group, and click the Add Variable button. A dialog appears.
- 4. Type this name: RTCESL\_LOC
- 5. To set up the value, look for the library by clicking the '...' button, or just type the installation path into the box: C:\NXP\RTCESL\CM0\_RTCESL\_4.5\_IAR. Click OK.
- 6. In the main dialog, click OK. See Figure 1-43.




Figure 1-43. New variable

# 1.5.4 Linking the files into the project

To include the library files into the project, create groups and add them.

- 1. Go to the main menu Project > Add Group...
- 2. Type RTCESL, and click OK.
- 3. Click on the newly created node RTCESL, go to Project > Add Group..., and create a MLIB subgroup.
- 4. Click on the newly created node MLIB, and go to the main menu Project > Add Files... See Figure 1-45.
- 5. Navigate into the library installation folder C:\NXP\RTCESL \CM0\_RTCESL\_4.5\_IAR\MLIB\Include, and select the *mlib.h* file. (If the file does not appear, set the file-type filter to Source Files.) Click Open. See Figure 1-44.
- 6. Navigate into the library installation folder C:\NXP\RTCESL \CM0\_RTCESL\_4.5\_IAR\MLIB, and select the *mlib.a* file. If the file does not appear, set the file-type filter to Library / Object files. Click Open.




Figure 1-44. Add Files dialog

7. Now you will see the files added in the workspace. See Figure 1-45.

#### Library integration into project (IAR Embedded Workbench)




Figure 1-45. Project workspace

# 1.5.5 Library path setup

- 1. In the main menu, go to Project > Options..., and a dialog appears.
- 2. In the left-hand column, select C/C++ Compiler.
- 3. In the right-hand part of the dialog, click on the Preprocessor tab (it can be hidden in the right; use the arrow icons for navigation).
- 4. In the text box (at the Additional include directories title), type the following folder (using the created variable):
  - \$RTCESL\_LOC\$\MLIB\Include
- 5. Click OK in the main dialog. See Figure 1-46.

41




Figure 1-46. Library path adition

Type the #include syntax into the code. Include the library included into the *main.c* file. In the workspace tree, double-click the *main.c* file. After the *main.c* file opens up, include the following line into the #include section:

#include "mlib.h"

When you click the Make icon, the project will be compiled without errors.

Library integration into project (IAR Embedded Workbench)

MLIB User's Guide, Rev. 4, 05/2020

# Chapter 2 Algorithms in detail

# 2.1 MLIB\_Abs

The MLIB\_Abs functions return the absolute value of the input. The function does not saturate the output. See the following equation:

$$MLIB\_Abs(x) = |x|$$

#### **Equation 1. Algorithm formula**

#### 2.1.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

The available versions of the MLIB\_Abs function are shown in the following table.

**Table 2-1. Function versions** 

Function name	Input type	Result type	Description
MLIB_Abs_F16	frac16_t	frac16_t	Absolute value of a 16-bit fractional value. The output is within the range <-1; 1).
MLIB_Abs_F32	frac32_t	_	Absolute value of a 32-bit fractional value. The output is within the range <-1; 1).

#### 2.1.2 Declaration

The available MLIB\_Abs functions have the following declarations:

```
frac16_t MLIB_Abs_F16(frac16_t f16Val)
frac32_t MLIB_Abs_F32(frac32_t f32Val)
```

#### 2.1.3 Function use

The use of the MLIB\_Abs function is shown in the following examples:

#### **Fixed-point version:**

# 2.2 MLIB\_AbsSat

The MLIB\_AbsSat functions return the absolute value of the input. The function saturates the output. See the following equation:

$$MLIB\_AbsSat(x) = |x|$$

**Equation 2. Algorithm formula** 

# 2.2.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <0; 1). The result may saturate.

The available versions of the MLIB\_AbsSat function are shown in the following table.

**Table 2-2. Function versions** 

Function name	Input type	Result type	Description
MLIB_AbsSat_F16	frac16_t	frac16_t	Absolute value of a 16-bit fractional value. The output is within the range <0; 1).
MLIB_AbsSat_F32	frac32_t	frac32_t	Absolute value of a 32-bit fractional value. The output is within the range <0; 1).

#### 2.2.2 Declaration

The available MLIB\_AbsSat functions have the following declarations:

```
frac16_t MLIB_AbsSat_F16(frac16_t f16Val)
frac32_t MLIB_AbsSat_F32(frac32_t f32Val)
```

#### 2.2.3 Function use

The use of the MLIB\_AbsSat function is shown in the following example:

# 2.3 MLIB\_Add

The MLIB\_Add functions return the sum of two addends. The function does not saturate the output. See the following equation:

MLIB Add
$$(a, b) = a + b$$

#### **Equation 3. Algorithm formula**

#### 2.3.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

#### MLIB Add

- Accumulator output with fractional inputs the output is the accumulator type, where the result can be out of the range <-1; 1). The inputs are the fractional values only.
- Accumulator output with mixed inputs the output is the accumulator type, where the result can be out of the range <-1; 1). The inputs are the accumulator and fractional values. The result may overflow.

The available versions of the MLIB\_Add function are shown in the following table.

Function name	Input type		Result	Description
	Addend 1	Addend 2	type	
MLIB_Add_F16	frac16_t	frac16_t	frac16_t	Addition of two 16-bit fractional addends. The output is within the range <-1; 1).
MLIB_Add_F32	frac32_t	frac32_t	frac32_t	Addition of two 32-bit fractional addends. The output is within the range <-1; 1).
MLIB_Add_A32ss	frac16_t	frac16_t	acc32_t	Addition of two 16-bit fractional addends; the result is a 32-bit accumulator. The output may be out of the range <-1; 1).
MLIB_Add_A32as	acc32_t	frac16_t	acc32_t	A 16-bit fractional addend is added to a 32-bit accumulator. The output may be out of the range <-1; 1).

Table 2-3. Function versions

#### 2.3.2 Declaration

The available MLIB\_Add functions have the following declarations:

```
frac16_t MLIB_Add_F16(frac16_t f16Add1, frac16_t f16Add2)
frac32_t MLIB_Add_F32(frac32_t f32Add1, frac32_t f32Add2)
acc32_t MLIB_Add_A32ss(frac16_t f16Add1, frac16_t f16Add2)
acc32_t MLIB_Add_A32as(acc32_t a32Accum, frac16_t f16Add)
```

# 2.3.3 Function use

The use of the MLIB\_Add function is shown in the following examples:

#### **Fixed-point version:**

```
a32Result = MLIB_Add_A32ss(f16Add1, f16Add2);
}
```

# 2.4 MLIB AddSat

The MLIB\_AddSat functions return the sum of two addends. The function saturates the output. See the following equation:

MLIB\_AddSat(a, b) = 
$$\begin{cases} 1, & a+b > 1 \\ -1, & a+b < -1 \\ a+b, & \text{else} \end{cases}$$

**Equation 4. Algorithm formula** 

#### 2.4.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_AddSat function are shown in the following table.

Function name	Input type		Result	Description
	Addend 1	Addend 2	type	
MLIB_AddSat_F16	frac16_t	frac16_t	frac16_t	Addition of two 16-bit fractional addends. The output is within the range <-1; 1).
MLIB_AddSat_F32	frac32_t	frac32_t	frac32_t	Addition of two 32-bit fractional addends. The output is within the range <-1; 1).

Table 2-4. Function versions

#### 2.4.2 Declaration

The available MLIB\_AddSat functions have the following declarations:

```
frac16_t MLIB_Add_F16(frac16_t f16Add1, frac16_t f16Add2)
frac32_t MLIB_Add_F32(frac32_t f32Add1, frac32_t f32Add2)
```

#### 2.4.3 Function use

The use of the MLIB\_AddSat function is shown in the following example:

MLIB User's Guide, Rev. 4, 05/2020

#### 2.5 MLIB Add4

The MLIB\_Add4 functions return the sum of four addends. The function does not saturate the output. See the following equation:

MLIB Add4(
$$a, b, c, d$$
) =  $a+b+c+d$ 

#### **Equation 5. Algorithm formula**

#### 2.5.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

The available versions of the MLIB\_Add4 function are shown in the following table.

**Function name** Input type Result Description type Add. 1 Add. 2 Add. 3 Add. 4 frac16 t frac16 t Addition of four 16-bit fractional addends. MLIB\_Add4\_F16 frac16 t frac16 t frac16 t The output is within the range <-1; 1). MLIB\_Add4\_F32 frac32 t frac32\_t frac32 t frac32 t frac32 t Addition of four 32-bit fractional addends. The output is within the range <-1; 1).

Table 2-5. Function versions

#### 2.5.2 Declaration

The available MLIB\_Add4 functions have the following declarations:

```
frac16_t MLIB_Add4_F16(frac16_t f16Add1, frac16_t f16Add2, frac16_t f16Add3, frac16_t
f16Add4)
frac32_t MLIB_Add4_F32(frac32_t f32Add1, frac32_t f32Add2, frac32_t f32Add3, frac32_t
f32Add4)
```

#### 2.5.3 Function use

The use of the MLIB\_Add4 function is shown in the following examples:

## **Fixed-point version:**

# 2.6 MLIB\_Add4Sat

The MLIB\_Add4Sat functions return the sum of four addends. The function saturates the output. See the following equation:

MLIB\_Add4Sat(a, b, c, d) = 
$$\begin{cases} 1, & a+b+c+d > 1 \\ -1, & a+b+c+d < -1 \\ a+b+c+d, & \text{else} \end{cases}$$

**Equation 6. Algorithm formula** 

# 2.6.1 Available versions

This function is available in the following versions:

#### MLIB Add4Sat

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_Add4Sat function are shown in the following table.

Table 2-6. Function versions

Function name	Input type				Result	Description
	Add. 1	Add. 2	Add. 3	Add. 4	type	
MLIB_Add4Sat_F16	frac16_t	frac16_t	frac16_t	frac16_t	frac16_t	Addition of four 16-bit fractional addends. The output is within the range <-1; 1).
MLIB_Add4Sat_F32	frac32_t	frac32_t	frac32_t	frac32_t	frac32_t	Addition of four 32-bit fractional addends. The output is within the range <-1; 1).

#### 2.6.2 Declaration

The available MLIB\_Add4Sat functions have the following declarations:

```
frac16_t MLIB_Add4Sat_F16(frac16_t f16Add1, frac16_t f16Add2, frac16_t f16Add3, frac16_t
f16Add4)

frac32_t MLIB_Add4Sat_F32(frac32_t f32Add1, frac32_t f32Add2, frac32_t f32Add3, frac32_t
f32Add4)
```

# 2.6.3 Function use

The use of the MLIB\_Add4Sat function is shown in the following example:

# 2.7 MLIB Clb

The MLIB\_Clb functions return the number of leading bits of the input. If the input is 0, it returns the size of the type minus one.

#### 2.7.1 Available versions

This function is available in the following versions:

• Integer output with fractional input - the output is the unsigned integer value when the input is fractional; the result is greater than or equal to 0.

The available versions of the MLIB\_Clb function are shown in the following table.

Function name	Input type	Result type	Description
MLIB_Clb_U16s	frac16_t	_	Counts the leading bits of a 16-bit fractional value. The output is within the range <0; 15>.
MLIB_Clb_U16l	frac32_t	_	Counts the leading bits of a 32-bit fractional value. The output is within the range <0; 31>.

Table 2-7. Function versions

#### 2.7.2 Declaration

The available MLIB\_Clb functions have the following declarations:

```
uint16_t MLIB_Clb_U16s(frac16_t f16Val)
uint16_t MLIB_Clb_U16l(frac32_t f32Val)
```

# 2.7.3 Function use

The use of the MLIB\_Clb function is shown in the following example:

MLIB User's Guide, Rev. 4, 05/2020

#### MLIB\_Conv

```
/* u16Result = clb(f32Val) */
u16Result = MLIB_Clb_U161(f32Val);
}
```

# 2.8 MLIB\_Conv

The MLIB\_Conv functions return the input value, converted to the output type.

#### 2.8.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1).

The available versions of the MLIB\_Conv function are shown in the following table.

Function name	Input type	Result type	Description
MLIB_Conv_F16l	frac32_t	frac16_t	Conversion of a 32-bit fractional value to a 16-bit fractional value. The output is within the range <-1; 1).
MLIB_Conv_F32s	frac16_t	frac32_t	Conversion of a 16-bit fractional value to a 32-bit fractional value. The output is within the range <-1; 1).

**Table 2-8. Function versions** 

#### 2.8.2 Declaration

The available MLIB\_Conv functions have the following declarations:

```
frac16_t MLIB_Conv_F161(frac32_t f32Val)
frac32_t MLIB_Conv_F32s(frac16_t f16Val)
```

# 2.8.3 Function use

The use of the MLIB\_Conv function is shown in the following examples:

# **Fixed-point version:**

```
#include "mlib.h"
static frac32_t f32Result;
static frac16_t f16Val;
```

# 2.9 MLIB\_Div

The MLIB\_Div functions return the fractional division of the numerator and denominator. The function does not saturate the output. See the following equation:

MLIB\_Div(a, b) = 
$$\begin{cases} \max, & a \ge 0 \land b = 0 \\ \min, & a < 0 \land b = 0 \\ \frac{a}{b}, & \text{else} \end{cases}$$

**Equation 7. Algorithm formula** 

#### 2.9.1 Available versions

This function is available in the following versions:

- Fractional output the output is the fractional portion of the result; the result is within the range <-1; 1). The function is only defined for: |nominator| < | denominator|. The function returns undefined results out of this condition.
- Accumulator output the output is the accumulator type, where the result may be out of the range <-1; 1).

The available versions of the MLIB\_Div function are shown in the following table:

Function name	Inpi	ut type	Result	Description
	Num.	Denom.	type	
MLIB_Div_F16	frac16_t	frac16_t	frac16_t	Division of a 16-bit fractional numerator and denominator. The output is within the range <-1; 1).
MLIB_Div_F16ls	frac32_t	frac16_t	frac16_t	Division of a 32-bit fractional numerator by a 16-bit fractional denominator; the output is a 16-bit fractional result. The output is within the range <-1; 1).
MLIB_Div_F16II	frac32_t	frac32_t	frac16_t	Division of a 32-bit fractional numerator and denominator; the output is a 16-bit fractional result. The output is within the range <-1; 1).
MLIB_Div_F32ls	frac32_t	frac16_t	frac32_t	Division of a 32-bit fractional numerator by a 16-bit fractional denominator; the output is a 32-bit fractional result. The output is within the range <-1; 1).

Table 2-9. Function versions

Table continues on the next page...

Table 2-9. Function versions (continued)

Function name	Inpu	ut type	Result	Description
	Num.	Denom.	type	
MLIB_Div_F32	frac32_t	frac32_t	frac32_t	Division of a 32-bit fractional numerator and denominator. The output is within the range <-1; 1).
MLIB_Div_A32ss	frac16_t	frac16_t	acc32_t	Division of a 16-bit fractional numerator and denominator; the output is a 32-bit accumulator result. The output may be out of the range <-1; 1).
MLIB_Div_A32Is	frac32_t	frac16_t	acc32_t	Division of a 32-bit fractional numerator by a 16-bit fractional denominator; the output is a 32-bit accumulator result. The output may be out of the range <-1; 1).
MLIB_Div_A32II	frac32_t	frac32_t	acc32_t	Division of a 32-bit fractional numerator and denominator; the output is a 32-bit accumulator result. The output may be out of the range <-1; 1).
MLIB_Div_A32as	acc32_t	frac16_t	acc32_t	Division of a 32-bit accumulator numerator by a 16-bit fractional denominator; the output is a 32-bit accumulator result. The output may be out of the range <-1; 1).

#### NOTE

This algorithm can use the MMDVSQ peripheral module. See the following sections for more details:

- Memory-mapped divide and square root support in Kinetis Design Studio
- Memory-mapped divide and square root support in Keil µVision
- Memory-mapped divide and square root support in IAR Embedded Workbench

#### 2.9.2 Declaration

The available MLIB\_Div functions have the following declarations:

```
frac16_t MLIB_Div_F16(frac16_t f16Num, frac16_t f16Denom)
frac16_t MLIB_Div_F16ls(frac32_t f32Num, frac16_t f16Denom)
frac16_t MLIB_Div_F16ll(frac32_t f32Num, frac32_t f32Denom)
frac32_t MLIB_Div_F32ls(frac32_t f32Num, frac16_t f16Denom)
frac32_t MLIB_Div_F32(frac32_t f32Num, frac32_t f32Denom)
acc32_t MLIB_Div_A32ss(frac16_t f16Num, frac16_t f16Denom)
acc32_t MLIB_Div_A32ls(frac32_t f32Num, frac16_t f16Denom)
acc32_t MLIB_Div_A32ll(frac32_t f32Num, frac32_t f32Denom)
acc32_t MLIB_Div_A32ll(frac32_t f32Num, frac32_t f32Denom)
acc32_t MLIB_Div_A32as(acc32_t a32Num, frac16_t f16Denom)
```

#### 2.9.3 Function use

The use of the MLIB\_Div function is shown in the following examples:

55

#### **Fixed-point version:**

```
#include "mlib.h"
static frac32 t f32Num, f32Result;
static frac16 t f16Denom;
void main(void)
 /* f32Result = f32Num / f16Denom */
 f32Result = MLIB_Div_F32ls(f32Num, f16Denom);
```

# 2.10 MLIB DivSat

The MLIB DivSat functions return the fractional division of the numerator and denominator. The function saturates the output. See the following equation:

$$MLIB\_DivSat(a, b) = \begin{cases} max, & \frac{a}{b} > max \lor a \ge 0 \land b = 0 \\ min, & \frac{a}{b} < min \lor a < 0 \land b = 0 \\ \frac{a}{b}, & else \end{cases}$$

**Equation 8. Algorithm formula** 

#### 2.10.1 Available versions

This function is available in the following versions:

- Fractional output the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.
- Accumulator output the output is the accumulator type, where the result may be out of the range <-1; 1).

The available versions of the MLIB\_DivSat function are shown in the following table:

**Function name** Input type Result Description type Num. Denom. MLIB\_DivSat\_F16 Division of a 16-bit fractional numerator and denominator. The frac16 t frac16 t frac16 t output is within the range <-1; 1).

Table 2-10. Function versions

Table continues on the next page...

MLIB User's Guide, Rev. 4, 05/2020

Table 2-10. Function versions (continued)

Function name	Inpu	t type	Result	Description
	Num.	Denom.	type	
MLIB_DivSat_F16ls	frac32_t	frac16_t	frac16_t	Division of a 32-bit fractional numerator by a 16-bit fractional denominator; the output is a 16-bit fractional result. The output is within the range <-1; 1).
MLIB_DivSat_F16II	frac32_t	frac32_t	frac16_t	Division of a 32-bit fractional numerator and denominator; the output is a 16-bit fractional result. The output is within the range <-1; 1).
MLIB_DivSat_F32ls	frac32_t	frac16_t	frac32_t	Division of a 32-bit fractional numerator by a 16-bit fractional denominator; the output is a 32-bit fractional result. The output is within the range <-1; 1).
MLIB_DivSat_F32	frac32_t	frac32_t	frac32_t	Division of a 32-bit fractional numerator and denominator. The output is within the range <-1; 1).
MLIB_DivSat_A32as	acc32_t	frac16_t	acc32_t	Division of a 32-bit accumulator numerator by a 16-bit fractional denominator; the output is a 32-bit accumulator result. The output may be out of the range <-1; 1).

#### NOTE

This algorithm can use the MMDVSQ peripheral module. See the following sections for more details:

- Memory-mapped divide and square root support in Kinetis Design Studio
- Memory-mapped divide and square root support in Keil µVision
- Memory-mapped divide and square root support in IAR Embedded Workbench

#### 2.10.2 Declaration

The available MLIB\_DivSat functions have the following declarations:

```
frac16_t MLIB_DivSat_F16(frac16_t f16Num, frac16_t f16Denom)
frac16_t MLIB_DivSat_F16ls(frac32_t f32Num, frac16_t f16Denom)
frac16_t MLIB_DivSat_F16ll(frac32_t f32Num, frac32_t f32Denom)
frac32_t MLIB_DivSat_F32ls(frac32_t f32Num, frac16_t f16Denom)
frac32_t MLIB_DivSat_F32(frac32_t f32Num, frac32_t f32Denom)
acc32_t MLIB_DivSat_A32as(acc32_t a32Num, frac16_t f16Denom)
```

#### 2.10.3 Function use

The use of the MLIB\_DivSat function is shown in the following example:

57

# 2.11 MLIB\_Div1Q

The MLIB\_Div1Q functions return the single-quadrant fractional division of the numerator and denominator. The numerator and denominator must be non-negative numbers, otherwise the function returns undefined results. The function does not saturate the output. See the following equation:

$$MLIB\_Div1Q(a, b) = \begin{cases} max, & a \ge 0 \land b = 0 \\ \frac{a}{b}, & a \ge 0 \land b > 0 \end{cases}$$

**Equation 9. Algorithm formula** 

#### 2.11.1 Available versions

This function is available in the following versions:

- Fractional output the output is the fractional portion of the result; the result is within the range <0; 1). The function is only defined for: nominator < denominator, and both are non-negative. The function returns undefined results out of this condition.
- Accumulator output the output is the accumulator type, where the result is greater than or equal to 0.

The available versions of the MLIB\_Div1Q function are shown in the following table:

Function name Input type Result type

Num. Denom.

MLIB\_Div1Q\_F16 frac16\_t frac16\_t Division of a non-negative 16-bit fractional numerator and denominator. The output is within the range <0; 1).

Table 2-11. Function versions

Table continues on the next page...

Table 2-11. Function versions (continued)

Function name	Inp	ut type	Result	Description
	Num.	Denom.	type	
MLIB_Div1Q_F16ls	frac32_t	frac16_t	frac16_t	Division of a non-negative 32-bit fractional numerator by a non-negative 16-bit fractional denominator; the output is a non-negative 16-bit fractional result. The output is within the range <0; 1).
MLIB_Div1Q_F16II	frac32_t	frac32_t	frac16_t	Division of a non-negative 32-bit fractional numerator and denominator; the output is a non-negative 16-bit fractional result. The output is within the range <0; 1).
MLIB_Div1Q_F32ls	frac32_t	frac16_t	frac32_t	Division of a non-negative 32-bit fractional numerator by a non-negative 16-bit fractional denominator; the output is a non-negative 32-bit fractional result. The output is within the range <0; 1).
MLIB_Div1Q_F32	frac32_t	frac32_t	frac32_t	Division of a non-negative 32-bit fractional numerator and denominator. The output is within the range <0; 1).
MLIB_Div1Q_A32ss	frac16_t	frac16_t	acc32_t	Division of a non-negative 16-bit fractional numerator and denominator; the output is a non-negative 32-bit accumulator result. The output is greater than or equal to 0.
MLIB_Div1Q_A32ls	frac32_t	frac16_t	acc32_t	Division of a non-negative 32-bit fractional numerator by a non-negative 16-bit fractional denominator; the output is a non-negative 32-bit accumulator result. The output is greater than or equal to 0.
MLIB_Div1Q_A32ll	frac32_t	frac32_t	acc32_t	Division of a non-negative 32-bit fractional numerator and denominator; the output is a non-negative 32-bit accumulator result. The output is greater than or equal to 0.
MLIB_Div1Q_A32as	acc32_t	frac16_t	acc32_t	Division of a non-negative 32-bit accumulator numerator by a non-negative 16-bit fractional denominator; the output is a 32-bit accumulator result. The output is greater than or equal to 0.

#### **NOTE**

This algorithm can use the MMDVSQ peripheral module. See the following sections for more details:

- Memory-mapped divide and square root support in Kinetis Design Studio
- Memory-mapped divide and square root support in Keil µVision
- Memory-mapped divide and square root support in IAR Embedded Workbench

#### 2.11.2 Declaration

The available MLIB\_Div1Q functions have the following declarations:

```
frac16_t MLIB_DivlQ_F16(frac16_t f16Num, frac16_t f16Denom)
frac16_t MLIB_DivlQ_F16ls(frac32_t f32Num, frac16_t f16Denom)
frac16_t MLIB_DivlQ_F16ll(frac32_t f32Num, frac32_t f32Denom)
```

MLIB User's Guide, Rev. 4, 05/2020

```
frac32_t MLIB_Div1Q_F32ls(frac32_t f32Num, frac16_t f16Denom)
frac32_t MLIB_Div1Q_F32(frac32_t f32Num, frac32_t f32Denom)
acc32_t MLIB_Div1Q_A32ss(frac16_t f16Num, frac16_t f16Denom)
acc32_t MLIB_Div1Q_A32ls(frac32_t f32Num, frac16_t f16Denom)
acc32_t MLIB_Div1Q_A32ll(frac32_t f32Num, frac32_t f32Denom)
acc32_t MLIB_Div1Q_A32as(acc32_t a32Num, frac16_t f16Denom)
```

#### 2.11.3 Function use

The use of the MLIB\_Div1Q function is shown in the following example:

# 2.12 MLIB\_Div1QSat

The MLIB\_Div1QSat functions return the fractional division of the numerator and denominator. The numerator and denominator must be non-negative numbers. The function saturates the output. See the following equation:

MLIB\_Div1QSat(a, b) = 
$$\begin{cases} max, & \frac{a}{b} > max \land a \ge 0 \land b \ge 0 \\ \frac{a}{b}, & a \ge 0 \land b > 0 \end{cases}$$

**Equation 10. Algorithm formula** 

#### 2.12.1 Available versions

This function is available in the following versions:

- Fractional output the output is the fractional portion of the result; the result is within the range <0; 1). The result may saturate.
- Accumulator output the output is the accumulator type, where the result is greater than or equal to 0.

#### MLIB Div1QSat

The available versions of the MLIB\_Div1QSat function are shown in the following table:

Table 2-12. Function versions

Function name	Input type		Result	Description	
	Num.	Denom.	type		
MLIB_Div1QSat_F16	frac16_t	frac16_t	frac16_t	Division of a non-negative 16-bit fractional numerator and denominator. The output is within the range <0; 1).	
MLIB_Div1QSat_F16ls	frac32_t	frac16_t	frac16_t	Division of a non-negative 32-bit fractional numerator by a non-negative 16-bit fractional denominator; the output is a non-negative 16-bit fractional result. The output is within the range <0; 1).	
MLIB_Div1QSat_F16ll	frac32_t	frac32_t	frac16_t	Division of a non-negative 32-bit fractional numerator and denominator; the output is a non-negative 16-bit fractional result. The output is within the range <0; 1).	
MLIB_Div1QSat_F32ls	frac32_t	frac16_t	frac32_t	Division of a non-negative 32-bit fractional numerator by a non-negative 16-bit fractional denominator; the output is a non-negative 32-bit fractional result. The output is within the range <0; 1).	
MLIB_Div1QSat_F32	frac32_t	frac32_t	frac32_t	Division of a non-negative 32-bit fractional numerator and denominator. The output is within the range <0; 1).	
MLIB_Div1QSat_A32as	acc32_t	frac16_t	acc32_t	Division of a non-negative 32-bit accumulator numerator by a non-negative 16-bit fractional denominator; the output is a 32-bit accumulator result. The output is greater than or equal to 0.	

#### NOTE

This algorithm can use the MMDVSQ peripheral module. See the following sections for more details:

- Memory-mapped divide and square root support in Kinetis Design Studio
- Memory-mapped divide and square root support in Keil µVision
- Memory-mapped divide and square root support in IAR Embedded Workbench

#### 2.12.2 Declaration

The available MLIB\_Div1QSat functions have the following declarations:

```
frac16_t MLIB_Div1QSat_F16(frac16_t f16Num, frac16_t f16Denom)
frac16_t MLIB_Div1QSat_F16ls(frac32_t f32Num, frac16_t f16Denom)
frac16_t MLIB_Div1QSat_F16ll(frac32_t f32Num, frac32_t f32Denom)
frac32_t MLIB_Div1QSat_F32ls(frac32_t f32Num, frac16_t f16Denom)
frac32_t MLIB_Div1QSat_F32(frac32_t f32Num, frac32_t f32Denom)
acc32_t MLIB_Div1QSat_A32as(acc32_t a32Num, frac16_t f16Denom)
```

#### 2.12.3 Function use

The use of the MLIB\_Div1QSat function is shown in the following example:

# 2.13 MLIB\_Log2

The MLIB\_Log2 functions return the binary logarithm of the input. See the following equation:

MLIB\_Log2(x) = 
$$\begin{cases} 0, & x \le 1\\ \text{Log}_2(x), & \text{else} \end{cases}$$

**Equation 11. Algorithm formula** 

#### 2.13.1 Available versions

This function is available in the following versions:

• Unsigned integer output - the output is the unsigned integer result.

The available versions of the MLIB\_Log2 function are shown in the following table.

Table 2-13. Function versions

Function name	Input type	Result type	Description					
MLIB_Log2_U16	uint16_t		Binary logarithm of a 16-bit unsigned integer value. The output is greater than or equal to 0.					

#### 2.13.2 Declaration

The available MLIB\_Log2 functions have the following declarations:

```
uint16 t MLIB Log2 U16(uint16 t u16Val)
```

#### 2.13.3 Function use

The use of the MLIB\_Log2 function is shown in the following example:

# 2.14 MLIB\_Mac

The MLIB\_Mac functions return the sum of the input accumulator, and the fractional product of two multiplicands. The function does not saturate the output. See the following equation:

```
MLIB Mac(a, b, c) = a + b \cdot c
```

**Equation 12. Algorithm formula** 

#### 2.14.1 Available versions

This function is available in the following versions:

- Fractional output the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.
- Accumulator output with mixed inputs the output is the accumulator type, where the result can be out of the range <-1; 1). The accumulator is the accumulator type, the multiplicands are the fractional types. The result may overflow.

The available versions of the MLIB\_Mac function are shown in the following table.

Table 2-14. Function versions

Function name	Input type		Result	Description	
	Accum.	Mult. 1	Mult. 2	type	
MLIB_Mac_F16	frac16_t	frac16_t	frac16_t	frac16_t	The upper 16-bit portion [1631] of the fractional product (of two 16-bit fractional multiplicands) is added to a 16-bit fractional accumulator. The output is within the range <-1; 1).
MLIB_Mac_F32lss	frac32_t	frac16_t	frac16_t	frac32_t	The 32-bit fractional product (of two 16-bit fractional multiplicands) is added to a 32-bit fractional accumulator. The output is within the range <-1; 1).
MLIB_Mac_F32	frac32_t	frac32_t	frac32_t	frac32_t	The upper 32-bit portion [3263] of the fractional product (of two 32-bit fractional multiplicands) is added to a 32-bit fractional accumulator. The output is within the range <-1; 1).
MLIB_Mac_A32ass	acc32_t	frac16_t	frac16_t	acc32_t	The upper 16-bit portion [1631] of the fractional product (of two 16-bit fractional multiplicands) is added to a 32-bit accumulator. The output may be out of the range <-1; 1).

#### 2.14.2 Declaration

The available MLIB\_Mac functions have the following declarations:

```
frac16_t MLIB_Mac_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_Mac_F32lss(frac32_t f32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_Mac_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_Mac_A32ass(acc32_t a32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
```

# 2.14.3 Function use

The use of the MLIB\_Mac function is shown in the following examples:

# **Fixed-point version:**

MLIB User's Guide, Rev. 4, 05/2020

```
MLIB_MacSat
    f32Result = MLIB_Mac_F32lss(f32Accum, f16Mult1, f16Mult2);
}
```

# 2.15 MLIB MacSat

The MLIB\_MacSat functions return the sum of the input accumulator and the fractional product of two multiplicands. The function saturates the output. See the following equation:

MLIB\_MacSat(a, b, c) = 
$$\begin{cases} 1, & a+b \cdot c > 1 \\ -1, & a+b \cdot c < -1 \\ a+b \cdot c, & \text{else} \end{cases}$$

**Equation 13. Algorithm formula** 

#### 2.15.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_MacSat function are shown in the following table.

**Function name** Input type Result **Description** type Accum. Mult. 1 Mult. 2 MLIB\_MacSat\_F16 frac16\_t frac16\_t frac16\_t frac16\_t The upper 16-bit portion [16..31] of the fractional product (of two 16-bit fractional multiplicands) is added to a 16-bit fractional accumulator. The output is within the range <-1; 1). MLIB MacSat F32lss frac32 t frac16 t frac16 t frac32 t The 32-bit fractional product (of two 16-bit fractional multiplicands) is added to a 32-bit fractional accumulator. The output is within the range <-1; 1). frac32\_t frac32\_t The upper 32-bit portion [32..63] of the fractional MLIB\_MacSat\_F32 frac32\_t frac32\_t product (of two 32-bit fractional multiplicands) is added to a 32-bit fractional accumulator. The output is within the range <-1; 1).

Table 2-15. Function versions

#### 2.15.2 Declaration

The available MLIB\_MacSat functions have the following declarations:

```
frac16_t MLIB_MacSat_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MacSat_F32lss(frac32_t f32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MacSat_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
```

#### 2.15.3 Function use

The use of the MLIB\_MacSat function is shown in the following example:

# 2.16 MLIB\_MacRnd

The MLIB\_MacRnd functions return the sum of the input accumulator and the rounded fractional product of two multiplicands. The round method is the round to nearest. The function does not saturate the output. See the following equation:

```
MLIB MacRnd(a, b, c) = a+round(b \cdot c)
```

#### **Equation 14. Algorithm formula**

#### 2.16.1 Available versions

This function is available in the following versions:

- Fractional output the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.
- Accumulator output with mixed inputs the output is the accumulator type where the result can be out of the range <-1; 1). The accumulator is the accumulator type, the multiplicands are the fractional types. The result may overflow.

#### MLIB MacRnd

The available versions of the MLIB\_MacRnd function are shown in the following table.

**Table 2-16. Function versions** 

Function name		Input type	•	Result	Description	
	Accum.	Mult. 1	Mult. 2	type		
MLIB_MacRnd_F16	frac16_t	frac16_t	frac16_t	frac16_t	The fractional product (of two 16-bit fractional multiplicands), rounded to the upper 16 bits, is added to a 16-bit fractional accumulator. The output is within the range <-1; 1).	
MLIB_MacRnd_F32lls	frac32_t	frac32_t	frac16_t	frac32_t	The fractional product (of a 32-bit and 16-bit fractional multiplicand), rounded to the upper 32 bits [1648], is added to a 32-bit fractional accumulator. The output is within the range <-1; 1).	
MLIB_MacRnd_F32	frac32_t	frac32_t	frac32_t	frac32_t	The fractional product (of two 32-bit fractional multiplicands), rounded to the upper 32 bits [3263], is added to a 32-bit fractional accumulator. The output is within the range <-1; 1).	
MLIB_MacRnd_A32ass	acc32_t	frac16_t	frac16_t	acc32_t	The fractional product (of two 16-bit fractional multiplicands), rounded to the upper 16 bits [1631], is added to a 32-bit accumulator. The output may be out of the range <-1; 1).	

#### 2.16.2 Declaration

The available MLIB\_MacRnd functions have the following declarations:

```
frac16_t MLIB_MacRnd_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MacRnd_F32lls(frac32_t f32Accum, frac32_t f32Mult1, frac16_t f16Mult2)
frac32_t MLIB_MacRnd_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_MacRnd_A32ass(acc32_t a32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
```

# 2.16.3 Function use

The use of the MLIB\_MacRnd function is shown in the following example:

MLIB User's Guide, Rev. 4, 05/2020

```
f16Result = MLIB_MacRnd_F16(f16Accum, f16Mult1, f16Mult2);
}
```

# 2.17 MLIB\_MacRndSat

The MLIB\_MacRndSat functions return the sum of the input accumulator and the rounded fractional product of two multiplicands. The round method is the round to nearest. The function saturates the output. See the following equation:

$$MLIB\_MacRndSat(a, b, c) = \begin{cases} 1, & a + round(b \cdot c) > 1 \\ -1, & a + round(b \cdot c) < -1 \\ a + round(b \cdot c), & else \end{cases}$$

**Equation 15. Algorithm formula** 

### 2.17.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_MacRndSat function are shown in the following table.

Function name		Input type	9	Result	Description	
	Accum.	Mult. 1	Mult. 2	type		
MLIB_MacRndSat_F16	frac16_t	frac16_t	frac16_t	frac16_t	The fractional product (of two 16-bit fractional multiplicands), rounded to the upper 16 bits, is added to a 16-bit fractional accumulator. The output is within the range <-1; 1).	
MLIB_MacRndSat_F32lls	frac32_t	frac32_t	frac16_t	frac32_t	The fractional product (of a 32-bit and 16-bit fractional multiplicands), rounded to the upper 32 bits [1648], is added to a 32-bit fractional accumulator. The output is within the range <-1; 1).	
MLIB_MacRndSat_F32	frac32_t	frac32_t	frac32_t	frac32_t	The fractional product (of two 32-bit fractional multiplicands), rounded to the upper 32 bits [3263], is added to a 32-bit fractional accumulator. The output is within the range	

**Table 2-17. Function versions** 

#### 2.17.2 Declaration

The available MLIB\_MacRndSat functions have the following declarations:

```
frac16_t MLIB_MacRndSat_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MacRndSat_F32lls(frac32_t f32Accum, frac32_t f32Mult1, frac16_t f16Mult2)
frac32_t MLIB_MacRndSat_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
```

#### 2.17.3 Function use

The use of the MLIB\_MacRndSat function is shown in the following example:

# 2.18 MLIB\_Mac4

The MLIB\_Mac4 functions return the sum of two products of two pairs of multiplicands. The function does not saturate the output. See the following equation:

MLIB Mac4
$$(a, b, c, d) = a \cdot b + c \cdot d$$

**Equation 16. Algorithm formula** 

#### 2.18.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

The available versions of the MLIB\_Mac4 function are shown in the following table.

Table 2-18. Function versions

Function name		Inpu	t type		Result	Description
	Product 1		Product 2		type	
	Mult. 1	Mult. 2	Mult. 1	Mult. 2		
MLIB_Mac4_F32ssss	frac16_t	frac16_t	frac16_t	frac16_t	frac32_t	Addition of two 32-bit fractional products (of two 16-bit fractional multiplicands). The output is within the range <-1; 1).

#### 2.18.2 Declaration

The available MLIB\_Mac4 functions have the following declarations:

```
frac32_t MLIB_Mac4_F32ssss(frac16_t f16Add1Mult1, frac16_t f16Add1Mult2, frac16_t
f16Add2Mult1, frac16_t f16Add2Mult2)
```

#### 2.18.3 Function use

The use of the MLIB\_Mac4 function is shown in the following examples:

#### **Fixed-point version:**

# 2.19 MLIB\_Mac4Sat

The MLIB\_Mac4Sat functions return the sum of two products of two pairs of multiplicands. The function saturates the output. See the following equation:

$$MLIB\_M ac4Sat(a, b, c, d) = \begin{cases} 1, & a \cdot b + c \cdot d > 1 \\ -1, & a \cdot b + c \cdot d < -1 \\ a \cdot b + c \cdot d, & else \end{cases}$$

**Equation 17. Algorithm formula** 

#### 2.19.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_Mac4Sat function are shown in the following table.

**Function name** Input type Result Description type **Product 1 Product 2** Mult. 1 Mult. 2 Mult. 1 Mult. 2 MLIB Mac4Sat F32ssss Addition of two 32-bit fractional frac16\_t frac16\_t frac16\_t frac16 t frac32\_t products (of two 16-bit fractional multiplicands). The output is within the range <-1; 1).

**Table 2-19. Function versions** 

#### 2.19.2 Declaration

The available MLIB\_Mac4Sat functions have the following declarations:

```
frac32_t MLIB_Mac4Sat_F32ssss(frac16_t f16Add1Mult1, frac16_t f16Add1Mult2, frac16_t
f16Add2Mult1, frac16 t f16Add2Mult2)
```

#### 2.19.3 Function use

The use of the MLIB\_Mac4Sat function is shown in the following example:

# 2.20 MLIB\_Mac4Rnd

The MLIB\_Mac4Rnd functions return the rounded sum of two products of two pairs of multiplicands. The round method is the round to nearest. The function does not saturate the output. See the following equation:

```
MLIB Mac4Rnd(a, b, c, d) = round(a \cdot b + c \cdot d)
```

**Equation 18. Algorithm formula** 

#### 2.20.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

#### MLIB Mac4Rnd

The available versions of the MLIB\_Mac4Rnd function are shown in the following table.

Table 2-20. Function versions

Function name		Inpu	t type		Result	Description
	Proc	duct 1	Product 2		type	
	Mult. 1	Mult. 2	Mult. 1	Mult. 2		
MLIB_Mac4Rnd_F16	frac16_t	frac16_t	frac16_t	frac16_t	frac16_t	Addition of two 16-bit fractional products (of two 16-bit fractional multiplicands), rounded to the upper 16 bits. The output is within the range <-1; 1).
MLIB_Mac4Rnd_F32	frac32_t	frac32_t	frac32_t	frac32_t	frac32_t	Addition of two 32-bit fractional products (of two 32-bit fractional multiplicands), rounded to the upper 32 bits. The output is within the range <-1; 1).

#### 2.20.2 Declaration

The available MLIB\_Mac4Rnd functions have the following declarations:

```
frac16_t MLIB_Mac4Rnd_F16(frac16_t f16Add1Mult1, frac16_t f16Add1Mult2, frac16_t
f16Add2Mult1, frac16_t f16Add2Mult2)

frac32_t MLIB_Mac4Rnd_F32(frac32_t f32Add1Mult1, frac32_t f32Add1Mult2, frac32_t
f32Add2Mult1, frac32_t f32Add2Mult2)
```

# 2.20.3 Function use

The use of the MLIB\_Mac4Rnd function is shown in the following example:

# 2.21 MLIB\_Mac4RndSat

The MLIB\_Mac4RndSat functions return the rounded sum of two products of two pairs of multiplicands. The round method is the round to nearest. The function saturates the output. See the following equation:

$$\text{MLIB\_M ac4RndSat}(a, b, c, d) = \begin{cases} 1, & \text{round}(a \cdot b + c \cdot d) > 1 \\ -1, & \text{round}(a \cdot b + c \cdot d) < -1 \\ \text{round}(a \cdot b + c \cdot d), & \text{else} \end{cases}$$

**Equation 19. Algorithm formula** 

### 2.21.1 Available versions

The function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_Mac4RndSat function are shown in the following table.

Function name		Input type			Result	Description
	Proc	duct 1	Pro	Product 2		
	Mult. 1	Mult. 2	Mult. 1	Mult. 2	1	
MLIB_Mac4RndSat_F16	frac16_t	frac16_t	frac16_t	frac16_t	frac16_t	Addition of two 16-bit fractional products (of two 16-bit fractional multiplicands), rounded to the upper 16 bits. The output is within the range <-1; 1).
MLIB_Mac4RndSat_F32	frac32_t	frac32_t	frac32_t	frac32_t	frac32_t	Addition of two 32-bit fractional products (of two 32-bit fractional multiplicands), rounded to the upper 32 bits. The output is within the range <-1; 1).

Table 2-21. Function versions

## 2.21.2 Declaration

The available MLIB\_Mac4RndSat functions have the following declarations:

```
frac16_t MLIB_Mac4RndSat_F16(frac16_t f16Add1Mult1, frac16_t f16Add1Mult2, frac16_t
f16Add2Mult1, frac16_t f16Add2Mult2)

frac32_t MLIB_Mac4RndSat_F32(frac32_t f32Add1Mult1, frac32_t f32Add1Mult2, frac32_t
f32Add2Mult1, frac32 t f32Add2Mult2)
```

## 2.21.3 Function use

The use of the MLIB\_Mac4RndSat function is shown in the following example:

# 2.22 MLIB\_Mnac

The MLIB\_Mnac functions return the product of two multiplicands minus the input accumulator. The function does not saturate the output. See the following equation:

MLIB Mnac
$$(a, b, c) = b \cdot c - a$$

### **Equation 20. Algorithm formula**

## 2.22.1 Available versions

This function is available in the following versions:

- Fractional output the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.
- Accumulator output with mixed inputs the output is the accumulator type, where the result can be out of the range <-1; 1). The accumulator is the accumulator type, the multiplicands are the fractional types. The result may overflow.

The available versions of the MLIB\_Mnac function are shown in the following table.

Table 2-22. Function versions

Function name		Input type	)	Result	Description
	Accum.	Mult. 1	Mult. 2	type	
MLIB_Mnac_F16	frac16_t	frac16_t	frac16_t	frac16_t	The 16-bit fractional accumulator is subtracted from the upper 16-bit portion [1631] of the fractional product (of two 16-bit fractional multiplicands). The output is within the range <-1; 1).
MLIB_Mnac_F32lss	frac32_t	frac16_t	frac16_t	frac32_t	The 32-bit fractional accumulator is subtracted from the 32-bit fractional product (of two 16-bit fractional multiplicands). The output is within the range <-1; 1).
MLIB_Mnac_F32	frac32_t	frac32_t	frac32_t	frac32_t	The 32-bit fractional accumulator is subtracted from the upper 32-bit portion [3263] of the fractional product (of two 32-bit fractional multiplicands). The output is within the range <-1; 1).
MLIB_Mnac_A32ass	acc32_t	frac16_t	frac16_t	acc32_t	The 32-bit accumulator is subtracted from the upper 16-bit portion [1631] of the fractional product (of two 16-bit fractional multiplicands). The output may be out of the range <-1; 1).

## 2.22.2 Declaration

The available MLIB\_Mnac functions have the following declarations:

```
frac16_t MLIB_Mnac_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_Mnac_F32lss(frac32_t f32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_Mnac_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_Mnac_A32ass(acc32_t a32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
```

## 2.22.3 Function use

The use of the MLIB\_Mnac function is shown in the following examples:

## **Fixed-point version:**

MLIB User's Guide, Rev. 4, 05/2020

#### **MLIB MnacSat**

```
/* f32Result = f16Mult1 * f16Mult2 - f32Accum */
f32Result = MLIB_Mnac_F32lss(f32Accum, f16Mult1, f16Mult2);
}
```

## 2.23 MLIB MnacSat

The MLIB\_MnacSat functions return the product of two multiplicands minus the input accumulator. The function saturates the output. See the following equation:

MLIB\_M nacSat(a, b, c) = 
$$\begin{cases} 1, & b \cdot c - a > 1 \\ -1, & b \cdot c - a < -1 \\ b \cdot c - a, & \text{else} \end{cases}$$

**Equation 21. Algorithm formula** 

### 2.23.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_MnacSat function are shown in the following table.

Function name		Input type	)	Result	Description		
	Accum.	Mult. 1	Mult. 2	type			
MLIB_MnacSat_F16	frac16_t	frac16_t	frac16_t	frac16_t	The 16-bit fractional accumulator is subtracted from the upper 16-bit portion [1631] of the fractional product (of two 16-bit fractional multiplicands). The output is within the range <-1; 1).		
MLIB_MnacSat_F32lss	frac32_t	frac16_t	frac16_t	frac32_t	The 32-bit fractional accumulator is subtracted from the 32-bit fractional product (of two 16-bit fractional multiplicands). The output is within the range <-1; 1).		
MLIB_MnacSat_F32	frac32_t	frac32_t	frac32_t	frac32_t	The 32-bit fractional accumulator is subtracted from the upper 32-bit portion [3263] of the fractional product (of two 32-bit fractional multiplicands). The output is within the range <-1; 1).		

Table 2-23. Function versions

# 2.23.2 Declaration

The available MLIB\_MnacSat functions have the following declarations:

```
frac16_t MLIB_MnacSat_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MnacSat_F32lss(frac32_t f32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MnacSat_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
```

#### 2.23.3 Function use

The use of the MLIB\_MnacSat function is shown in the following example:

# 2.24 MLIB\_MnacRnd

The MLIB\_MnacRnd functions return the rounded product of two multiplicands minus the input accumulator. The round method is the round to nearest. The function does not saturate the output. See the following equation:

```
MLIB MnacRnd(a, b, c) = round(b \cdot c) – a
```

### **Equation 22. Algorithm formula**

## 2.24.1 Available versions

This function is available in the following versions:

- Fractional output the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.
- Accumulator output with mixed inputs the output is the accumulator type, where the result can be out of the range <-1; 1). The accumulator is the accumulator type, the multiplicands are the fractional types. The result may overflow.

#### MLIB MnacRnd

The available versions of the MLIB\_MnacRnd function are shown in the following table.

**Table 2-24. Function versions** 

Function name		Input type	,	Result	Description
	Accum.	Mult. 1	Mult. 2	type	
MLIB_MnacRnd_F16	frac16_t	frac16_t	frac16_t	frac16_t	The 16-bit fractional accumulator is subtracted from the fractional product (of two 16-bit fractional multiplicands) rounded to the upper 16 bits. The output is within the range <-1; 1).
MLIB_MnacRnd_F32lls	frac32_t	frac32_t	frac16_t	frac32_t	The 32-bit fractional accumulator is subtracted from the fractional product (of a 32-bit and a 16-bit fractional multiplicand) rounded to the upper 32 bits [1648]. The output is within the range <-1; 1).
MLIB_MnacRnd_F32	frac32_t	frac32_t	frac32_t	frac32_t	The 32-bit fractional accumulator is subtracted from the fractional product (of two 32-bit fractional multiplicands) rounded to the upper 32 bits [3263]. The output is within the range <-1; 1).
MLIB_MnacRnd_A32ass	acc32_t	frac16_t	frac16_t	acc32_t	The 32-bit accumulator is subtracted from the fractional product (of two 16-bit fractional multiplicands) rounded to the upper 16-bits [1631]. The output may be out of the range <-1; 1).

## 2.24.2 Declaration

The available MLIB\_MnacRnd functions have the following declarations:

```
frac16_t MLIB_MnacRnd_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MnacRnd_F32lls(frac32_t f32Accum, frac32_t f32Mult1, frac16_t f16Mult2)
frac32_t MLIB_MnacRnd_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_MnacRnd_A32ass(acc32_t a32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
```

## 2.24.3 Function use

The use of the MLIB\_MnacRnd function is shown in the following example:

MLIB User's Guide, Rev. 4, 05/2020

79

# 2.25 MLIB\_MnacRndSat

The MLIB\_MnacRndSat functions return the rounded product of two multiplicands minus the input accumulator. The round method is the round to nearest. The function saturates the output. See the following equation:

$$MLIB\_M \, nacRndSat(a, b, c) = \begin{cases} 1, & round(b \cdot c) - a > 1 \\ -1, & round(b \cdot c) - a < -1 \\ round(b \cdot c) - a, & else \end{cases}$$

**Equation 23. Algorithm formula** 

### 2.25.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_MnacRndSat function are shown in the following table.

Function name		Input type	)	Result	Description	
	Accum.	Mult. 1	Mult. 1 Mult. 2			
MLIB_MnacRndSat_F16	frac16_t	frac16_t	frac16_t	frac16_t	The 16-bit fractional accumulator is subtracted from the fractional product (of two 16-bit fractional multiplicands) rounded to the upper 16 bits. The output is within the range <-1; 1).	
MLIB_MnacRndSat_F32lls	frac32_t	frac32_t	frac16_t	frac32_t	The 32-bit fractional accumulator is subtracted from the fractional product (of a 32-bit and a 16-bit fractional multiplicand) rounded to the upper 32 bits [1648]. The output is within the range <-1; 1).	
MLIB_MnacRndSat_F32	frac32_t	frac32_t	frac32_t	frac32_t	The 32-bit fractional accumulator is subtracted from the fractional product (of two 32-bit fractional multiplicands) rounded to the upper 32 bits [3263]. The output is within the range <-1; 1).	

**Table 2-25. Function versions** 

#### 2.25.2 Declaration

The available MLIB\_MnacRndSat functions have the following declarations:

```
frac16_t MLIB_MnacRnd_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MnacRnd_F32lls(frac32_t f32Accum, frac32_t f32Mult1, frac16_t f16Mult2)
frac32_t MLIB_MnacRnd_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
```

## 2.25.3 Function use

The use of the MLIB\_MnacRndSat function is shown in the following example:

## 2.26 MLIB Msu

The MLIB\_Msu functions return the fractional product of two multiplicands subtracted from the input accumulator. The function does not saturate the output. See the following equation:

```
MLIB_Msu(a, b, c) = a - b \cdot c
```

## **Equation 24. Algorithm formula**

## 2.26.1 Available versions

This function is available in the following versions:

- Fractional output the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.
- Accumulator output with mixed inputs the output is the accumulator type, where the result can be out of the range <-1; 1). The accumulator is the accumulator type, the multiplicands are the fractional types. The result may overflow.

The available versions of the MLIB\_Msu function are shown in the following table.

Function name		Input type	)	Result	Description
	Accum.	Mult. 1	Mult. 2	type	
MLIB_Msu_F16	frac16_t	frac16_t	frac16_t	frac16_t	The upper 16-bit portion [1631] of the fractional product (of two 16-bit fractional multiplicands) is subtracted from a 16-bit fractional accumulator. The output is within the range <-1; 1).
MLIB_Msu_F32lss	frac32_t	frac16_t	frac16_t	frac32_t	The 32-bit fractional product (of two 16-bit fractional multiplicands) is subracted from a 32-bit fractional accumulator. The output is within the range <-1; 1).
MLIB_Msu_F32	frac32_t	frac32_t	frac32_t	frac32_t	The upper 32-bit portion [3263] of the fractional product (of two 32-bit fractional multiplicands) is subtracted from a 32-bit fractional accumulator. The output is within the range <-1; 1).
MLIB_Msu_A32ass	acc32_t	frac16_t	frac16_t	acc32_t	The upper 16-bit portion [1631] of the fractional product (of two 16-bit fractional multiplicands) is subtracted from a 32-bit accumulator. The output may be out of the range <-1; 1).

Table 2-26. Function versions

## 2.26.2 Declaration

The available MLIB\_Msu functions have the following declarations:

```
frac16_t MLIB_Msu_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_Msu_F32lss(frac32_t f32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_Msu_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_Msu_A32ass(acc32_t a32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
```

## 2.26.3 Function use

The use of the MLIB\_Msu function is shown in the following examples:

## **Fixed-point version:**

```
#include "mlib.h"
static acc32 t a32Accum, a32Result;
```

MLIB User's Guide, Rev. 4, 05/2020

#### MLIB MsuSat

# 2.27 MLIB\_MsuSat

The MLIB\_MsuSat functions return the fractional product of two multiplicands subtracted from the input accumulator. The function saturates the output. See the following equation:

$$MLIB\_M suSat(a, b, c) = \begin{cases} 1, & a - b \cdot c > 1 \\ -1, & a - b \cdot c < -1 \\ a - b \cdot c, & else \end{cases}$$

**Equation 25. Algorithm formula** 

## 2.27.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_MsuSat function are shown in the following table.

Table 2-27. Function versions

Function name		Input type	,	Result	Description
	Accum.	Mult. 1	Mult. 2	type	
MLIB_MsuSat_F16	frac16_t	frac16_t	frac16_t	frac16_t	The upper 16-bit portion [1631] of the fractional product (of two 16-bit fractional multiplicands) is subtracted from a 16-bit fractional accumulator. The output is within the range <-1; 1).
MLIB_MsuSat_F32lss	frac32_t	frac16_t	frac16_t	frac32_t	The 32-bit fractional product (of two 16-bit fractional multiplicands) is subtracted from a 32-bit fractional accumulator. The output is within the range <-1; 1).
MLIB_MsuSat_F32	frac32_t	frac32_t	frac32_t	frac32_t	The upper 32-bit portion [3263] of the fractional product (of two 32-bit fractional multiplicands) is subracted from a 32-bit fractional accumulator. The output is within the range <-1; 1).

83

#### 2.27.2 Declaration

The available MLIB\_MsuSat functions have the following declarations:

```
frac16_t MLIB_MsuSat_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MsuSat_F32lss(frac32_t f32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MsuSat_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
```

#### 2.27.3 Function use

The use of the MLIB\_MsuSat function is shown in the following example:

## 2.28 MLIB MsuRnd

The MLIB\_MsuRnd functions return the rounded fractional product of two multiplicands subtracted from the input accumulator. The round method is the round to nearest. The function does not saturate the output. See the following equation:

```
MLIB_M suRnd(a, b, c) = a - round(b \cdot c)
```

## **Equation 26. Algorithm formula**

## 2.28.1 Available versions

This function is available in the following versions:

#### MLIB MsuRnd

- Fractional output the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.
- Accumulator output with mixed inputs the output is the accumulator type, where the result can be out of the range <-1; 1). The accumulator is the accumulator type, the multiplicands are the fractional types. The result may overflow.

The available versions of the MLIB\_MsuRnd function are shown in the following table.

**Function name** Input type Result **Description** type Mult. 1 Mult. 2 Accum. frac16\_t MLIB\_MsuRnd\_F16 frac16\_t frac16\_t frac16\_t The fractional product (of two 16-bit fractional multiplicands), rounded to the upper 16 bits, is subtracted from a 16-bit fractional accumulator. The output is within the range <-1; 1). MLIB\_MsuRnd\_F32lls frac32\_t frac32\_t frac16\_t frac32 t The fractional product (of a 32-bit and 16-bit fractional multiplicands), rounded to the upper 32 bits [16..48], is subtracted from a 32-bit fractional accumulator. The output is within the range <-1; 1). MLIB MsuRnd F32 frac32 t frac32\_t frac32 t frac32 t The fractional product (of two 32-bit fractional multiplicands), rounded to the upper 32 bits [32..63], is subtracted from a 32-bit fractional accumulator. The output is within the range <-1; 1). MLIB\_MsuRnd\_A32ass acc32\_t frac16 t frac16 t acc32 t The fractional product (of two 16-bit fractional multiplicands), rounded to the upper 16 bits [16..31], is subtracted from a 32-bit accumulator. The output may be out of the range <-1; 1).

Table 2-28. Function versions

## 2.28.2 Declaration

The available MLIB\_MsuRnd functions have the following declarations:

```
frac16_t MLIB_MsuRnd_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MsuRnd_F32lls(frac32_t f32Accum, frac32_t f32Mult1, frac16_t f16Mult2)
frac32_t MLIB_MsuRnd_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_MsuRnd_A32ass(acc32_t a32Accum, frac16_t f16Mult1, frac16_t f16Mult2)
```

## 2.28.3 Function use

The use of the MLIB\_MsuRnd function is shown in the following example:

#include "mlib.h"

# 2.29 MLIB\_MsuRndSat

The MLIB\_MsuRndSat functions return the rounded fractional product of two multiplicands subtracted from the input accumulator. The round method is the round to nearest. The function saturates the output. See the following equation:

$$\label{eq:mlib_mark} \text{MLIB\_M suRndSat}(a,b,c) = \begin{cases} 1, & a - \operatorname{round}(b \cdot c) > 1 \\ -1, & a - \operatorname{round}(b \cdot c) < -1 \\ a - \operatorname{round}(b \cdot c), & \text{else} \end{cases}$$

**Equation 27. Algorithm formula** 

## 2.29.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_MsuRndSat function are shown in the following table.

Function name		Input type			Description		
	Accum.	Mult. 1	Mult. 2	type			
MLIB_MsuRndSat_F16	frac16_t	frac16_t	frac16_t	frac16_t	The fractional product (of two 16-bit fractional multiplicands), rounded to the upper 16 bits, is subtracted from a 16-bit fractional accumulator. The output is within the range <-1; 1).		
MLIB_MsuRndSat_F32lls	frac32_t	frac32_t	frac16_t	frac32_t	The fractional product (of a 32-bit and 16-bit fractional multiplicands), rounded to the upper 32 bits [1648], is subtracted from a 32-bit fractional accumulator. The output is within the range <-1; 1).		

Table 2-29. Function versions

Table continues on the next page...

Table 2-29. Function versions (continued)

Function name		Input type		Result	Description
	Accum.	Mult. 1	Mult. 2	type	
MLIB_MsuRndSat_F32	frac32_t	frac32_t	frac32_t	frac32_t	The fractional product (of two 32-bit fractional multiplicands), rounded to the upper 32 bits [3263], is subtracted from a 32-bit fractional accumulator. The output is within the range <-1; 1).

#### 2.29.2 Declaration

The available MLIB\_MsuRndSat functions have the following declarations:

```
frac16_t MLIB_MsuRndSat_F16(frac16_t f16Accum, frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MsuRndSat_F32lls(frac32_t f32Accum, frac32_t f32Mult1, frac16_t f16Mult2)
frac32_t MLIB_MsuRndSat_F32(frac32_t f32Accum, frac32_t f32Mult1, frac32_t f32Mult2)
```

### 2.29.3 Function use

The use of the MLIB\_MsuRndSat function is shown in the following example:

# 2.30 MLIB\_Msu4

The MLIB\_Msu4 functions return the subtraction of the products of two multiplicands. The function does not saturate the output. See the following equation:

 $MLIB_M su4(a, b, c, d) = a \cdot b - c \cdot d$ 

**Equation 28. Algorithm formula** 

#### 2.30.1 Available versions

The function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

The available versions of the MLIB\_Msu4 function are shown in the following table.

**Function name** Input type Description Result type Minuend product **Subtrahend product** Mult. 1 Mult. 1 Mult. 2 Mult. 2 MLIB\_Msu4\_F32ssss frac16 t frac16 t frac16 t frac16 t frac32 t Subtraction of two 32-bit fractional products (of two 16-bit fractional multiplicands). The output is within the range <-1; 1).

Table 2-30. Function versions

## 2.30.2 Declaration

The available MLIB\_Msu4 functions have the following declarations:

```
frac32_t MLIB_Msu4_F32ssss(frac16_t f16MinMult1, frac16_t f16MinMult2, frac16_t f16SubMult1,
frac16 t f16SubMult2)
```

# 2.30.3 Function use

The use of the MLIB\_Msu4 function is shown in the following examples:

## **Fixed-point version:**

```
#include "mlib.h"
static frac32_t f32Result;
static frac16_t f16MinMult1, f16MinMult2, f16SubMult1, f16SubMult2;
void main(void)
{
```

MLIB User's Guide, Rev. 4, 05/2020

#### MLIB Msu4Sat

# 2.31 MLIB\_Msu4Sat

The MLIB\_Msu4Sat functions return the subtraction of the products of two multiplicands. The function saturates the output. See the following equation:

$$MLIB\_Msu4Sat(a, b, c, d) = \begin{cases} 1, & a \cdot b - c \cdot d > 1 \\ -1, & a \cdot b - c \cdot d < -1 \\ a \cdot b - c \cdot d, & else \end{cases}$$

**Equation 29. Algorithm formula** 

## 2.31.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_Msu4Sat function are shown in the following table.

Function name		Inj	out type	Result	Description	
	Minuen	Minuend product Subtrahend product			type	
	Mult. 1	Mult. 2	Mult. 1	Mult. 2		
MLIB_Msu4Sat_F32ssss	frac16_t	frac16_t	frac16_t	frac16_t	frac32_t	Subtraction of two 32-bit fractional products (of two 16-bit fractional multiplicands). The output is within the range <-1; 1).

Table 2-31. Function versions

## 2.31.2 Declaration

The available MLIB\_Msu4Sat functions have the following declarations:

```
frac32_t MLIB_Msu4Sat_F32ssss(frac16_t f16MinMult1, frac16_t f16MinMult2, frac16_t
f16SubMult1, frac16 t f16SubMult2)
```

#### 2.31.3 Function use

The use of the MLIB\_Msu4Sat function is shown in the following example:

## 2.32 MLIB Msu4Rnd

The MLIB\_Msu4Rnd functions return the rounded subtraction of two products of two pairs of multiplicands. The round method is the round to nearest. The function does not saturate the output. See the following equation:

```
MLIB_Msu4Rnd(a, b, c, d) = round(a \cdot b - c \cdot d)
```

#### **Equation 30. Algorithm formula**

# 2.32.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

#### MLIB Msu4Rnd

The available versions of the MLIB\_Msu4Rnd function are shown in the following table.

Table 2-32. Function versions

Function name		In	out type		Result	Description
	Minuen	d product	Subtrahe	end product	type	
	Mult. 1	Mult. 2	Mult. 1	Mult. 2	1	
MLIB_Msu4Rnd_F16	frac16_t	frac16_t	frac16_t	frac16_t	frac16_t	Subtraction of two 16-bit fractional products (of two 16-bit fractional multiplicands), rounded to the upper 16 bits. The output is within the range <-1; 1).
MLIB_Msu4Rnd_F32	frac32_t	frac32_t	frac32_t	frac32_t	frac32_t	Subtraction of two 32-bit fractional products (of two 32-bit fractional multiplicands), rounded to the upper 32 bits. The output is within the range <-1; 1).

## 2.32.2 Declaration

The available MLIB\_Msu4Rnd functions have the following declarations:

```
frac16_t MLIB_Msu4Rnd_F16(frac16_t f16MinMult1, frac16_t f16MinMult2, frac16_t f16SubMult1,
frac16_t f16SubMult2)

frac32_t MLIB_Msu4Rnd_F32(frac32_t f32MinMult1, frac32_t f32MinMult2, frac32_t f32SubMult1,
frac32_t f32SubMult2)
```

# 2.32.3 Function use

The use of the MLIB\_Msu4Rnd function is shown in the following example:

91

# 2.33 MLIB\_Msu4RndSat

The MLIB\_Msu4RndSat functions return the rounded subtraction of two products of two pairs of multiplicands. The round method is the round to nearest. The function saturates the output. See the following equation:

$$MLIB\_Msu4RndSat(a, b, c, d) = \begin{cases} 1, & round(a \cdot b - c \cdot d) > 1 \\ -1, & round(a \cdot b - c \cdot d) < -1 \\ round(a \cdot b - c \cdot d), & else \end{cases}$$

**Equation 31. Algorithm formula** 

### 2.33.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_Msu4RndSat function are shown in the following table.

Function name		In	put type	Result	Description	
	Minuen	d product	Subtrah	end product	type	
	Mult. 1	Mult. 2	Mult. 1	Mult. 2	1	
MLIB_Msu4RndSat_F16	frac16_t	frac16_t	frac16_t	frac16_t	frac16_t	Subtraction of two 16-bit fractional products (of two 16-bit fractional multiplicands), rounded to the upper 16 bits. The output is within the range <-1; 1).
MLIB_Msu4RndSat_F32	frac32_t	frac32_t	frac32_t	frac32_t	frac32_t	Subtraction of two 32-bit fractional products (of two 32-bit fractional multiplicands), rounded to the upper 32 bits. The output is within the range <-1; 1).

Table 2-33. Function versions

# 2.33.2 Declaration

The available MLIB\_Msu4RndSat functions have the following declarations:

NXP Semiconductors

MLIB User's Guide, Rev. 4, 05/2020

```
frac16_t MLIB_Msu4RndSat_F16(frac16_t f16MinMult1, frac16_t f16MinMult2, frac16_t
f16SubMult1, frac16_t f16SubMult2)

frac32_t MLIB_Msu4RndSat_F32(frac32_t f32MinMult1, frac32_t f32MinMult2, frac32_t
f32SubMult1, frac32_t f32SubMult2)
```

## 2.33.3 Function use

The use of the MLIB\_Msu4RndSat function is shown in the following example:

# 2.34 MLIB\_Mul

The MLIB\_Mul functions return the product of two multiplicands. The function does not saturate the output. See the following equation:

$$MLIB\_Mul(a, b) = a \cdot b$$

#### **Equation 32. Algorithm formula**

## 2.34.1 Available versions

This function is available in the following versions:

• Fractional output with fractional inputs - the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the fractional values only. The result may overflow.

- Fractional output with mixed inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the accumulator and fractional values. The result may overflow.
- Accumulator output the output is the accumulator type where the result can be out of the range <-1; 1). The result may overflow.

The available versions of the MLIB\_Mul function are shown in the following table:

**Function name** Input type Result **Description** type Mult. 1 Mult. 2 MLIB\_Mul\_F16 frac16\_t frac16\_t frac16\_t Product of two 16-bit fractional multiplicands; the output are the upper 16 bits of the results [16..31]. The output is within the range <-1;1). MLIB\_Mul\_F16as acc32 t frac16 t frac16 t Product of a 32-bit accumulator and a 16-bit fractional multiplicand; the output is a 16-bit fractional portion, which has the upper 16 bits of the fractional value of the result [16..31]. The output is within the range <-1; 1). MLIB\_Mul\_F32ss frac16\_t frac16\_t frac32\_t Product of two 16-bit fractional multiplicands; the result is a 32-bit fractional value. The output is within the range <-1; 1). MLIB Mul F32 Product of two 32-bit fractional multiplicands; the output are the frac32 t frac32 t frac32 t upper 32 bits of the results [16..31]. The output is within the range <-1;1). acc32 t acc32 t acc32 t MLIB Mul A32 Product of two 32-bit accumulator multiplicands; the output is a 32bit accumulator, which has the upper mid bits of the result [16..47]. The output is within the range <-65536.0; 65536.0).

**Table 2-34. Function versions** 

## 2.34.2 Declaration

The available MLIB\_Mul functions have the following declarations:

```
frac16_t MLIB_Mul_F16(frac16_t f16Mult1, frac16_t f16Mult2)
frac16_t MLIB_Mul_F16as(acc32_t a32Accum, frac16_t f16Mult)
frac32_t MLIB_Mul_F32ss(frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_Mul_F32(frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_Mul_A32(acc32_t a32Mult1, acc32_t a32Mult1)
```

## 2.34.3 Function use

The use of the MLIB\_Mul function is shown in the following examples:

## **Fixed-point version:**

```
#include "mlib.h"
```

#### **MLIB MulSat**

# 2.35 MLIB\_MulSat

The MLIB\_MulSat functions return the product of two multiplicands. The function saturates the output. See the following equation:

$$MLIB\_MulSat(a, b) = \begin{cases} max, & a \cdot b > max \\ min, & a \cdot b < min \\ a \cdot b, & else \end{cases}$$

**Equation 33. Algorithm formula** 

## 2.35.1 Available versions

This function is available in the following versions:

- Fractional output with fractional inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the fractional values only. The result may saturate.
- Fractional output with mixed inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the accumulator and fractional values. The result may saturate.
- Accumulator output the output is the accumulator type where the result can be out of the range <-1;1). The result may overflow.

The available versions of the MLIB\_MulSat function are shown in the following table:

Function name

Input type

Mult. 1

Mult. 2

MLIB\_MulSat\_F16

Mac16\_t

Mult. 2

Mesult type

Product of two 16-bit fractional multiplicands; the output is the upper 16 bits of the results [16..31]. The output is within the range <-1; 1).

**Table 2-35. Function versions** 

Table continues on the next page...

Table 2-35. Function versions (continued)

Function name	Inpu	t type	Result	Description
	Mult. 1	Mult. 2	type	
MLIB_MulSat_F16as	acc32_t	frac16_t	frac16_t	Product of a 32-bit accumulator and a 16-bit fractional multiplicand; the output is a 16-bit fractional value, which has the upper 16 bits of the fractional portion of the result [1631]. The output is within the range <-1; 1).
MLIB_MulSat_F32ss	frac16_t	frac16_t	frac32_t	Product of two 16-bit fractional multiplicands; the result is a 32-bit fractional value. The output is within the range <-1; 1).
MLIB_MulSat_F32	frac32_t	frac32_t	frac32_t	Product of two 32-bit fractional multiplicands; the output are the upper 32 bits of the results [1631]. The output is within the range <-1; 1).
MLIB_MulSat_A32	acc32_t	acc32_t	acc32_t	Product of two 32-bit accumulator multiplicands; the output is a 32-bit accumulator, which has the mid bits of the result [1647]. The output is within the range <-65536.0; 65536.0).

## 2.35.2 Declaration

The available MLIB\_MulSat functions have the following declarations:

```
frac16_t MLIB_MulSat_F16(frac16_t f16Mult1, frac16_t f16Mult2)
frac16_t MLIB_MulSat_F16as(acc32_t a32Accum, frac16_t f16Mult)
frac32_t MLIB_MulSat_F32ss(frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MulSat_F32(frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_MulSat_A32(acc32_t a32Mult1, acc32_t a32Mult1)
```

## 2.35.3 Function use

The use of the MLIB\_MulSat function is shown in the following example:

# 2.36 MLIB\_MulNeg

#### MLIB\_MulNeg

The MLIB\_MulNeg functions return the negative product of two multiplicands. The function does not saturate the output. See the following equation:

MLIB MulNeg
$$(a, b) = -a \cdot b$$

#### **Equation 34. Algorithm formula**

## 2.36.1 Available versions

This function is available in the following versions:

- Fractional output with fractional inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the fractional values only.
- Fractional output with mixed inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the accumulator and fractional values. The result may overflow.
- Accumulator output the output is the accumulator type where the result can be out of the range <-1;1). The result may overflow.

The available versions of the MLIB\_MulNeg function are shown in the following table.

Function name	Inpu	t type	Result	Description
	Mult. 1	Mult. 2	type	
MLIB_MuNegl_F16	frac16_t	frac16_t	frac16_t	Negative product of two 16-bit fractional multiplicands; the output are the upper 16 bits of the results [1631]. The output is within the range <-1; 1).
MLIB_MulNeg_F16as	acc32_t	frac16_t	frac16_t	Negative product of a 32-bit accumulator and a 16-bit fractional multiplicand; the output is a 16-bit fractional value, which has the upper 16 bits of the fractional portion of the result [1631]. The output is within the range <-1; 1).
MLIB_MulNeg_F32ss	frac16_t	frac16_t	frac32_t	Negative product of two 16-bit fractional multiplicands; the result is a 32-bit fractional value. The output is within the range <-1; 1).
MLIB_MulNeg_F32	frac32_t	frac32_t	frac32_t	Negative product of two 32-bit fractional multiplicands; the output are the upper 32 bits of the results [1631]. The output is within the range <-1; 1).
MLIB_MulNeg_A32	acc32_t	acc32_t	acc32_t	Product of two 32-bit accumulator multiplicands; the output is a 32-bit accumulator, which has the mid bits of the result [1647]. The output is within the range <-65536.0; 65536.0).

Table 2-36. Function versions

### 2.36.2 Declaration

The available MLIB\_MulNeg functions have the following declarations:

```
frac16_t MLIB_MulNeg_F16(frac16_t f16Mult1, frac16_t f16Mult2)
frac16_t MLIB_MulNeg_F16as(acc32_t a32Accum, frac16_t f16Mult)
frac32_t MLIB_MulNeg_F32ss(frac16_t f16Mult1, frac16_t f16Mult2)
frac32_t MLIB_MulNeg_F32(frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_MulNeg_A32(acc32_t a32Mult1, acc32_t a32Mult1)
```

#### 2.36.3 Function use

The use of the MLIB\_MulNeg function is shown in the following examples:

### **Fixed-point version:**

# 2.37 MLIB\_MulNegSat

The MLIB\_MulNegSat functions return the negative product of two multiplicands. The function saturates the output. See the following equation:

$$MLIB\_MulNegSat(a, b) = \begin{cases} max, & -a \cdot b > max \\ min, & -a \cdot b < min \\ -a \cdot b, & else \end{cases}$$

**Equation 35. Algorithm formula** 

# 2.37.1 Available versions

This function is available in the following versions:

- Fractional output with mixed inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the accumulator and fractional values. The result may saturate.
- Accumulator output the output is the accumulator type where the result can be out of the range <-1; 1). The result may overflow.

#### MLIB MulRnd

The available versions of the MLIB\_MulNegSat function are shown in the following table:

**Table 2-37. Function versions** 

Function name	Inpu	t type	Result	Description
	Mult. 1	Mult. 2	type	
MLIB_MulNegSat_F16as	acc32_t	frac16_t	frac16_t	Negative product of a 32-bit accumulator and a 16-bit fractional multiplicand; the output is a 16-bit fractional value, which has the upper 16 bits of the fractional portion of the result [1631]. The output is within the range <-1; 1).
MLIB_MulNegSat_A32	acc32_t	acc32_t	acc32_t	Negative product of two 32-bit accumulator multiplicands; the output is a 32-bit accumulator, which has the middle bits of the result [1647]. The output is within the range <-65536.0; 65536.0).

#### 2.37.2 Declaration

The available MLIB\_MulNegSat functions have the following declarations:

```
frac16_t MLIB_MulNegSat_F16as(acc32_t a32Accum, frac16_t f16Mult)
acc32_t MLIB_MulNegSat_A32(acc32_t a32Mult1, acc32_t a32Mult2)
```

## 2.37.3 Function use

The use of the MLIB\_MulNegSat function is shown in the following example:

## 2.38 MLIB MulRnd

The MLIB\_MulRnd functions return the rounded product of two multiplicands. The round method is the round to nearest. The function does not saturate the output. See the following equation:

MLIB MulRnd(a, b) = round( $a \cdot b$ )

#### **Equation 36. Algorithm formula**

#### 2.38.1 Available versions

This function is available in the following versions:

- Fractional output with fractional inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the fractional values only. The result may overflow.
- Fractional output with mixed inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the accumulator and fractional values. The result may overflow.
- Accumulator output the output is the accumulator type where the result can be out of the range <-1; 1). The result may overflow.

The available versions of the MLIB\_MulRnd function are shown in the following table:

Function name	Inpu	t type	Result	Description
	Mult. 1	Mult. 2	type	
MLIB_MulRnd_F16	frac16_t	frac16_t	frac16_t	Product of two 16-bit fractional multiplicands; the output is rounded to the upper 16 bits of the results [1631]. The output is within the range <-1; 1).
MLIB_MulRnd_F16as	acc32_t	frac16_t	frac16_t	Product of a 32-bit accumulator and a 16-bit fractional multiplicand; the output is a 16-bit fractional value, which is rounded to the upper 16 bits of the fractional portion of the result [1631]. The output is within the range <-1; 1).
MLIB_MulRnd_F32ls	frac32_t	frac16_t	frac32_t	Product of a 32-bit and a 16-bit fractional multiplicand; the output is rounded to the upper 32 bits of the fractional portion of the result [1647]. The output is within the range <-1; 1).
MLIB_MulRnd_F32	frac32_t	frac32_t	frac32_t	Product of two 32-bit fractional multiplicands; the output is rounded to the upper 32 bits of the results [1631]. The output is within the range <-1; 1).
MLIB_MulRnd_A32	acc32_t	acc32_t	acc32_t	Product of two 32-bit accumulator multiplicands; the output is rounded to the middle bits of the result [1647]. The output is within the range <-65536.0; 65536.0).

Table 2-38. Function versions

#### 2.38.2 Declaration

The available MLIB\_MulRnd functions have the following declarations:

#### MLIB MulRndSat

```
frac16_t MLIB_MulRnd_F16(frac16_t f16Mult1, frac16_t f16Mult2)
frac16_t MLIB_MulRnd_F16as(acc32_t a32Accum, frac16_t f16Mult)
frac32_t MLIB_MulRnd_F32ls(frac32_t f32Mult1, frac16_t f16Mult2)
frac32_t MLIB_MulRnd_F32(frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_MulRnd_A32(acc32_t a32Mult1, acc32_t a32Mult1)
```

#### 2.38.3 Function use

The use of the MLIB\_MulRnd function is shown in the following example:

# 2.39 MLIB\_MulRndSat

The MLIB\_MulRndSat functions return the rounded product of two multiplicands. The round method is the round to nearest. The function saturates the output. See the following equation:

$$MLIB\_MulRndSat(a, b) = \begin{cases} max, & round(a \cdot b) > max \\ min, & round(a \cdot b) < min \\ round(a \cdot b), & else \end{cases}$$

**Equation 37. Algorithm formula** 

## 2.39.1 Available versions

This function is available in the following versions:

• Fractional output with fractional inputs - the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the fractional values only. The result may saturate.

- Fractional output with mixed inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the accumulator and fractional values. The result may saturate.
- Accumulator output the output is the accumulator type where the result can be out of the range <-1; 1). The result may overflow.

The available versions of the MLIB\_MulRndSat function are shown in the following table:

Function name	Inpu	t type	Result	Description
	Mult. 1	Mult. 2	type	
MLIB_MulRndSat_F16	frac16_t	frac16_t	frac16_t	Product of two 16-bit fractional multiplicands; the output is rounded to the upper 16 bits of the results [1631]. The output is within the range <-1; 1).
MLIB_MulRndSat_F16as	acc32_t	frac16_t	frac16_t	Product of a 32-bit accumulator and a 16-bit fractional multiplicand; the output is a 16-bit fractional value, which is rounded to the upper 16 bits of the fractional portion of the result [1631]. The output is within the range <-1; 1).
MLIB_MulRndSat_F32ls	frac32_t	frac16_t	frac32_t	Product of a 32-bit multiplicand and a 16-bit fractional multiplicand; the output is rounded to the upper 32 bits of the fractional portion of the result [1647]. The output is within the range <-1; 1).
MLIB_MulRndSat_F32	frac32_t	frac32_t	frac32_t	Product of two 32-bit fractional multiplicands; the output is rounded to the upper 32 bits of the results [1631]. The output is within the range <-1; 1).
MLIB_MulRndSat_A32	acc32_t	acc32_t	acc32_t	Product of two 32-bit accumulator multiplicands; the output is rounded to the the mid bits of the result [1647]. The output is within the range <-65536.0; 65536.0).

Table 2-39. Function versions

## 2.39.2 Declaration

The available MLIB\_MulRndSat functions have the following declarations:

```
frac16_t MLIB_MulRndSat_F16(frac16_t f16Mult1, frac16_t f16Mult2)
frac16_t MLIB_MulRndSat_F16as(acc32_t a32Accum, frac16_t f16Mult1)
frac32_t MLIB_MulRndSat_F32ls(frac32_t f32Mult1, frac16_t f16Mult2)
frac32_t MLIB_MulRndSat_F32(frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_MulRndSat_A32(acc32_t a32Mult1, acc32_t a32Mult1)
```

# 2.39.3 Function use

The use of the MLIB\_MulRndSat function is shown in the following example:

#### MLIB\_MulNegRnd

# 2.40 MLIB\_MulNegRnd

The MLIB\_MulNegRnd functions return the rounded negative product of two multiplicands. The round method is the round to nearest. The function does not saturate the output. See the following equation:

```
MLIB MulNegRnd(a, b) = round(-a \cdot b)
```

#### **Equation 38. Algorithm formula**

## 2.40.1 Available versions

This function is available in the following versions:

- Fractional output with fractional inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the fractional values only.
- Fractional output with mixed inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the accumulator and fractional values. The result may overflow.
- Accumulator output the output is the accumulator type where the result can be out of the range <-1; 1). The result may overflow.

The available versions of the MLIB\_MulNegRnd function are shown in the following table:

Function name

Input type

Mult. 1

Mult. 2

MLIB\_MulNegRnd\_F16

Mult. 2

Result type

Result type

Mult. 2

Mult. 2

Megative product of two 16-bit fractional multiplicands; the output is rounded to the upper 16 bits of the results [16..31]. The output is within the range <-1; 1).

Table 2-40. Function versions

Table continues on the next page...

Table 2-40. Function versions (continued)

Function name	Inpu	t type	Result	Description
	Mult. 1	Mult. 2	type	
MLIB_MulNegRnd_F16as	acc32_t	frac16_t	frac16_t	Negative product of a 32-bit accumulator and a 16-bit fractional multiplicand; the output is a 16-bit fractional value, which is rounded to the upper 16 bits of the fractional portion of the result [1631]. The output is within the range <-1; 1).
MLIB_MulNegRnd_F32ls	frac32_t	frac16_t	frac32_t	Negative product of a 32-bit fractional multiplicand and a 16-bit fractional multiplicand; the output is rounded to the upper 32 bits of the fractional portion of the result [1647]. The output is within the range <-1; 1).
MLIB_MulNegRnd_F32	frac32_t	frac32_t	frac32_t	Negative product of two 32-bit fractional multiplicands; the output is rounded to the upper 32 bits of the results [1631]. The output is within the range <-1; 1).
MLIB_MulNegRnd_A32	acc32_t	acc32_t	acc32_t	Product of two 32-bit accumulator multiplicands; the output is rounded to the the middle bits of the result [1647]. The output is within the range <-65536.0; 65536.0).

### 2.40.2 Declaration

The available MLIB\_MulNegRnd functions have the following declarations:

```
frac16_t MLIB_MulNegRnd_F16(frac16_t f16Mult1, frac16_t f16Mult2)
frac16_t MLIB_MulNegRnd_F16as(acc32_t a32Accum, frac16_t f16Mult1)
frac32_t MLIB_MulNegRnd_F32ls(frac32_t f32Mult1, frac16_t f16Mult2)
frac32_t MLIB_MulNegRnd_F32(frac32_t f32Mult1, frac32_t f32Mult2)
acc32_t MLIB_MulNegRnd_A32(acc32_t a32Mult1, acc32_t a32Mult1)
```

## 2.40.3 Function use

The use of the MLIB\_MulNegRnd function is shown in the following example:

# 2.41 MLIB\_MulNegRndSat

The MLIB\_MulNegRndSat functions return the rounded negative product of two multiplicands. The round method is the round to nearest. The function saturates the output. See the following equation:

$$MLIB\_MulNegRndSat(a, b) = \begin{cases} max, & round(-a \cdot b > max) \\ min, & round(-a \cdot b < min) \\ round(-a \cdot b), & else \end{cases}$$

**Equation 39. Algorithm formula** 

### 2.41.1 Available versions

This function is available in the following versions:

- Fractional output with mixed inputs the output is the fractional portion of the result; the result is within the range <-1; 1). The inputs are the accumulator and fractional values. The result may saturate.
- Accumulator output the output is the accumulator type where the result can be out of the range <-1; 1). The result may overflow.

The available versions of the MLIB\_MulNegRndSat function are shown in the following table:

Function name	Input type		Result	Description
	Mult. 1	Mult. 2	type	
MLIB_MulNegRndSat_F16as	acc32_t	frac16_t	frac16_t	Negative product of a 32-bit accumulator and a 16-bit fractional multiplicand; the output is rounded to the upper 16 bits of the fractional portion of the result [1631]. The output is within the range <-1; 1).
MLIB_MulNegRndSat_A32	acc32_t	acc32_t	acc32_t	Negative product of two 32-bit accumulator multiplicands; the output is rounded to the middle 32 bits of the result [1647]. The output is within the range <-65536.0; 65536.0).

Table 2-41. Function versions

### 2.41.2 Declaration

The available MLIB\_MulNegRndSat functions have the following declarations:

```
frac16_t MLIB_MulNegRndSat_F16as(acc32_t a32Accum, frac16_t f16Mult)
acc32 t MLIB_MulNegRndSat_A32(acc32_t a32Mult1, acc32_t a32Mult2)
```

## 2.41.3 Function use

The use of the MLIB\_MulNegRndSat function is shown in the following example:

# 2.42 MLIB\_Neg

The MLIB\_Neg functions return the negative value of the input. The function does not saturate the output. See the following equation:

MLIB Neg(x) = 
$$-x$$

### **Equation 40. Algorithm formula**

# 2.42.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

The available versions of the MLIB\_Neg function are shown in the following table:

Table 2-42. Function versions

Function name	Input type	Result type	Description
MLIB_Neg_F16	frac16_t		Negative value of a 16-bit fractional value. The output is within the range <-1; 1).
MLIB_Neg_F32	frac32_t	_	Negative value of a 32-bit fractional value. The output is within the range <-1; 1).

#### 2.42.2 Declaration

The available MLIB\_Neg functions have the following declarations:

```
frac16_t MLIB_Neg_F16(frac16_t f16Val)
frac32_t MLIB_Neg_F32(frac32_t f32Val)
```

### 2.42.3 Function use

The use of the MLIB\_Neg function is shown in the following examples:

### **Fixed-point version:**

# 2.43 MLIB\_NegSat

The MLIB\_NegSat functions return the negative value of the input. The function saturates the output. See the following equation:

```
MLIB NegSat(x) = -x
```

**Equation 41. Algorithm formula** 

# 2.43.1 Available versions

The function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_NegSat function are shown in the following table:

Table 2-43. Function versions

Function name	Input type	Result type	Description
MLIB_NegSat_F16	frac16_t	frac16_t	Negative value of a 16-bit value. The output is within the range <-1; 1).
MLIB_NegSat_F32	frac32_t	frac32_t	Negative value of a 32-bit value. The output is within the range <-1; 1).

#### 2.43.2 Declaration

The available MLIB\_NegSat functions have the following declarations:

```
frac16_t MLIB_NegSat_F16(frac16_t f16Val)
frac32_t MLIB_NegSat_F32(frac32_t f32Val)
```

## 2.43.3 Function use

The use of the MLIB\_NegSat function is shown in the following example:

# 2.44 MLIB\_Rcp

The MLIB\_Rcp functions return the reciprocal value for the input value. The function does not saturate the output. See the following equation:

$$MLIB\_Rcp(x) = \begin{cases} max, & x = 0 \\ \frac{1}{x}, & else \end{cases}$$

**Equation 42. Algorithm formula** 

#### 2.44.1 Available versions

This function is available in the following versions:

• Accumulator output with fractional input - the output is the accumulator type, where the absolute value of the result is greater than or equal to 1. The input is the fractional type.

The available versions of the MLIB\_Rcp function are shown in the following table.

Function name	Input type	Result type	Description
MLIB_Rcp_A32s	frac16_t	acc32_t	Reciprocal for a 16-bit fractional value; the output is a 32-bit accumulator value. The absolute value of the output is greater than or equal to 1. The division is performed with 32-bit accuracy.
MLIB_Rcp1_A32s	frac16_t	acc32_t	Reciprocal for a 16-bit fractional value; the output is a 32-bit accumulator value. The absolute value of the output is greater than or equal to 1. Faster version, where the division is performed with 16-bit accuracy.

Table 2-44. Function versions

#### NOTE

This algorithm can use the MMDVSQ peripheral module. See the following chapters for more details:

- Memory-mapped divide and square root support in Kinetis Design Studio
- Memory-mapped divide and square root support in Keil µVision
- Memory-mapped divide and square root support in IAR Embedded Workbench

## 2.44.2 Declaration

The available MLIB\_Rcp functions have the following declarations:

```
acc32_t MLIB_Rcp_A32s(frac16_t f16Denom)
acc32_t MLIB_Rcp1_A32s(frac16_t f16Denom)
```

## 2.44.3 Function use

The use of the MLIB\_Rcp function is shown in the following example:

# 2.45 MLIB\_Rcp1Q

The MLIB\_Rcp1Q functions return the single quadrant reciprocal value for the input value. The input value must be a nonnegative number, otherwise the function returns undefined results. The function does not saturate the output. See the following equation:

$$MLIB\_Rcp1Q(x) = \begin{cases} max, & x = 0 \\ \frac{1}{x}, & x > 0 \end{cases}$$

**Equation 43. Algorithm formula** 

#### 2.45.1 Available versions

This function is available in the following versions:

• Accumulator output with fractional input - the output is the accumulator type, where the result is greater than or equal to 1. The function is not defined for negative inputs. The input is the fractional type.

The available versions of the MLIB\_Rcp1Q function are shown in the following table.

Function name	Input type	Result type	Description
MLIB_Rcp1Q_A32s	frac16_t	acc32_t	Reciprocal for a nonnegative 16-bit fractional value; the output is a positive 32-bit accumulator value. The output is greater than or equal to 1. The division is performed with 32-bit accuracy.
MLIB_Rcp1Q1_A32s	frac16_t	acc32_t	Reciprocal for a nonnegative 16-bit fractional value; the output is a positive 32-bit accumulator value. The output is greater than or equal to 1. Faster version, where the division is performed with 16-bit accuracy.

Table 2-45. Function versions

#### NOTE

This algorithm can use the MMDVSQ peripheral module. See the following chapters for more details:

MLIB User's Guide, Rev. 4, 05/2020

- Memory-mapped divide and square root support in Kinetis Design Studio
- Memory-mapped divide and square root support in Keil µVision
- Memory-mapped divide and square root support in IAR Embedded Workbench

#### 2.45.2 Declaration

The available MLIB\_Rcp1Q functions have the following declarations:

```
acc32_t MLIB_Rcp1Q_A32s(frac16_t f16Denom)
acc32_t MLIB_Rcp1Q1_A32s(frac16_t f16Denom)
```

#### 2.45.3 Function use

The use of the MLIB\_Rcp1Q function is shown in the following example:

## 2.46 MLIB\_Rnd

The MLIB\_Rnd functions round the input to the nearest value to meet the return type's size. The function does not saturate the output. See the following equation:

```
MLIB Rnd(x) = round(x)
```

#### **Equation 44. Algorithm formula**

#### 2.46.1 Available versions

This function is available in the following versions:

MLIB User's Guide, Rev. 4, 05/2020

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

The available versions of the MLIB\_Rnd function are shown in the following table.

Table 2-46. Function versions

Function name	Input type	Result type	Description
MLIB_Rnd_F16I	frac32_t		Rounding of a 32-bit fractional value to a 16-bit fractional value. The output is within the range <-1; 1).

## 2.46.2 Declaration

The available MLIB\_Rnd functions have the following declarations:

```
frac16_t MLIB_Rnd_F16l(frac32_t f32Val)
```

#### 2.46.3 Function use

The use of the MLIB\_Rnd function is shown in the following example:

```
#include "mlib.h"
static frac32_t f32Val;
static frac16_t f16Result;

void main(void)
{
  f32Val = FRAC32(0.85);     /* f32Val = 0.85 */
    /* f16Result = round(f32Val)*/
    f16Result = MLIB_Rnd_F161(f32Val);
}
```

## 2.47 MLIB RndSat

The MLIB\_RndSat functions round the input to the nearest value to meet the return type's size. The function saturates the output. See the following equation:

MLIB RndSat(x) = round(x)

**Equation 45. Algorithm formula** 

#### 2.47.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_RndSat function are shown in the following table.

**Table 2-47. Function versions** 

Function name	Input type	Result type	Description
MLIB_RndSat_F16l	frac32_t	frac16_t	Rounding of a 32-bit fractional value to a 16-bit fractional value. The output is within the range <-1; 1).

#### 2.47.2 Declaration

The available MLIB\_RndSat functions have the following declarations:

```
frac16_t MLIB_RndSat_F16l(frac32_t f32Val)
```

#### 2.47.3 Function use

The use of the MLIB\_RndSat function is shown in the following example:

```
#include "mlib.h"
static frac32_t f32Val;
static frac16_t f16Result;

void main(void)
{
   f32Val = FRAC32(0.9997996);     /* f32Val = 0.9997996 */
     /* f16Result = sat(round(f32Val)) */
     f16Result = MLIB_RndSat_F161(f32Val);
}
```

## 2.48 MLIB\_Sat

The MLIB\_Sat functions return the fractional portion of the accumulator input. The output is saturated if necessary. See the following equation:

$$MLIB\_Sat(x) = \begin{cases} 1, & x > 1 \\ -1, & x < -1 \\ x, & else \end{cases}$$

#### **Equation 46. Algorithm formula**

#### 2.48.1 Available versions

This function is available in the following versions:

• Fractional output with accumulator input - the output is the fractional portion of the result; the result is within the range <-1; 1). The result is saturated.

The available versions of the MLIB\_Sat function are shown in the following table.

Table 2-48. Function versions

Function name	Input type	Result type	Description
MLIB_Sat_F16a	acc32_t	_	Saturation of a 32-bit accumulator value to a 16-bit fractional value. The output is within the range <-1; 1).

#### 2.48.2 Declaration

The available MLIB\_Sat functions have the following declarations:

```
frac16_t MLIB_Sat_F16a(acc32_t a32Accum)
```

## 2.48.3 Function use

The use of the MLIB\_Sat function is shown in the following example:

## 2.49 MLIB\_Sh1L

The MLIB\_Sh1L functions return the arithmetically one-time-shifted value to the left. The function does not saturate the output. See the following equation:

$$MLIB\_Sh1L(x) = x \ll 1$$

#### **Equation 47. Algorithm formula**

#### 2.49.1 Available versions

The function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

The available versions of the MLIB\_Sh1L function are shown in the following table.

Table 2-49. Function versions

Function name	Input type	Result type	Description
MLIB_Sh1L_F16	frac16_t	_	Shift of a 16-bit fractional value by one time to the left. The output is within the range <-1; 1).
MLIB_Sh1L_F32	frac32_t	frac32_t	Shift of a 32-bit fractional value by one time to the left. The output is within the range <-1; 1).

## 2.49.2 Declaration

The available MLIB\_Sh1L functions have the following declarations:

```
frac16_t MLIB_Sh1L_F16(frac16_t f16Val)
frac32_t MLIB_Sh1L_F32(frac32_t f32Val)
```

## 2.49.3 Function use

The use of the MLIB\_Sh1L function is shown in the following example:

```
#include "mlib.h"
static frac32 t f32Result, f32Val;
```

MLIB User's Guide, Rev. 4, 05/2020

## 2.50 MLIB\_Sh1LSat

The MLIB\_Sh1LSat functions return the arithmetically one-time-shifted value to the left. The function saturates the output. See the following equation:

MLIB\_Sh1LSat(x) = 
$$\begin{cases} 1, & x > 0.5 \\ -1, & x < -0.5 \\ x \ll 1, & \text{else} \end{cases}$$

**Equation 48. Algorithm formula** 

#### 2.50.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_Sh1LSat function are shown in the following table.

Function name	Input type	Result type	Description
MLIB_Sh1LSat_F16	frac16_t	frac16_t	Shift of a 16-bit fractional value by one time to the left. The output is within the range <-1; 1).
MLIB_Sh1LSat_F32	frac32_t	frac32_t	Shift of a 32-bit fractional value by one time to the left. The output is within the range <-1; 1).

Table 2-50. Function versions

#### 2.50.2 Declaration

The available MLIB\_Sh1LSat functions have the following declarations:

```
frac16_t MLIB_Sh1LSat_F16(frac16_t f16Val)
frac32_t MLIB_Sh1LSat_F32(frac32_t f32Val)
```

#### 2.50.3 Function use

The use of the MLIB\_Sh1LSat function is shown in the following example:

## 2.51 MLIB\_Sh1R

The MLIB\_Sh1R functions return the arithmetically one-time-shifted value to the right. See the following equation:

MLIB Sh1R(
$$x$$
) =  $x \gg 1$ 

#### **Equation 49. Algorithm formula**

#### 2.51.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-0.5; 0.5).

The available versions of the MLIB\_Sh1R function are shown in the following table.

Table 2-51. Function versions

Function name	Input type	Result type	Description
MLIB_Sh1R_F16	frac16_t	_	Shift of a 16-bit fractional value by one time to the right. The output is within the range <-0.5; 0.5).
MLIB_Sh1R_F32	frac32_t		Shift of a 32-bit fractional value by one time to the right. The output is within the range <-0.5; 0.5).

## 2.51.2 Declaration

The available MLIB\_Sh1R functions have the following declarations:

```
frac16_t MLIB_Sh1R_F16(frac16_t f16Val)
frac32_t MLIB_Sh1R_F32(frac32_t f32Val)
```

### 2.51.3 Function use

The use of the MLIB\_Sh1R function is shown in the following example:

## 2.52 MLIB\_ShL

The MLIB\_ShL functions return the arithmetically shifted value to the left a specified number of times. The function does not saturate the output. See the following equation:

MLIB ShL
$$(x, n) = x \ll n$$

#### **Equation 50. Algorithm formula**

## 2.52.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

#### **MLIB ShLSat**

The available versions of the MLIB\_ShL function are shown in the following table.

Table 2-52. Function versions

Function name	Inpu	t type	Result	Description
	Value	Shift	type	
MLIB_ShL_F16	frac16_t	uint16_t	frac16_t	Shift of a 16-bit fractional value to the left by a number of times given by the second argument; the shift is allowed within the range <0; 15>. The output is within the range <-1; 1).
MLIB_ShL_F32	frac32_t	uint16_t	frac32_t	Shift of a 32-bit fractional value to the left by a number of times given by the second argument; the shift is allowed within the range <0; 31>. The output is within the range <-1; 1).

#### 2.52.2 Declaration

The available MLIB\_ShL functions have the following declarations:

```
frac16_t MLIB_ShL_F16(frac16_t f16Val, uint16_t u16Sh)
frac32_t MLIB_ShL_F32(frac32_t f32Val, uint16_t u16Sh)
```

#### 2.52.3 Function use

The use of the MLIB\_ShL function is shown in the following example:

## 2.53 MLIB\_ShLSat

The MLIB\_ShLSat functions return the arithmetically shifted value to the left a specified number of times. The function saturates the output. See the following equation:

MLIB\_ShLSat(x, n) = 
$$\begin{cases} 1, & x > \frac{1}{2^n} \\ -1, & x < \frac{-1}{2^n} \\ x \ll n, & \text{else} \end{cases}$$

**Equation 51. Algorithm formula** 

#### 2.53.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_ShLSat function are shown in the following table.

Function name	Inpu	Input type		Description
	Value	Shift	type	
MLIB_ShLSat_F16	frac16_t	uint16_t	frac16_t	Shift of a 16-bit fractional value to the left by a number of times given by the second argument; the shift is allowed within the range <0; 15>. The output is within the range <-1; 1).
MLIB_ShLSat_F32	frac32_t	uint16_t	frac32_t	Shift of a 32-bit fractional value to the left by a number of times given by the second argument; the shift is allowed within the range <0; 31>. The output is within the range <-1; 1).

Table 2-53. Function versions

#### 2.53.2 Declaration

The available MLIB\_ShLSat functions have the following declarations:

```
frac16_t MLIB_ShLSat_F16(frac16_t f16Val, uint16_t u16Sh)
frac32_t MLIB_ShLSat_F32(frac32_t f32Val, uint16_t u16Sh)
```

## 2.53.3 Function use

The use of the MLIB\_ShLSat function is shown in the following example:

```
#include "mlib.h"
static frac16 t f16Result, f16Val;
static uint16 t u16Sh;
void main(void)
```

MLIB User's Guide, Rev. 4, 05/2020 **NXP Semiconductors** 119

#### MLIB ShR

## 2.54 MLIB\_ShR

The MLIB\_ShR functions return the arithmetically shifted value to the right a specified number of times. See the following equation:

MLIB ShR 
$$(x, n) = x \gg n$$

#### **Equation 52. Algorithm formula**

#### 2.54.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1).

The available versions of the MLIB\_ShR function are shown in the following table.

**Function name** Input type Result Description type Value Shift MLIB ShR F16 uint16 t frac16 t frac16 t Shift of a 16-bit fractional value to the right by a number of times given by the second argument; the shift is allowed within the range <0; 15>. The output is within the range <-1; 1). Shift of a 32-bit fractional value to the right by a number of times MLIB ShR F32 frac32 t uint16 t frac32 t given by the second argument; the shift is allowed within the range <0; 31>. The output is within the range <-1; 1).

Table 2-54. Function versions

## 2.54.2 Declaration

The available MLIB\_ShR functions have the following declarations:

```
frac16_t MLIB_ShR_F16(frac16_t f16Val, uint16_t u16Sh)
frac32_t MLIB_ShR_F32(frac32_t f32Val, uint16_t u16Sh)
```

#### 2.54.3 Function use

The use of the MLIB\_ShR function is shown in the following example:

## 2.55 MLIB\_ShLBi

The MLIB\_ShLBi functions return the arithmetically shifted value to the left a specified number of times. If the number of shifts is positive, the shift is performed to the left; if negative, to the right. The function does not saturate the output. See the following equation:

MLIB ShLBi
$$(x, n) = x \ll n$$

**Equation 53. Algorithm formula** 

## 2.55.1 Available versions

The function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

The available versions of the MLIB\_ShLBi function are shown in the following table.

Table 2-55. Function versions

Table continues on the next page...

Table 2-55. Function versions (continued)

Function name	Input	type Result		Description
	Value	Shift	type	
MLIB_ShLBi_F32	frac32_t	int16_t		Bidirectional shift of a 32-bit fractional value to the left by a number of times given by the second argument; if the second argument is negative, the shift is performed to the right. The shift is allowed within the range <-31; 31>. The output is within the range <-1; 1).

#### 2.55.2 Declaration

The available MLIB\_ShLBi functions have the following declarations:

```
frac16_t MLIB_ShLBi_F16(frac16_t f16Val, int16_t i16Sh)
frac32_t MLIB_ShLBi_F32(frac32_t f32Val, int16_t i16Sh)
```

#### 2.55.3 Function use

The use of the MLIB\_ShLBi function is shown in the following example:

## 2.56 MLIB\_ShLBiSat

The MLIB\_ShLBiSat functions return the arithmetically shifted value to the left a specified number of times. If the number of shifts is positive, the shift is performed to the left; if negative, to the right. The function saturates the output. See the following equation:

MLIB\_ShLBiSat(x, n) = 
$$\begin{cases} 1, & x > \frac{1}{2^n} \land n > 0 \\ -1, & x < \frac{-1}{2^n} \land n > 0 \\ x \ll n, & \text{else} \end{cases}$$

**Equation 54. Algorithm formula** 

#### 2.56.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_ShLBiSat function are shown in the following table.

Function name	Input	type	Result	Description
	Value	Shift	type	
MLIB_ShLBiSat_F16	frac16_t	int16_t	frac16_t	Bidirectional shift of a 16-bit fractional value to the left by a number of times given by the second argument; if the second argument is negative, the shift is performed to the right. The shift is allowed within the range <-15; 15>. The output is within the range <-1; 1).
MLIB_ShLBiSat_F32	frac32_t	int16_t	frac32_t	Bidirectional shift of a 32-bit fractional value to the left by a number of times given by the second argument; if the second argument is negative, the shift is performed to the right. The shift is allowed within the range <-31; 31>. The output is within the range <-1; 1).

Table 2-56. Function versions

## 2.56.2 Declaration

The available MLIB\_ShLBiSat functions have the following declarations:

```
frac16_t MLIB_ShLBiSat_F16(frac16_t f16Val, int16_t i16Sh)
frac32_t MLIB_ShLBiSat_F32(frac32_t f32Val, int16_t i16Sh)
```

## 2.56.3 Function use

The use of the MLIB\_ShLBiSat function is shown in the following example:

```
#include "mlib.h"
static frac16 t f16Result, f16Val;
```

MLIB User's Guide, Rev. 4, 05/2020

#### MLIB ShRBi

## 2.57 MLIB\_ShRBi

The MLIB\_ShRBi functions return the arithmetically shifted value to the right a specified number of times. If the number of shifts is positive, the shift is performed to the right; if negative, to the left. The function does not saturate the output. See the following equation:

MLIB ShRBi
$$(x, n) = x \gg n$$

#### **Equation 55. Algorithm formula**

## 2.57.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

The available versions of the MLIB\_ShRBi function are shown in the following table.

Table 2-57. Function versions

Function name	Input	type	Result	Description
	Value	Shift	type	
MLIB_ShRBi_F16	frac16_t	int16_t	frac16_t	Bidirectional shift of a 16-bit fractional value to the right by a number of times given by the second argument; if the second argument is negative, the shift is performed to the left. The shift is allowed within the range <-15; 15>. The output is within the range <-1; 1).
MLIB_ShRBi_F32	frac32_t	int16_t	frac32_t	Bidirectional shift of a 32-bit fractional value to the right by a number of times given by the second argument; if the second argument is negative, the shift is performed to the left. The shift is allowed within the range <-31; 31>. The output is within the range <-1; 1).

## 2.57.2 Declaration

The available MLIB\_ShRBi functions have the following declarations:

```
frac16_t MLIB_ShRBi_F16(frac16_t f16Val, int16_t i16Sh)
frac32_t MLIB_ShRBi_F32(frac32_t f32Val, int16_t i16Sh)
```

#### 2.57.3 Function use

The use of the MLIB\_ShRBi function is shown in the following example:

## 2.58 MLIB ShRBiSat

The MLIB\_ShRBiSat functions return the arithmetically shifted value to the right a specified number of times. If the number of shifts is positive, the shift is performed to the right; if negative, to the left. The function saturates the output. See the following equation:

MLIB\_ShRBiSat(x, n) = 
$$\begin{cases} 1, & x > \frac{1}{2^n} \land n < 0 \\ -1, & x < \frac{-1}{2^n} \land n < 0 \end{cases}$$

$$x \gg n, \text{ else}$$

**Equation 56. Algorithm formula** 

#### 2.58.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

#### MLIB\_Sign

The available versions of the MLIB\_ShRBiSat function are shown in the following table.

Table 2-58. Function versions

Function name	Input	Input type		Description
	Value	Shift	type	
MLIB_ShRBiSat_F16	frac16_t	int16_t	frac16_t	Bidirectional shift of a 16-bit fractional value to the right by a number of times given by the second argument; if the second argument is negative, the shift is performed to the left. The shift is allowed within the range <-15; 15>. The output is within the range <-1; 1).
MLIB_ShRBiSat_F32	frac32_t	int16_t	frac32_t	Bidirectional shift of a 32-bit fractional value to the right by a number of times given by the second argument; if the second argument is negative, the shift is performed to the left. The shift is allowed within the range <-31; 31>. The output is within the range <-1; 1).

#### 2.58.2 Declaration

The available MLIB\_ShRBiSat functions have the following declarations:

```
frac16_t MLIB_ShRBiSat_F16(frac16_t f16Val, int16_t i16Sh)
frac32_t MLIB_ShRBiSat_F32(frac32_t f32Val, int16_t i16Sh)
```

## 2.58.3 Function use

The use of the MLIB\_ShRBiSat function is shown in the following example:

# 2.59 MLIB\_Sign

The MLIB\_Sign functions return the sign of the input. See the following equation:

127

MLIB\_Sign(x) = 
$$\begin{cases} 1, & x > 0 \\ 0, & x = 0 \\ -1, & x < 0 \end{cases}$$

**Equation 57. Algorithm formula** 

#### 2.59.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1).

The available versions of the MLIB\_Sign function are shown in the following table.

Table 2-59. Function versions

Function name	Input type	Result type	Description
MLIB_Sign_F16	frac16_t	frac16_t	Sign of a 16-bit fractional value. The output is within the range <-1; 1).
MLIB_Sign_F32	frac32_t	frac32_t	Sign of a 32-bit fractional value. The output is within the range <-1; 1).

#### 2.59.2 Declaration

The available MLIB\_Sign functions have the following declarations:

```
frac16_t MLIB_Sign_F16(frac16_t f16Val)
frac32_t MLIB_Sign_F32(frac32_t f32Val)
```

## 2.59.3 Function use

The use of the MLIB\_Sign function is shown in the following examples:

## **Fixed-point version:**

NXP Semiconductors

MLIB User's Guide, Rev. 4, 05/2020

## 2.60 MLIB\_Sub

The MLIB\_Sub functions subtract the subtrahend from the minuend. The function does not saturate the output. See the following equation:

MLIB Sub
$$(a, b) = a - b$$

#### **Equation 58. Algorithm formula**

#### 2.60.1 Available versions

This function is available in the following versions:

- Fractional output the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.
- Accumulator output with fractional inputs the output is the accumulator type, where the result can be out of the range <-1; 1). The inputs are the fractional values only.
- Accumulator output with mixed inputs the output is the accumulator type, where the result can be out of the range <-1; 1). The inputs are the accumulator and fractional values. The result may overflow.

The available versions of the MLIB\_Sub function are shown in the following table.

**Function name** Input type Result Description type Minuend **Subtrahend** MLIB\_Sub\_F16 frac16\_t frac16\_t frac16\_t Subtraction of a 16-bit fractional subtrahend from a 16-bit fractional minuend. The output is within the range <-1; 1). MLIB Sub F32 frac32 t frac32 t frac32 t Subtraction of a 32-bit fractional subtrahend from a 32-bit fractional minuend. The output is within the range <-1; 1). MLIB\_Sub\_A32ss frac16 t frac16 t acc32\_t Subtraction of a 16-bit fractional subtrahend from a 16-bit fractional minuend; the result is a 32-bit accumulator. The output may be out of the range <-1; 1). MLIB\_Sub\_A32as acc32\_t frac16 t acc32\_t Subtraction of a 16-bit fractional subtrahend from a 32-bit accumulator. The output may be out of the range <-1; 1).

Table 2-60. Function versions

#### 2.60.2 Declaration

The available MLIB\_Sub functions have the following declarations:

```
frac16_t MLIB_Sub_F16(frac16_t f16Min, frac16_t f16Sub)
frac32_t MLIB_Sub_F32(frac32_t f32Min, frac32_t f32Sub)
acc32_t MLIB_Sub_A32ss(frac16_t f16Min, frac16_t f16Sub)
acc32_t MLIB_Sub_A32as(acc32_t a32Accum, frac16_t f16Sub)
```

#### 2.60.3 Function use

The use of the MLIB\_Sub function is shown in the following examples:

#### **Fixed-point version:**

# 2.61 MLIB\_SubSat

The MLIB\_SubSat functions subtract the subtrahend from the minuend. The function saturates the output. See the following equation:

MLIB\_SubSat(a, b) = 
$$\begin{cases} 1, & a-b > 1 \\ -1, & a-b < -1 \\ a-b, & \text{else} \end{cases}$$

**Equation 59. Algorithm formula** 

#### 2.61.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

#### MLIB Sub4

The available versions of the MLIB\_SubSat function are shown in the following table.

Table 2-61. Function versions

Function name	Inp	Input type		Description
	Minuend	Subtrahend	type	
MLIB_SubSat_F16	frac16_t	frac16_t	_	Subtraction of a 16-bit fractional subtrahend from a 16-bit fractional minuend. The output is within the range <-1; 1).
MLIB_SubSat_F32	frac32_t	frac32_t	frac32_t	Subtraction of a 32-bit fractional subtrahend from a 32-bit fractional minuend. The output is within the range <-1; 1).

#### 2.61.2 Declaration

The available MLIB\_SubSat functions have the following declarations:

```
frac16_t MLIB_SubSat_F16(frac16_t f16Min, frac16_t f16Sub)
frac32_t MLIB_SubSat_F32(frac32_t f32Min, frac32_t f32Sub)
```

#### 2.61.3 Function use

The use of the MLIB\_SubSat function is shown in the following example:

# 2.62 MLIB\_Sub4

The MLIB\_Sub4 functions return the subtraction of three subtrahends from the minuend. The function does not saturate the output. See the following equation:

```
MLIB\_Sub4(a, b, c, d) = a - b - c - d
```

#### **Equation 60. Algorithm formula**

#### 2.62.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may overflow.

The available versions of the MLIB\_Sub4 function are shown in the following table.

Function name		Input	type		Result	Description			
	Minuend	Sub. 1	Sub. 2	Sub. 3	type				
	frac16_t	frac16_t	frac16_t	frac16_t	frac16_t	Subtraction of three 16-bit fractional subtrahends from 16-bit fractional minuend. The output is within the range <-1; 1).			
MLIB_Sub4_F32	frac32_t	frac32_t	frac32_t	frac32_t	frac32_t	Subtraction of three 32-bit fractional subtrahends from 32-bit fractional minuend. The output is within the range <-1; 1).			

Table 2-62. Function versions

#### 2.62.2 Declaration

The available MLIB\_Sub4 functions have the following declarations:

```
frac16_t MLIB_Sub4_F16(frac16_t f16Min, frac16_t f16Sub1, frac16_t f16Sub2, frac16_t f16Sub3)
frac32_t MLIB_Sub4_F32(frac32_t f32Min, frac32_t f32Sub1, frac32_t f32Sub2, frac32_t f32Sub3)
```

## 2.62.3 Function use

The use of the MLIB\_Sub4 function is shown in the following examples:

## **Fixed-point version:**

MLIB User's Guide, Rev. 4, 05/2020

#### MLIB Sub4Sat

```
/* f16Result = sat(f16Min - f16Sub1 - f16Sub2 - f16Sub3) */
f16Result = MLIB_Sub4_F16(f16Min, f16Sub1, f16Sub2, f16Sub3);
}
```

## 2.63 MLIB\_Sub4Sat

The MLIB\_Sub4Sat functions return the subtraction of three subtrahends from the minuend. The function saturates the output. See the following equation:

MLIB\_Sub4Sat(a, b, c, d) = 
$$\begin{cases} 1, & a-b-c-d > 1 \\ -1, & a-b-c-d < -1 \\ a-b-c-d, & \text{else} \end{cases}$$

**Equation 61. Algorithm formula** 

#### 2.63.1 Available versions

This function is available in the following versions:

• Fractional output - the output is the fractional portion of the result; the result is within the range <-1; 1). The result may saturate.

The available versions of the MLIB\_Sub4Sat function are shown in the following table.

Function name		Input	type		Result	Description
	Minuend	Sub. 1	Sub. 2	Sub. 3	type	
MLIB_Sub4Sat_F16	frac16_t	frac16_t	frac16_t	frac16_t	frac16_t	Subtraction of three 16-bit fractional subtrahends from 16-bit fractional minuend. The output is within the range <-1; 1).
MLIB_Sub4Sat_F32	frac32_t	frac32_t	frac32_t	frac32_t	frac32_t	Subtraction of three 32-bit fractional subtrahends from 32-bit fractional minuend. The output is within the range <-1; 1).

Table 2-63. Function versions

## 2.63.2 Declaration

The available MLIB\_Sub4Sat functions have the following declarations:

```
frac16_t MLIB_Sub4Sat_F16(frac16_t f16Min, frac16_t f16Sub1, frac16_t f16Sub2, frac16_t
f16Sub3)
frac32_t MLIB_Sub4Sat_F32(frac32_t f32Min, frac32_t f32Sub1, frac32_t f32Sub2, frac32_t
```

MLIB User's Guide, Rev. 4, 05/2020

#### 2.63.3 Function use

The use of the MLIB\_Sub4Sat function is shown in the following example:

MLIB\_Sub4Sat

# Appendix A Library types

## A.1 bool\_t

The bool\_t type is a logical 16-bit type. It is able to store the boolean variables with two states: TRUE (1) or FALSE (0). Its definition is as follows:

typedef unsigned short bool\_t;

The following figure shows the way in which the data is stored by this type:

Logi Value Unused cal **TRUE FALSE** 

Table A-1. Data storage

To store a logical value as bool\_t, use the FALSE or TRUE macros.

## A.2 uint8\_t

The uint8\_t type is an unsigned 8-bit integer type. It is able to store the variables within the range <0; 255>. Its definition is as follows:

typedef unsigned char uint8\_t;

The following figure shows the way in which the data is stored by this type:

Table A-2. Data storage

	7	6	5	4	3	2	1	0				
Value				Inte	eger							
255	1	1	1	1	1	1	1	1				
255		F					F					
11	0	0	0	0	1	0	1	1				
"		0			В							
124	0	1	1	1	1	1	0	0				
124		7				(						
159	1	0	0	1	1	1	1	1				
159		9					=					
_					1							


# A.3 uint16\_t

The uint16\_t type is an unsigned 16-bit integer type. It is able to store the variables within the range <0; 65535>. Its definition is as follows:

typedef unsigned short uint16 t;

The following figure shows the way in which the data is stored by this type:

Table A-3. Data storage



## A.4 uint32\_t

The uint32\_t type is an unsigned 32-bit integer type. It is able to store the variables within the range <0; 4294967295>. Its definition is as follows:

typedef unsigned long uint32\_t;

The following figure shows the way in which the data is stored by this type:

Table A-4. Data storage

	31	24	23	16	15	8	7	
Value				In	teger			
4294967295	F	F	F	F	F	F	F	F
2147483648	8	0	0	0	0	0	0	0
55977296	0	3	5	6	2	5	5	0
3451051828	С	D	В	2	D	F	3	4

## A.5 int8\_t

The int8\_t type is a signed 8-bit integer type. It is able to store the variables within the range <-128; 127>. Its definition is as follows:

typedef char int8\_t;

The following figure shows the way in which the data is stored by this type:

Table A-5. Data storage

	7	6	5	4	3	2	1	0			
Value	Sign				Integer						
127	0	1	1	1	1	1	1	1			
127	<u>.</u>	7	,	•			F	•			
100	1	0	0	0	0	0	0	0			
-128	'	8			0						
60	0	0	1	1	1	1	0	0			
60		3				(	C				
-97	1	0	0	1	1	1	1	1			
-97		9		•	F						

## A.6 int16\_t

The int16\_t type is a signed 16-bit integer type. It is able to store the variables within the range <-32768; 32767>. Its definition is as follows:

typedef short int16\_t;

The following figure shows the way in which the data is stored by this type:

Value Sign Integer F F F -32768 С Ε -24768 F 

Table A-6. Data storage

## A.7 int32 t

The int32\_t type is a signed 32-bit integer type. It is able to store the variables within the range <-2147483648; 2147483647>. Its definition is as follows:

typedef long int32\_t;

The following figure shows the way in which the data is stored by this type:

24 23 16 15 8 7 Value Integer F F F F F -2147483648 С F D В D -843915468 

Table A-7. Data storage

## A.8 frac8\_t

The frac8\_t type is a signed 8-bit fractional type. It is able to store the variables within the range <-1; 1). Its definition is as follows:

typedef char frac8\_t;

The following figure shows the way in which the data is stored by this type:

	7	6	5	4	3	2	1	0
Value	Sign				Fractional			
0.99219	0	1	1	1	1	1	1	1
0.99219	•	7	,				F	
-1.0	1	0	0	0	0	0	0	0
-1.0	•	8	3	•			0	
0.46875	0	0	1	1	1	1	0	0
0.40075		3	3	•			С	
-0.75781	1	0	0	1	1	1	1	1
-0./5/61		S		•			F	
L								

Table A-8. Data storage

To store a real number as frac8\_t, use the FRAC8 macro.

# A.9 frac16\_t

The frac16\_t type is a signed 16-bit fractional type. It is able to store the variables within the range <-1; 1). Its definition is as follows:

typedef short frac16 t;

The following figure shows the way in which the data is stored by this type:

15 14 13 12 10 7 5 3 2 1 11 Value Fractional Sign 0 1 1 1 1 1 1 1 1 1 1 1 1 0.99997 F F -1.0 1 0 0 0

Table A-9. Data storage

Table continues on the next page...

MLIB User's Guide, Rev. 4, 05/2020

Table A-9. Data storage (continued)

		8	3			(	)			(	)		0				
0.47257	0	0	1	1	1	1	0	0	1	0	0	1	1	1	1	0	
0.47337	0.47357				С			9			E						
-0.75586	1	0	0	1	1	1	1	1	0	1	0	0	0	0	0	0	
-0.73300		(	9		F				4 0					)			

To store a real number as frac16\_t, use the FRAC16 macro.

## A.10 frac32\_t

The frac32\_t type is a signed 32-bit fractional type. It is able to store the variables within the range <-1; 1). Its definition is as follows:

typedef long frac32\_t;

The following figure shows the way in which the data is stored by this type:

Table A-10. Data storage

	31	24	23	16	15	8	7	0
Value	S			Fra	ctional			
0.999999995	7	F	F	F	F	F	F	F
-1.0	8	0	0	0	0	0	0	0
0.02606645970	0	3	5	6	2	5	5	0
-0.3929787632	С	D	В	2	D	F	3	4

To store a real number as frac32\_t, use the FRAC32 macro.

# A.11 acc16\_t

The acc16\_t type is a signed 16-bit fractional type. It is able to store the variables within the range <-256; 256). Its definition is as follows:

typedef short acc16\_t;

The following figure shows the way in which the data is stored by this type:

141

**Table A-11. Data storage** 

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Value	Sign				Integer					Fractional						
255.9921875	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
233.9921073		7				F	=			F	=			ı	=	
-256.0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
-230.0		8	3		0			0			0					
1.0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
1.0		0			0				8	3			(	)		
-1.0	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
-1.0		F	=			F			8				0			
13.7890625	0	0	0	0	0	1	1	0	1	1	1	0	0	1	0	1
10.7030023		0				6	3		E					į	5	
-89.71875	1	1	0	1	0	0	1	1	0	0	1	0	0	1	0	0
-69.71675		D			3			2				4				

To store a real number as acc16\_t, use the ACC16 macro.

# A.12 acc32 t

The acc32\_t type is a signed 32-bit accumulator type. It is able to store the variables within the range <-65536; 65536). Its definition is as follows:

typedef long acc32\_t;

The following figure shows the way in which the data is stored by this type:

Table A-12. Data storage

	31		24 23		16 15		8 7	
Value	S	S Integer				Fractional		
65535.999969	7	F	F	F	F	F	F	F
-65536.0	8	0	0	0	0	0	0	0
1.0	0	0	0	0	8	0	0	0
-1.0	F	F	F	F	8	0	0	0
23.789734	0	0	0	В	Е	5	1	6
-1171.306793	F	D	В	6	5	8	В	С

To store a real number as acc32\_t, use the ACC32 macro.

MLIB User's Guide, Rev. 4, 05/2020 **NXP Semiconductors** 

#### A.13 FALSE

The FALSE macro serves to write a correct value standing for the logical FALSE value of the bool\_t type. Its definition is as follows:

#### A.14 TRUE

The TRUE macro serves to write a correct value standing for the logical TRUE value of the bool\_t type. Its definition is as follows:

#### A.15 FRAC8

The FRAC8 macro serves to convert a real number to the frac8\_t type. Its definition is as follows:

```
\#define\ FRAC8(x)\ ((frac8_t)((x) < 0.9921875\ ?\ ((x) >= -1\ ?\ (x)*0x80\ :\ 0x80)\ :\ 0x7F))
```

The input is multiplied by  $128 (=2^7)$ . The output is limited to the range <0x80; 0x7F>, which corresponds to <-1.0;  $1.0-2^{-7}>$ .

143

#### **A.16 FRAC16**

The FRAC16 macro serves to convert a real number to the frac16\_t type. Its definition is as follows:

```
\#define\ FRAC16(x)\ ((frac16_t)((x) < 0.999969482421875?((x) >= -1?(x)*0x8000:0x8000):0x7FFF))
```

The input is multiplied by  $32768 (=2^{15})$ . The output is limited to the range <0x8000; 0x7FFF>, which corresponds to <-1.0;  $1.0-2^{-15}>$ .

## **A.17 FRAC32**

The FRAC32 macro serves to convert a real number to the frac32\_t type. Its definition is as follows:

```
\#define\ FRAC32(x)\ ((frac32_t)((x) < 1 ? ((x) >= -1 ? (x)*0x80000000) : 0x80000000) : 0x7FFFFFFFF))
```

The input is multiplied by 2147483648 (= $2^{31}$ ). The output is limited to the range <0x80000000; 0x7FFFFFFF, which corresponds to <-1.0;  $1.0-2^{-31}$ >.

#### A.18 ACC16

The ACC16 macro serves to convert a real number to the acc16\_t type. Its definition is as follows:

```
\#define\ ACC16(x)\ ((acc16_t)((x) < 255.9921875?((x) >= -256?(x)*0x80:0x8000):0x7FFF))
```

The input is multiplied by  $128 (=2^7)$ . The output is limited to the range <0x8000; 0x7FFF> that corresponds to <-256.0; 255.9921875>.

#### A.19 ACC32

The ACC32 macro serves to convert a real number to the acc32\_t type. Its definition is as follows:

```
#define ACC32(x) ((acc32_t)((x) < 65535.999969482421875 ? ((x) >= -65536 ? (x)*0x8000 : 0x80000000) : 0x7FFFFFFF)
```

The input is multiplied by  $32768 (=2^{15})$ . The output is limited to the range <0x80000000; 0x7FFFFFFF, which corresponds to <-65536.0;  $65536.0-2^{-15}>$ .

How to Reach Us:

Home Page:

nxp.com

Web Support:

nxp.com/support

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. Freescale reserves the right to make changes without further notice to any products herein.

Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: www.freescale.com/salestermsandconditions.

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc. ARM and Cortex are the registered trademarks of ARM Limited, in EU and/or elsewhere. ARM logo is the trademark of ARM Limited. All rights reserved. All other product or service names are the property of their respective owners.

© 2020 NXP B.V.

Document Number CM0MLIBUG Revision 4, 05/2020



