


# G.722 Codec

# **Programmer's Guide**



© 2012-2013 Tensilica, Inc.

Printed in the United States of America

All Rights Reserved

This publication is provided "AS IS." Tensilica, Inc. (hereafter "Tensilica") does not make any warranty of any kind, either expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Information in this document is provided solely to enable system and software developers to use Tensilica processors. Unless specifically set forth herein, there are no express or implied patent, copyright or any other intellectual property rights or licenses granted hereunder to design or fabricate Tensilica integrated circuits or integrated circuits based on the information in this document. Tensilica does not warrant that the contents of this publication, whether individually or as one or more groups, meets your requirements or that the publication is error-free. This publication could include technical inaccuracies or typographical errors. Changes may be made to the information herein, and these changes may be incorporated in new editions of this publication.

The following terms are trademarks of Tensilica, Inc.: FLIX, OSKit, Sea of Processors, TurboXim, Vectra, Xenergy, Xplorer, and XPRES. All other trademarks and registered trademarks are the property of their respective companies.

Version 1.0 January 2013 PD-12-8612-10-00

# **Contents**

C	ontents		ii
Fi	gures		iv
Ta	ables		iv
1.	Intr	oduction to the HiFi G.722 Codec	1
	1.1	G.722 Background	1
	1.2	Document Overview	
	1.3	HiFi G.722 Codec Specifications	2
	1.4	HiFi G.722 Codec Performance	2
	1.4.1 1.4.2	,	
_			
2.		eneric HiFi Speech Codec API	
	2.1	Memory Management	
	2.2	C Language API	
		Generic API Errors	
	2.4 2.5	Common API Errors	
	_	Files Describing the API	
3.		Fi Audio Engine G.722 Codec	
	3.1	I/O Formats	
	3.2	Frame Types	
	3.3	API Functions	
	3.3.1	F <b>5</b> -	
	3.3.2 3.3.3	,	
	3.3.4	3	
	3.4	Files Specific to the G.722 Codec	
4.		roduction to Example Test Bench	
	4.1	Making Executables	
	4.2	Usage	
_	D.	forence	20

# **Figures**

Figure 1 HiFi Speech Codec Interfaces	E
Figure 2 Speech Codec Flow Overview	
	Tables
Table 3-1 Frame Types	
Table 3-2 Library Identification Functions	
Table 3-3 Memory Management Functions	
Table 3-4 G.722 Encoder Initialization Function	12
Table 3-5 G.722 Decoder Initialization Function	13
Table 3-6 G.722 Encoder Execution Function	

### 1. Introduction to the HiFi G.722 Codec

The HiFi Audio Engine G.722 Codec implements the speech codec standard specified as ITU-T Recommendation G.722 (11/1988)<sup>[1]</sup>, including Erratum 1 (05/2003)<sup>[2]</sup>. This codec supports packet-loss concealment according to G.722 Appendix IV (11/2009)<sup>[3]</sup>.

## 1.1 G.722 Background

G.722 is an ITU standard codec that provides 7 kHz wide-band audio with a data rate of 64 kbit/s. It offers a significant improvement in speech quality over narrow-band codecs such as G.711.The coding system uses sub-band adaptive differential pulse code modulation (SB-ADPCM) with a bit rate of 64 kbit/s.

The system is henceforth referred to as 64 kbit/s (7 kHz) audio coding. In the SB-ADPCM technique used, the frequency band is split into two sub-bands (higher and lower) and the signals in each sub-band are encoded using ADPCM.

Packet loss concealment algorithm, also known as frame erasure concealment algorithms, hide transmission losses in audio systems where the input signal is encoded and packateised. When packaet loss is informed to the G.722 decoder, it performs the analysis of the past lower-band reconstructed signal and extrapolates the missing signal using linear predictive coding (LPC), pitch-synchronous period repetations and adaptive muting. Once good frame is received, the decoded signal is cross faded with the extrapolated signal. In the higher band, decoder reapets the previous frame pith synchronously, with adaptive muting and high pass post-processing. The ADPCM states are updated after each frame erasure.

### 1.2 Document Overview

This document covers all the information required to integrate the HiFi speech codecs into an application. The HiFi codec libraries implement a simple API to encapsulate the complexities of the coding operations and simplify the application and system implementation.

## 1.3 HiFi G.722 Codec Specifications

The HiFi Audio Engine G.722 Codec from Tensilica implements the following features:

■ ITU-T G.722 compliant encoder and decoder

 Runtime option for G.722 Appendix IV: A low-complexity algorithm for packet-loss concealment with ITU-T G.722

Sample rates: 16 kHz

Bit rate supported: 64 kbit/sPCM sample size: 16 bit.

The HiFi G.722 codec implementation is GPL free. The base codec implementation has been verified with the reference vectors provided by ITU G.722 implementation in G.191. The PLC implementation was verified using the test vectors provided with G.722 Annex IV<sup>[3]</sup>.

### 1.4 HiFi G.722 Codec Performance

The HiFi Audio Engine G.722 Codec from Tensilica was characterized on the 5-stage HiFi Audio Engine processor core. The memory usage and performance figures are provided for design reference.

### **1.4.1 Memory**

Te	Data		
HiFi Mini	HiFi 2	HiFi 3	Kbytes
11.7	13.8	14.5	0.5

#### **Encoder**

Run Time Memory (Bytes)					
Persistent	Scratch	Stack	Input	Output	
196	0	288	NS*BPS	NS/2	

### **Decoder without PLC**

Run Time Memory (Bytes)					
Persistent Scratch Stack Input Output				Output	
1956	1000	368	BS	BS*2*BPS	

### **Decoder with PLC**

Frame Size	ne Size Run Time Memory (By		rtes)		
msec	Persistent	Scratch	Stack	Input	Output
10	1956	1000	368	80	320
20	1956	1000	368	160	640

**Note** NS: Number of PCM sample to be encoded. Each encoded sample is 4 bits.

**Note** BS: Number of bytes to be decoded by the decoder.

**Note** BPS: Number of bytes per PCM sample, which is 2.

Input and output buffers are allocated by the test-bench and buffer sizes are calculated using equations specified in above tables.

## 1.4.2 Timings

### **Encoder**

Data Rate	Data Rate Frame size		Average CPU Load (MHz)		
kbps	msec	HiFi Mini	HiFi 2	HiFi 3	
64	10	5.3	5.0	5.0	

### **Decoder**

Data Rate	Frame size	PLC	Average (	CPU Load	(MHz)
kbps	msec		HiFi Mini	HiFi 2	HiFi 3
64	10	off	4.5	4.3	4.4
64	10	on	4.8	4.7	4.7
64	20	on	4.6	4.4	4.5

**Note** Performance specification measurements are carried out on a cycle-accurate simulator assuming an ideal memory system, *i.e.*, one with zero memory wait states. This is equivalent to running with all code and data in local memories or using an infinite-size, pre-filled cache model.

## 2. Generic HiFi Speech Codec API

This chapter describes the API which is common to all the HiFi speech codec libraries. The API facilitates any codec that works in the overall method shown in the following diagram.




Figure 1 HiFi Speech Codec Interfaces

The following section, Section 2.1, discusses all the types of run time memory required by the codecs. There is no state information held in static memory, therefore, a single thread can perform time division processing of multiple codecs. Additionally, multiple threads can perform concurrent codec processing.

## 2.1 Memory Management

The HiFi speech codec API supports a flexible memory scheme and a simple interface that eases the integration into the final application. The API allows the codecs to request the required memory for their operations during run time. The run time memory requirement consists primarily of the scratch and persistent memory. The codecs also require an input buffer and output buffer for the passing of data into and out of the codec.

#### **API Handle / Persistent Memory**

The codec API stores persistent state information in a structure that is referenced via a opaque handle. The handle is passed by the application for each API call. This object contains all state and history information that is maintained from one codec frame invocation to the next within the same thread or instance. The codecs expect that the contents of the persistent memory be unchanged by the system apart from the codec library itself for the complete lifetime of the codec operation.

### **Scratch Memory**

This is the temporary buffer used by the codec during a single frame processing call. The contents of this memory region should not be changed if the actual codec execution process is active, *i.e.*, if the thread running the codec is inside any API call. This region can be used freely by the system between successive calls to the codec.

#### **Input Buffer**

This is the buffer used by the algorithm for accepting input data. Before the call to the codec, the input buffer needs to be completely filled with input data.

### **Output Buffer**

This is the buffer in which the algorithm writes the output. This buffer needs to be made available for the codec before its execution call. The output buffer pointer can be changed by the application between calls to the codec. This allows the codec to write directly to the required output area.

## 2.2 C Language API

An overview of the codec flow is shown in Figure 2. The speech codec API consists of query, initialization and execution functions. In the naming scheme below, <codec> is either the codec name (for example, g722), or the codec name with an  $_enc$  or  $_dec$  suffix for encoder- and decoder-specific functions respectively.

#### Query Functions: xa\_<codec>\_get\_<data>

The query functions are used in the startup and the memory allocation codec stages to obtain information about the version and the memory requirements of the codec library.

### Initialization Functions: xa\_<codec>\_init

The initialization functions are used to reset the codec to its initial state. Because the codec library is fully reentrant, a process can initialize the codec library multiple times and multiple processes can initialize the same codec library as appropriate.

#### Execution Functions: xa <codec>

The execution functions are used to encode and decode speech frames.

The G.722 Codec sequence, as well as the functions associated with each stage, are described in detail in Section 3.




Figure 2 Speech Codec Flow Overview

### 2.3 Generic API Errors

Speech codec API functions return error code of type  $XA\_ERRORCODE$  which is of type signed int. The format of the error codes are defined in the following table.

31	30-15	14 - 11	10 - 6	5 - 0
Fatal	Reserved	Class	Codec	Sub code

The errors that can be returned from the API are sub divided into those that are fatal, which require the restarting of the whole codec and those that are nonfatal and are provided for information to the application.

The class of an error can be either API, Config or Execution. The API category errors are concerned with the incorrect use of the API. The Config errors are produced when the codec parameters are incorrect or outside the supported usage. The Execution errors are returned

after a call to the main encoding or decoding process and indicate situations that have arisen due to the input data.

### 2.4 Common API Errors

All these errors are fatal and should not be encountered during normal application operation. They signal that a serious error has occurred in the application that is calling the codec.

- XA\_API\_FATAL\_MEM\_ALLOC
  - At least one of the pointers passed into the API function is NULL.
- XA\_API\_FATAL\_MEM\_ALIGN
  - At least one of the pointers passed into the API function is not properly aligned.

## 2.5 Files Describing the API

### The common include files (include):

- xa\_error\_standards.h
  - The macros and definitions for all the generic errors
- xa\_error\_handler.h
  - The macros and definition for error handler
- xa\_type\_def.h
  - All the types required for the API calls

## 3. HiFi Audio Engine G.722 Codec

The HiFi Audio Engine G.722 Codec conforms to the generic speech codec API and the codec flow shown in **Figure 2**. The supported I/O formats and frame types, as well as the API functions and the files specific to the G.722 Codec are described below.

### 3.1 I/O Formats

The G.722 encoder takes as input 16 bit PCM samples sampled at 16KHz, and generates compressed output bit stream. Number of samples to be encoded are passed to the encoder execute function. Each PCM sample is encoded to 4 bits. Number of samples to be encoded per execute call should be multiple of 2. Encoder application should decide input buffer size and corresponding output buffer size and allocates the buffers depending on the number of PCM samples to be encoded per execute API call. G.722 encoded bit stream contains 2 encoded PCM samples per byte..

The G.722 Decoder accepts compressed bitstream and generates PCM output. Input and output buffer requirements differ depends on whether PLC is enabled at the decoder initialization time.

If the decoder is initialized with PLC disabled, the decoder execute function accepts number of compressed bytes to be decoded. Each compressed byte corresponds to 2 decoded PCM samples. The size of the input and the output buffers should be decided by the decoder application depending on number of bytes to be decoded per execute API call.

If PLC option is enabled, then the input buffer of the decoder must be either 80 or 160 bytes, representing 10ms or 20ms frame length respectively. Accordingly, the decoder outputs 160 or 320 PCM samples that corresponds to 10 ms or 20 ms speech frame respectively.

## 3.2 Frame Types

When PLC is enabled, each input frame to the Decoder must be identified as being either a normal frame, or an erased (lost) frame. This indication is done using the enumeration  $xa \ q722 \ frame \ type \ e.$  Table 3-1 describes each frame type.

Table 3-1 Frame Types

Frame Type	Description
XA_G722_GOOD_FRAME	Normal frame.
XA_G722_BAD_FRAME	Erased (lost) frame. It only has an effect when PLC is enabled.

### 3.3 API Functions

The G.722 Codec API functions relevant to each stage in the codec flow are specified in the following sections.

### 3.3.1 Startup Stage

The API startup functions described below get the various identifications strings from the codec library. They are for information only and their usage is optional. These functions do not take any input arguments and return const char \*.

Table 3-2 Library Identification Functions

Function	Description
xa_g722_get_lib_name_string	Get the name of the library.
xa_g722_get_lib_version_string	Get the version of the library.
xa_g722_get_lib_api_version_string	Get the version of the API.

### **Example**

```
const char *name = xa_g722_get_lib_name_string();
const char *ver = xa_g722_get_lib_version_string();
const char *apiver = xa_g722_get_lib_api_version_string();
```

#### **Errors**

None.

### 3.3.2 Memory Allocation Stage

During the memory allocation stage, the application needs to reserve the necessary memory for the G.722 Encoder and Decoder API handles (persistent state) and scratch buffers. The required alignment of the handles and the scratch buffers is 4 bytes. The application can use the functions listed in Table 3-3 to query the codec library for the required size of each buffer. The functions take no input arguments and return WORD32.

While input and output buffers are required for the operation of the codec, they do not need to be reserved at this stage. Pointers to the frame buffers are passed in each invocation of the main codec execution function. The size and alignment requirements of the I/O buffers are specified in Section Execution Stage.

**Table 3-3 Memory Management Functions** 

Function	Description
xa_g722_enc_get_handle_byte_size	Returns the size of the G.722 Encoder API handle (persistent state) in bytes.
xa_g722_dec_get_handle_byte_size	Returns the size of the G.722 Decoder API handle (persistent state) in bytes.
xa_g722_enc_get_scratch_byte_size	Returns the size of the G.722 Encoder scratch memory.
xa_g722_dec_get_scratch_byte_size	Returns the size of the G.722 Decoder scratch memory.

### **Example**

```
WORD32 enc_handle_size, dec_handle_size;
WORD32 enc_scratch_size, dec_scratch_size;

enc_handle_size = xa_g722_enc_get_handle_byte_size();
dec_handle_size = Xa_g722_dec_get_handle_byte_size();
enc_scratch_size = xa_g722_enc_get_scratch_byte_size();
dec_scratch_size = xa_g722_dec_get_scratch_byte_size();
```

#### **Errors**

None

### 3.3.3 Initialization Stage

In the initialization stage, the application points the G.722 codec to its API handle and scratch buffer. The application also specifies various other parameters related to the operation of the codec and places the codec in its initial state. The API functions for G.722 Encoder and Decoder initialization are specified in Table 3-4 and Table 3-5, respectively.

Table 3-4 G.722 Encoder Initialization Function

Function	xa_g722_enc_init
Syntax	XA_ERRORCODE xa_g722_enc_init(
	xa_codec_handle_t handle,
	pVOID scratch)
Description	Reset the encoder API handle into its initial state.
Parameters	Input: handle Pointer to the Encoder persistent memory. This is an opaque handle. Required size: see xa_g722_enc_get_handle_byte_size. Required alignment: 4 bytes.
	Input: scratch Pointer to the Encoder scratch buffer. Required size: see xa_g722_enc_get_scratch_byte_size. Required alignment: None

### **Example**

### **Errors**

- XA\_API\_FATAL\_MEM\_ALLOC
  - handle is NULL.
- XA\_API\_FATAL\_MEM\_ALIGN
  - handle does not meet the alignment requirements.

Table 3-5 G.722 Decoder Initialization Function

Function	xa_g722_dec_init
Syntax	XA_ERRORCODE xa_g722_dec_init(
	xa_codec_handle_t handle,
	pVOID scratch,
	WORD32 plc_enable)
Description	Reset the decoder API handle into its initial state.
Parameters	Input: handle
	Pointer to the Decoder persistent memory. This is an opaque handle.
	Required size: see xa_g722_dec_get_handle_byte_size.
	Required alignment: 4 bytes.
	Input: scratch
	Pointer to the decoder scratch buffer.
	Required size: see xa_g722_dec_get_scratch_byte_size.
	Required alignment: 2 bytes.
	Input: plc_enable
	Configuration of the PLC
	0: core g722 decoder without PLC
	1: Configure g722 decoder with PLC

### **Example**

### **Errors**

- XA\_API\_FATAL\_MEM\_ALLOC
  - handle is NULL.
- XA\_API\_FATAL\_MEM\_ALIGN
  - handle or scratch do not meet alignment requirements.

### 3.3.4 Execution Stage

The G.722 encoder takes as input 16KHz speech samples, and generates compressed bit stream as output. Number of PCM samples to be encoded per execute call is supplied to the encoder execute function. Number of PCM samples to be encoded must be multiple of 2. Please refer to section 3.1 for detils on how to calculate input output buffer sizes for the encoder.

Similarly, G.722 decoder accepts compressed bit stream and generates PCM samples. Number of bytes to be decoded per execute call is supplied to the decoder execute function. If the decoder is initialized with PLC mode enabled, then number of bytes to process must be either 80 or 160 bytes, corresponding to 10ms or 20ms frame respetively. This restriction is imposed by the G.722 PLC algorithm which works on 10 or 20ms frames only. Refer to section 3.1 for details on input, output buffer allocaton for the decoder.

The following macros that specify the relevant I/O buffer sizes for the encoder and decoder:

- XA\_G722\_MAX\_NUM\_BITS\_PER\_ENCODED\_SAMPLE: 4
- XA\_G722\_NUM\_BITS\_PER\_PCM\_SAMPLE: 16

The syntax of the G.722 Encoder and Decoder execution functions are specified in Table 3-6 and Table 3-7 respectively.

Table 3-6 G.722 Encoder Execution Function

Function	xa_g722_enc
Syntax	XA_ERRORCODE xa_g722_enc (
	xa_codec_handle_t handle,
	pWORD16 inp_speech,
	pWORD8 enc_speech
	WORD32 num_samples);
Description	Encode speech samples.
Parameters	Input: handle
	The opaque Encoder handle.
	Required alignment: 4 bytes.
	Input: inp_speech
	A pointer to the input speech frame.
	Required alignment: 2 bytes.
	Input: num_samples
	Number of PCM sample to be encoded.
	Restriction: Number of PCM sample to be encoded must be multiple of 2.
	Output: enc_speech
	A pointer to the encoded speech frame.
	This is the output buffer.
	Required alignment: 1 byte.

### **Example**

### **Errors**

- XA\_API\_FATAL\_MEM\_ALLOC
  - One of the input pointers is NULL.
- XA\_API\_FATAL\_MEM\_ALIGN
  - handle or inp\_speech do not meet the alignment requirements.
- XA\_G722\_EXECUTE\_FATAL\_INVALID\_NUM\_SAMPLES\_TO\_PROCESS
  - Number of PCM samples to be encoded should be multiple of 2.

Table 3-7 G.722 Decoder Execution Function

Function	xa_g722_dec
Syntax	<pre>XA_ERRORCODE xa_g722_dec (     xa_codec_handle_t handle,     pUWORD8 enc_speech,     pWORD16 synth_speech,     WORD32 num_bytes,     xa_g722_frame_type_e frame_type);</pre>
Description	Decode number of compressed bytes of speech, depending on the frame type.
Parameters	Input: handle The opaque Decoder handle. Required alignment: 4 bytes.  Input: enc_speech A pointer to the encoded speech frame. Required alignment: 1 byte.  Input: num_bytes Number of input bytes given to the decoder to process.  Output: synth_speech Pointer to the synthesized speech. Required alignment: 2 bytes.  Input: frame_type According to use of packet-loss concealment, the decoder need to specify the type of frame (See Table 3.1).

### **Example**

### **Errors**

- XA\_API\_FATAL\_MEM\_ALLOC
  - One of the input pointers is NULL.
- XA\_API\_FATAL\_MEM\_ALIGN
  - handle is not 4-byte aligned. synth\_speech is not 2-byte aligned.

- XA\_G722\_EXECUTE\_FATAL\_INSUFFICIENT\_BYTES\_TO\_PROCESS
  - This error is generated if the decoder is configured to run with PLC enabled and recives num\_bytes are not equal to 80 or 160 bytes.

## 3.4 Files Specific to the G.722 Codec

The G.722 codec API header file (include/g722\_codec)

xa\_g722\_codec\_api.h

The G.722 codec library (lib)

xa\_g722\_codec.a

## 4. Introduction to Example Test Bench

The G.722 Codec library is provided with two sample ITU-T conformance test bench applications: one for the encoder and one for the decoder. The supplied test benches contain the following files:

### Test bench source files (test/src)

```
xa_g722_enc_sample_testbench.c
```

- xa\_g722\_dec\_sample\_testbench.c
- xa\_g722\_codec\_error\_handler.c

### Makefile to build the executables (test/build)

makefile\_testbench\_sample

## 4.1 Making Executables

To build the applications, follow these steps:

- 1. From the directory: test/build.
- 2. At the command-line prompt, type:

```
xt-make -f makefile_testbench_sample clean xa_g722_codec_test
```

This will build the encoder example test bench  $xa_g722_{enc_test}$  and the decoder example test bench  $xa_g722_{dec_test}$ .

#### Note:

If you have source code distribution, you must build the G.722 library before you can build the testbench. Follow these steps:

- 1. Go to build.
- 2. at the command prompt, type: make clean all install

The G.722 library will be built and copied to the lib directory

## 4.2 Usage

#### **Encoder Test Bench**

The sample application encoder executable can be run from the command line as follows:

```
xt-run xa_g722_enc_test <speech_file> <bitstream_file>
```

#### Where:

<speech\_file>

Input speech file.

<br/>
<br/>
ditstream file>

Output speech file encoded in the ITU-T conformance format.

#### **Decoder Test Bench**

The sample application decoder executable can be run from the command line as follows:

#### Where:

<bitstream\_file>

• input speech file encoded in the ITU-T conformance format

<synth file>

• output synthesized speech file.

-plc

- This is an optional parameter.
- If supplied, the decode does the PLC according to frame erasure pattern specified by G.192 compatable loss pattern file.
- If not supplied, decoder operates in core decode mode without PLC.

```
[loss_pattern_file]
```

• This must be specified if –plc option is supiled to decoder. If supplied, a G.192-compliant pattern loss file to simulate frame loss patterns.

[-20ms]

• This is an optional parameter. If supplied, the decode use 20ms frames. If not supplied, the testbench assumes 10ms frames.

.

If no command line arguments are given, the Encoder or Decoder application reads the commands from the parameter file  $paramfilesimple\_encode.txt$  or  $paramfilesimple\_decode.txt$  respectively

The syntax for writing the paramfilesimple file is:

```
@Start
@Input_path <path to be appended to all input files>
@Output_path <path to be appended to all output files>
<command line 1>
<command line 2>
....
@Stop
```

The G.722 encoder and decoder can be run for multiple test files using the different command lines. The syntax for command lines in the parameter file is the same as the syntax for specifying options on the command line to the test bench program.

**Note** All the @<command>s should be at the first column of a line except the @New\_line command.

**Note** All the @<command>s are case sensitive. If the command line in the parameter file has to be broken to two parts on two different lines use the @New\_line command.

Eg.

<command line part 1> @New\_line
<command line part 2>.

**Note** Blank lines will be ignored.

**Note** Individual lines can be commented out using "//" at the beginning of the line.

.

# 5. Reference

[1]	International Telecommunication Union, "7 kHz Audio Coding Within 64 KBIT/S." ITU-T Recommendation G.722 (11/88).
	http://www.itu.int/rec/T-REC-G.722-198811-I/en
[2]	International Telecommunication Union, "Erratum 1 (05/2003) to ITU-T Recommendation G.722 (11/1988)" ITU-T Recommendation G.722 (1988) Erratum 1 (05/03). http://www.itu.int/rec/T-REC-G.722-200305-I!Err1/en
[3]	International Telecommunication Union, "Appendix IV: A low-complexity algorithm for packet-loss concealment with ITU-T G.722." ITU-T Recommendation G.722 (1988) Appendix IV (11/09).
	http://www.itu.int/rec/T-REC-G.722-200911-I!AppIV/en