## GENERAL INFORMATION:

| | |
|---|---|
| **SIMPLWINDOWS NAME:** | Qsys Camera Presets |
| **CATEGORY:** | Qsys |
| **VERSION:** | 5.0.0 |
| **SUMMARY:** | Controls a Q-SYS camera preset script component that manages presets for up to 6 cameras with 16 presets each. Selects the active camera, recalls and saves presets for it, turns tracking on and off, selects router outputs, and loads/saves the preset file. Reports camera and preset names, button states and status text. |
| **GENERAL NOTES:** | Preset recall and save act on the camera currently selected in the Q-SYS component (Cam1_Select–Cam6_Select).<br><br>Camera select, preset recall and router output inputs only turn their Q-SYS button on; turning the others off (interlock) is up to the Q-SYS script.<br><br>Preset_Name_1–Preset_Name_16 show the names for the selected camera only. They update when Q-SYS reports a name change; selecting a different camera does not by itself resend the names already received.<br><br>Empty strings from Q-SYS are ignored, so a camera name, preset name or status that is cleared in Q-SYS keeps its last value on the string outputs. |
| **CRESTRON HARDWARE REQUIRED:** | 3 Series Processor or 4 Series Processor |
| **SETUP OF CRESTRON HARDWARE:** | Requires a Qsys Core module in the same program with a matching CoreID. |
| **VENDOR FIRMWARE:** | N/A |
| **VENDOR SETUP:** | Works with the Q-SYS camera preset script component using its standard control names (e.g. Cam Select 1, PresetRecall 1, RouterOutput 1). Script Access must be External or All. |
| **GENERATION:** | Generated by Claude Code from SIMPL+ and SIMPL# source files |

## CONTROL:

| | | |
|---|---|---|
| **[Cam1_Select]–[Cam6_Select]** | D | Pulse to select the corresponding camera (sets Cam Select N on). |
| **[Preset_Recall_1]–[Preset_Recall_16]** | D | Pulse to recall the corresponding preset on the selected camera (sets PresetRecall N on). |
| **[Preset_Save_1]–[Preset_Save_16]** | D | Pulse to save the selected camera's current position to the corresponding preset (triggers PresetSave N). |
| **[Tracking_On]** | D | Pulse to turn camera tracking on. |
| **[Tracking_Off]** | D | Pulse to turn camera tracking off. |
| **[Load_Presets]** | D | Pulse to load presets from the preset file (triggers LoadPresets). |
| **[Save_Presets]** | D | Pulse to save presets to the preset file (triggers SavePresets). |
| **[Recalibrate]** | D | Pulse to recalibrate the cameras (triggers Recalibrate). |

| | | |
|---|---|---|
| **[Refresh_Files]** | D | Pulse to refresh the list of preset files (triggers RefreshFiles). |
| **[Router_Output_1]–[Router_Output_11]** | D | Pulse to select the corresponding router output (sets RouterOutput N on). |

## FEEDBACK:

| | | |
|---|---|---|
| **[Cam1_Select_Fb]–[Cam6_Select_Fb]** | D | High while the corresponding camera is selected. |
| **[Preset_Button_1_Fb]–[Preset_Button_16_Fb]** | D | Follows the state of the corresponding PresetButtons N control in Q-SYS. |
| **[PnH_Progress_1]–[PnH_Progress_16]** | D | Follows the state of the corresponding PnHProgress N control in Q-SYS. |
| **[Tracking_Fb]** | D | High while camera tracking is on. |
| **[Router_Output_1_Fb]–[Router_Output_11_Fb]** | D | High while the corresponding router output is selected. |
| **[Camera1_Name]–[Camera6_Name]** | S | Name of the corresponding camera, from the Camera N control. |
| **[Status_Text]** | S | Status text reported by the component. |
| **[Autosave_Status]** | S | Autosave status text reported by the component. |
| **[Preset_Name_1]–[Preset_Name_16]** | S | Name of the corresponding preset for the selected camera, from the Camera N Presets P control. |

## PARAMETERS:

| | | |
|---|---|---|
| **CoreID** | S | Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module.<br>Default: 1 |
| **ComponentName** | S | Code Name of the camera preset component in the Q-SYS design. |

## TESTING:

| | |
|---|---|
| **SAMPLE PROGRAM:** | 3-Series: 3 Series Test.smw<br>4-Series: 4 Series Test.smw |
| **REVISION HISTORY:** | |