GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Generic String Component Control
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Controls and monitors a single text control of any Q-SYS component (e.g. a text box, or any control set by its string value).
GENERAL NOTES:	SetStringValue accepts up to 255 characters. An empty string clears the control. StringValue reports the control's string as Q-SYS reports it. For numeric controls this is Q-SYS's formatted text (e.g. "-10.0dB"); for a combo box it is the selected choice's text.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	Works with a control on any Q-SYS component; the component's Script Access must be External or All.
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

[SetStringValue]	S	Sets the control's string value to the text received.

FEEDBACK:

[StringValue]	S	The control's current string value.

PARAMETERS:

CoreID	S	Used to address this module to the Qsys Core module with the same CoreID. Default: 1
ComponentName	S	Code Name of the Q-SYS component that contains the control.
ComponentControlName	S	Name of the control within the component to be controlled.

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	