GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Nvm Decoder
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Controls the HDMI output of a Q-SYS NVM decoder component: source selection, video freeze, video mute and HDMI output enable, with feedback for each.
GENERAL NOTES:	Source is sent to Q-SYS as text (e.g. 2 is sent as "2"), because the decoder's source select is a string control. CurrentSource is parsed back from that string. The Toggle inputs use the module's current feedback to decide the new state, so feedback must have been received from Q-SYS for a toggle to act correctly.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	Works with a Q-SYS NVM Series decoder; Script Access must be External or All. The module always controls the decoder's HDMI output 1.
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

[VideoFreezeOn]	D	Pulse to freeze the HDMI output video.
[VideoFreezeOff]	D	Pulse to unfreeze the HDMI output video.
[VideoFreezeToggle]	D	Pulse to toggle video freeze, based on VideoFreezeIsOn.
[VideoMuteOn]	D	Pulse to mute (blank) the HDMI output video.
[VideoMuteOff]	D	Pulse to unmute the HDMI output video.
[VideoMuteToggle]	D	Pulse to toggle video mute, based on VideoMuteIsOn.
[HdmiEnabledOn]	D	Pulse to enable the HDMI output.
[HdmiEnabledOff]	D	Pulse to disable the HDMI output.
[HdmiEnabledToggle]	D	Pulse to toggle the HDMI output enable, based on HdmiEnabledIsOn.
[Source]	A	Source index to route to the HDMI output. Sent each time the value changes.

FEEDBACK:

[VideoFreezeIsOn]	D	High when video freeze is on.
[VideoFreezeIsOff]	D	High when video freeze is off.
[VideoMuteIsOn]	D	High when video mute is on.
[VideoMuteIsOff]	D	High when video mute is off.
[HdmiEnabledIsOn]	D	High when the HDMI output is enabled.
[HdmiEnabledIsOff]	D	High when the HDMI output is disabled.
[CurrentSource]	A	Source index currently selected on the HDMI output, as reported by Q-SYS.

PARAMETERS:

CoreID	S	Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module. Default: 1
ComponentName	S	Code Name of the NVM decoder component in the Q-SYS design.

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	