GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Camera Router
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Selects the camera routed to one output of a Q-SYS Camera Router component and reports the camera currently routed to that output.
GENERAL NOTES:	Input values are passed straight through to the select_N control; no scaling is applied. In Q-SYS 10.4 the component previously called Mediacast Router was renamed Camera Router, and a new, different Mediacast Router was added. This module is for the Camera Router (and the pre-10.4 Mediacast Router); for the new Mediacast Router or an AV Stream Router, use Qsys AV Stream Mediacast Router. Use one instance of this module per router output to be controlled.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	Works with a Q-SYS Camera Router component (named Mediacast Router before Q-SYS 10.4); Script Access must be External or All.
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

Input	A	Camera (router input) number to route to the output. Sent each time the value changes.

FEEDBACK:

[InputValue]	A	Camera (router input) number currently routed to the output, as reported by Q-SYS.

PARAMETERS:

CoreID	S	Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module. Default: 1
ComponentName	S	Code Name of the Camera Router component in the Q-SYS design.
OutputNumber	Dec	Router output to control. Selects which select_N control is used.

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	