GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Fader
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Controls the level and mute of a Q-SYS gain component (any component with controls named gain and mute, such as a Gain block) and reports level and mute state.
GENERAL NOTES:	Volume and VolumePrecentage use the gain control's position (0 to 1 in Q-SYS) scaled to 0–65535. Position follows the control's taper as configured in Q-SYS, so a given percentage may not correspond to a fixed dB value. VolumeDB sets the gain directly in whole dB. Enter negative values as signed analog values (e.g. -20d). Q-SYS limits the value to the gain control's min/max range. After a VolumeDB command, VolumeValue briefly shows the plain number sent (e.g. -20) until Q-SYS reports its formatted text (e.g. -20.0dB). VolumeUp/VolumeDown step from the last level reported by Q-SYS: one step on press, then after VolumeHoldTillRepeatTime, one step every VolumeRepeatTime until release. Level is clamped to 0–65535. MuteToggle uses MuteIsOn to decide the new state.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	Works with any Q-SYS component that has controls named gain and mute, typically a Gain block; Script Access must be External or All.
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

[MuteOn]	D	Pulse to mute.
[MuteOff]	D	Pulse to unmute.
[MuteToggle]	D	Pulse to toggle mute.
[VolumeUp]	D	Hold to raise the level by VolumeStep, repeating while held.
[VolumeDown]	D	Hold to lower the level by VolumeStep, repeating while held.
[Volume]	A	Sets the fader position, 0–65535 (0–100% of the fader's travel in Q-SYS).
[VolumeDB]	A	Sets the gain in dB as a signed value (e.g. -20d = -20 dB).

FEEDBACK:

[MuteIsOn]	D	High while the component is muted.
[MuteIsOff]	D	High while the component is not muted.
[VolumeValue]	S	Gain as text, as formatted by Q-SYS (e.g. -10.0dB).
[VolumePrecentage]	A	Fader position, 0–65535. Pairs with the Volume input.

PARAMETERS:

CoreID	S	Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module. Default: 1
ComponentName	S	Code Name of the gain component in the Q-SYS design.
VolumeStep	Dec	Amount (in 0–65535 position units) to change the level per VolumeUp/VolumeDown step.
VolumeRepeatTime	Time	Time between repeated steps while VolumeUp/VolumeDown is held.
VolumeHoldTillRepeatTime	Dec	Delay after the first step before repeating starts while VolumeUp/VolumeDown is held, in hundredths of a second (e.g. 50d = 0.5 s).

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	