GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Generic Integer Named Control
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Controls and monitors a single numeric Q-SYS Named Control (e.g. a gain fader, knob or integer value).
GENERAL NOTES:	Use either SetUnsignedIntegerValue or SetSignedIntegerValue depending on whether the control is to be driven by position (0-100% of travel) or by its actual value. IntegerValueScaled pairs with SetUnsignedIntegerValue when ScaleUnsigned is set to Yes; IntegerValueUnscaled pairs with SetSignedIntegerValue. Q-SYS position is the control's position within its range. Position follows the control's taper as configured in Q-SYS, so a given percentage may not correspond to a fixed dB value. IntegerValueUnscaled is the control's value truncated to a whole number (e.g. -12.7 dB reports as -12), so fractional steps are not visible.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	Uses a Q-SYS Named Control.
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

[SetUnsignedIntegerValue]	A	Sets the control. With ScaleUnsigned = Yes, 0-65535 is sent as the control's position (0-100% of its range). With ScaleUnsigned = No, the number is sent unchanged as the control's value (0-65535).
[SetSignedIntegerValue]	A	Sets the control's value directly, in the control's own units (e.g. dB for a gain control). Not affected by ScaleUnsigned.

FEEDBACK:

[IntegerValueScaled]	A	The control's position in Q-SYS scaled to 0-65535 (0-100% of its range).
[IntegerValueUnscaled]	A	The control's value in its own units (e.g. dB), as a signed whole number.

PARAMETERS:

CoreID	S	Used to address this module to the Qsys Core module with the same CoreID. Default: 1
NamedControlName	S	Name of the control as entered in Q-SYS Designer's Named Controls.
ScaleUnsigned	Dec	Selects how SetUnsignedIntegerValue is sent: No = raw value, Yes = scaled 0-65535 to 0-100% position. Default: No

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	