GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Camera Presets
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Controls a Q-SYS camera preset script component that manages presets for up to 6 cameras with 16 presets each. Selects the active camera, recalls and saves presets for it, turns tracking on and off, selects router outputs, and loads/saves the preset file. Reports camera and preset names, button states and status text. The component is addressed as a Named Component by its Code Name (ComponentName parameter). The module uses the component's controls by name (Cam Select N, PresetRecall N, PresetSave N, Tracking, RouterOutput N, etc.).
GENERAL NOTES:	Preset recall and save act on the camera currently selected in the Q-SYS component (Cam1_Select–Cam6_Select). Preset_Name_1–Preset_Name_16 show the names for the selected camera only. They update when Q-SYS reports a name change; selecting a different camera does not by itself resend the names already received. Empty strings from Q-SYS are ignored, so a camera name, preset name or status that is cleared in Q-SYS keeps its last value on the string outputs. All feedback follows the Q-SYS controls, so it also updates when changes are made from Q-SYS or another control system.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	The Q-SYS design must contain the camera preset script component with its standard control names (Cam Select 1–6, PresetRecall 1–16, PresetSave 1–16, PresetButtons 1–16, PnHProgress 1–16, RouterOutput 1–11, Camera 1–6, Camera N Presets 1–16, Tracking, LoadPresets, SavePresets, Recalibrate, RefreshFiles, Status Text, AutosaveStatus). In Q-SYS Designer, set the component's Code Name to match the ComponentName parameter and set its Script Access to External (or All).
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

[Cam1_Select]–[Cam6_Select]	D	Pulse to select the corresponding camera (sets Cam Select N on).
[Preset_Recall_1]–[Preset_Recall_16]	D	Pulse to recall the corresponding preset on the selected camera (sets PresetRecall N on).
[Preset_Save_1]–[Preset_Save_16]	D	Pulse to save the selected camera's current position to the corresponding preset (triggers PresetSave N).
[Tracking_On]	D	Pulse to turn camera tracking on.

[Tracking_Off]	D	Pulse to turn camera tracking off.
[Load_Presets]	D	Pulse to load presets from the preset file (triggers LoadPresets).
[Save_Presets]	D	Pulse to save presets to the preset file (triggers SavePresets).
[Recalibrate]	D	Pulse to recalibrate the cameras (triggers Recalibrate).
[Refresh_Files]	D	Pulse to refresh the list of preset files (triggers RefreshFiles).
[Router_Output_1]–[Router_Output_11]	D	Pulse to select the corresponding router output (sets RouterOutput N on).

FEEDBACK:

[Cam1_Select_Fb]–[Cam6_Select_Fb]	D	High while the corresponding camera is selected.
[Preset_Button_1_Fb]–[Preset_Button_16_Fb]	D	Follows the state of the corresponding PresetButtons N control in Q-SYS.
[PnH_Progress_1]–[PnH_Progress_16]	D	Follows the state of the corresponding PnHProgress N control in Q-SYS.
[Tracking_Fb]	D	High while camera tracking is on.
[Router_Output_1_Fb]–[Router_Output_11_Fb]	D	High while the corresponding router output is selected.
[Camera1_Name]–[Camera6_Name]	S	Name of the corresponding camera, from the Camera N control.
[Status_Text]	S	Status text reported by the component.
[Autosave_Status]	S	Autosave status text reported by the component.
[Preset_Name_1]–[Preset_Name_16]	S	Name of the corresponding preset for the selected camera, from the Camera N Presets P control.

PARAMETERS:

CoreID	S	Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module. Default: 1
ComponentName	S	Code Name of the camera preset component in the Q-SYS design.

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	